

User's Manual
for type ACS 400 frequency
converters from 2.2 to 37 kW



ACS 400 Frequency Converter

User's Manual

3AFY 64036947 R0125 REV A
EN
Effective: 25.5.1999

Safety



Warning! Only a competent electrician may install the ACS 400.



Warning! Dangerous voltages are present when mains supply is connected. Wait at least 5 minutes after disconnecting the supply before removing the cover. Measure the voltage at DC terminals (U_{c+} , U_{c-}) before servicing the unit. See E.



Warning! Even when the motor is stopped there are dangerous voltages present at Power Circuit terminals U1, V1, W1 and U2, V2, W2 and U_{c+} , U_{c-} .



Warning! Even when the ACS 400 is powered down, there may be dangerous external voltages at relay terminals RO1A, RO1B, RO1C, RO2A, RO2B, RO2C.



Warning! Never attempt to repair a broken unit; contact the supplier.



Warning! The ACS 400 will start up automatically after an input voltage interruption if the external run command is on.



Warning! When the control terminals of two or more ACS100/140/400 units are connected in parallel, the auxiliary voltage for these control connections must be taken from a single source which can either be one of the units or an external supply.



Warning! The heat sink may reach a high temperature (see S, Table 11).

Note! For more technical information, contact the supplier.

Note about compatibility: The supplied ACS 400 frequency converter and this manual are fully compatible with ACS-PAN-A Control Panel revision F and later. If you use a control panel with older revision code, certain new parameter names and alarms will not be displayed properly. In this case, refer to displayed numeric parameter values, parameter numbers and alarm codes instead.

Table of Contents

Safety	iii
Installation	1
Reference Sections	3
Environment for Storage, Transportation and Stationary Use	3
Dimensions (mm)	4
Mounting the ACS 400 on the Wall	6
Removing the Cover	7
Terminal Interface	9
Attaching a Warning Sticker	9
Type Designation Label and Code Key	10
Motor	11
Floating Network	11
Cable Connections	12
Control Terminals	20
Connection Examples	22
Replacing the Cover	23
Power On	23
Environmental Information	23
Protection Features	24
Motor Overload Protection	25
Loadability of ACS 400	25
Type Series and Technical Data	26
Product Conformity	27
Accessories	28

Programming. 29

ACS-PAN-A Control Panel. 29

Control Modes29

Output Display30

Menu Structure30

Setting Parameter Value31

Menu Functions32

LED Indicators33

Diagnostic displays34

Resetting the Drive from the Control Panel34

Contrast Setting34

ACS100-PAN Control Panel 35

Control Modes35

Output Display36

Menu Structure36

Setting Parameter Value36

Menu Functions37

Diagnostic Displays38

Resetting the Drive from the Control Panel38

ACS 400 Basic Parameters 39

Application Macros 43

Application Macro Factory (0)44

Application Macro Factory (1)45

Application Macro ABB Standard46

Application Macro 3-wire47

Application Macro Alternate48

Application Macro Motor Potentiometer49

Application Macro Hand - Auto50

Application Macro PID Control51

Application Macro Premagnetise52

Application Macro PFC Control53

ACS 400 Complete Parameter List	55
Group 99: Start-up Data	63
Group 01: Operating Data	64
Group 10: Command Inputs	66
Group 11: Reference Select	68
Group 12: Constant Speeds	72
Group 13: Analogue Inputs	73
Group 14: Relay Outputs	74
Group 15: Analogue Output	76
Group 16: System Controls	77
Group 20: Limits	79
Group 21: Start/Stop	80
Group 22: Accel/Decel	82
Group 25: Critical Freq	83
Group 26: Motor Control	84
Group 30: Fault Functions	85
Group 31: Automatic Reset	89
Group 32: Supervision	90
Group 33: Information	91
Group 34: Process Variables	92
Group 40: PID Control	94
Group 41: PID Control (2)	99
Group 50: Communication	100
Group 51: Ext Comm Module	102
Group 52: Standard Modbus	103
Group 81: PFC Control	105

Standard Serial Communication	115
Overview	115
Earthing and Termination	117
Activating Modbus Protocol	118
Communication settings	119
Control Locations	120
Output signal source selection	121
Diagnostic Counters	123

Communication	124
Introduction to Modbus	124
Register Read and Write	124
Register Mapping	125
Exception Codes	126
Function Codes	126
The Control Word and the Status Word	127
References	130
Actual Values	131
Fault and Alarm Status	133
Diagnostics	135
General	135
Alarm and Fault displays.	135
Fault Resetting	135
Appendix A	141
Local Control vs. Remote Control	141
Local Control	141
Remote Control	142
Internal Signal Connections for the Macros	143
Appendix B	145
ACS 400 Pump and Fan Control (PFC) Macro	145
Introduction	145
PID Controller	147
Relay Outputs	148
Adding More I/O to ACS 400	148
Setting up NDIO modules	148
Alternation Switchgear	148

Installation

Study these installation instructions carefully before proceeding. **Failure to observe the warnings and instructions given may cause a malfunction or personal hazard.**

Preparation before installation

To install the ACS 400 you need the following: screwdrivers, wire stripper, tape measure, 4 pieces of Ø 5 mm screws or nuts and bolts (depending on the mounting surface), drill.

At this point it is a good idea to check the motor parameters and write them down: supply voltage, nominal current, nominal frequency, cos phi, nominal power and nominal speed.

Unpacking the unit

The ACS 400 comes in a box that in addition to the unit itself and this User's Manual contains Cable Gland Plates, Warning Stickers, an EMC Instruction and a separate Installation Guide. The separate Installation Guide gives a summary of the installation instructions described here.

To help you marking the fixing points for installation of your ACS 400 a Wall Mounting Template is drawn on the lid of the box. Remove the lid and save it.

Step by step instructions

The installation of the ACS 400 has been broken down into a number of steps that are listed in Figure 1 on page 2. The steps must be carried out in the order shown. To the right of each step reference is made to one or more Reference Sections on the following pages of this User's Manual. These sections give detailed information needed for the correct installation of the unit.



Warning! Before you begin read "Safety" on page iii.

- 1 **CHECK** the environment. See **A**
- 2 **MOUNT** the ACS 400 on the wall. See **B, C**
- 3 **REMOVE** the cover. See **D**
- 4 **ATTACH** a warning sticker in the language of your choice. See **E, F**
- 5 **IDENTIFY** power and control terminals. See **E, H, I**
- 6 **CHECK** voltage supply and fuses. See **G, S**
- 7 **CHECK** the motor. See **K, S**
- 8 **CHECK** I/O jumpers J1 and J2. See **E, J, L**
- 9 **CONNECT** power terminals. See **E, H, I**
- 10 **CONNECT** control wires. See **E, H, I, J, L**
- 11 **REPLACE** the cover. See **M**
- 12 **TURN** the power on. See **N**

Figure 1 Step by step instructions for installing the ACS 400. The references after each step refer to one or more of the Reference Sections on the following pages in this User's Manual.

Reference Sections

A Environment for Storage, Transportation and Stationary Use

Table 1

ACS 400	Stationary Use	Storage and Transportation in the protective package
Installation Site Altitude	<ul style="list-style-type: none"> 0...1000 m if P_N and I_2 100% 1000...2000 m if P_N and I_2 derated 1% every 100 m above 1000 m 	-
Ambient Temperature	<ul style="list-style-type: none"> 0...40 °C max. 50 °C if P_N and I_2 derated to 90% 	-40...+70 °C
Relative Humidity	< 95% (non-condensing)	
Contamination Levels (IEC 721-3-3)	No conductive dust allowed. The ACS 400 should be installed in clean air according to IP classification. Cooling air must be clean, free from corrosive materials and electrically conductive dust. In UL installations the ACS 400 should be installed in clean and dry air, free from dripping water.	
	<ul style="list-style-type: none"> chemical gases: Class 3C2 solid particles: Class 3S2 	Storage <ul style="list-style-type: none"> chemical gases: Class 1C2 solid particles: Class 1S3 Transportation <ul style="list-style-type: none"> chemical gases: Class 2C2 solid particles: Class 2S2
Atmospheric Pressure		
Sinusoidal Vibration (IEC-60068-2-6)	<ul style="list-style-type: none"> 2-9 Hz 0.3 mm 9-200 Hz 2 m/s² 	Storage <ul style="list-style-type: none"> 2-9 Hz 1.5 mm 9-200 Hz 5 m/s² Transportation <ul style="list-style-type: none"> 2-9 Hz 3.5 mm 9-200 Hz 10 m/s²
Shock (IEC 68-2-29)	not allowed	<ul style="list-style-type: none"> max. 100 m/s² (330 ft./s²), 11 ms
Free Fall	not allowed	<ul style="list-style-type: none"> 76 cm (30 in.), frame size R1 61 cm (24 in.), frame size R2 46 cm (18 in.), frame size R3 31 cm (12 in.), frame size R4

B Dimensions (mm)

Units with IP 21/NEMA1 Enclosures




Figure 2 IP 21/NEMA1 enclosures.

Table 2 Dimensions of units with IP 21/NEMA1 enclosures.

Dimension Reference (mm)	Frame Size, IP 21/NEMA1 *			
	R1	R2	R3	R4
W	125	125	203	203
W1	98	98	160	160
W2			98	98
H	330	430	545	636
H1	318	417	528	619
H2	300	400	500	600
H3	373	473	586	686
D	209	221	248	282
D1	105	117	144	177
D2	147	159	200	233
a	5.5	5.5	6.5	6.5
b	10	10	13	13
c	5.5	6.0	8.0	8.0
d	5.5	5.5	6.5	6.5
Mass (kg)	5.5	8.5	19.0	28.6

* See paragraph S for frame size assignments for type codes.

Units with IP 54/NEMA12 Enclosures

The IP 54 protection class has a different outer plastic cover compared to the IP 21. The IP 54 enclosure uses the same skeleton (inner plastic part) as the IP 21 enclosure, but an internal fan is added to improve the cooling of the unit. This kind of structure increases the dimensions compared to the IP 21 enclosure, but the loadability of the units with IP 54 enclosure is the same as that of the IP 21 units.




Figure 3 IP 54/NEMA12 enclosures.

Table 3 Dimensions of units with IP 54/NEMA12 enclosures.

Dimension Reference (mm)	Frame Size, IP 54/NEMA12 *			
	R1	R2	R3	R4
W	215	215	257	257
W1	98	98	160	160
W2			98	98
H	453	551	642	742
H1	318	417	528	619
H2	330	430	545	636
D	240	253	280	312
D1	95	107	132	145
a	5.5	5.5	6.5	6.5
b	10	10	13	14
c	5.5	5.5	8.0	8.0
d	5.5	5.5	6.5	6.5
Mass (kg)	7.2	11.2	22.3	32.3

See paragraph S for frame size assignments for type codes.

C Mounting the ACS 400 on the Wall



Warning! Before installing the ACS 400 ensure the mains supply to the installation is off.
Note! ACS 400 can be mounted onto an air duct when flange mounting option set is used.

1

The lid of the packing-box shows the Wall Mounting Template.
Remove the lid from the box.




Figure 4 Removing the wall mounting template.

2

The ACS 400 should only be mounted vertically on a smooth, solid surface, free from heat, damp, and condensation. Ensure minimum air flow gaps of 200 mm above and below, and 30 mm on the sides of the unit.

- 1 Using the mounting template, mark the position of the fixing holes.
- 2 Drill the holes.
- 3 Screw in four screws or affix nuts and bolts (depending on the mounting surface).



Figure 5 Marking and drilling the fixing holes.

3

IP 21 / NEMA1

Position the ACS 400 onto the fixings and securely tighten in all four corners.

Note! Only lift the ACS 400 by its metal chassis.




Figure 6 Affixing type IP 21 / NEMA1 frequency converters.

IP 54 / NEMA12

- 1 Remove the front cover, see Figure 10.
- 2 Remove the rubber plugs by pushing from outside.
- 3 Screw in the screws.
- 4 Replace the rubber plugs.




Figure 7 Affixing type IP 54 / NEMA12 frequency converters.

D Removing the Cover

IP 21 / NEMA1

Opening units frame size R1 and R2 (unit width 125 mm).

- 1 Remove the control panel.
- 2 In the control panel slot there is a little hole. Lift the retaining lever inside.
- 3 Remove the cover.




Figure 8 Opening the frame size R1 and R2 frequency converters of type IP 21 / NEMA1.

Opening units frame size R3 and R4 (unit width 203 mm).

- 1 Remove the control panel if fitted.
- 2 Lift the retaining lever and simultaneously pull the upper front cover slightly.
- 3 Lift the other retaining lever e.g. with a screwdriver.
- 4 Open the upper part of the front cover and remove it.
- 5 Press the retaining lever and pull.
- 6 Remove the lower part of the front cover.




Figure 9 Opening the frame size R3 and R4 frequency converters of type IP 21 / NEMA1.

IP 54 / NEMA12

- 1 Take the screws off.
- 2 Remove the front cover.
- 3 Remove control panel if needed.




Figure 10 Opening type IP 54 / NEMA1 frequency converters.

E Terminal Interface




Figure 11 Terminal interface.

F Attaching a Warning Sticker

The contents of the packing box includes warning stickers in different languages. Attach a warning sticker in the language of your choice to the place on the inside plastic skeleton as indicated above, in section E, 'Terminal Interface'.

G Type Designation Label and Code Key

The Type Designation Label is attached on to the heat sink.






ABB Industry Oy	MADE IN FINLAND	U1	3~ 380...480 V	For more information see ACS400 User's Manual
Type	ACS401000432	U2	3~ 0 - 0...U1 V	<div>LISTED 45Y1</div> <div>  </div> <div>IND.CONT.EQ</div> <div>    </div>
Code	63996611	I1n / I1nsq	4.7 / 6.2 A	
 Ser.no *1982800001*		I2n / I2nsq	4.9 / 6.6 A	
		f1	48...63 Hz	
		f2	0...250Hz	

Figure 12 ACS 400 type designation label.

The figure below shows the key for the type designation.




Figure 13 The key to the type designation code.

Serial number label is attached on the upper part of the back plate of the unit between fixing holes.

Type	ACS401000432		
Code	63996611	Ser.no.	*1982800001*

Figure 14 Serial number label.

H Motor

Check the compatibility of the motor. By default, the motor must be a three-phase induction motor, with U_N from 380 to 480 V and f_N either 50 Hz or 60 Hz. If the motor values differ from these, the group 99 parameter values must be changed.

The motor nominal current, I_N , must not exceed the nominal output current of the ACS 400, I_{2N} in constant torque applications or I_{2NSQ} in variable torque applications (See **G** and **R**).



Warning! Ensure the motor is suitable for use with the ACS 400. The ACS 400 must be installed by a competent person. **If in doubt, contact your supplier.**

I Floating Network

Make sure that no excessive emission is propagated to neighbouring low voltage networks. In some cases, the natural suppression in transformers and cables is sufficient. If in doubt, the supply transformer with static screening between the primary and secondary windings can be used.

Note! Remove both grounding screws otherwise you may cause danger or damage the unit. Location of the grounding screws is shown in Figure 15 and Figure 16.

Note! In IT networks do not use RFI filter. The mains becomes connected to earth through the filter capacitors. In floating networks this may cause danger or damage the unit.




Figure 15 Removing the grounding screws from frame size R1 and R2 frequency converters.




Figure 16 Removing the grounding screws from frame size R3 and R4 frequency converters.

J Cable Connections

IP 21 Units

A package, containing three screws and two gland plates, is included with type IP 21 (NEMA1) ACS 400 frequency converters.




Figure 17 Gland plate for **power cables (A)** and for **control cables (B)**, type IP 21 / NEMA1 frequency converters.

To open the front cover, see “Removing the Cover” on page 7.

Connect the gland plate for power cables with one screw. The threaded hole for the screw is located in the middle of the heat sink, at the bottom end.





Figure 18 Fixing the gland plate for power cables (A), type IP 21 / NEMA1 frequency converters.

Table 4 Cable connections.

Terminal	Description	Note
U1, V1, W1	3~ power supply input	Do not use in 1~ supply!
PE	Protective Earth	Follow local rules for cable cross-sections.
U2, V2, W2	Power output to motor	See R.
Uc+, Uc-	DC bus	For optional ACS-BRK braking unit.
	Motor cable shield	

Follow local rules for cable type and cross-sections. Use screened motor cable.
Route the motor cable away from control wires and the power supply cable to avoid electromagnetic interference.




Figure 19 Motor cable connection for frame sizes R1 and R2 (IP 21 / NEMA1).

Note! See ACS 400 EMC instructions.




Figure 20 Motor cable connection for frame sizes R3 and R4 (IP 21 / NEMA1).

The gland plate for control cables (B), see Figure 17.




Figure 21 Fixing the gland plate for control cables (B), type IP 21 / NEMA1 frequency converters.




Figure 22 Control cable connections (IP 21 / NEMA1).

Note! See ACS 400 EMC instructions.

IP 54 Units

A package, containing five screws and two gland plates, is included with the type IP 54 (NEMA12) ACS 400 frequency converters.




Figure 23 Gland plate for **power cables (A)** and for **control cables (B)**, type IP 54 / NEMA 12 frequency converters.

To open the front cover, see “Removing the Cover” on page 7.





Figure 24 Fixing the gland plate for power cables (A), type IP 54 / NEMA12 frequency converters.

Connect the power cables before installing the gland plate for control cables (IP 54 / NEMA12). Different diameters are marked on the grommet surface. Cut the grommets after checking the correct cable size.

Table 5

Terminal	Description	Note
U1, V1, W1	3~ power supply input	Do not use in 1~ supply!
PE	Protective Earth	Follow local rules for cable cross-sections.
U2, V2, W2	Power output to motor	See R.
Uc+, Uc-	DC bus	For optional ACS-BRK braking unit.
	Motor cable shield	

Follow local rules for cable type and cross-sections. Use shielded motor cable.
Route the motor cable away from control wires and the power supply cable to avoid electromagnetic interference.




Figure 25 Motor cable connection for frame sizes R1 and R2 (IP 54 / NEMA12).

Note! See ACS 400 EMC instructions.




Figure 26 Motor cable connection for frame sizes R3 and R4 (IP 54 / NEMA12).

Note! See ACS 400 EMC instructions.




Figure 27 Fixing the gland plate for control cables (B), type IP 54 / NEMA12 frequency converters.






Figure 28 Control cable connections (IP 54 / NEMA12).

Note! See ACS 400 EMC instructions.

K Control Terminals

Main I/O terminal X1

Table 6

X1	Identification	Description														
1	SCR	Terminal for signal cable screen. (Connected internally to frame earth.)														
2	AI 1	Analogue input channel 1, programmable. Default: 0 - 10 V ($R_i = 200\text{ k}\Omega$) (J1:AI1 open) \Leftrightarrow 0 - 50 Hz frequency reference 0 - 20 mA ($R_i = 500\ \Omega$) (J1:AI1 closed) \Leftrightarrow 0 - 50 Hz frequency reference Resolution 0.1 % accuracy $\pm 1\ \%$.														
3	AGND	Analogue input circuit common. (Connected internally to frame earth through 1 M Ω .)														
4	10 V	10 V/10 mA reference voltage output for analogue input potentiometer, accuracy $\pm 2\ \%$.														
5	AI 2	Analogue input channel 2, programmable. Default: 0 - 20 mA ($R_i = 500\ \Omega$) (J1:AI2 closed) 0 - 10 V ($R_i = 200\text{ k}\Omega$) (J1:AI2 open) Resolution 0.1 % accuracy $\pm 1\ \%$.														
6	AGND	Analogue input circuit common. (Connected internally to frame earth through 1 M Ω .)														
7	AO1	Analogue output, programmable. Default: 0 - 20 mA (load < 500 Ω) \Leftrightarrow 0 - 50 Hz output frequency.														
8	AGND	Common for DI return signals.														
9	24 V	Auxiliary voltage output 24 V DC +20 %, -10 % / 250 mA (reference to AGND). Short circuit protected.														
10	DCOM1	Digital input common 1 for DI1, DI2 and DI3. To activate a digital input, there must be $\geq +10\text{ V}$ (or $\leq -10\text{ V}$) between that input and DCOM1. The 24 V may be provided by the ACS 400 (X1:9) as in the connection examples (see L) or by an external 12 - 24 V source of either polarity.														
DI Configuration		<table><tr><th>Factory (0)</th><th>Factory (1)</th></tr><tr><td>11 DI 1</td><td>Start. Activate to start. Motor will ramp up to frequency reference. Disconnect to stop. Motor will coast to stop.</td></tr><tr><td>12 DI 2</td><td>Reverse. Activate to reverse rotation direction.</td></tr><tr><td>13 DI 3</td><td>Jog. Activate to set output frequency to jogging frequency (default: 5 Hz).</td></tr><tr><td>14 DI 4</td><td>Must be deactivated for Factory 0).</td></tr><tr><td>15 DI 5</td><td>Must be activated for Factory (1).</td></tr><tr><td>16 DCOM2</td><td>Ramp pair selection (ACC1/DEC1 or ACC2/DEC2).</td></tr></table>	Factory (0)	Factory (1)	11 DI 1	Start. Activate to start. Motor will ramp up to frequency reference. Disconnect to stop. Motor will coast to stop.	12 DI 2	Reverse. Activate to reverse rotation direction.	13 DI 3	Jog. Activate to set output frequency to jogging frequency (default: 5 Hz).	14 DI 4	Must be deactivated for Factory 0).	15 DI 5	Must be activated for Factory (1).	16 DCOM2	Ramp pair selection (ACC1/DEC1 or ACC2/DEC2).
Factory (0)	Factory (1)															
11 DI 1	Start. Activate to start. Motor will ramp up to frequency reference. Disconnect to stop. Motor will coast to stop.															
12 DI 2	Reverse. Activate to reverse rotation direction.															
13 DI 3	Jog. Activate to set output frequency to jogging frequency (default: 5 Hz).															
14 DI 4	Must be deactivated for Factory 0).															
15 DI 5	Must be activated for Factory (1).															
16 DCOM2	Ramp pair selection (ACC1/DEC1 or ACC2/DEC2).															
17	RO1C	 Relay output 1, programmable (default: fault \Rightarrow 17 connected to 18). 12 - 250 V AC / 30 V DC, 10 mA - 2 A														
18	RO1A															
19	RO1B															
20	RO2C	 Relay output 2, programmable (default: running \Rightarrow 20 connected to 22). 12 - 250 V AC / 30 V DC, 10 mA - 2 A														
21	RO2A															
22	RO2B															

Digital input impedance 1.5 k Ω .

Use multi-strand 0.5-1.5 mm² wire.

Note! DI 4 is read only when powered-up (Factory macro 0 and 1).

Note! For fail safe reasons the fault relay signals a "fault", when the ACS 400 is powered down.

Note! Terminals 3, 6 and 8 are at the same potential.

Note! DI4 and DI5 are galvanically isolated from DI1-DI3. To utilise DI4 and DI5 a jumper wire must be connected. See section **L** for details.

Note! If control panel is available, also other macros can be selected. The digital input depends on the macro selected.

Analogue input configuration

The analogue input signal is selected with jumper J1: AI open = voltage input (U) and AI connected = current input (I).

Examples on selecting the analogue input signal

1. AI1 = U 0 - 10 V

AI2 = I 0(4) - 20 mA

2. AI1 = U 0 - 10 V

AI2 = U 0 - 10 V

3. AI1 = I 0(4) - 20 mA

AI2 = I 0(4) - 20 mA

RS485 terminal X3

Table 7

X3	Description
1	Screen
2	B
3	A
4	AGND
5	Screen

J2

RS485 interf.

Termin. Not termin.

= open

 = closed

Signal termination is selected by jumper J2.

L Connection Examples




Figure 29 I/O examples.





Figure 30 RS485 Multidrop application.

M Replacing the Cover

Do not turn the power on before replacing the front cover.


IP 21 / NEMA1 Units:

1. First locate the bottom fixing clips.
2. Click the retaining lever to its place.
3. Replace the control panel.




Replacing the front cover to IP 21/ NEMA1 units from size ACS401-x016-3-x and up.

1. Hook the bottom end fingers of the lower part of the front cover.
2. Click the retaining lever to its place.
3. Hook the bottom end fingers.
4. Click the retaining levers into place.
5. Replace the control panel if available.



IP54 / NEMA12 Units:

1. Replace the control panel.
2. Replace the front cover.
3. Tighten the screws (max. torque 1.5 Nm).



N Power On

When power is supplied to the ACS 400, the green LED comes on.

Note! Only three power-ups in five minutes are allowed.

Note! Before increasing motor speed, check that the motor is running in desired direction.

O Environmental Information

The package is made of corrugated cardboard and can be recycled.

A product to be disposed of contains valuable raw material that should be recycled, thus preserving energy and natural resources. Instructions for disposal are available from ABB sales and service companies.

P Protection Features

The ACS 400 has a number of protective features:

- Overcurrent
- Overvoltage
- Undervoltage
- Overtemperature
- Output earth fault
- Output short circuit
- Input phase loss (3~)
- I/O terminal short circuit protection
- Motor overload protection (see **Q**)
- Output overload protection (see **R**)
- Stall protection
- Underload

The ACS 400 has the following LED alarm and fault indicators:

- For location of LEDs, see section E or if ACS-PAN-A control panel is connected, see the instructions on page 29.

Table 8

Red LED: off Green LED: blinking	
ABNORMAL CONDITION	
POSSIBLE CAUSES: <ul style="list-style-type: none"> • Acceleration or deceleration ramp is too fast in relation to load torque requirement • A short voltage interruption 	ABNORMAL CONDITION: <ul style="list-style-type: none"> • ACS 400 cannot fully follow control commands. • Blinking lasts 15 seconds.

Table 9

Red LED: on Green LED: on	
FAULT	
POSSIBLE CAUSES: <ul style="list-style-type: none"> • Transient overcurrent • Over-/undervoltage • Overtemperature • Motor overload (see section Q) CHECK: <ul style="list-style-type: none"> • the supply line for disturbances. • the drive for mechanical problems that might cause overcurrent. • that the heat sink is clean. 	ACTION: <ul style="list-style-type: none"> • Give a stop signal to reset fault. • Give a start signal to restart the drive. NOTE: <ul style="list-style-type: none"> • If the drive fails to start, check that the input voltage is within the tolerance range.

Table 10

Red LED: blinking Green LED: on	
FAULT	
POSSIBLE CAUSE: <ul style="list-style-type: none"> • Output earth fault • Short circuit • DC bus ripple too large CHECK: <ul style="list-style-type: none"> • the insulation in the motor circuit. 	ACTION: <ul style="list-style-type: none"> • Turn the power off. • Wait for the LEDs to turn off. • Turn the power back on. Caution! This action may start the drive.

Note! Whenever the ACS 400 detects a fault condition, the fault relay activates. The motor stops and the ACS 400 will wait to be reset. If the fault still persists and no external cause has been identified, contact your ACS 400 supplier.

Q Motor Overload Protection

If the motor current I_{out} exceeds nominal current I_N of the motor for a prolonged period, the ACS 400 automatically protects the motor against overheating by tripping.

The trip time depends on the extent of the overload (I_{out} / I_N), the output frequency and f_{nom} . Times given apply to a "cold start".

ACS 400 provides overload protection in accordance with the National Electric Code (US). Default setting is motor thermal protection ON. For more information see Group 30 parameters, page 85 in this manual.





Figure 31


R Loadability of ACS 400

In the event of an output overload, the ACS 400 will first show an alarm and then trip.



duty cycle = t/T

$T < 10 \text{ min}$



**Ambient temperature,
 θ_{amb} max. is 40°C.**

**50°C is permissible,
if I_2 and I_{max} are derated to 90 %.**

I_{max} = maximum output current in squared torque ($I_{2NSQmax}$) and constant torque (I_{2Nmax}) applications, see Table 11.

Figure 32

S Type Series and Technical Data

Table 11

400 V series											
3~ Input U ₁ 380V - 480V ±10 % 48 - 63 Hz	ACS401-	004- 3-X	005- 3-X	006- 3-X	009- 3-X	011- 3-X	016- 3-X	020- 3-X	025- 3-X	030- 3-X	041- 3-X
Frame size		R1			R2		R3		R4		
Nominal ratings (See G)	Unit										
Nominal motor P _N Squared torque	kW	3.0	4.0	5.5	7.5	11	15	18.5	22	30	37
Input current I _{1NSQ}	A	6.2	8.3	11.1	14.8	21.5	29	35	41	56	68
Continuous output current I _{2NSQ}	A	6.6	8.8	11.6	15.3	23	30	38	44	59	72
Max. output current I _{2NSQmax} *	A	7.3	9.7	12.8	16.8	25.3	33	42	48	65	79
Nominal motor P _N Constant torque and power	kW	2.2	3.0	4.0	5.5	7.5	11	15	18.5	22	30
Input current I _{1N}	A	4.7	6.2	8.3	11.1	14.8	21.5	29	35	41	56
Continuous output current I _{2N} *	A	4.9	6.6	8.8	11.6	15.3	23	30	38	44	59
Max. output current I _{2Nmax}	A	7.4	9.9	13.2	17.4	23	34	45	57	66	88
Output voltage U ₂	V	0 - U ₁									
Switching frequency f _{SW}	kHz	4 (Standard) 8 (Low noise **)									
Protection limits	(See O)										
Overcurrent (peak)	A	20.3	27.5	37	48	64	76	99	125	145	195
Overvoltage: Trip limit	V DC	842 (corresponds to 624 VAC input)									
Undervoltage: Trip limit	V DC	333 (corresponds to 247 VAC input)									
Overtemperature	°C	95 (heat sink)									
Max. cable length f _{SW} = 4 kHz f _{SW} = 8 kHz	m	100 50			200 100		200 100		200 100		
Max. wire sizes and screw torque of connectors											
Power terminals ***	mm ²	10, AWG6 (stranded)/ Torque 1.3-1.5 Nm					16, AWG4 (stranded) / Torque 1.5-1.8 Nm		35, AWG2 (stranded) / Torque 3.2-3.7 Nm		
Control terminals	mm ²	0.5 - 1.5 (AWG22...AWG16) / Torque 0.4 Nm									
Line fuse 3~ **** ACS401-	A	10	10	16	16	25	35	50	50	63	80
Power losses (at nominal point)											
Power circuit	W	90	120	170	230	330	450	560	660	900	1100
Control circuit	W	6	6	6	6	6	6	6	6	6	6

* Power stages are designed for the continuous I_{2NSQ} current. These values are valid when the altitude is less than 1000 m ASL. See Q.

** Low noise setting only available with optional control panel. Derate P_N and I₂ to 80%.

*** Follow local rules for cable cross-sections, see **H**. Shielded motor cable is recommended.

**** Fuse type: UL class CC or T. For non-UL installations IEC269 gG.

Note! Use 60°C rated power cable (75°C if ambient temperature exceeds 45°C).

Note! The output contactor can be used only as a safety device. Do not close the contactor when the ACS 400 is running.

ACS 400 is suitable for use in a circuit capable of delivering not more than 65 kA rms symmetrical amperes, 480 V maximum.

T Product Conformity

CE Marking

The ACS 400 complies with the requirements of the European

- Low Voltage Directive 73/23/EEC with amendments
- EMC Directive 89/336/EEC with amendments

Corresponding declarations and a list of main standards are available on request.

Note! See ACS 400 EMC instructions.

A frequency converter and a Complete Drive Module (CDM) or a Basic Drive Module (BDM), as defined in IEC 61800-2, is not considered as a safety related device mentioned in the Machinery Directive and related harmonised standards. The CDM/BDM/frequency converter can be considered as a part of safety device if the specific function of the CDM/BDM/frequency converter fulfils the requirements of the particular safety standard. The specific function of the CDM/BDM/frequency converter and the related safety standard is mentioned in the documentation of the equipment.

UL, ULc and C-Tick Markings

All markings are for both IP 21 and IP 54 enclosures.

		UL	ULc	C-Tick
ACS 401	R1	✓	✓	✓
ACS 401	R2	✓	✓	✓
ACS 401	R3	✓	✓	✓
ACS 401	R4	✓	✓	pending

U Accessories

ACS 400-PAN-A

Control panel for use with the ACS 400.

ACS 100-PAN

Control panel for use with the ACS 100 / ACS 140 / ACS 400.

PEC-98-0008

Panel Extension Cable kit for use with the ACS 100 / ACS 140 / ACS 400.

ACS400-IFX1-3

RFI input filters.

ACS-BRK-

Braking units.

RS485/232 Adapter

DDCS Communication Module

For using fieldbus adapters and I/O extension modules.

ACS 400 is supported by DriveWare


Contact your supplier.

Flange Mounting Set

PROGRAMMING

ACS-PAN-A Control Panel

ACS-PAN-A is an alphanumeric control panel with LCD display and multiple languages. The control panel can be connected to and detached from the converter at any time. The panel can be used to copy parameters to other ACS 400 converters with the same software revision (parameter 3301).



Control Modes

The very first time the drive is powered up, it is controlled from the Control Terminal Block X1 (remote control, **REM**). The ACS 400 is controlled from the control panel when the drive is in local control (**LOC**).

Switch to local control (**LOC**) by pressing and holding the LOC/REM button until first LOCAL CONTROL or later LOCAL, KEEP RUN is displayed:

- If the button is released while LOCAL CONTROL is displayed, the panel frequency reference is set to the current external reference and the drive is stopped.
- When LOCAL, KEEP RUN is displayed, the current run/stop status and the frequency reference are copied from the user I/O.

Start and stop the drive by pressing the START/STOP button.

Change the shaft direction by pressing the REVERSE button (parameter 1003 must be set to REQUEST).

Switch back to remote control (**REM**) by pressing and holding the LOC/REM button until REMOTE CONTROL is displayed.

Shaft Direction

RUN > < RUN	<ul style="list-style-type: none"> • Drive is running and at setpoint • Shaft direction is forward (>) or reverse (<)
RUN > (or < RUN) Arrow head blinking rapidly	Drive is running but not at setpoint.
> (or <) Arrow head blinking slowly	Drive is stopped.

Output Display

When the control panel is powered up, the panel displays a selection of actual values, see Figure 33. Whenever the MENU button is pressed and held, the control panel resumes this **OUTPUT** display.




Figure 33 Output display variables.


The frequency reference can be modified using UP/DOWN buttons when it is underlined. Pressing UP or DOWN buttons changes the output immediately.

The reference can be modified in local control mode, but also in remote control mode if the ACS 400 is parameterised in such a way.

Menu Structure


ACS 400 has a large number of parameters. Of these, only the so-called **basic parameters** are initially visible. See “Selecting Full Parameter Set” on page 32 for details on specifying the full parameter set.

The menu consists of parameter groups and menu functions.



Setting Parameter Value

Parameter set mode is entered by pressing ENTER. In set mode, value is underlined. Value is altered by using UP/DOWN buttons. Modified value is stored by pressing ENTER. Modifications can be cancelled and set mode inactivated by pressing MENU.




Note! In the parameter set mode the cursor blinks, when the parameter value is altered.

Note! To view the parameter default value in the parameter set mode, press the UP/DOWN buttons simultaneously.

Menu Functions


Scroll the Menu for desired menu function, then press and hold ENTER down until display blinks to start the operation.

Copy Parameters from Drive to Panel (upload)



Note! Drive must be stopped and in local control. Parameter 1602 PARAMETER LOCK must be set to 1 (OPEN).


Copy Parameters from Panel to Drive (download)



Note! Drive must be stopped and in local control. Parameter 1602 PARAMETER LOCK must be set to 1 (OPEN).

Selecting Full Parameter Set

Normally only the basic parameters are visible. When full Menu is active, an asterisk appears on the second row of the panel display in Menu. Activate this function again to resume the short Menu.



LED Indicators

Red LED	Green LED	
OFF	ON	Power ON and drive is operating normally.
OFF	BLINKS	Alarm is active.
ON	ON	Fault is active. Drive can be reset from the control panel.
BLINKS	ON	Fault is active. Turn power off to reset the drive.

Diagnostic displays

When the red LED of the ACS-PAN-A is on or blinking, a fault is active. The relevant fault message flashes in the panel display.

When the green LED of the ACS-PAN-A is blinking, an alarm is active. The relevant alarm message is shown in the panel display. Alarms 1-7 arise from button operation and green LED does not blink for them.

The alarm and fault messages disappear when MENU, ENTER or the arrow buttons of control panel are pressed. The message will reappear after a few seconds if the keypad is not touched and alarm or fault is still active.




Figure 34 Fault and alarm messages

Refer to Diagnostics section for complete list of alarms and faults.

Resetting the Drive from the Control Panel

To reset a fault when the red LED is on, press the RESET button.

Caution! Resetting the fault may start the drive when in remote control.

To reset a fault when the red LED is blinking, turn the power off.


Caution! Turning the power on again may start the drive immediately.

Contrast Setting

Display contrast can be adjusted any time. Increase contrast by pressing and holding ENTER and UP buttons. Decrease contrast by pressing and holding ENTER and DOWN buttons. The buttons must be pressed down simultaneously.

ACS100-PAN Control Panel

The control panel can be connected to and detached from the converter at any time. This panel does not support the upload and download functions when used with ACS 400, in which case ACS-PAN-A is needed.



Control Modes

The very first time the drive is powered up, it is controlled from the Control Terminals (remote control, **REM**). The ACS 400 is controlled from the control panel when the drive is in local control (**LOC**).

Switch to local control (**LOC**) by pressing and holding the MENU and ENTER buttons down simultaneously until first **Loc** or later **LCr** is displayed:

- If the buttons are released while **Loc** is displayed, the panel frequency reference is set to the current external reference and the drive is stopped.
- When **LCr** is displayed, the current run/stop status and the frequency reference are copied from the user I/O.

Start and stop the drive by pressing the START/STOP button.

Change the shaft direction by pressing the REVERSE button (parameter 1003 must be set to REQUEST).

Switch back to remote control (**REM**) by pressing and holding the MENU and ENTER buttons down simultaneously until **rE** is displayed.

Shaft Direction


FWD / REV Visible	<ul style="list-style-type: none"> • Shaft direction is forward / reverse • Drive is running and at set point
FWD / REV Blinking rapidly	Drive is accelerating / decelerating.
FWD / REV Blinking slowly	Drive is stopped.

Output Display

When the control panel is powered up, the panel displays the actual output frequency. Whenever the MENU button is pressed and held, the control panel resumes this **OUTPUT** display.


To toggle between output frequency and output current, press the UP or DOWN button.

To set the output frequency, press ENTER. Pressing the UP/DOWN buttons changes the output immediately. Press ENTER again to return to **OUTPUT** display.



Menu Structure


ACS 400 has a large number of parameters. Of these, only the so-called **basic parameters** are initially visible. The menu function -LG- is used to make the full parameter set visible.



Setting Parameter Value

Press ENTER to view the parameter value.

To set a new value, press and hold ENTER until **SET** is displayed.



Note! **SET** blinks, if the parameter value is altered. **SET** is not displayed, if the value cannot be altered.


Note! To view the parameter default value, press the UP/DOWN buttons simultaneously.

Menu Functions

Scroll the Parameter groups for the desired menu function. Press and hold ENTER until the display blinks to start the function.

Note! ACS100-PAN upload and download functions are not operational with ACS 400. The relatively small permanent memory of the ACS100-PAN cannot store all the ACS 400 parameter values.

Select between basic and full menu



Diagnostic Displays

When the red LED of the ACS 400 is on or blinking, a fault is active. The relevant fault message flashes in the panel display.

When the green LED of the ACS 400 is blinking, an alarm is active. The relevant alarm message is shown in the panel display. Alarms 1-7 arise from button operation and green LED does not blink for them.

The alarm and fault messages disappear when MENU, ENTER or the arrow buttons of control panel are pressed. The message will reappear after a few seconds if the keypad is not touched and alarm or fault is still active.




Figure 35 Fault and alarm messages.

Refer to Diagnostics section for complete list of alarms and faults.

Resetting the Drive from the Control Panel

To reset a fault when the red LED is on, press the START/STOP button.

Caution! Resetting the fault may start the drive when in remote control.

To reset a fault when the red LED is blinking, turn the power off.

Caution! Turning the power on again may start the drive immediately.

ACS 400 Basic Parameters

ACS 400 has a large number of parameters. Of these, only the so called basic parameters are initially visible.

Setting up only a few basic parameters is sufficient in applications where the preprogrammed application macros of the ACS 400 can provide all desired functionality. For a full description of programmable features provided by the ACS 400, see “ACS 400 Complete Parameter List”, starting page 55.

The following table lists the basic parameters.

S = Parameters can be modified only when the drive is stopped.

Code	Name	User	S
Group 99			
START-UP DATA			
9901	LANGUAGE Language selection. 0 = ENGLISH 4 = SPANISH 8 = DANISH 12 = (reserved) 1 = ENGLISH (AM) 5 = PORTUGUESE 9 = FINNISH 2 = GERMAN 6 = DUTCH 10 = SWEDISH 3 = ITALIAN 7 = FRENCH 11 = RUSSIAN		
9902	APPLIC MACRO Selects application macro. Sets parameter values to their default values. Refer to “Application Macros”, starting page 43 for detailed description of each macro. 0 = FACTORY 1 = ABB STANDARD 2 = 3-WIRE 3 = ALTERNATE 4 = MOTOR POT 5 = HAND/AUTO 6 = PID CONTROL 7 = PREMAGN 8 = PFC CONTROL Default value: 0 (FACTORY MACRO)		✓
9905	MOTOR NOM VOLT Nominal motor voltage from motor name plate. Range of this parameter depends on the type of the ACS 400. Default value for 400 V unit: 400 V 200 V unit: 230 V		✓
9906	MOTOR NOM CURR Nominal motor current from motor name plate. Values for this parameter range from $0.5 \cdot I_N$ - $1.5 \cdot I_N$, where I_N is nominal current of the ACS 400. Default value: I_N		✓

Code	Name	User	S
9907	MOTOR NOM FREQ Nominal motor frequency from motor name plate. Range: 0 - 250 Hz Default value: 50 Hz		✓
9908	MOTOR NOM SPEED Nominal motor speed from motor name plate. Range 0 - 3600 rpm Default: 1440 rpm		✓
9909	MOTOR NOM POWER Nominal motor power from name plate. Range: 0.1 - 100.0 kW Default: 2.0 - 30.0 kW depending on the type of the frequency converter		✓
9910	MOTOR COS PHI Nominal motor cos phi from name plate. Range: 0.50 - 0.99 Default: 0.83		✓
Group 01 OPERATING DATA			
0128	LAST FAULT Last recorded fault (0 = no fault). See "Diagnostics", starting page 135. Can be cleared with the control panel by pressing UP and DOWN buttons simultaneously when in parameter set mode.		
Group 10 COMMAND INPUTS			
1003	DIRECTION Rotation direction lock. 1 = FORWARD 2 = REVERSE 3 = REQUEST If you select REQUEST, the direction is set according to the given direction command. Default: 3 (REQUEST) or 1 (FORWARD) depending on the selected application macro.		✓
Group 11 REFERENCE SELECT			
1105	EXT REF1 MAX Maximum frequency reference in Hz. Range: 0 - 250 Hz Default value: 50 Hz or 52 Hz depending on the selected application macro.		

Code	Name	User	S
Group 12			
CONSTANT SPEEDS			
1202	CONST SPEED 1 Range for all constant speeds: 0 - 250.0 Hz Default value: 5.0 Hz		
1203	CONST SPEED 2 Default value: 10.0 Hz		
1204	CONST SPEED 3 Default value: 15.0 Hz		
Group 13			
ANALOGUE INPUTS			
1301	MINIMUM AI1 Minimum value of AI1 in per cent. Defines relative analogue input value where frequency reference reaches minimum value. Range: 0 - 100 % Default value: 0 %		
Group 15			
ANALOGUE OUTPUT			
1503	AO CONTENT MAX Defines output frequency where analogue output reaches 20 mA. Default value: 50.0 Hz or 52 Hz depending on the selected application macro. Note! Analogue output content is programmable. Values given here are valid only if other analogue output configuration parameters have not been modified. Description of all parameters is given in "ACS 400 Complete Parameter List" starting on page 55.		
Group 20			
LIMITS			
2003	MAX CURRENT Maximum output current. Range: $0.5 \cdot I_N - 1.5 \dots 1.7 \cdot I_N^{**}$, where I_N is nominal current of the ACS 400. Default value: $1.5 \cdot I_N$		
2008	MAXIMUM FREQ Maximum output frequency. Range: 0 - 250 Hz Default value: 50 Hz or 52 Hz depending on the selected application macro.		✓

** The maximum factor depending on the type of the frequency converter at 4 kHz switching frequency.

The table continues on the next page.

Code	Name	User	S
Group 21 START/STOP			
2102	STOP FUNCTION Conditions during motor stopping. 1 = COAST Motor coasts to stop. 2 = RAMP Ramp deceleration as defined by the active deceleration time 2203 DECELER TIME 1 or 2205 DECELER TIME 2. Default value: 1 (COAST)		
Group 22 ACCELER/DECELER			
2202	ACCELER TIME 1 Ramp 1: time from zero to maximum frequency (0 - MAXIMUM FREQ). Range for all ramp time parameters is 0.1 - 1800 s. Default value: 5.0 s		
2203	DECELER TIME 1 Ramp 1: time from maximum to zero frequency (MAXIMUM FREQ - 0). Default value: 5.0 s		
2204	ACCELER TIME 2 Ramp 2: time from zero to maximum frequency (0 - MAXIMUM FREQ). Default value: 60.0 s		
2205	DECELER TIME 2 Ramp 2: time from maximum to zero frequency (MAXIMUM FREQ - 0). Default value: 60.0 s		
Group 26 MOTOR CONTROL			
2606	U/f RATIO U/f below field weakening point. 1 = LINEAR 2 = SQUARE LINEAR is preferred for constant torque applications. SQUARE is preferred for centrifugal pump and fan applications to increase motor efficiency and to reduce motor noise. Default value: 1 (LINEAR)		✓
Group 33 INFORMATION			
3301	SW VERSION Software version code.		

S = Parameters can be modified only when the drive is stopped.

Application Macros

Application Macros are preprogrammed parameter sets. They minimise the number of different parameters to be set during start-up. The Factory Macro is the factory-set default macro.

Note! The Factory Macro is intended for applications where there is NO control panel available. It *should not be used* when control panel is in use, because macro dependent parameters cannot be set. With other macros the control panel is needed.

Parameter Values

Selecting an application macro with parameter 9902 APPLIC MACRO will set all other parameters (except the group 99 Start-up Data parameters, the parameter lock 1602 and groups 50 - 52 serial communication parameters) to their default values.

Default values of certain parameters depend on the selected macro. These are listed with the description of each macro. Default values for other parameters are given in "ACS 400 Complete Parameter List" starting on page 55.

Connection Examples

In the following connection examples please note:

- All the digital inputs are connected using negative (NPN) logic.

Application Macro Factory (0)

This macro is intended for applications where there is NO control panel available. It provides a general purpose 2-wire I/O configuration.

The value of parameter 9902 is 0 (FACTORY). DI4 is not connected.

Input signals

- Start, stop and direction (DI1,2)
- Analogue reference (AI1)
- Constant speed 1 (DI3)
- Ramp pair 1/2 selection (DI5)


Output signals

- An. output AO: Frequency
- Relay output 1: Fault
- Relay output 2: Running

U/I jumper J1

AI1:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
AI2:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

0 - 10 V
0(4) - 20 mA



External Reference 1: 0...10 V <=> 0...50 Hz

Reference voltage 10 VDC
Not used

Output frequency 0...20 mA <=> 0...50 Hz

+24 VDC

Start/Stop: Activate to start ACS400
Fwd/Rev: Activate to reverse rotation direction
Constant Speed 1: Default: 5 Hz
Leave unconnected!*
Ramp pair selection. Activate to select ramp pair 2.

Relay output 1, programmable
Default: **Fault** =>17 connected to 18
Relay output 2, programmable
Default: **Running** =>20 connected to 22

***Note!** DI 4 is used to configure ACS 400. It is read only once when power is connected. All parameters marked with * are determined by the DI4 input.

Factory (0) parameter values:

*	1001 EXT 1 COMMANDS	2 (DI1,2)	1402 RELAY OUTPUT 2	2 (RUN)
	1002 EXT 2 COMMANDS	0 (NOT SEL)	1503 AO CONTENT MAX	50.0 Hz
	1003 DIRECTION	3 (REQUEST)	1601 RUN ENABLE	0 (NOT SEL)
	1102 EXT1/EXT2 SEL	6 (EXT1)	1604 FAULT RESET SEL	6 (START/STOP)
	1103 EXT REF1 SELECT	1 (AI1)	2008 MAXIMUM FREQ	50 Hz
	1105 EXT REF1 MAX	50 Hz	2105 PREMAGN SEL	0 (NOT SEL)
	1106 EXT REF2 SELECT	0 (KEYPAD)	2201 ACC/DEC 1/2 SEL	5 (DI5)
*	1201 CONST SPEED SEL	3 (DI3)	4001 PID GAIN	1.0
	1401 RELAY OUTPUT 1	3 (FAULT (-1))	4002 PID INTEG TIME	60 s

Application Macro Factory (1)

This macro is intended for applications where there is NO control panel available. It provides a general purpose 3-wire I/O configuration.

The value of parameter 9902 is 0 (FACTORY). DI 4 is connected.

Input signals


- Start, stop and direction (DI1,2,3)
- Analogue reference (AI1)
- Ramp pair 1/2 selection (DI5)

Output signals

- An. output AO:
- Frequency
- Relay output 1: Fault
- Relay output 2: Running

U/I jumper J1

A11:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 - 10 V
A12:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0(4) -10mA
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	



External Reference 1: 0...10 V \Leftrightarrow 0...50 Hz

Reference voltage 10 VDC
Not used

Output frequency 0...20 mA \Leftrightarrow 0...50 Hz

+24 VDC

Momentary activation with DI2 activated: **Start**
Momentary deactivation: **Stop**
Fwd/Rev: activate to reverse rotation direction
Has to be connected!*
Ramp pair selection. Activate to select ramp pair 2.

Relay output 1, programmable
Default: **Fault** \Rightarrow 17 connected to 18

Relay output 2, programmable
Default: **Running** \Rightarrow 20 connected to 22

***Note!** DI 4 is used to configure ACS 400. It is read only once when power is connected. All parameters marked with * are determined by the DI4 input.

Note! Deactivation of stop signal interlocks panel START/STOP button in local control mode.

Factory (1) parameter values:

* 1001 EXT 1 COMMANDS	4 (DI1P,2P,P)	1402 RELAY OUTPUT 2	2 (RUN)
1002 EXT 2 COMMANDS	0 (NOT SEL)	1503 AO CONTENT MAX	50 Hz
1003 DIRECTION	3 (REQUEST)	1601 RUN ENABLE	0 (NOT SEL)
1102 EXT1/EXT2 SEL	6 (EXT1)	1604 FAULT RESET SEL	6 (START/STOP)
1103 EXT REF1 SELECT	1 (AI1)	2008 MAXIMUM FREQ	50 Hz
1105 EXT REF1 MAX	50 Hz	2105 PREMAGN SEL	0 (NOT SEL)
1106 EXT REF2 SELECT	0 (KEYPAD)	2201 ACC/DEC 1/2 SEL	5 (DI5)
* 1201 CONST SPEED SEL	0 (NOT SEL)	4001 PID GAIN	1.0
1401 RELAY OUTPUT 1	3 (FAULT (-1))	4002 PID INTEG TIME	60 s

Application Macro ABB Standard

This general purpose macro is typical 2-wire I/O configuration. It gives two more preset speeds compared to Factory Macro (0).

The value of parameter 9902 is 1 (ABB STANDARD).

Input signals

- Start, stop and direction (DI1,2)
- Analogue reference (AI1)
- Preset speed selection (DI3,4)
- Ramp pair 1/2 selection (DI5)


Output signals

- An. output AO: Frequency
- Relay output 1: Fault
- Relay output 2: Running

U/I jumper J1

AI1:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
AI2:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

0 - 10 V
0(4) - 20 mA



External Reference 1: 0...10 V <=> 0...50 Hz

Reference voltage 10 VDC
Not used

Output frequency 0...20 mA <=> 0...50 Hz

+24 VDC

Start/Stop: Activate to start
Fwd/Rev: Activate to reverse rotation direction
Constant speed selection*
Constant speed selection*
Ramp pair selection. Activate to select ramp pair 2.

Relay output 1, programmable
Default: **Fault** => 17 connected to 18

Relay output 2, programmable
Default: **Running** => 20 connected to 22

*Constant speed selection: 0 = open, 1 = connected

DI3	DI4	Output
0	0	Reference through AI1
1	0	Const speed 1 (1202)
0	1	Const speed 2 (1203)
1	1	Const speed 3 (1204)

ABB Standard parameter values:

1001 EXT 1 COMMANDS	2 (DI1,2)	1402 RELAY OUTPUT 2	2 (RUN)
1002 EXT 2 COMMANDS	0 (NOT SEL)	1503 AO CONTENT MAX	50 Hz
1003 DIRECTION	3 (REQUEST)	1601 RUN ENABLE	0 (NOT SEL)
1102 EXT1/EXT2 SEL	6 (EXT1)	1604 FAULT RESET SEL	0 (KEYPAD)
1103 EXT REF1 SELECT	1 (AI1)	2008 MAXIMUM FREQ	50 Hz
1105 EXT REF1 MAX	50 Hz	2105 PREMAGN SEL	0 (NOT SEL)
1106 EXT REF2 SELECT	0 (KEYPAD)	2201 ACC/DEC 1/2 SEL	5 (DI5)
1201 CONST SPEED SEL	7 (DI3,4)	4001 PID GAIN	1.0
1401 RELAY OUTPUT 1	3 (FAULT (-1))	4002 PID INTEG TIME	60 s

Application Macro 3-wire

This macro is intended for those applications where the drive is controlled using momentary push-buttons. It gives two more preset speeds compared to Factory Macro (1) by using DI4 and DI5.

The value of parameter 9902 is 2 (3-WIRE).

Input signals

- Start, stop and direction (DI1,2,3)
- Analogue reference (AI1)
- Preset speed selection (DI4,5)

Output signals


- An. output AO: Frequency
- Relay output 1: Fault
- Relay output 2: Running

U/I jumper J1

AI1:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
AI2:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

0 - 10 V

0(4) - 10 mA



External Reference 1: 0...10 V \Leftrightarrow 0...50 Hz

Reference voltage 10 VDC
Not used

Output frequency 0...20 mA \Leftrightarrow 0...50 Hz

+24 VDC

Momentary activation with DI2 activated: **Start**
Momentary deactivation: **Stop**
Activate to reverse rotation: **Fwd/Rev**
Constant speed selection*
Constant speed selection*

Relay output 1, programmable
Default: fault \Rightarrow 17 connected to 18

Relay output 2, programmable
Default: running \Rightarrow 20 connected to 22

*Constant speed selection: 0 = open, 1 = connected

DI4	DI5	Output
0	0	Reference through AI1
1	0	Constant speed 1 (1202)
0	1	Constant speed 2 (1203)
1	1	Constant speed 3 (1204)

Note! Deactivation of stop signal interlocks panel START/STOP button in local control mode.

Application Macro 3-wire parameter values:

1001 EXT 1 COMMANDS	4 (DI1P,2P,3)	1402 RELAY OUTPUT 2	2 (RUN)
1002 EXT 2 COMMANDS	0 (NOT SEL)	1503 AO CONTENT MAX	50 Hz
1003 DIRECTION	3 (REQUEST)	1601 RUN ENABLE	0 (NOT SEL)
1102 EXT1/EXT2 SEL	6 (EXT1)	1604 FAULT RESET SEL	0 (KEYPAD)
1103 EXT REF1 SELECT	1 (AI1)	2008 MAXIMUM FREQ	50 Hz
1105 EXT REF1 MAX	50 Hz	2105 PREMAGN SEL	0 (NOT SEL)
1106 EXT REF2 SELECT	0 (KEYPAD)	2201 ACC/DEC 1/2 SEL	0 (NOT SEL)
1201 CONST SPEED SEL	8 (DI4,5)	4001 PID GAIN	1.0
1401 RELAY OUTPUT 1	3 (FAULT (-1))	4002 PID INTEG TIME	60 s

Application Macro Alternate

This macro offers an I/O configuration that is adopted to a sequence of DI control signals used when alternating the direction of rotation of the drive.

The value of parameter 9902 is 3 (ALTERNATE).

Input signals

- Start, stop and direction (DI1,2)
- Analogue reference (AI1)
- Preset speed selection (DI3,4)
- Ramp pair 1/2 selection (DI5)


Output signals

- An. output AO: Frequency
- Relay output 1: Fault
- Relay output 2: Running

U/I jumper J1

AI1:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
AI2:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

0 - 10 V
0(4) - 20 mA



External Reference 1: 0...10 V <=> 0...50 Hz

Reference voltage 10 VDC
Not used

Output frequency 0...20 mA <=> 0...50 Hz

+24 VDC

Start fwd: If DI1 state is the same as DI2, drive stops

Start reverse

Constant Speed selection*

Constant Speed selection*

Ramp pair selection. Activate to select ramp pair 2.

Relay output 1, programmable

Default: **Fault** =>17 connected to 18

Relay output 2, programmable

Default: **Running** =>20 connected to 22

*Constant speed selection: 0 = open, 1 = connected

DI3	DI4	Output
0	0	Reference through AI1
1	0	Constant speed 1 (1202)
0	1	Constant speed 2 (1203)
1	1	Constant speed 3 (1204)

Application macro Alternate parameter values:

1001 EXT 1 COMMANDS	9 (DI1F,2R)	1402 RELAY OUTPUT 2	2 (RUN)
1002 EXT 2 COMMANDS	0 (NOT SEL)	1503 AO CONTENT MAX	50 Hz
1003 DIRECTION	3 (REQUEST)	1601 RUN ENABLE	0 (NOT SEL)
1102 EXT1/EXT2 SEL	6 (EXT1)	1604 FAULT RESET SEL	0 (KEYPAD)
1103 EXT REF1 SELECT	1 (AI1)	2008 MAXIMUM FREQ	50 Hz
1105 EXT REF1 MAX	50 Hz	2105 PREMAGN SEL	0 (NOT SEL)
1106 EXT REF2 SELECT	0 (KEYPAD)	2201 ACC/DEC 1/2 SEL	5 (DI5)
1201 CONST SPEED SEL	7 (DI3,4)	4001 PID GAIN	1.0
1401 RELAY OUTPUT 1	3 (FAULT (-1))	4002 PID INTEG TIME	60 s

Application Macro Motor Potentiometer

This macro provides a cost-effective interface for PLCs that vary the speed of the drive using only digital signals.


The value of parameter 9902 is 4 (MOTOR POT).

Input signals

- Start, stop and direction (DI1,2)
- Reference up (DI3)
- Reference down (DI4)
- Preset speed selection (DI5)

Output signals

- An. output AO: Frequency
- Relay output 1: Fault
- Relay output 2: Running



External Reference 1: 0...10 V

Reference voltage 10 VDC
Not used

Output frequency 0...20 mA \Leftrightarrow 0...50 Hz

+24 VDC

Start/Stop: Activate to start.

Forward/Reverse: Activate to reverse rotation direction

Reference up: Activate to increase reference*

Reference down: Activate to decrease reference*

Constant speed 1

Relay output 1, programmable

Default: **Fault** \Rightarrow 17 connected to 18

Relay output 2, programmable

Default: **Running** \Rightarrow 20 connected to 22

*Note!

- If both DI 3 and DI 4 are active or inactive, reference is kept stable.
- Reference is stored during stop or power down condition.
- Analogue reference is not followed when motor potentiometer is selected.

Motor potentiometer parameter values:

1001 EXT 1 COMMANDS	2 (DI1,2)	1402 RELAY OUTPUT 2	2 (RUN)
1002 EXT 2 COMMANDS	0 (NOT SEL)	1503 AO CONTENT MAX	50 Hz
1003 DIRECTION	3 (REQUEST)	1601 RUN ENABLE	0 (NOT SEL)
1102 EXT1/EXT2 SEL	6 (EXT1)	1604 FAULT RESET SEL	0 (KEYPAD)
1103 EXT REF1 SELECT	6 (DI3U,4D)	2008 MAXIMUM FREQ	50 Hz
1105 EXT REF1 MAX	50 Hz	2105 PREMAGN SEL	0 (NOT SEL)
1106 EXT REF2 SELECT	0 (KEYPAD)	2201 ACC/DEC 1/2 SEL	0 (NOT SEL)
1201 CONST SPEED SEL	5 (DI5)	4001 PID GAIN	1.0
1401 RELAY OUTPUT 1	3 (FAULT (-1))	4002 PID INTEG TIME	60 s

Application Macro Hand - Auto

This macro offers an I/O configuration that is typically used in HVAC applications.

The value of parameter 9902 is 5 (HAND/AUTO).

Input signals


- Start/stop (DI1,5) and rev (DI2,4)
- Two an. references (AI1,AI2)
- Control location selection (DI3)

Output signals

- An. output AO: Frequency
- Relay output 1: Fault
- Relay output 2: Running

U/I Jumper J1

A11:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 - 10 V
A12:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0(4) - 20 mA
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	



External Reference 1: 0...10 V <=> 0...50 Hz (**Hand Control**)

Reference voltage 10 VDC

External reference 2: 0...20 mA <=> 0...50 Hz (**Auto Control**)

Output frequency 0...20 mA <=> 0...50 Hz

+24 VDC

Start/Stop: Activate to start ACS 400 (**Hand**).

Forward/Reverse: Activate to reverse rotation direction (**Hand**)

EXT1/EXT2 Selection: Activate to select auto control

Forward/Reverse (Auto)

Start/Stop: Activate to start ACS 400 (**Auto**)

Relay output 1, programmable

Default: **Fault** => 17 connected to 18

Relay output 2, programmable

Default: **Running** => 20 connected to 22

Hand-Auto parameter values:

1001 EXT 1 COMMANDS	2 (DI1,2)	1402 RELAY OUTPUT 2	2 (RUN)
1002 EXT 2 COMMANDS	7 (DI5,4)	1503 AO CONTENT MAX	50 Hz
1003 DIRECTION	3 (REQUEST)	1601 RUN ENABLE	0 (NOT SEL)
1102 EXT1/EXT2 SEL	3 (DI3)	1604 FAULT RESET SEL	0 (KEYPAD)
1103 EXT REF1 SELECT	1 (AI1)	2008 MAXIMUM FREQ	50 Hz
1105 EXT REF1 MAX	50 Hz	2105 PREMAGN SEL	0 (NOT SEL)
1106 EXT REF2 SELECT	2 (AI2)	2201 ACC/DEC 1/2 SEL	0 (NOT SEL)
1201 CONST SPEED SEL	0 (NOT SEL)	4001 PID GAIN	1.0
1401 RELAY OUTPUT 1	3 (FAULT (-1))	4002 PID INTEG TIME	60 s

Application Macro PID Control

This macro is intended for use with different closed-loop control systems such as pressure control, flow control, etc.

The value of parameter 9902 is 6 (PID CTRL).

Input signals

- Start/stop (DI1,5)
- Analogue reference (AI1)
- Actual value (AI2)
- Control location selection (DI2)
- Constant speed (DI3)
- Run enable (DI4)


Output signals

- An. output AO: Frequency
- Relay output 1: Fault
- Relay output 2: Running

U/I Jumper J1

AI1:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
AI2:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

0 - 10 V
0(4) - 20 mA



EXT1 (**Manual**) or EXT2 (**PID**) reference: 0...10 V

Reference voltage 10 VDC
Actual signal; 0...20 mA (**PID**)

Output frequency 0...20 mA \Leftrightarrow 0...50 Hz

+24 VDC

Start/Stop: Activate to start ACS 400 (**Manual**).

EXT1/EXT2 Selection: Activate to select PID control

Constant speed 1: not used if PID control*

Run enable: deactivation always stops ACS 400

Start/Stop: Activate to start ACS 400 (**PID**)

Relay output 1, programmable
Default: **Fault** \Rightarrow 17 connected to 18

Relay output 2, programmable
Default: **Running** \Rightarrow 20 connected to 22

Note!

* Constant speed is not considered while in PID control (PID).

PID control parameters (group 40) do not belong to the Basic parameter set.

PID Control parameter values:

1001 EXT 1 COMMANDS	1 (DI1)	1402 RELAY OUTPUT 2	2 (RUN)
1002 EXT 2 COMMANDS	6 (DI5)	1503 AO CONTENT MAX	50 Hz
1003 DIRECTION	1 (FORWARD)	1601 RUN ENABLE	4 (DI4)
1102 EXT1/EXT2 SEL	2 (DI2)	1604 FAULT RESET SEL	0 (KEYPAD)
1103 EXT REF1 SELECT	1 (AI1)	2008 MAXIMUM FREQ	50 Hz
1105 EXT REF1 MAX	50 Hz	2105 PREMAGN SEL	0 (NOT SEL)
1106 EXT REF2 SELECT	1 (AI1)	2201 ACC/DEC 1/2 SEL	0 (NOT SEL)
1201 CONST SPEED SEL	3 (DI3)	4001 PID GAIN	1.0
1401 RELAY OUTPUT 1	3 (FAULT(-1))	4002 PID INTEG TIME	60 s

Application Macro Premagnetise

This macro is intended for those applications where the drive must start very quickly. Building up the flux in the motor always takes time. With the Premagnetise Macro, this delay can be eliminated.

The value of parameter 9902 is 7 (PREMAGN).

Input signals

- Start, stop and direction (DI1,2)
- Analogue reference (AI1)
- Preset speed selection (DI3,4)
- Premagnetise (DI5)


Output signals

- An. output AO: Frequency
- Relay output 1: Fault
- Relay output 2: Running

U/I Jumper J1

AI1:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
AI2:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

0 - 10 V
0(4) - 20 mA



External Reference 1: 0...10 V <=> 0...50 Hz

Reference voltage 10 VDC
Not used

Output frequency 0...20 mA <=> 0...50 Hz

+24 VDC

Start/Stop: Active to start ACS 400
Fwd/Rev: Activate to reverse rotation
Constant Speed selection*
Constant Speed selection*
Premagnetise: Activate to start premagnetising

Relay output 1, programmable
Default: **Fault** => 17 connected to 18

Relay output 2, programmable
Default: **Running** => 20 connected to 22

*Constant speed selection: 0 = open, 1 = connected

DI3	DI4	Output
0	0	Reference through AI1
1	0	Constant speed 1 (1202)
0	1	Constant speed 2 (1203)
1	1	Constant speed 3 (1204)

Premagnetise parameter values:

1001 EXT 1 COMMANDS	2 (DI1,2)	1402 RELAY OUTPUT 2	2 (RUN)
1002 EXT 2 COMMANDS	0 (NOT SEL)	1503 AO CONTENT MAX	50 Hz
1003 DIRECTION	3 (REQUEST)	1601 RUN ENABLE	0 (NOT SEL)
1102 EXT1/EXT2 SEL	6 (EXT1)	1604 FAULT RESET SEL	0 (KEYPAD)
1103 EXT REF1 SELECT	1 (KEYPAD)	2008 MAXIMUM FREQ	50 Hz
1105 EXT REF1 MAX	50 Hz	2105 PREMAGN SEL	5 (DI5)
1106 EXT REF2 SELECT	0 (KEYPAD)	2201 ACC/DEC 1/2 SEL	0 (NOT SEL)
1201 CONST SPEED SEL	7 (DI3,4)	4001 PID GAIN	1.0
1401 RELAY OUTPUT 1	3 (FAULT (-1))	4002 PID INTEG TIME	60 s

Application Macro PFC Control

This macro is intended for pump and fan control applications. For more information see Appendix B.

The value of parameter 9902 is 8 (PFC CONTROL).

Input signals

- Start and stop (DI1)
- Analogue reference (AI1)
- Actual value (AI2)
- Control location selection (DI3)
- Run enable (DI2)

Output signals


- An. output AO: Frequency
- Relay output 1: Speed regulated motor
- Relay output 2: Auxiliary motor

U/I Jumper J1

AI1:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
AI2:	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

0 - 10 V

0(4) - 20 mA



EXT1 (**Manual**) or EXT2 (**PID/PFC**) reference: 0...10 V

Reference voltage 10 VDC

Actual signal; 0...20 mA (**PID**)

Output frequency 0...20 mA <=> 0...52 Hz

+24 VDC

Start/Stop: Activate to start ACS 400.

Run enable: Deactivation always stops ACS 400

EXT1/EXT2 Selection: Activate to select PFC control

Interlock: Deactivation stops ACS 400

Interlock: Deactivation stops constant speed motor

Relay output 1, programmable

Default: **Speed regulated motor switched on**
=> 17 connected to 18

Relay output 2, programmable

Default: **Auxiliary motor switched on** => 20 connected to 22

PFC parameter values:

1001 EXT 1 COMMANDS	1 (DI1)	1402 RELAY OUTPUT 2	29 (PFC)
1002 EXT 2 COMMANDS	1 (DI1)	1503 AO CONTENT MAX	52 Hz
1003 DIRECTION	1 (FORWARD)	1601 RUN ENABLE	2 (DI2)
1102 EXT1/EXT2 SEL	3 (DI3)	1604 FAULT RESET SEL	0 (KEYPAD)
1103 EXT REF1 SELECT	1 (AI1)	2008 MAXIMUM FREQ	52 Hz
1105 EXT REF1 MAX	52 Hz	2105 PREMAGN SEL	0 (NOT SEL)
1106 EXT REF2 SELECT	1 (AI1)	2201 ACC/DEC 1/2 SEL	0 (NOT SEL)
1201 CONST SPEED SEL	0 (NOT SEL)	4001 PID GAIN	2,5
1401 RELAY OUTPUT 1	29 (PFC)	4002 PID INTEG TIME	3 s

ACS 400 Complete Parameter List

Initially, only the so called basic parameters (shaded grey in Table 12) are visible. Use the appropriate menu function of the control panel to make the full parameter set visible.

S = Parameters can be modified only when the drive is stopped.

M = Default value depends on the selected macro (*).

Table 12 Full parameter set.

Code	Name	Range	Resolution	Default	User	S	M
Group 99							
START-UP DATA							
9901	LANGUAGE	0 - 12	1	0 (ENGLISH)			
9902	APPLIC MACRO	0 - 8	1	0 (FACTORY)		✓	
9905	MOTOR NOM VOLT	200, 208, 220, 230, 240, 380, 400, 415, 440, 460, 480 V	-	230 V / 400 V		✓	
9906	MOTOR NOM CURR	$0.5 \cdot I_N - 1.5 \cdot I_N$	0.1 A	$1.0 \cdot I_N$		✓	
9907	MOTOR NOM FREQ	0 - 250 Hz	1 Hz	50 Hz		✓	
9908	MOTOR NOM SPEED	0 - 3600 rpm	1 rpm	1440 rpm		✓	
9909	MOTOR NOM POWER	0.1 - 100 kW	0.1 kW	2 - 30 kW		✓	
9910	MOTOR COS PHI	0.50 - 0.99	0.01	0.83		✓	
Group 01							
OPERATING DATA							
0102	SPEED	0 - 9999 rpm	1 rpm	-			
0103	OUTPUT FREQ	0 - 250 Hz	0.1 Hz	-			
0104	CURRENT	-	0.1 A	-			
0105	TORQUE	-	0.1 %	-			
0106	POWER	-	0.1 kW	-			
0107	DC BUS VOLTAGE	0 - 999.9 V	0.1 V	-			
0109	OUTPUT VOLTAGE	0 - 480 V	0.1 V	-			
0110	ACS400 TEMP	0 - 150 °C	0.1 °C	-			
0111	EXTERNAL REF 1	0 - 250 Hz	0.1 Hz	-			
0112	EXTERNAL REF 2	0 - 100 %	0.1 %	-			
0113	CTRL LOCATION	0 - 2	1	-			
0114	RUN TIME (R)	0 - 9999 h	1 h	-			
0115	kWh COUNTER (R)	0 - 9999 kWh	1 kWh	-			
0116	APPL BLK OUTPUT	0 - 100 %	0.1 %	-			
0117	DI1-DI4 STATUS	0000 - 1111 (0 - 15 decimal)	1	-			
0118	AI1	0 - 100 %	0.1 %	-			
0119	AI2	0 - 100 %	0.1 %	-			
0121	DI5 & RELAYS	0000 - 0111 (0 - 7 decimal)	1	-			
0122	AO	0 - 20 mA	0.1 mA	-			
0124	ACTUAL VALUE 1	0 - 100 %	0.1 %	-			
0125	ACTUAL VALUE 2	0 - 100 %	0.1 %	-			
0126	CONTROL DEV	-100 - 100 %	0.1 %	-			

Code	Name	Range	Resolution	Default	User	S	M
0127	PID ACT VALUE	0 - 100 %	0.1 %				
0128	LAST FAULT	0 - 26	1	0			
0129	PREVIOUS FAULT	0 - 26	1	0			
0130	OLDEST FAULT	0 - 26	1	0			
0131	SER LINK DATA 1	0 - 255	1				
0132	SER LINK DATA 2	0 - 255	1				
0133	SER LINK DATA 3	0 - 255	1				
0134	PROCESS VAR 1	0 - 65535 or -32768 - 32767	1				
0135	PROCESS VAR 2	0 - 65535 or -32768 - 32767	1				
0136	RUN TIME	0.00 - 99.99 kh	0.01 kh				
0137	MWh COUNTER	0 - 9999 MWh	1 MWh				
Group 10 COMMAND INPUTS							
1001	EXT1 COMMANDS	0 - 10	1	*		✓	✓
1002	EXT2 COMMANDS	0 - 10	1	*		✓	✓
1003	DIRECTION	1 - 3	1	*		✓	✓
Group 11 REFERENCE SELECT							
1101	KEYPAD REF SEL	1 - 2	1	1 (REF1 (Hz))			
1102	EXT1/EXT2 SEL	1 - 8	1	*		✓	✓
1103	EXT REF1 SELECT	0 - 10	1	*		✓	✓
1104	EXT REF1 MIN	0 - 250 Hz	1 Hz	0 Hz			
1105	EXT REF1 MAX	0 - 250 Hz	1 Hz	*			✓
1106	EXT REF2 SELECT	0 - 10	1	*		✓	✓
1107	EXT REF2 MIN	0 - 100 %	1 %	0 %			
1108	EXT REF2 MAX	0 - 500 %	1 %	100 %			
Group 12 CONSTANT SPEEDS							
1201	CONST SPEED SEL	0 - 10	1	*		✓	✓
1202	CONST SPEED 1	0 - 250 Hz	0.1 Hz	5 Hz			
1203	CONST SPEED 2	0 - 250 Hz	0.1 Hz	10 Hz			
1204	CONST SPEED 3	0 - 250 Hz	0.1 Hz	15 Hz			
1205	CONST SPEED 4	0 - 250 Hz	0.1 Hz	20 Hz			
1206	CONST SPEED 5	0 - 250 Hz	0.1 Hz	25 Hz			
1207	CONST SPEED 6	0 - 250 Hz	0.1 Hz	40 Hz			
1208	CONST SPEED 7	0 - 250 Hz	0.1 Hz	50 Hz			
Group 13 ANALOGUE INPUTS							
1301	MINIMUM AI1	0 - 100 %	1 %	0 %			
1302	MAXIMUM AI1	0 - 100 %	1 %	100 %			
1303	FILTER AI1	0 - 10 s	0.1 s	0.1 s			
1304	MINIMUM AI2	0 - 100 %	1 %	0 %			

Code	Name	Range	Resolution	Default	User	S	M
1305	MAXIMUM AI2	0 - 100 %	1 %	100 %			
1306	FILTER AI2	0 - 10 s	0.1 s	0.1 s			
Group 14							
RELAY OUTPUTS							
1401	RELAY OUTPUT 1	0 - 31	1	*		✓	✓
1402	RELAY OUTPUT 2	0 - 31	1	*		✓	✓
1403	RELAY 1 ON DELAY	0 - 3600 s	0.1 s; 1 s	0 s			
1404	RELAY 1 OFF DELAY	0 - 3600 s	0.1 s; 1 s	0 s			
1405	RELAY 2 ON DELAY	0 - 3600 s	0.1 s; 1 s	0 s			
1406	RELAY 2 OFF DELAY	0 - 3600 s	0.1 s; 1 s	0 s			
Group 15							
ANALOGUE OUTPUT							
1501	AO CONTENT	102 - 137	1	103			
1502	AO CONTENT MIN			0.0 Hz			
1503	AO CONTENT MAX			*			✓
1504	MINIMUM AO	0.0 - 20.0 mA	0.1 mA	0 mA			
1505	MAXIMUM AO	0.0 - 20.0 mA	0.1 mA	20.0 mA			
1506	FILTER AO	0 - 10 s	0.1 s	0.1 s			
Group 16							
SYSTEM CONTROLS							
1601	RUN ENABLE	0 - 6	1	*		✓	✓
1602	PARAMETER LOCK	0 - 2	1	1 (OPEN)			
1604	FAULT RESET SEL	0 - 7	1	*		✓	✓
1605	LOCAL LOCK	0 - 1	1	0 (OPEN)			
1607	PARAM. SAVE	0 - 1	1	0 (DONE)			
Group 20							
LIMITS							
2003	MAX CURRENT	$0.5 \cdot I_N - 1.5 \dots 1.7 \cdot I_N^{**}$	0.1 A	$1.5 \cdot I_N^{**}$			
2005	OVERVOLT CTRL	0 - 1	1	1 (ENABLE)			
2006	UNDERVOLT CTRL	0 - 2	1	1 (ENABLE TIME)			
2007	MINIMUM FREQ	0 - 250 Hz	1 Hz	0 Hz			
2008	MAXIMUM FREQ	0 - 250 Hz	1 Hz	*		✓	✓
Group 21							
START/STOP							
2101	START FUNCTION	1 - 4	1	1 (RAMP)		✓	
2102	STOP FUNCTION	1 - 2	1	1 (COAST)			
2103	TORQ BOOST CURR	$0.5 \cdot I_N - 1.5 \dots 1.7 \cdot I_N^{**}$	0.1 A	$1.2 \cdot I_N^{**}$		✓	
2104	STOP DC INJ TIME	0 - 250 s	0.1 s	0 s			
2105	PREMAGN SEL	0 - 6	1	*		✓	✓
2106	PREMAGN MAX TIME	0.0 - 25.0 s	0.1 s	2.0 s			
2107	START INHIBIT	0 - 1	1	1 (ON)			

Code	Name	Range	Resolution	Default	User	S	M
Group 22							
ACCEL/DECEL							
2201	ACC/DEC 1/2 SEL	0 - 5	1	*		✓	✓
2202	ACCELER TIME 1	0.1 - 1800 s	0.1; 1 s	5 s			
2203	DECELER TIME 1	0.1 - 1800 s	0.1; 1 s	5 s			
2204	ACCELER TIME 2	0.1 - 1800 s	0.1; 1 s	60 s			
2205	DECELER TIME 2	0.1 - 1800 s	0.1; 1 s	60 s			
2206	RAMP SHAPE	0 - 3	1	0 (LINEAR)			
Group 25							
CRITICAL FREQ							
2501	CRIT FREQ SEL	0 - 1	1	0 (OFF)			
2502	CRIT FREQ 1 LO	0 - 250 Hz	1 Hz	0 Hz			
2503	CRIT FREQ 1 HI	0 - 250 Hz	1 Hz	0 Hz			
2504	CRIT FREQ 2 LO	0 - 250 Hz	1 Hz	0 Hz			
2505	CRIT FREQ 2 HI	0 - 250 Hz	1 Hz	0 Hz			
Group 26							
MOTOR CONTROL							
2603	IR COMPENSATION	0 - 30 V 200 V units 0 - 60 V 400 V units	1 V	10 V			
2604	IR COMP RANGE	0 - 250 Hz	1 Hz	50 Hz			
2605	LOW NOISE	0 - 1	1	0 (OFF)		✓	
2606	U/f RATIO	1 - 2	1	1 (LINEAR)		✓	
2607	SLIP COMP RATIO	0 - 250 %	1 %	0 %		✓	
Group 30							
FAULT FUNCTIONS							
3001	AI<MIN FUNCTION	0 - 3	1	1 (FAULT)			
3002	PANEL LOSS	1 - 3	1	1 (FAULT)			
3003	EXTERNAL FAULT	0 - 5	1	0 (NOT SEL)			
3004	MOT THERM PROT	0 - 2	1	1 (FAULT)			
3005	MOT THERM TIME	256 - 9999 s	1 s	500 s			
3006	MOT LOAD CURVE	50 - 150 %	1 %	100 %			
3007	ZERO SPEED LOAD	25 - 150 %	1 %	70 %			
3008	BREAK POINT	1 - 250 Hz	1 Hz	35 Hz			
3009	STALL FUNCTION	0 - 2	1	0 (NOT SEL)			
3010	STALL CURRENT	$0.5 \cdot I_N - 1.5 \dots 1.7 \cdot I_N^{**}$	0.1 A	$1.2 \cdot I_N^{**}$			
3011	STALL FREQ HI	0.5 - 50 Hz	0.1 Hz	20 Hz			
3012	STALL TIME	10...400 s	1 s	20 s			
3013	UNDERLOAD FUNC	0 - 2	1	0 (NOT SEL)			
3014	UNDERLOAD TIME	10...400 s	1 s	20 s			
3015	UNDERLOAD CURVE	1 - 5	1	1			

Code	Name	Range	Resolution	Default	User	S	M
Group 31							
AUTOMATIC RESET							
3101	NR OF TRIALS	0 - 5	1	0			
3102	TRIAL TIME	1.0 - 180.0 s	0.1 s	30 s			
3103	DELAY TIME	0.0 - 3.0 s	0.1 s	0 s			
3104	AR OVERCURRENT	0 - 1	1	0 (DISABLE)			
3105	AR OVERVOLTAGE	0 - 1	1	0 (DISABLE)			
3106	AR UNDERVOLTAGE	0 - 1	1	0 (DISABLE)			
3107	AR AI<MIN	0 - 1	1	0 (DISABLE)			
Group 32							
SUPERVISION							
3201	SUPERV 1 PARAM	102 - 137	1	103			
3202	SUPERV 1 LIM LO			0.0 Hz			
3203	SUPERV 1 LIM HI			0.0 Hz			
3204	SUPERV 2 PARAM	102 - 137	1	103			
3205	SUPERV 2 LIM LO			0.0 Hz			
3206	SUPERV 2 LIM HI			0.0 Hz			
Group 33							
INFORMATION							
3301	SW VERSION	0.0.0.0 - f.f.f.f	-	-			
3302	TEST DATE	yy.ww	-	-			
Group 34							
PROCESS VARIABLES							
3401	DISPLAY SEL	1 - 2	1	1(STANDARD)			
3402	P VAR 1 SEL	102 - 137	1	104			
3403	P VAR 1 MULTIP	1 - 9999	1	1			
3404	P VAR 1 DIVISOR	1 - 9999	1	1			
3405	P VAR 1 SCALING	0 - 3	1	1			
3406	P VAR 1 UNIT	0 - 31	1	1 (A)			
3407	P VAR 2 SEL	102 - 137	1	103			
3408	P VAR 2 MULTIP	1 - 9999	1	1			
3409	P VAR 2 DIVISOR	1 - 9999	1	1			
3410	P VAR 2 SCALING	0 - 3	1	1			
3411	P VAR 2 UNIT	0 - 31	1	3 (Hz)			

Code	Name	Range	Resolution	Default	User	S	M
Group 40							
PID CONTROL							
4001	PID GAIN	0.1 - 100	0.1	*			✓
4002	PID INTEG TIME	0.1 - 320 s	0.1 s	*			✓
4003	PID DERIV TIME	0 - 10 s	0.1 s	0 s			
4004	PID DERIV FILTER	0 - 10 s	0.1 s	1 s			
4005	ERROR VALUE INV	0 - 1	1	0 (NO)			
4006	ACTUAL VAL SEL	1 - 9	1	1 (ACT1)		✓	
4007	ACT1 INPUT SEL	1 - 2	1	2 (AI2)		✓	
4008	ACT2 INPUT SEL	1 - 2	1	2 (AI2)		✓	
4009	ACT1 MINIMUM	0 - 1000 %	1 %	0 %			
4010	ACT1 MAXIMUM	0 - 1000 %	1 %	100 %			
4011	ACT2 MINIMUM	0 - 1000 %	1 %	0 %			
4012	ACT2 MAXIMUM	0 - 1000 %	1 %	100 %			
4013	PID SLEEP DELAY	0.0 - 3600 s	0.1; 1 s	60 s			
4014	PID SLEEP LEVEL	0.0 - 120 Hz	0.1 Hz	0 Hz			
4015	WAKE-UP LEVEL	0.0 - 100 %	0.1 %	0 %			
4016	PID PARAM SET	1 - 7	1	6 (SET 1)			
4017	WAKE-UP DELAY	0 - 60 s	0.01 s	0.50 s			
4018	SLEEP SELECTION	0 - 5	1	0 (INTERNAL)		✓	
4019	SET POINT SEL	1 - 2	1	2 (EXTERNAL)			
4020	INTERNAL SETPNT	0.0 - 100.0 %	0.1 %	40 %			
Group 41							
PID CONTROL (2)							
4101	PID GAIN	0.1 - 100	0.1	1.0			
4102	PID INTEG TIME	0.1 - 320 s	0.1 s	60 s			
4103	PID DERIV TIME	0 - 10 s	0.1s	0 s			
4104	PID DERIV FILTER	0 - 10 s	0.1 s	1 s			
4105	ERROR VALUE INV	0 - 1	1	0 (NO)			
4106	ACTUAL VAL SEL	1 - 9	1	1 (ACT1)		✓	
4107	ACT1 INPUT SEL	1 - 2	1	2 (AI2)		✓	
4108	ACT2 INPUT SEL	1 - 2	1	2 (AI2)		✓	
4109	ACT1 MINIMUM	0 - 1000 %	1 %	0 %			
4110	ACT1 MAXIMUM	0 - 1000 %	1 %	100 %			
4111	ACT2 MINIMUM	0 - 1000 %	1 %	0 %			
4112	ACT2 MAXIMUM	0 - 1000 %	1 %	100 %			
4119	SET POINT SEL	1 - 2	1	2 (EXTERNAL)			
4120	INTERNAL SETPNT	0.0 - 100.0 %	0.1 %	40.0 %			

Code	Name	Range	Resolution	Default	User	S	M
Group 50							
COMMUNICATION							
5001	DDCS BIT RATE	1, 2, 4, 8	-	1 (1 Mbits/s)		✓	
5002	DDCS NODE NR	1 - 254	1	1		✓	
5003	COMM FAULT TIME	0.1 - 60 s	0.1 s	1 s			
5004	COMM FAULT FUNC	0 - 3	1	0 (NOT SEL)			
5005	PROTOCOL SEL	0 - 3	1	0 (NOT SEL)		✓	
5006	COMM COMMANDS	0 - 2	1	0 (NOT SEL)		✓	
5007	DDCS BUS MODE	1 - 2	1	1 (FIELD BUS)		✓	
Group 51							
EXT COMM MODULE							
5101-5115	FIELD BUS PAR1 - 15	-	-	-			
Group 52							
STANDARD MODBUS							
5201	STATION NUMBER	1 - 247	1	1			
5202	COMM SPEED	3, 6, 12, 24, 48, 96, 192	-	96 (9600 bits/s)			
5203	PARITY	0 - 2	1	0 (NONE)			
5206	BAD MESSAGES	0 - FFFF	1	-			
5207	GOOD MESSAGES	0 - FFFF	1	-			
5208	BUFFER OVERRUNS	0 - FFFF	1	-			
5209	FRAME ERRORS	0 - FFFF	1	-			
5210	PARITY ERRORS	0 - FFFF	1	-			
5211	CRC ERRORS	0 - FFFF	1	-			
5212	BUSY ERRORS	0 - FFFF	1	-			
5213	SER FAULT MEM 1	0 - 255	1	-			
5214	SER FAULT MEM 2	0 - 255	1	-			
5215	SER FAULT MEM 3	0 - 255	1	-			
Group 81							
PFC CONTROL							
8103	REFERENCE STEP 1	0.0 - 100 %	0.1 %	0 %			
8104	REFERENCE STEP 2	0.0 - 100 %	0.1 %	0 %			
8105	REFERENCE STEP 3	0.0 - 100 %	0.1 %	0 %			
8109	START FREQ 1	0.0 - 250 Hz	0.1 Hz	50Hz			
8110	START FREQ 2	0.0 - 250 Hz	0.1 Hz	50 Hz			
8111	START FREQ 3	0.0 - 250 Hz	0.1 Hz	50 Hz			
8112	LOW FREQ 1	0.0 - 250 Hz	0.1 Hz	25 Hz			
8113	LOW FREQ 2	0.0 - 250 Hz	0.1 Hz	25 Hz			
8114	LOW FREQ 3	0.0 - 250 Hz	0.1 Hz	25 Hz			
8115	AUX MOT START D	0.0 - 3600 s	0.1 s; 1 s	5 s			
8116	AUX MOT STOP D.	0.0 - 3600 s	0.1 s; 1 s	3 s			
8117	NR OF AUX MOT	0 - 3	1	1			
8118	AUTOCHNG INTERV	0.0 - 336 h	0.1 h	0.0 h (NOT SEL)			
8119	AUTOCHNG LEVEL	0.0 - 100.0 %	0.1 %	50 %			

Code	Name	Range	Resolution	Default	User	S	M
8120	INTERLOCKS	0 - 6	1	4 (DI4)		✓	
8121	REG BYPASS CTRL	0 - 1	1	0 (NO)			
8122	PFC START DELAY	0 - 10 s	0.01 s	0.5 s			

* The maximum factor depending on the type of the frequency converter at 4 kHz switching frequency.

Group 99: Start-up Data

The Start-up Data parameters are a special set of parameters for setting up the ACS 400 and for entering motor information.

Code	Description
9901	<p>LANGUAGE Language selection for the ACS-PAN-A control panel.</p> <p>0 = ENGLISH 3 = ITALIAN 6 = DUTCH 9 = FINNISH 12 = (reserved) 1 = ENGLISH (AM) 4 = SPANISH 7 = FRENCH 10 = SWEDISH 2 = GERMAN 5 = PORTUGUESE 8 = DANISH 11 = RUSSIAN</p>
9902	<p>APPLIC MACRO Application macro selection. This parameter is used to select the Application Macro which will configure the ACS 400 for a particular application. Refer to "Application Macros", starting page 43, for a list and description of available Application Macros.</p> <p>0 = FACTORY 2 = 3-WIRE 4 = MOTOR POT 6 = PID CONTROL 8 = PFC CONTROL 1 = ABB STANDARD 3 = ALTERNATE 5 = HAND/AUTO 7 = PREMAGN</p>
9905	<p>MOTOR NOM VOLT Nominal motor voltage from motor rating plate. This parameter sets the maximum output voltage supplied to motor by ACS 400. MOTOR NOM FREQ sets the frequency at which output voltage is equal to the MOTOR NOM VOLT. The ACS 400 cannot supply the motor with a voltage greater than the mains voltage. See Figure 36.</p>
9906	<p>MOTOR NOM CURR Nominal motor current from rating plate. The allowed range is $0.5 \cdot I_N \dots 1.5 \cdot I_N$ of ACS 400.</p>
9907	<p>MOTOR NOM FREQ Nominal motor frequency from rating plate (field weakening point). See Figure 36.</p>
9908	<p>MOTOR NOM SPEED Nominal motor speed from rating plate.</p>
9909	<p>MOTOR NOM POWER Nominal motor power from rating plate.</p>
9910	<p>MOTOR COS PHI Nominal motor cos phi from rating plate.</p>






Figure 36 Output voltage as a function of output frequency.

Group 01: Operating Data

This group contains drive operating data, including actual signals and fault memories. Actual Signal values are measured or calculated by the drive and they cannot be set by the user. Fault memories can be cleared by the user from the control panel.

Code	Description
0102	SPEED Displays the calculated speed of the motor (rpm).
0103	OUTPUT FREQ Displays the frequency (Hz) applied to the motor. (Also shown in OUTPUT display.)
0104	CURRENT Displays the motor current, as measured by the ACS 400. (Also shown in OUTPUT display.)
0105	TORQUE Output torque. Calculated value of torque on motor shaft in % of motor nominal torque.
0106	POWER Displays the measured motor power in kW. Note! ACS100-PAN will not display the unit ("kW").
0107	DC BUS VOLTAGE Displays the DC bus voltage, as measured by the ACS 400. The voltage is displayed in Volts DC.
0109	OUTPUT VOLTAGE Displays the voltage applied to the motor.
0110	ACS 400 TEMP Displays the temperature of the ACS 400 heatsink in Centigrade.
0111	EXTERNAL REF 1 The value of external reference 1 in Hz.
0112	EXTERNAL REF 2 The value of external reference 2 in %.
0113	CTRL LOCATION Displays the active control location. Alternatives are: 0 = LOCAL 1 = EXT1 2 = EXT2 See "Appendix A", starting page 141, for description of different control locations.
0114	RUN TIME (R) Shows the total running time of the ACS 400 in hours (h). Can be reset by pressing UP and DOWN buttons simultaneously when in parameter set mode.
0115	kWh COUNTER (R) Shows the counted the kilowatt hours of ACS 400 in operation. Can be reset by pressing UP and DOWN buttons simultaneously when in parameter set mode.
0116	APPL BLK OUTPUT The reference value in per cent received from the application block. The value is from PID control or PFC control, depending on the selected macro. Otherwise the value is from 0112 EXT REF 2.
0117	DI1-DI4 STATUS Status of the four digital inputs. Status is displayed as a binary number. If the input is activated, the display will indicate 1. If the input is deactivated, the display will be 0. <div><div>ACS100-PAN</div><div><div>DI 4 DI 3 DI 2 DI 1</div></div><div>ACS-PAN</div><div><div>000001101BIN</div></div></div>

Code	Description
0118	AI1 Relative value of analogue input 1 displayed in %.
0119	AI2 Relative value of analogue input 2 displayed in %.
0121	DI5 & RELAYS Status of digital input 5 and relay outputs. 1 indicates that the relay is energised and 0 indicates that the relay is de-energised. 
0122	AO Value of analogue output signal in milliamperes.
0124	ACTUAL VALUE 1 PID/PFC controller actual value 1 (ACT1), displayed in per cent.
0125	ACTUAL VALUE 2 PID/PFC controller actual value 2 (ACT2), displayed in per cent.
0126	CONTROL DEV Displays the difference between the reference value and the actual value of the PID/PFC controller.
0127	PID ACT VALUE Feedback signal (actual value) for PID/PFC controller.
0128	LAST FAULT Last recorded fault (0=no fault). See "Diagnostics", starting page 135. Can be cleared with the control panel by pressing UP and DOWN buttons simultaneously when in parameter set mode.
0129	PREVIOUS FAULT Previous recorded fault. See "Diagnostics", starting page 135. Can be cleared with the control panel by pressing UP and DOWN buttons simultaneously when in parameter set mode.
0130	OLDEST FAULT Oldest recorded fault. See "Diagnostics", starting page 135. Can be cleared with the control panel by pressing UP and DOWN buttons simultaneously when in parameter set mode.
0131	SER LINK DATA 1 Free data location that can be written from serial link.
0132	SER LINK DATA 2 Free data location that can be written from serial link.
0133	SER LINK DATA 3 Free data location that can be written from serial link.
0134	PROCESS VAR 1 Process variable 1, as selected by the parameters in group 34.
0135	PROCESS VAR 2 Process variable 2, as selected by the parameters in group 34.
0136	RUN TIME Shows the total running time of ACS 400 in thousands of hours (kh).
0137	MWh COUNTER Counts the megawatt hours of ACS 400 in operation.

Group 10: Command Inputs

Start, Stop and Direction commands can be given from the control panel or from two external locations (EXT1, EXT2). The selection between the two external locations is made with parameter 1102 EXT1/EXT2 SEL. For more information on control locations refer to “Appendix A”, starting page 141.

Code	Description
1001	<p>EXT1 COMMANDS</p> <p>Defines the connections and the source of Start/Stop/Direction commands for External control location 1 (EXT1).</p> <p>0 = NOT SEL No Start/Stop/Direction command source for EXT1 is selected.</p> <p>1 = DI1 Two-wire Start/Stop connected to digital input DI1. DI1 deactivated = Stop; DI1 activated = Start. *</p> <p>2 = DI1,2 Two-wire Start/Stop, Direction. Start/Stop is connected to digital input DI1 as above. Direction is connected to digital input DI2. DI2 deactivated = Forward; DI2 activated = Reverse. To control direction, value of parameter 1003 DIRECTION should be REQUEST.</p> <p>3 = DI1P,2P Three-wire Start/Stop. Start/Stop commands are given by means of momentary push-buttons (the P stands for “pulse”). The Start push-button is normally open, and connected to digital input DI1. The Stop push-button is normally closed, and connected to digital input DI2. Multiple Start push-buttons are connected in parallel; multiple Stop push-buttons are connected in series. *,**</p> <p>4 = DI1P,2P,3 Three-wire Start/Stop, Direction. Start/Stop connected as with DI1P,2P. Direction is connected to digital input DI3. DI3 deactivated = Forward; DI3 activated = Reverse. To control Direction, value of parameter 1003 DIRECTION should be REQUEST. **</p> <p>5 = DI1P,2P,3P Start Forward, Start Reverse, and Stop. Start and Direction commands are given simultaneously with two separate momentary push-buttons (the P stands for “pulse”). The Stop push-button is normally closed, and connected to digital input DI3. The Start Forward and Start Reverse push-buttons are normally open, and connected to digital inputs DI1 and DI2 respectively. Multiple Start push-buttons are connected in parallel, and multiple Stop push-buttons are connected in series. To control direction, value of parameter 1003 DIRECTION should be REQUEST. **</p> <p>6 = DI5 Two-wire Start/Stop, connected to digital input DI5. DI5 deactivated = Stop and DI5 activated = Start. *</p> <p>7 = DI5,4 Two-wire Start/Stop/Direction. Start/Stop is connected to digital input DI5. Direction is connected to digital input DI4. DI4 deactivated = Forward and DI4 activated = Reverse. To control direction, value of parameter 1003 DIRECTION should be REQUEST.</p> <p>8 = KEYPAD The Start/Stop and Direction commands are given from the control panel when External control location 1 is active. To control direction, value of parameter 1003 DIRECTION should be REQUEST.</p> <p>9 = DI1F,2R Start forward command is given when DI1= activated and DI2= deactivated. Start reverse command is given if DI1 is deactivated and DI2 is activated. In other cases Stop command is given.</p> <p>10 = COMM The Start/Stop and Direction commands are given through serial communication.</p> <p>*Note! In cases 1, 3, 6 direction is set with parameter 1003 DIRECTION. Selecting value 3 (REQUEST) fixes direction to Forward.</p> <p>**Note! Stop signal must be activated before Start command can be given.</p>

1002	EXT2 COMMANDS Defines the connections and the source of Start, Stop and Direction commands for external control location 2 (EXT2). Refer to parameter 1001 EXT1 COMMANDS above.
1003	DIRECTION 1 = FORWARD 2 = REVERSE 3 = REQUEST Rotation direction lock. This parameter allows you to fix the direction of rotation of the motor to forward or reverse. If you select 3 (REQUEST), the direction is set according to the given direction command.

Group 11: Reference Select

Reference commands can be given from the control panel or from two external locations. The selection between the two external locations is made with parameter 1102 EXT1/EXT2 SEL. For more information on control locations, refer to "Appendix A", starting page 141.

Code	Description
1101	KEYPAD REF SEL Selection of active control panel reference in local control mode. 1 = REF1 (Hz) Control panel reference is given in Hz. 2 = REF2 (%) Control panel reference is given as a percentage (%).
1102	EXT1/EXT2 SEL Sets the input used for selecting the external control location, or fixes it to EXT1 or EXT2. The external control location of both Start/Stop/Direction commands and reference is determined by this parameter. 1...5 = DI1...DI5 External control location 1 or 2 is selected according to the state of the selected digital input (DI1 ... DI5), where deactivated = EXT1 and activated = EXT2. 6 = EXT1 External control location 1 (EXT1) is selected. The control signal sources for EXT1 are defined with parameter 1001 (Start/Stop/Direction commands) and parameter 1103 (reference). 7 = EXT2 External control location 2 (EXT2) is selected. The control signal sources for EXT2 are defined with parameter 1002 (Start/Stop/Direction commands) and parameter 1106 (reference). 8 = COMM External control location 1 or 2 is chosen through serial communication.

EXT REF1 SELECT

This parameter selects the signal source of external reference 1.

0 = KEYPAD

Reference is given from the control panel.

1 = AI 1

Reference is given through analogue input 1.

2 = AI 2

Reference is given through analogue input 2.

3 = AI1/JOYST; 4 = AI2/JOYST

Reference is given through analogue input 1 (or 2 accordingly) configured for a joystick. The minimum input signal runs the drive at maximum reference in the reverse direction. The maximum input signal runs the drive at maximum reference in the forward direction (See Figure 37). See also parameter 1003 DIRECTION.

Caution: Minimum reference for joystick should be 0.3 V (0.6 mA) or higher. If a 0 ... 10 V signal is used, the ACS 400 will operate at maximum reference in the reverse direction if the control signal is lost. Set parameter 1301 MINIMUM AI1 to a value 3 % (corresponding 0.3 V) or higher, and parameter 3001 AI<MIN FUNCTION to 1 (FAULT), and the ACS 400 will stop in case the control signal is lost.




Figure 37 Joystick control. Maximum for external reference 1 is set with Parameter 1105 and minimum with Parameter 1104.

5 = DI3U,4D(R)

Speed reference is given through digital inputs as motor potentiometer control. Digital input DI3 increases the speed (the U stands for "up"), and digital input DI4 decreases the speed (the D stands for "down"). (R) indicates that the reference will be reset to zero when a Stop command is given. The rate of change of the reference signal is controlled by parameter 2204 ACCELER TIME 2.

6 = DI3U,4D

Same as above, except that the speed reference is not reset to zero on a Stop command. When the ACS 400 is started, the motor will ramp up at the selected acceleration rate to the stored reference.

7 = DI4U,5D

Same as above, except that the digital inputs in use are DI4 and DI5.

8 = COMM

The reference is given through serial communication.

9 = COMM + AI1

10 = COMM * AI1

The reference is given through serial communication. The analogue input 1 signal is combined to the fieldbus reference (sum or multiplication). For more information, see chapter "Standard Serial Communication" on page 115.

1104	EXT REF1 MIN Sets the minimum frequency reference for external reference 1 in Hz. When analogue input signal is at minimum, external reference 1 equals to EXT REF1 MIN. See Figure 38 on page 71.
1105	EXT REF1 MAX Sets the maximum frequency reference for external reference 1 in Hz. When analogue input signal is at maximum, external reference 1 equals to EXT REF1 MAX. See Figure 38 on page 71.
1106	EXT REF2 SELECT This parameter selects the signal source for external reference 2. The alternatives are the same as with external reference 1.
1107	EXT REF2 MIN Sets the minimum reference in %. When analogue input signal is at minimum value external reference 2 equals to EXT REF2 MIN. See Figure 38. <ul style="list-style-type: none"> • If the PID Control or PFC macro is selected, this parameter sets the minimum process reference. • If any other macro than PID is selected, this parameter sets the minimum frequency reference. This value is given as a percentage of the maximum frequency.
1108	EXT REF2 MAX Sets the maximum reference in %. When analogue input signal is at maximum, external reference 2 equals to EXT REF2 MAX. See Figure 38. <ul style="list-style-type: none"> • If the PID Control or PFC macro is selected, this parameter sets the maximum process reference. • If any other macro than PID Control is selected, this parameter sets the maximum frequency reference. This value is given as percentage of maximum frequency.





Figure 38 Setting EXT REF MINIMUM and EXT REF MAXIMUM. The range of the analogue input signal is set by parameters 1301 and 1302 or parameters 1304 and 1305, depending on the analogue input used.

Group 12: Constant Speeds

The ACS 400 has 7 programmable constant speeds, ranging from 0 to 250 Hz. Negative speed values cannot be given for constant speeds.

Constant speed selections are ignored if the process PID reference is followed, the drive is in local control mode or PFC (Pump-Fan Control) is active.

Note! Parameter 1208 CONST SPEED 7 acts also as a so-called fault speed which may be activated if the control signal is lost. Refer to parameter 3001 AI<MIN FUNCTION and parameter 3002 PANEL LOSS.

Code	Description																																																			
1201	CONST SPEED SEL This parameter defines which digital inputs are used to select Constant Speeds. 0 = NOT SEL Constant speed function disabled. 1...5 = DI1...DI5 Constant Speed 1 is selected with digital inputs DI1-DI5. Digital input activated = Constant Speed 1 activated. 6 = DI1,2 Three Constant Speeds (1 ... 3) are selected with two digital inputs. Constant Speed selection with digital inputs DI1,2. <i>Table 13 Constant Speed selection with digital inputs DI1,2.</i> <table border="1"><thead><tr><th>DI 1</th><th>DI 2</th><th>Function</th></tr></thead><tbody><tr><td>0</td><td>0</td><td>No constant speed</td></tr><tr><td>1</td><td>0</td><td>Constant speed 1 (1202)</td></tr><tr><td>0</td><td>1</td><td>Constant speed 2 (1203)</td></tr><tr><td>1</td><td>1</td><td>Constant speed 3 (1204)</td></tr></tbody></table> 0 = DI deactivated, 1 = DI activated 7 = DI3,4 Three Constant Speeds (1 ... 3) are selected with two digital inputs as in DI1,2. 8 = DI4,5 Three Constant Speeds (1 ... 3) are selected with two digital inputs as in DI1,2. 9 = DI1,2,3 Seven Constant Speeds (1 ... 7) are selected with three digital inputs. <i>Table 14 Constant Speed selection with digital inputs DI1,2,3.</i> <table border="1"><thead><tr><th>DI 1</th><th>DI 2</th><th>DI 3</th><th>Function</th></tr></thead><tbody><tr><td>0</td><td>0</td><td>0</td><td>No constant speed</td></tr><tr><td>1</td><td>0</td><td>0</td><td>Constant speed 1 (1202)</td></tr><tr><td>0</td><td>1</td><td>0</td><td>Constant speed 2 (1203)</td></tr><tr><td>1</td><td>1</td><td>0</td><td>Constant speed 3 (1204)</td></tr><tr><td>0</td><td>0</td><td>1</td><td>Constant speed 4 (1205)</td></tr><tr><td>1</td><td>0</td><td>1</td><td>Constant speed 5 (1206)</td></tr><tr><td>0</td><td>1</td><td>1</td><td>Constant speed 6 (1207)</td></tr><tr><td>1</td><td>1</td><td>1</td><td>Constant speed 7 (1208)</td></tr></tbody></table> 0 = DI deactivated, 1 = DI activated 10 = DI3,4,5 Seven Constant Speeds (1 ... 7) are selected with three digital inputs as in DI1,2,3.	DI 1	DI 2	Function	0	0	No constant speed	1	0	Constant speed 1 (1202)	0	1	Constant speed 2 (1203)	1	1	Constant speed 3 (1204)	DI 1	DI 2	DI 3	Function	0	0	0	No constant speed	1	0	0	Constant speed 1 (1202)	0	1	0	Constant speed 2 (1203)	1	1	0	Constant speed 3 (1204)	0	0	1	Constant speed 4 (1205)	1	0	1	Constant speed 5 (1206)	0	1	1	Constant speed 6 (1207)	1	1	1	Constant speed 7 (1208)
	DI 1	DI 2	Function																																																	
	0	0	No constant speed																																																	
	1	0	Constant speed 1 (1202)																																																	
	0	1	Constant speed 2 (1203)																																																	
	1	1	Constant speed 3 (1204)																																																	
	DI 1	DI 2	DI 3	Function																																																
	0	0	0	No constant speed																																																
	1	0	0	Constant speed 1 (1202)																																																
	0	1	0	Constant speed 2 (1203)																																																
1	1	0	Constant speed 3 (1204)																																																	
0	0	1	Constant speed 4 (1205)																																																	
1	0	1	Constant speed 5 (1206)																																																	
0	1	1	Constant speed 6 (1207)																																																	
1	1	1	Constant speed 7 (1208)																																																	
1202	CONST SPEED 1... CONST SPEED 7																																																			
-1208	Constant speeds 1-7.																																																			

Group 13: Analogue Inputs

Code	Description
1301	MINIMUM AI1 Relative minimum value of AI1 (%). Value corresponds to minimum reference set by parameter 1104 EXT REF1 MIN or 1107 EXT REF2 MIN. Minimum AI cannot be greater than maximum AI. See Figure 38 on page 71.
1302	MAXIMUM AI1 Maximum value of AI1 (%). Value corresponds to maximum reference set by parameter 1105 EXT REF1 MAX or 1108 EXT REF2 MAX. See Figure 38 on page 71.
1303	FILTER AI1 Filter time constant for analogue input AI1. As the analogue input value changes, 63 % of the change takes place within the time specified by this parameter. Note! Even if you select 0 s for the filter time constant, the signal is still filtered with a time constant of 25 ms due to the signal interface hardware. This cannot be changed by any parameters. <p>Figure 39 Filter time constant for analogue input AI1.</p>
1304	MINIMUM AI2 Minimum value of AI2 (%). Value corresponds to minimum reference set by parameter 1104 EXT REF1 MIN or 1107 EXT REF2 MIN. Minimum AI cannot be greater than maximum AI.
1305	MAXIMUM AI2 Maximum value of AI2 (%). Value corresponds to maximum reference set by parameter 1105 EXT REF1 MAX or 1108 EXT REF2 MAX.
1306	FILTER AI2 Filter time constant for AI2. Refer to parameter 1303 FILTER AI1.

Example. To set the minimum allowed analogue input value to 4 mA, value for parameter 1301 MINIMUM AI1 (1304 MINIMUM AI2) is calculated as follows:

$$\begin{aligned}
 \text{Value (\%)} &= \text{Desired minimum value} / \text{Full range of the analogue input} * 100\% \\
 &= 4 \text{ mA} / 20 \text{ mA} * 100\% \\
 &= 20\%.
 \end{aligned}$$

Note! In addition to this parameter setting, the analog input must be configured for 0-20 mA current signal. Refer to section “Connection Examples” on page 22.

Group 14: Relay Outputs

Code	Description
1401	<p>RELAY OUTPUT 1</p> <p>Relay output 1 content. Selects which information is indicated with relay output 1.</p> <p>0 = NOT SEL Relay is not used and is de-energised.</p> <p>1 = READY The ACS 400 is ready to function. The relay is energised unless no run enable signal is present or a fault exists and supply voltage is within range.</p> <p>2 = RUN Relay energised when the ACS 400 is running.</p> <p>3 = FAULT (-1) Relay energised when power is applied, and de-energised upon a fault trip.</p> <p>4 = FAULT Relay energised when a fault is active.</p> <p>5 = ALARM Relay energised when an alarm is active. To see which alarms cause the relay to energise, refer to section "Diagnostics" on page 135.</p> <p>6 = REVERSED Relay energised when motor rotates in reverse direction.</p> <p>7 = SUPRV1 OVER Relay energised when first supervised parameter (3201) exceeds the limit (3203). See "Group 32: Supervision", starting page 90.</p> <p>8 = SUPRV1 UNDER Relay energised when first supervised parameter (3201) drops below the limit (3202). See "Group 32: Supervision", starting page 90.</p> <p>9 = SUPRV2 OVER Relay energised when second supervised parameter (3204) exceeds the limit (3206). See "Group 32: Supervision", starting page 90.</p> <p>10 = SUPRV2 UNDER Relay energised when second supervised parameter (3204) drops below the limit (3205). See "Group 32: Supervision", starting page 90.</p> <p>11 = AT SET POINT Relay energised when output frequency is equal to reference frequency.</p> <p>12 = FAULT (RST) Relay energised when the ACS 400 is in a fault condition and will reset after the programmed autoreset delay (refer to parameter 3103 DELAY TIME).</p> <p>13 = FLT/ALARM Relay is energised when fault or alarm occurs. To see which alarms and faults cause the relay to energise, refer to section "Diagnostics" on page 135.</p> <p>14 = EXT CONTROL Relay is energised if external control is selected.</p> <p>15 = REF 2 SEL Relay is energised if EXT2 is selected.</p> <p>16 = CONST FREQ Relay is energised when a constant speed is selected.</p> <p>17 = REF LOSS Relay is energised when reference or active control place is lost.</p> <p>18 = OVERCURRENT Relay is energised when overcurrent alarm or fault appears.</p> <p>19 = OVERVOLTAGE Relay is energised when overvoltage alarm or fault appears.</p> <p>20 = ACS400 TEMP Relay is energised when ACS 400 overtemperature alarm or fault exists.</p>

Code	Description
	<p>21 = ACS OVERLOAD Relay is energised when ACS 400 overload alarm or fault exists.</p> <p>22 = UNDERVOLTAGE Relay is energised when undervoltage alarm or fault exists.</p> <p>23 = AI1 LOSS Relay is energised when AI1 signal is lost.</p> <p>24 = AI2 LOSS Relays energised when AI2 signal is lost.</p> <p>25 = MOT OVR TEMP Relay is energised when motor overtemperature alarm or fault exists.</p> <p>26 = STALL Relay is energised when stall alarm or fault exists.</p> <p>27 = UNDERLOAD Relay is energised when underload alarm or fault exists.</p> <p>28 = PID SLEEP Relay is energised when PID sleep function is active.</p> <p>29 = PFC Relay output is reserved for PFC control (Pump-Fan Control). This option should be selected only when PFC control macro is used.</p> <p>30 = AUTOCHANGE Relay is energised when PFC autochange operation is performed. This option should be selected only when PFC control macro is used.</p> <p>31 = STARTED Relay is energised when drive receives start command (even if Run Enable signal is not present). Relay is de-energised when stop command is received or fault occurs.</p>
1402	RELAY OUTPUT 2 Relay output 2 content. Refer to parameter 1401 RELAY OUTPUT 1.
1403	RO 1 ON DELAY Switch-on delay for relay 1.
1404	RO 1 OFF DELAY Switch-off delay for relay 1
1405	RO 2 ON DELAY Switch-on delay for relay 2.
1406	RO 2 OFF DELAY Switch-off delay for relay 2.

Selected controlling signal

Relay status

1403 ON DELAY 1404 OFF DELAY

Figure 40

Group 15: Analogue Output

Analogue output is used to output the value of any parameter of the Operating Data group (Group 1) as a current signal. Output current minimum and maximum values are configurable, as are the allowed minimum and maximum values for the observed parameter.

If analogue output content maximum value (parameter 1503) is set to less than minimum value (parameter 1502), output current is inversely proportional to the value of the observed parameter.

Code	Description
1501	AO CONTENT Content for analogue output. Number of any parameter of the Operating Data group (Group 01).
1502	AO CONTENT MIN Analogue output content minimum. Display depends on parameter 1501.
1503	AO CONTENT MAX Analogue output content maximum. Display depends on parameter 1501.
1504	MINIMUM AO Minimum output current.
1505	MAXIMUM AO Maximum output current.
1506	AO FILTER Filter time constant for AO.




Figure 41 Analogue output scaling.

Group 16: System Controls

Code	Description
1601	<p>RUN ENABLE Selects the source of the run enable signal.</p> <p>0 = NOT SEL The ACS 400 is ready to start without an external run enable signal.</p> <p>1...5 = DI1 ... DI5 To activate the run enable signal, the selected digital input must be activated. If the voltage drops and deactivates the selected digital input, the ACS 400 will coast to stop and not start until the run enable signal resumes.</p> <p>6 = COMM The run enable signal is given through serial communication (Command Word bit #3).</p>
1602	<p>PARAMETER LOCK Parameter lock for control panel.</p> <p>0 = LOCKED Parameter modification disabled.</p> <p>1 = OPEN Panel operations are allowed and parameter modification is enabled.</p> <p>2 = NOT SAVED Parameter values can be changed, but they are not stored in permanent memory.</p> <p>Note! This parameter is not affected by macro selection.</p> <p>Note! Parameter writes through Standard Modbus or DDCS channels are not affected by this parameter.</p>
1604	<p>FAULT RESET SEL Fault reset source.</p> <p>Note! Fault reset is always possible with control panel.</p> <p>Note! Option 6 (START/STOP) should not be selected when start, stop and direction commands are given through serial communication.</p> <p>0 = KEYPAD Fault reset is executed from the control panel keypad.</p> <p>1...5 = DI1 ... DI5 Fault reset is executed from a digital input. Reset is activated by deactivating the input.</p> <p>6 = START/STOP Fault reset is activated by Stop command.</p> <p>7 = COMM Fault reset is executed through serial communication.</p>
1605	<p>LOCAL LOCK Local lock. When LOCAL LOCK is active (1=LOCKED), panel cannot change to local mode.</p> <p>0 = OPEN Control location can be changed from control panel.</p> <p>1 = LOCKED Panel cannot change to local mode.</p> <p>Note! Option 1 LOCKED can be selected only in remote mode.</p>

Code	Description
1607	<p>PARAM. SAVE</p> <p>Parameter save function. Selection 1 (SAVE...) saves all altered parameters to permanent memory. Value 0 (DONE) is displayed when all parameter are saved.</p> <p>When parameters are altered through Standard Modbus or DDCS channels, altered values are not automatically saved to permanent memory. Instead, this parameter must be used.</p> <p>0 = DONE 1 = SAVE...</p> <p>Note! Parameter modifications done from the control panel are normally stored immediately to permanent memory. However, if 1602 PARAMETER LOCK is set to 2 (NOT SAVED), modifications done from the control panel are saved only if this parameter 1607 is used.</p>

Group 20: Limits

Code	Description
2003	MAX CURRENT Maximum output current. The maximum output current that the ACS 400 will supply to the motor.
2005	OVERVOLT CTRL DC overvoltage controller enable. Fast braking of a high inertia load causes the DC bus voltage to rise to the overvoltage control limit. To prevent the DC voltage from exceeding the limit, the overvoltage controller automatically decreases the braking torque by increasing output frequency. Caution! If a braking chopper and a braking resistor are connected to the ACS 400, this parameter value must be set to 0 to ensure proper operation of the chopper. 0 = DISABLE 1 = ENABLE
2006	UNDERVOLT CTRL DC undervoltage controller enable. If the DC bus voltage drops due to loss of input power, the undervoltage controller will decrease the motor speed in order to keep the DC bus voltage above the lower limit. By decreasing the output frequency, the inertia of the load will cause regeneration back into the ACS 400, thus keeping the DC bus charged, and preventing an undervoltage trip. This will increase power loss ride-through on systems with a high inertia, such as a centrifuge or fan. 0 = DISABLE 1 = ENABLE (TIME) Enable with 500 ms time limit for operation. 2 = ENABLE Enable without time limit for operation.
2007	MINIMUM FREQ Operating range minimum output frequency. Note! Keep MINIMUM FREQ \leq MAXIMUM FREQ.
2008	MAXIMUM FREQ Operating range maximum output frequency.

Group 21: Start/Stop

ACS 400 supports several start and stop modes, including flying start and torque boosting at start. DC current can be injected either before the start command (premagnetising) or automatically right after the start command (starting with DC hold).

DC hold can be used when stopping the drive with ramp. If drive is stopping by coasting, DC brake can be used.

Note! Too long a DC injection time or premagn max time causes the motor to heat up.

Code	Description
2101	START FUNCTION Conditions during motor acceleration. 1 = RAMP Ramp acceleration as set. 2 = FLYING Flying start. Use this setting if the motor is already rotating and the drive will start smoothly at the current frequency. The drive will automatically search the correct output frequency. 3 = TORQUE BOOST Automatic torque boost might be necessary in drives with high starting torque. Torque boost is only applied at start. Boosting is stopped when output frequency exceeds 20 Hz or when output frequency is equal to reference. See also parameter 2103 TORQ BOOST CURR. 4 = FLY + BOOST Activates both the flying start and torque boost. Note! If torque boost is used the switching frequency is always 4 kHz. In this case parameter 2605 LOW NOISE is ignored.
2102	STOP FUNCTION Conditions during motor deceleration. 1 = COAST Motor coasts to stop. 2 = RAMP Ramp deceleration as defined by the active deceleration time 2203 DECELER TIME 1 or 2205 DECELER TIME 2.
2103	TORQ BOOST CURR Maximum supplied current during torque boost. See also parameter 2101 START FUNCTION.
2104	STOP DC INJ TIME DC injection time after modulation has stopped. If 2102 STOP FUNCTION is 1 (COAST), ACS 400 uses DC braking. If 2102 STOP FUNCTION is 2 (RAMP), ACS 400 uses DC hold after ramp.
2105	PREMAGN SEL Options 1- 5 select source for premagnetising command. Option 6 selects start with DC hold. 0 = NOT SEL Premagnetising not used. 1...5 = DI1...DI5 Premagnetising command is received through a digital input. 6 = CONST Constant premagnetising time after start command. Time is defined by parameter 2106 PREMAGN MAX TIME.
2106	PREMAGN MAX TIME Maximum premagnetising time.

Code	Description
2107	<p>START INHIBIT</p> <p>Start inhibit control. Start inhibit means that a pending start command is ignored when:</p> <ul style="list-style-type: none"> • fault is reset, or • Run Enable activates while start command is active, or • mode change from local to remote takes place, or • mode change from remote to local takes place, or • from EXT1 to EXT2 takes place, or • from EXT2 to EXT1 takes place <p>0 = OFF Start inhibit control disabled. Drive will start after fault is reset, Run Enable is activated or mode is changed while there is a pending start command.</p> <p>1 = ON Start inhibit control enabled. Drive will not start after fault is reset, Run Enable is activated or mode is changed. In order to start the drive again, give start command anew.</p>

Group 22: Accel/Decel

Two acceleration/deceleration ramp pairs can be used. If both ramp pairs are used, selection can be made between these in run time through a digital input. The S curve of the ramps is adjustable.

Code	Description
2201	ACC/DEC 1/2 SEL Selects the source for the ramp pair selection signal. 0 = NOT SEL The first ramp pair is used (ACCELER TIME 1/DECELER TIME 1). 1...5 = DI1...DI5 Ramp pair selection is done through a digital input (DI1 to DI5). Digital input deactivated = Ramp pair 1 (ACCELER TIME 1/DECELER TIME 1) is used. Digital input activated = Ramp pair 2 (ACCELER TIME 2/DECELER TIME 2) is used.
2202	ACCELER TIME 1 Ramp 1: time from zero to maximum frequency (0 - MAXIMUM FREQ).
2203	DECELER TIME 1 Ramp 1: time from maximum frequency to zero (MAXIMUM FREQ - 0).
2204	ACCELER TIME 2 Ramp 2: time from zero to maximum frequency (0 - MAXIMUM FREQ).
2205	DECELER TIME 2 Ramp 2: time from maximum frequency to zero (MAXIMUM FREQ - 0).
2206	RAMP SHAPE Acceleration/deceleration ramp shape selection 0 = LINEAR 1 = FAST S CURVE 2 = MEDIUM S CRV 3 = SLOW S CURVE




Figure 42 Definition of acceleration/deceleration ramp time.

Group 25: Critical Freq

In some mechanical systems, certain speed ranges can cause resonance problems. With this parameter group, it is possible to set up to two different speed ranges that the ACS 400 will skip over.

Code	Description
2501	CRIT FREQ SEL Critical frequencies activation. 0 = OFF 1 = ON
2502	CRIT FREQ 1 LO Critical frequency 1 start. Note! If LOW > HI, no critical frequency lock-out will happen.
2503	CRIT FREQ 1 HI Critical frequency 1 end.
2504	CRIT FREQ 2 LO Critical frequency 2 start.
2505	CRIT FREQ 2 HI Critical frequency 2 end. Note! If LOW > HI, no critical frequency lock-out will happen.

Example: A fan system vibrates badly from 18 Hz to 23 Hz and from 46 Hz to 52 Hz. Set the parameters as follows:

CRIT FREQ 1 LO = 18 Hz and CRIT FREQ 1 HI = 23 Hz

CRIT FREQ 2 LO = 46 Hz and CRIT FREQ 2 HI = 52 Hz




Figure 43 Example of critical frequencies setting in a fan system with bad vibrations at frequency ranges 18 Hz to 23 Hz and 46 Hz to 52 Hz.

Group 26: Motor Control

Code	Description												
2603	<div><div><div>IR COMPENSATION IR compensation voltage at 0 Hz. Note! IR compensation should be kept as low as possible to prevent overheating. Refer to Table 15.</div><div>400 V Units<table><tr><td>P_N / kW</td><td>3</td><td>7.5</td><td>15</td><td>22</td><td>37</td></tr><tr><td>IR comp / V</td><td>21</td><td>18</td><td>15</td><td>12</td><td>10</td></tr></table></div></div><div>Table 15 Typical IR compensation values.</div></div>	P _N / kW	3	7.5	15	22	37	IR comp / V	21	18	15	12	10
P _N / kW	3	7.5	15	22	37								
IR comp / V	21	18	15	12	10								
2604	IR COMP RANGE IR compensation range. Defines frequency after which IR compensation is 0 V.												
2605	LOW NOISE Motor acoustical noise option. 0 = OFF Standard (switching frequency 4 kHz). 1 = ON(1) Low noise (switching frequency 8 kHz). Note! When the low noise setting is used, the maximum loadability of the ACS 400 is I ₂ at 30 °C ambient temperature or 0.8 * I ₂ at 40 °C.												
2606	U/f RATIO U/f ratio below field weakening point. 1 = LINEAR 2 = SQUARE Linear is preferred for constant torque applications, Square for centrifugal pump and fan applications. (Square is more silent for most operating frequencies.)												
2607	SLIP COMP RATIO A squirrel-cage motor will slip under load. The slip can be compensated by increasing the frequency as the motor torque increases. This parameter defines the gain for the slip. 100 % means full slip compensation; 0 % means no slip compensation.												




Figure 44 Operation of IR compensation

Group 30: Fault Functions



ACS 400 can be configured to respond as desired to certain abnormal external conditions: analogue input fault, external fault signal and panel loss.


In these cases, the drive can either continue operation at current speed or at a set constant speed while showing an alarm, ignore the condition, or trip on a fault and stop.

Motor thermal protection parameters 3004 - 3008 provide a means of adjusting the motor load curve. For example, limiting the load near zero speed might be necessary if the motor does not have a cooling fan.

Stall protection (parameters 3009 - 3012) includes parameters for stall frequency, stall time and current.

Code	Description
3001	AI<MIN FUNCTION Operation in case of AI signal drops below minimum limit. 0 = NOT SEL No operation. 1 = FAULT A fault indication is displayed and the ACS 400 coasts to stop. 2 = CONST SP 7 A warning indication is displayed and the speed is set according to parameter 1208 CONST SPEED7. 3 = LAST SPEED A warning indication is displayed and the speed is set to the level the ACS 400 was last operating at. This value is determined by the average speed over the last 10 seconds. Caution: If you select CONST SPEED 7 or LAST SPEED, make sure that it is safe to continue operation in case analogue input signal is lost.
3002	PANEL LOSS Operation in case of control panel loss fault. 1 = FAULT A fault indication is displayed and the ACS 400 coasts to stop. 2 = CONST SP 7 A warning indication is displayed and the speed is set according to parameter 1208 CONST SPEED7. 3 = LAST SPEED A warning indication is displayed and the speed is set to the level the ACS 400 was last operating at. This value is determined by the average speed over the last 10 seconds. Caution: If you select CONST SPEED 7 or LAST SPEED, make sure that it is safe to continue operation in case panel is lost.
3003	EXTERNAL FAULT External fault input selection. 0 = NOT SEL External fault signal is not used. 1...5 = DI1...DI5 This selection defines the digital input used for an external fault signal. If an external fault occurs, i.e. digital input is deactivated, the ACS 400 is stopped and the motor coasts to stop and fault indication is displayed.

Code	Description
3004	<p>MOT THERM PROT</p> <p>Motor overtemperature function. This parameter defines the operation of the motor thermal protection function which protects the motor from overheating.</p> <p>0 = NOT SEL</p> <p>1 = FAULT Displays a warning indication at the warning level (95 % of the nominal value). Displays a fault indication when the motor temperature reaches the 100 % level. The ACS 400 coasts to stop.</p> <p>2 = WARNING A warning indication is displayed when the motor temperature reaches the warning level (95 % of the nominal value).</p>
3005	<p>MOT THERM TIME</p> <p>Time for 63 % temperature rise. This is the time within which the motor temperature reaches 63 % of the final temperature rise. Figure 45 shows motor thermal time definition.</p> <p>If thermal protection according to UL requirements for NEMA class motors is desired, use this rule of thumb - MOTOR THERM TIME equals 35 times t6 (t6 in seconds is the time that the motor can safely operate at six times its rated current, given by the motor manufacturer). The thermal time for a Class 10 trip curve is 350 s, for a Class 20 trip curve 700 s and for a Class 30 trip curve 1050 s.</p>  <p><i>Figure 45 Motor thermal time.</i></p>
3006	<p>MOT LOAD CURVE</p> <p>Motor current maximum limit. MOTOR LOAD CURVE sets the maximum allowable operating load of the motor. When set to 100 %, the maximum allowable load is equal to the value of Start-up Data parameter 9906 MOTOR NOM CURRENT. The load curve level should be adjusted if the ambient temperature differs from the nominal value.</p>  <p><i>Figure 46 Motor load curve.</i></p>

Code	Description
3007	ZERO SPEED LOAD This parameter defines the maximum allowable current at zero speed relative to 9906 MOTOR NOM CURR. Refer to Figure 46.
3008	BREAK POINT Break point of motor load curve. Refer to Figure 46 for an example of a motor load curve. See Figure 48.
3009	STALL FUNCTION This parameter defines the operation of the stall protection. The protection is activated if the output current becomes too high compared to output frequency, refer to Figure 47. 0 = NOT SEL Stall protection is not used. 1 = FAULT When the protection is activated the ACS 400 coasts to stop. Fault indication is displayed. 2 = WARNING A warning indication is displayed. The indication disappears in half the time set by parameter 3012 STALL TIME.
	 <p style="text-align: center;">Figure 47 Motor stall protection.</p>
3010	STALL CURRENT Current limit for stall protection. Refer to Figure 47.
3011	STALL FREQ HI This parameter sets the frequency value for the stall function. Refer to Figure 47.
3012	STALL TIME This parameter sets the time value for the stall function.
3013	UNDERLOAD FUNCTION Removal of motor load may indicate a process malfunction. The protection is activated if: <ul style="list-style-type: none"> • The motor torque drops below the load curve selected by parameter 3015 UNDERLOAD CURVE. • This condition has lasted longer than the time set by parameter 3014 UNDERLOAD TIME. • Output frequency is higher than 10 % of the nominal frequency of the motor and higher than 5 Hz. 0 = NOT SEL Underload protection is not used. 1 = FAULT When the protection is activated the ACS 400 coasts to stop. Fault indication is displayed. 2 = WARNING A warning indication is displayed.
3014	UNDERLOAD TIME Time limit for underload protection.

Code	Description
3015	UNDERLOAD CURVE This parameter provides five selectable curves shown in Figure 49. If the load drops below the set curve for longer than the time set by parameter 3014, the underload protection is activated. Curves 1...3 reach maximum at the motor rated frequency set by parameter 9907 MOTOR NOM FREQ.




Figure 48 Thermal protection trip times when parameters 3005 MOT THERM TIME, 3006 MOT LOAD CURVE and 3007 ZERO SPEED LOAD have default values.




Figure 49 Underload curve types. T_M nominal torque of the motor, f_N nominal frequency of the motor.

Group 31: Automatic Reset

The automatic reset system can be used for resetting overcurrent, overvoltage, undervoltage and analogue input loss faults automatically. Number of allowed automatic reset operations within a certain time is selectable.

Warning! If parameter 3107 AR AI<MIN is enabled, the drive may restart even after a long stop when the analogue input signal is restored. Ensure that the use of this feature will not cause physical injury and/or damage equipment.

Code	Description
3101	NR OF TRIALS Sets the number of allowed autoresets within a certain time. The time is defined with parameter 3102 TRIAL TIME. The ACS 400 prevents additional autoresets and remains stopped until a successful reset is performed from the control panel or from a place selected by parameter 1604 FAULT RESET SEL.
3102	TRIAL TIME The time within which a limited number of fault autoresets is allowed. The allowed number of faults per this time period is given with parameter 3101 NR OF TRIALS.
3103	DELAY TIME This parameter sets the time that the ACS 400 will wait after a fault occurs before attempting to reset. If set to zero, the ACS 400 will reset immediately.
3104	AR OVERCURRENT 0 = DISABLE 1 = ENABLE If 1 is selected, the fault (motor overcurrent) is reset automatically after the delay set by parameter 3103, and the ACS 400 resumes normal operation.
3105	AR OVERVOLTAGE 0 = DISABLE 1 = ENABLE If 1 is selected, the fault (DC bus overvoltage) is reset automatically after the delay set by parameter 3103, and the ACS 400 resumes normal operation.
3106	AR UNDERVOLTAGE 0 = DISABLE 1 = ENABLE If 1 is selected, the fault (DC bus undervoltage) is reset automatically after the delay set by parameter 3103 DELAY TIME, and the ACS 400 resumes normal operation.
3107	AR AI<MIN 0 = DISABLE 1 = ENABLE If 1 is selected, the fault (analogue input signal under minimum level) is reset automatically after the delay set by parameter 3103 DELAY TIME.





Figure 50 Operation of automatic reset function. In this example, if the fault occurs at the moment "Now", it is automatically reset if parameter 3101 NR OF TRIALS value is greater than or equal to 4.

Group 32: Supervision

Parameters of this group are used together with relay output parameters 1401 RELAY OUTPUT 1 and 1402 RELAY OUTPUT 2. Any two parameters of the Operating Data group (Group 1) can be supervised. Relays can be configured to be energised when the values of supervised parameters are either too low or too high.

Code	Description
3201	SUPERV 1 PARAM First supervised parameter number of the Operating Data group (Group 01).
3202	SUPERV 1 LIM LO First supervision limit low. Display of this parameter depends on selected supervised parameter (3201).
3203	SUPERV 1 LIM HI First supervision limit high. Display of this parameter depends on selected supervised parameter (3201).
3204	SUPERV 2 PARAM Second supervised parameter number of the Operating Data group (Group 01).
3205	SUPERV 2 LIM LO Second supervision limit low. Display of this parameter depends on selected supervised parameter (3204).
3206	SUPERV 2 LIM HI Second supervision limit high. Display of this parameter depends on selected supervised parameter (3204).



A = Parameter 1401 RELAY OUTPUT 1 (1402 RELAY OUTPUT 2)
value is SUPRV1 OVER or SUPRV2 OVER

B = Parameter 1401 RELAY OUTPUT 1 (1402 RELAY OUTPUT 2)
value is SUPRV1 UNDER or SUPRV2 UNDER

Figure 51 Operating data supervision using relay outputs.


Group 33: Information

Code	Description
3301	SW VERSION Software version.
3302	TEST DATE Displays the test date of the ACS 400 (yy.ww).

Group 34: Process Variables

Parameters of this group can be used to create custom process variables. Values of process variables can be seen in parameters 0134 PROCESS VAR 1 and 0135 PROCESS VAR 2 AND optionally in the ACS-PAN output display. Value is calculated by taking given parameter from the operating data group (Group 1), and multiplying and dividing it with given coefficients. The unit and number of decimal digits is configurable.

See example below.

Code	Description																																	
3401	<div><div>DISPLAY SEL Selects displayed variables for the output display of the ACS-PAN control panel. 1 = STANDARD Panel displays standard variables. 2 = PROCESS VAR Panel displays process variables. See Figure 52.</div><div></div></div>	<div><p>Figure 52 ACS-PAN output display when process variable display is selected.</p></div>																																
3402	<div><div>P VAR 1 SEL Selection of process variable 1. Number of any parameter of the group 1 OPERATING DATA.</div></div>																																	
3403	<div><div>P VAR 1 MULTIP Process variable 1 multiplier.</div></div>																																	
3404	<div><div>P VAR 1 DIVISOR Process variable 1 divider.</div></div>																																	
3405	<div><div>P VAR 1 SCALING Decimal point location of process variable 1, when displayed. Refer to Figure 53.</div><div><table><tr><th>Value</th><th>Display</th></tr><tr><td>0</td><td>125</td></tr><tr><td>1</td><td>12.5</td></tr><tr><td>2</td><td>1.25</td></tr><tr><td>3</td><td>0.125</td></tr></table></div></div>	Value	Display	0	125	1	12.5	2	1.25	3	0.125	<div><p>Figure 53 Display with different decimal point locations when calculated value is 125.</p></div>																						
Value	Display																																	
0	125																																	
1	12.5																																	
2	1.25																																	
3	0.125																																	
3406	<div><div>P VAR 1 UNIT Process variable unit.</div><div><table><tr><td>0 = NOT SEL</td><td>4 = %</td><td>8 = kh</td><td>12 = mV</td><td>16 = °F</td><td>20 = m³/h</td><td>24 = GPM</td><td>28 = MGD</td></tr><tr><td>1 = A</td><td>5 = s</td><td>9 = °C</td><td>13 = kW</td><td>17 = hp</td><td>21 = dm³/s</td><td>25 = PSI</td><td>29 = inHg</td></tr><tr><td>2 = V</td><td>6 = h</td><td>10 = lb ft</td><td>14 = W</td><td>18 = MWh</td><td>22 = bar</td><td>26 = CFM</td><td>30 = FPM</td></tr><tr><td>3 = Hz</td><td>7 = rpm</td><td>11 = mA</td><td>15 = kWh</td><td>19 = m/s</td><td>23 = kPa</td><td>27 = ft</td><td>31 = Cst</td></tr></table></div></div>	0 = NOT SEL	4 = %	8 = kh	12 = mV	16 = °F	20 = m ³ /h	24 = GPM	28 = MGD	1 = A	5 = s	9 = °C	13 = kW	17 = hp	21 = dm ³ /s	25 = PSI	29 = inHg	2 = V	6 = h	10 = lb ft	14 = W	18 = MWh	22 = bar	26 = CFM	30 = FPM	3 = Hz	7 = rpm	11 = mA	15 = kWh	19 = m/s	23 = kPa	27 = ft	31 = Cst	
0 = NOT SEL	4 = %	8 = kh	12 = mV	16 = °F	20 = m ³ /h	24 = GPM	28 = MGD																											
1 = A	5 = s	9 = °C	13 = kW	17 = hp	21 = dm ³ /s	25 = PSI	29 = inHg																											
2 = V	6 = h	10 = lb ft	14 = W	18 = MWh	22 = bar	26 = CFM	30 = FPM																											
3 = Hz	7 = rpm	11 = mA	15 = kWh	19 = m/s	23 = kPa	27 = ft	31 = Cst																											

Code	Description
3407	P VAR 2 SEL Selection of process variable 2. Number of any parameter of the group 1 OPERATING DATA.
3408	P VAR 2 MULTIP Process variable 2 multiplier.
3409	P VAR 2 DIVISOR Process variable 2 divider.
3410	P VAR 2 SCALING Decimal point location of process variable 2, when displayed.
3411	P VAR 2 UNIT Process variable 2 unit. See parameter 3406.

Example. Assume that a two pole motor is directly connected to a roll 0.1 m in diameter and the line speed is to be displayed in m/s. The following settings are then needed:

3401 DISPLAY SEL = 2 (PROCESS VAR)

3402 P VAR 1 SEL = 0103 (OUTPUT FREQ)

3406 P VAR 1 UNIT = 19 (m/s)

Since 1 Hz output equals 1 rev/s, equals $\pi \times 0.1$ m/s line speed, or approximately 0.314 m/s, is:

$$\text{line speed} = \frac{\text{output freq} \times 314}{1000} \text{ m/s}$$

Select:

3403 P VAR 1 MULTIP = 314

3404 P VAR 1 DIVISOR = 1000

Since variable 0103 OUTPUT FREQ is displayed with 0.1 Hz resolution, it is internally scaled so that value 10 represents 1 Hz. Therefore 3405 P VAR 1 SCALING = 1 must be selected.


Group 40: PID Control


The PID Control Macro allows the ACS 400 to take a reference signal (setpoint) and an actual signal (feedback), and automatically adjust the speed of the drive to match the actual signal to the reference.

There exist two PID parameter sets (group 40 for set 1 parameters and group 41 for set 2 parameters). Normally only set 1 parameters are used. Set 2 parameters can be taken in use by parameter 4016 PID PARAM SET. Selection between parameter sets can be done eg. through a digital input.

PID sleep function can be used to stop the regulation when the output of the PID controller falls below preset limit. Regulation is resumed when the process actual value falls below preset limit. Alternatively, sleep function can be activated and deactivated through a digital input.

Figure 68 on page 144 (Appendix A) shows the connections of internal signals when the PID Control macro is selected.

Code	Description
4001	<p>PID GAIN</p> <p>This parameter defines the gain of the PID Controller. The setting range is 0.1... 100. If you select 1, a 10 % change in error value causes the PID Controller output to change by 10 %.</p>
4002	<p>PID INTEG TIME</p> <p>PID controller integration time. Defined as the time in which the maximum output is achieved if a constant error value exists and the gain is 1. Integration time 1 s denotes that a 100 % change is achieved in 1 s.</p> 

Code	Description
4003	<p>PID DERIV TIME PID controller derivation time. If the process error value changes linearly, D part adds a constant value into the PID controller output. The derivative is filtered with a 1-pole filter. The time constant of the filter is defined by parameter 4004 PID DERIV FILTER.</p>  <p>The graph illustrates the PID derivation time. The vertical axis represents the Process Error Value, with a dashed line at 100%. The horizontal axis represents time (t). A solid line starts at the origin (0,0) and increases linearly until it reaches the 100% level. Once it reaches 100%, the line becomes horizontal. A bracket on the horizontal axis indicates the duration of the linear increase, labeled 'PID derivation time'. A horizontal line segment at a level below 100% is labeled 'Gain', representing the constant derivative output during the linear error increase.</p>
4004	<p>PID DERIV FILTER Time constant for the filter of D part. By increasing the filter time constant it is possible to smooth the effect of the D part and suppress noise.</p>
4005	<p>ERROR VALUE INV Process error value inversion. Normally, a decrease in feedback signal causes an increase in drive speed. If a decrease in feedback signal is desired to cause a decrease in speed, set ERROR VALUE INV to 1 (YES).</p> <p>0 = NO 1 = YES</p>
4006	<p>ACTUAL VAL SEL PID controller feedback (actual) signal selection. Feedback signal can be a combination of two actual values ACT1 and ACT2. Source for actual value 1 is selected by parameter 4007 and source for actual value 2 is selected by parameter 4008.</p> <p>1 = ACT1 Actual value 1 is used as the feedback signal.</p> <p>2 = ACT1-ACT2 Difference of actual values 1 and 2 is used as the feedback signal.</p> <p>3 = ACT1+ACT2 Sum of actual values 1 and 2.</p> <p>4 = ACT1*ACT2 Product of actual values 1 and 2.</p> <p>5 = ACT1/ACT2 Quotient of actual values 1 and 2.</p> <p>6 = MIN (A1, A2) Smaller of actual values 1 and 2.</p> <p>7 = MAX (A1, A2) Greater of actual values 1 and 2.</p> <p>8 = sqrt (A1-A2) Square root of difference of actual values 1 and 2.</p> <p>9 = sqA1 + sqA2 Sum of square roots of actual values 1 and 2.</p>

Code	Description
4007	ACT1 INPUT SEL Source for actual value 1 (ACT1). 1 = AI 1 Analogue input 1 is used as actual value 1. 2 = AI 2 Analogue input 2 is used as actual value 1.
4008	ACT2 INPUT SEL Source for actual value 2 (ACT2). 1 = AI 1 Analogue input 1 is used as actual value 2. 2 = AI 2 Analogue input 2 is used as actual value 2.
4009	ACT1 MINIMUM Minimum value for actual value 1 (ACT1). Refer to Figure 54 and to Group 13 parameters for analogue input minimum and maximum settings.
4010	ACT1 MAXIMUM Maximum value for actual value 1 (ACT1). Refer to Figure 54 and to Group 13 parameters for analogue input minimum and maximum settings.
4011	ACT2 MINIMUM Minimum value for actual value 2 (ACT2). Refer to parameter 4009.
4012	ACT2 MAXIMUM Maximum value for actual value 2 (ACT2). Refer to parameter 4010.




Figure 54 Actual value scaling. The range of the analogue input signal is set by parameters 1301 and 1302 or parameters 1304 and 1305, depending on the analogue input used.

Code	Description
4013	PID SLEEP DELAY Time delay for the sleep function, see Figure 55. If the ACS 400 output frequency is below a set level (parameter 4014 SLEEP LEVEL) longer than PID SLEEP DELAY, ACS 400 is stopped. Alarm 28 is displayed when PID sleep is active.
4014	PID SLEEP LEVEL Level for activation of sleep function, see Figure 55. When the ACS 400 output frequency falls below the sleep level, the sleep delay counter is started. When the ACS 400 output frequency rises above the sleep level, the sleep delay counter is reset.
4015	WAKE-UP LEVEL Level for deactivation of sleep function. This parameter sets a process actual value limit for the sleep function (see Figure 55). The limit floats with the process reference. The limit is calculated as follows: $\text{limit} = \text{process reference} * 4015 \text{ WAKE-UP LEVEL} / 100$ When sleep function is active, normal operation is resumed when the process actual value goes below this limit, and stays below the limit for at least time period set by parameter 4017 WAKE-UP DELAY. Note! Wake-up level comparison is also inverted when error value is inverted using parameter 4005 ERROR VALUE INV.
4016	PID PARAM SET PID parameter set selection. When set 1 is selected, parameters 4001-4012 and 4019-4020 are used. When set 2 is selected, parameters 4101-4112 and 4119-4120 are used. 1...5 = DI1...DI5 PID parameter set is selected through a digital input (DI1...DI5). Parameter set 1 is used when the digital input is not active. Parameter set 2 is used when the digital input is active. 6 = SET 1 PID parameter set 1 is active. 7 = SET 2 PID parameter set 2 is active.
4017	WAKE-UP DELAY Delay for deactivation of PID sleep function. Refer to parameter 4015 WAKE-UP LEVEL and Figure 55.
4018	SLEEP SELECTION PID sleep function control. 0 = INTERNAL When INTERNAL is selected, the sleep state is controlled by the output frequency, process reference and process actual value. Refer to parameters 4015 WAKE-UP LEVEL and 4014 PID SLEEP LEVEL. 1...5 = DI1...DI5 Sleep state is activated and deactivated using a digital input.
4019	SET POINT SEL Set point selection. Defines the reference signal source for the PID controller. Note! When PID regulator is by-passed (parameter 8121 REG BYPASS CTRL), this parameter has no significance. 1 = INTERNAL Process reference is a constant value set with parameter 4020 INTERNAL SETPNT. 2 = EXTERNAL Process reference is read from a source defined with parameter 1106 EXT REF2 SELECT. The ACS 400 must be in remote mode (REM is shown on control panel display).* * Process reference to PID controller can also be given from the control panel in local mode (LOC is shown on control panel display) if the panel reference is given as percentage, i.e. value of parameter 1101 KEYPAD REF SEL = 2 (REF2 (%)).
4020	INTERNAL SETPNT Sets a constant process reference (%) for the PID controller. PID controller follows this reference if parameter 4019 SET POINT SEL is set to 1 (INTERNAL).




Figure 55 Sleep function operation.

Group 41: PID Control (2)

Parameters of this group belong to PID parameter set 2. The operation of parameters 4101 - 4112, 4119 - 4120 is analogous with set 1 parameters 4001 - 4012, 4019 - 4020.

PID parameter set 2 can be selected by parameter 4016 PID PARAM SET.

Group 50: Communication

Parameters of this group define some general communication settings. Parameters 5001-5002 and 5007 are used only if DDCS option module is installed.

Code	Description
5001	DDCS BIT RATE DDCS link baud rate in Mbits/s.
5002	DDCS NODE NR DDCS link node number.
5003	COMM FAULT TIME Communication time out delay. This applies both to standard Modbus and DDCS link. When communication loss supervision is activated by parameter 5004 COMM FAULT FUNC, the bus master must write Control Word, Reference 1 or Reference 2 periodically. The maximum period is set by this parameter.
5004	COMM FAULT FUNC Communication fault function. This applies both to standard Modbus and DDCS link. 0 = NOT SEL No operation. 1 = FAULT A fault indication is displayed and the ACS 400 coasts to stop. 2 = CONST SP 7 A warning indication is displayed and the speed is set according to parameter 1208 CONST SPEED7. 3 = LAST SPEED A warning indication is displayed and the speed is set to the level the ACS 400 was last operating at. This value is determined by the average speed over the last 10 seconds. Caution: If you select CONST SPEED 7 or LAST SPEED, make sure that it is safe to continue operation in case communication is lost.
5005	PROTOCOL SEL Defines what communication protocols are used. Options 1 (DDCS) and 3 (STD MDB+DDCS) should be selected only if DDCS communication module is installed. 0 = NOT SEL No serial communication is active. 1 = DDCS DDCS serial communication is active. 2 = STD MODBUS Standard Modbus protocol is active. 3 = STD MDB+DDCS Both standard Modbus and DDCS are active.
5006	COMM COMMANDS The commands source protocol selection. Although the ACS 400 can communicate simultaneously via several serial communication channels, the controlling commands - start, stop, direction and reference - can be received only from a single communication channel, selectable by this parameter. 0 = NOT SEL Controlling commands are not received via serial communication. 1 = STD MODBUS Controlling commands can be received through Channel 1 standard Modbus protocol. 2 = DDCS Controlling commands can be received through the DDCS link.

Code	Description
5007	<p>DDCS BUS MODE Sets the operation mode of the DDCS link.</p> <p>1=FIELDBUS Fieldbus adapter is used in DDCS link. (The ACS 400 acts as the slave station on the DDCS link).</p> <p>2=IO EXTENSION Input/output extension module (type name NDIO) is used on DDCS link. The ACS 400 acts as the master station on the DDCS link, and is capable to control the digital inputs and outputs of the extension module.</p> <p>Note! Value 2 (IO EXTENSION) should be used only when PFC (Pump-Fan Control) macro is selected.</p>

Group 51: Ext Comm Module

Parameters of this group need to be adjusted only when an external fieldbus communication module is installed. Refer to communication module documentation for more information on these parameters.

Code	Description																						
5101	<div><div>FIELDBUSPAR 1 Parameter 1 of communication module on the DDCS link. Value reflects the type of the connected communication module.</div><div><i>Table 16 List of module types.</i><table><tr><th>Value</th><th>Module type</th></tr><tr><td>0</td><td>No module connected.</td></tr><tr><td>1</td><td>NPBA Profibus</td></tr><tr><td>2</td><td>NMBA Modbus</td></tr><tr><td>3</td><td>NIBA Interbus-S</td></tr><tr><td>4</td><td>NCSA CS31 bus</td></tr><tr><td>5</td><td>NCAN CANopen</td></tr><tr><td>6</td><td>NDNA DeviceNet</td></tr><tr><td>7</td><td>NLON LONWORKS</td></tr><tr><td>8</td><td>NMBP Modbus+</td></tr><tr><td>9</td><td>Others</td></tr></table></div></div>	Value	Module type	0	No module connected.	1	NPBA Profibus	2	NMBA Modbus	3	NIBA Interbus-S	4	NCSA CS31 bus	5	NCAN CANopen	6	NDNA DeviceNet	7	NLON LONWORKS	8	NMBP Modbus+	9	Others
Value	Module type																						
0	No module connected.																						
1	NPBA Profibus																						
2	NMBA Modbus																						
3	NIBA Interbus-S																						
4	NCSA CS31 bus																						
5	NCAN CANopen																						
6	NDNA DeviceNet																						
7	NLON LONWORKS																						
8	NMBP Modbus+																						
9	Others																						
5102 - 5115	<div>FIELDBUSPAR 2 - FIELDBUSPAR 15 Refer to communication module documentation for more information on these parameters.</div>																						

Group 52: Standard Modbus

The ACS 400 can be connected to Modbus fieldbus system. Parameters of this group are used to set up station number, communication speed and parity. Parameters 5206 - 5215 are diagnostic counters that can be used to debug the fieldbus system. Refer to "Standard Serial Communication" on page 115 for more information.

Modifications of parameters in this group take effect on the next power-up.

Code	Description
5201	STATION NUMBER Sets the slave number for the ACS 400 in Modbus network. Range: 1 - 247
5202	COMM SPEED Defines the communication speed of the ACS 400 in bits per second (bits/s). 3 = 300 bits/s 48 = 4800 bits/s 6 = 600 bits/s 96 = 9600 bits/s 12 = 1200 bits/s 192 = 19200 bits/s 24 = 2400 bits/s
5203	PARITY Defines the parity to be used with the Modbus communication. Parameter also defines the number of stop bits. With Modbus communication, the number of stop bits is 2 with no parity bit, and 1 with even or odd parity. 0 = NONE 1 = EVEN 2 = ODD
5206	BAD MESSAGES This diagnostics counter increases by one every time the ACS 400 finds any kind of communication error. During normal operation, this counter hardly ever increases.
5207	GOOD MESSAGES This diagnostics counter increases by one every time a valid Modbus message has been received by the ACS 400. During normal operation, this counter is increasing constantly.
5208	BUFFER OVERRUNS Longest possible message length for the ACS 400 is 32 bytes. If a message exceeding 32 bytes is received, this diagnostic counter increases by one every time a character which cannot be placed in the buffer is received.
5209	FRAME ERRORS This diagnostic counter increases by one every time when a character with a framing error is received from the bus. <ul style="list-style-type: none">• Communication speed settings of the devices connected in the bus differ.• Ambient noise levels may be too high.
5210	PARITY ERRORS This diagnostic counter increases by one every time when a character with a parity error is received from the bus. <ul style="list-style-type: none">• Parity settings of the devices connected on the bus differ.• Ambient noise levels may be too high.

Code	Description
5211	CRC ERRORS This diagnostic counter increases by one every time when a message with a CRC error is received. <ul style="list-style-type: none"> • Ambient noise levels may be too high. • CRC calculation is not performed correctly.
5212	BUSY ERRORS This diagnostic counter increases by one every time the ACS 400 receives a character from the bus while it is still processing the previous message. <ul style="list-style-type: none"> • There might be two stations with the same station number. • Ambient noise levels may be too high.
5213	SER FAULT MEM 1 Last Modbus exception code sent.
5214	SER FAULT MEM 2 Previous Modbus exception code sent.
5215	SER FAULT MEM 3 Oldest Modbus exception code sent.

Group 81: PFC Control

Parameters for Pump-Fan Control (PFC). Appendix B gives detailed information on PFC. Chapter Application Macros describes the default signal connections.

Code	Description
8103	<p>REFERENCE STEP 1</p> <p>Sets a percentage value that is added to the process reference when <u>at least one</u> auxiliary (constant speed) motor is running. Default value is 0 %.</p> <p>Example: An ACS 400 operates three parallel pumps that pump water to a pipe. The pressure in the pipe is controlled. The constant pressure reference is set by parameter 4020 INTERNAL SETPNT.</p> <p>At low water consumption level only the speed regulated pump is run. When water consumption increases, constant speed pumps are started; first one pump, and if the demand is still growing, also the other pump.</p> <p>When water flow increases, the pressure loss increases between the beginning (measurement site) and the end of the pipe. By setting suitable reference steps (parameters 8103 REFERENCE STEP1 and 8104 REFERENCE STEP2) the process reference is increased along the increasing pumping capacity. The reference steps compensate the growing pressure loss and prevent the pressure fall at the end of the pipe.</p>
8104	<p>REFERENCE STEP 2</p> <p>Sets a percentage value that is added to the process reference when <u>at least two</u> auxiliary (constant speed) motors are running. Default value is 0 %. See parameter 8103 REFERENCE STEP1</p>
8105	<p>REFERENCE STEP 3</p> <p>Sets a percentage value that is added to the process reference when <u>at least three</u> auxiliary (constant speed) motors are running. Default value is 0 %. See parameter 8103 REFERENCE STEP1.</p>
8109	<p>START FREQ 1</p> <p>Sets a frequency limit. See Figure 56 on page 106. When ACS 400 output frequency exceeds value (8109 START FREQ 1 + 1 Hz) and no auxiliary motors are running, the Start Delay counter is started. When the time set with parameter 8115 AUX MOT START D is elapsed and if the output frequency is still above value (8109 START FREQ 1 - 1 Hz), the first auxiliary motor is started.</p> <p>After the first auxiliary motor is started, ACS 400 output frequency is decreased by value (8109 START FREQ 1 - 8112 LOW FREQ 1).</p> <p>Note! Start Frequency 1 should be within limits 8112 LOW FREQ 1 and 2008 MAXIMUM FREQ -1.</p>
8110	<p>START FREQ 2</p> <p>Sets a frequency limit (see Figure 56). When ACS 400 output frequency exceeds value (8110 START FREQ 2 + 1 Hz) and one auxiliary motor is running, the Start Delay counter is started. When the time set with parameter 8115 AUX MOT START D is elapsed and if the output frequency is still above value (8110 START FREQ 2 - 1 Hz), the second auxiliary motor is started.</p> <p>After the second auxiliary motor is started, ACS 400 output frequency is decreased by value (8110 START FREQ 2 - 8113 LOW FREQ 2).</p> <p>Note! Start Frequency 2 should be within limits 8113 LOW FREQ 2 and 2008 MAXIMUM FREQ -1.</p>
8111	<p>START FREQ 3</p> <p>Sets a frequency limit (see Figure 56). When ACS 400 output frequency exceeds value (8111 START FREQ 3 + 1 Hz) and two auxiliary motors are running, the Start Delay counter is started. When the time set with parameter 8115 AUX MOT START D is elapsed and if the output frequency is still above value (8111 START FREQ 3 - 1 Hz), the third auxiliary motor is started.</p> <p>After the third auxiliary motor is started, ACS 400 output frequency is decreased by value (8111 START FREQ 3 - 8114 LOW FREQ 3).</p> <p>Note! Start Frequency 3 should be within limits 8114 LOW FREQ 3 and 2008 MAXIMUM FREQ -1.</p>
8112	<p>LOW FREQ 1</p> <p>Sets a frequency limit (see Figure 56). When ACS 400 output frequency falls below value (8112 LOW FREQ 1 - 1 Hz) and one auxiliary motor is running, the Stop Delay counter is started. When the time set with parameter 8116 AUX MOT STOP D. is elapsed and if the output frequency is still below value (8112 LOW FREQ 1 + 1 Hz), the first auxiliary motor is stopped.</p> <p>After the auxiliary motor is stopped, ACS 400 output frequency is increased by value (8109 START FREQ 1 - 8112 LOW FREQ 1).</p> <p>Note! Low Frequency 1 should be within limits 2007 MINIMUM FREQ +1 and 8109 START FREQ 1.</p>

Code	Description
8113	<p>LOW FREQ 2</p> <p>Sets a frequency limit (see Figure 56). When ACS 400 output frequency falls below value (8113 LOW FREQ 2 - 1 Hz) and two auxiliary motors are running, the Stop Delay counter is started. When the time set with parameter 8116 AUX MOT STOP D. is elapsed and if the output frequency is still below value (8113 LOW FREQ 2 + 1 Hz), the second auxiliary motor is stopped.</p> <p>After the auxiliary motor is stopped, ACS 400 output frequency is increased by a value (8110 START FREQ 2 - 8113 LOW FREQ 2).</p> <p>Note! Low Frequency 2 should be within limits 2007 MINIMUM FREQ +1 and 8110 START FREQ 2</p>
8114	<p>LOW FREQ 3</p> <p>Sets a frequency limit (see Figure 56). When ACS 400 output frequency falls below value (8114 LOW FREQ 3 - 1 Hz) and three auxiliary motors are running a Stop Delay counter is started. When the time set with parameter 8116 AUX MOT STOP D. is elapsed and if the output frequency is still below value (8114 LOW FREQ 3 + 1 Hz), the third auxiliary motor is stopped.</p> <p>After the auxiliary motor is stopped, ACS 400 output frequency is increased by value (8111 START FREQ 3 - 8114 LOW FREQ 3).</p> <p>Note! Low Frequency 3 should be within limits 2007 MINIMUM FREQ +1 and 8111 START FREQ 3.</p>
8115	<p>AUX MOT START D</p> <p>Sets the Start Delay for the auxiliary motors. See parameter 8109 START FREQ 1 and Figure 56 for more information.</p>
8116	<p>AUX MOT STOP D.</p> <p>Sets the Stop Delay for the auxiliary motors. See parameter 8112 LOW FREQ 1 for more information.</p> <div data-bbox="134 670 1008 1244"> <p>The graph illustrates the relationship between frequency and time during motor start and stop sequences. The frequency starts at f_{min} and increases linearly. When it reaches the level of 8109 START FREQ 1 + 1 Hz, the Start Delay (8115 AUX MOT START D) begins. During this delay, the frequency continues to increase. Once the delay ends, the frequency drops to the level of 8112 LOW FREQ 1 - 1 Hz. This drop is labeled 'Frequency decrease during the Stop Delay'. The frequency then remains constant at this level for the Stop Delay (8116 AUX MOT STOP D.). After the stop delay, the frequency increases again, labeled 'Frequency increase during the Start Delay', until it reaches f_{max}. Below the graph, a timeline for 'Aux Motor 1 Stop/Start' shows the 'Start' event occurring at the beginning of the Start Delay and the 'Stop' event occurring at the end of the Stop Delay.</p> </div> <p>Figure 56 Start Frequency, Low Frequency, Start Delay and Stop Delay.</p>


Code	Description																																																
8117	<p>NR OF AUX MOT Sets the number of auxiliary motors.</p> <p>Relay outputs</p> <p>Start/stop signals for the auxiliary motors are given through relay outputs. In addition, one relay output is used to connect the speed regulated motor to the ACS 400.</p> <p>ACS 400 relay outputs RO1 and RO2 can be used to control the motors. It is also possible to use up to two optional external digital input/output modules (NDIO).</p> <p>ACS 400 relay output 1 is used for Pump and Fan motor control if 1401 RELAY OUTPUT 1 value is 29 (PFC). Relay output 2 is used for Pump and Fan motor control if 1402 RELAY OUTPUT 2 value is 29 (PFC).</p> <p>Table 17 depicts the use of relay outputs for different settings of parameters 1401 and 1402. If Autochange function is not used, first relay output configured for PFC use controls the speed regulated motor. If Autochange function is used, the ACS 400 Autochange logic assigns the relay outputs to corresponding motors (of which one is speed controlled).</p> <p><i>Table 17 Usage of relay outputs. Relay output configuration is set by parameters 1401, 1402 and 8117. Number of relay outputs needed depends on the number of auxiliary motors. For example, if number of auxiliary motors is 2, total of three relay outputs (motors 1,2 and 3) are needed. x = Any other setting than 29 (PFC).</i></p> <table><tr><th colspan="2">Parameter setting</th><th colspan="2">ACS 400 relays</th><th colspan="2">NDIO module 1 (Module node number = 5)</th><th colspan="2">NDIO module 2 (Module node number = 6)</th></tr><tr><th>1401 RELAY OUTPUT 1</th><th>1402 RELAY OUTPUT 2</th><th>Relay output RO1 function</th><th>Relay output RO2 function</th><th>NDIO relay output 1 function</th><th>NDIO relay output 2 function</th><th>NDIO relay output 1 function</th><th>NDIO relay output 2 function</th></tr><tr><td>29 (PFC)</td><td>29 (PFC)</td><td>Motor 1 start/stop</td><td>Motor 2 start/stop</td><td>Motor 3 start/stop</td><td>Motor 4 start/stop</td><td>Not used</td><td>Not used</td></tr><tr><td>29 (PFC)</td><td>x</td><td>Motor 1 start/stop</td><td>e.g. Fault</td><td>Motor 2 start/stop</td><td>Motor 3 start/stop</td><td>Motor 4 start/stop</td><td>Not used</td></tr><tr><td>x</td><td>29 (PFC)</td><td>e.g. Fault</td><td>Motor 1 start/stop</td><td>Motor 2 start/stop</td><td>Motor 3 start/stop</td><td>Motor 4 start/stop</td><td>Not used</td></tr><tr><td>x</td><td>x</td><td>e.g. Run</td><td>e.g. Fault</td><td>Motor 1 start/stop</td><td>Motor 2 start/stop</td><td>Motor 3 start/stop</td><td>Motor 4 start/stop</td></tr></table>	Parameter setting		ACS 400 relays		NDIO module 1 (Module node number = 5)		NDIO module 2 (Module node number = 6)		1401 RELAY OUTPUT 1	1402 RELAY OUTPUT 2	Relay output RO1 function	Relay output RO2 function	NDIO relay output 1 function	NDIO relay output 2 function	NDIO relay output 1 function	NDIO relay output 2 function	29 (PFC)	29 (PFC)	Motor 1 start/stop	Motor 2 start/stop	Motor 3 start/stop	Motor 4 start/stop	Not used	Not used	29 (PFC)	x	Motor 1 start/stop	e.g. Fault	Motor 2 start/stop	Motor 3 start/stop	Motor 4 start/stop	Not used	x	29 (PFC)	e.g. Fault	Motor 1 start/stop	Motor 2 start/stop	Motor 3 start/stop	Motor 4 start/stop	Not used	x	x	e.g. Run	e.g. Fault	Motor 1 start/stop	Motor 2 start/stop	Motor 3 start/stop	Motor 4 start/stop
Parameter setting		ACS 400 relays		NDIO module 1 (Module node number = 5)		NDIO module 2 (Module node number = 6)																																											
1401 RELAY OUTPUT 1	1402 RELAY OUTPUT 2	Relay output RO1 function	Relay output RO2 function	NDIO relay output 1 function	NDIO relay output 2 function	NDIO relay output 1 function	NDIO relay output 2 function																																										
29 (PFC)	29 (PFC)	Motor 1 start/stop	Motor 2 start/stop	Motor 3 start/stop	Motor 4 start/stop	Not used	Not used																																										
29 (PFC)	x	Motor 1 start/stop	e.g. Fault	Motor 2 start/stop	Motor 3 start/stop	Motor 4 start/stop	Not used																																										
x	29 (PFC)	e.g. Fault	Motor 1 start/stop	Motor 2 start/stop	Motor 3 start/stop	Motor 4 start/stop	Not used																																										
x	x	e.g. Run	e.g. Fault	Motor 1 start/stop	Motor 2 start/stop	Motor 3 start/stop	Motor 4 start/stop																																										
8118	<p>AUTOCHNG INTERV Sets the interval for the Autochange function. The time is counted only when ACS 400 Start signal is on. See parameter 8119 AUTOCHNG LEVEL for information on the operation of the Autochange.</p> <p>0.0 = NOT SEL</p> <p>This setting switches off the Autochange function.</p> <p>Note! The ACS 400 always coasts to stop when autochange is performed.</p> <p>Warning! If the Autochange function is used, the Interlocks must be in use. In Autochange system there is a contactor between ACS 400 output terminals and the speed controlled motor. The contactor is damaged if opened without first interrupting the ACS 400 inverter bridge switching. The inverter switching is interrupted when the Interlock is switched off and the ACS 400 coasts to stop.</p>																																																

Code	Description
8119	<p>AUTOCHNG LEVEL</p> <p>Sets the operation limit for the Autochange logic. This parameter can be used to deny Autochange when the Pump-Fan system is operating near maximum capacity. When the output from PID/PFC control block exceeds the level set by this parameter, Autochange operation is not possible.</p> <div data-bbox="280 239 862 590"> </div> <p><i>Figure 57 Autochange level.</i></p> <p>Autochange operation</p> <p>The purpose of the Autochange operation is to ensure equal duty time for all the motors. Each motor in the system will in its turn be connected to the ACS 400 as well as direct on line. Starting order of the motors is changed when Autochange is done.</p> <p>To use the Autochange function, an external alternation switchgear is needed. Refer to Appendix B for more information. When Autochange is used, the interlocks (parameter 8120) must also be taken into use.</p> <p>The Autochange is performed when the Autochange Interval (parameter 8118) is elapsed from the previous autochange and the output from PFC is below the level set by this parameter.</p> <p>Autochange operation is as follows:</p> <ol style="list-style-type: none"> 1. The speed controlled motor stops. The contactor of the speed controlled motor is switched off. 2. The starting order is changed (the starting order counter steps onward). 3. The contactor of the motor that will be the new speed controlled motor is switched off (if the motor is running). If other motors are running, they will not be interrupted. 4. The contactor of the new speed controlled motor is switched on. The autochange switchgear connects this motor to the ACS 400. 5. Time set with parameter 8122 PFC START DELAY is waited. 6. Speed controlled motor starts. If a constant speed motor was stopped in Step 3, one more motor is connected direct on-line by switching on the contactor of that motor. After this step the same number of motors is running than before the Autochange. 7. Normal PFC operation continues. <p>As an example, in a three motor system the starting order is changed as follows:</p> <p>First start: Motor no. 1, motor no. 2, motor no. 3.</p> <p>Second start: Motor no. 2, motor no. 3, motor no. 1.</p> <p>Third start: Motor no. 3, motor no. 1, motor no. 2. (etc...)</p> <p>If some motors in the system are interlocked, the Autochange logic skips them. If all interlocks are active and no motor can be started, interlock alarm (Alarm 30) is displayed.</p> <p>Note! The ACS 400 always coasts to stop when autochange is performed.</p> <p>Note! Autochange can also occur during PID sleep.</p> <p>Note! When ACS 400 power supply is switched off, the values of the starting order counter and Autochange Interval counter are stored in the permanent memory. The counters continue from the stored values after the power supply is switched on again.</p>

Code	Description																																																
8120	<p>INTERLOCKS Controls the use of the Interlock function.</p> <p>Warning! If the Autochange function is used, also the Interlocks must be taken into use (see parameter 8118 AUTOCHNG INTERV).</p> <p>0 = NOT SEL No Interlocks function is in use. All digital inputs are available for other purposes.</p> <p>1 = DI1 Interlocks function is in use. Depending on the number of motors, the digital inputs are reserved for the interlock signals according to following table.</p> <table><tr><th></th><th colspan="3">Interlock signals</th></tr><tr><th>No of aux. motors (param. 8117)</th><th>ACS 400 digital inputs</th><th>NDIO module 1</th><th>NDIO module 2</th></tr><tr><td>0</td><td>DI1: Motor 1 DI2-DI5 free</td><td>Not used</td><td>Not used</td></tr><tr><td>1</td><td>DI1: Motor 1 DI2: Motor 2 DI3-DI5 free</td><td></td><td></td></tr><tr><td>2</td><td>DI1: Motor 1 DI2: Motor 2 DI3: Motor 3 DI4-DI5 free</td><td></td><td></td></tr><tr><td>3</td><td>DI1: Motor 1 DI2: Motor 2 DI3: Motor 3 DI4: Motor 4 DI5 free</td><td></td><td></td></tr></table> <p>2 = DI2 Interlocks function is in use. Depending on the number of motors, the digital inputs are reserved for the interlock signals according to following table.</p> <table><tr><th></th><th colspan="3">Interlock signals</th></tr><tr><th>No of aux. motors (param. 8117)</th><th>ACS 400 digital inputs</th><th>NDIO module 1</th><th>NDIO module 2</th></tr><tr><td>0</td><td>DI1: free DI2: Motor 1 DI3-DI5 free</td><td>Not used</td><td>Not used</td></tr><tr><td>1</td><td>DI1: free DI2: Motor 1 DI3: Motor 2 DI4-DI5 free</td><td></td><td></td></tr><tr><td>2</td><td>DI1: free DI2: Motor 1 DI3: Motor 2 DI4: Motor 3 DI5: free</td><td></td><td></td></tr><tr><td>3</td><td>DI1: free DI2: Motor 1 DI3: Motor 2 DI4: Motor 3 DI5: Motor 4</td><td></td><td></td></tr></table>		Interlock signals			No of aux. motors (param. 8117)	ACS 400 digital inputs	NDIO module 1	NDIO module 2	0	DI1: Motor 1 DI2-DI5 free	Not used	Not used	1	DI1: Motor 1 DI2: Motor 2 DI3-DI5 free			2	DI1: Motor 1 DI2: Motor 2 DI3: Motor 3 DI4-DI5 free			3	DI1: Motor 1 DI2: Motor 2 DI3: Motor 3 DI4: Motor 4 DI5 free				Interlock signals			No of aux. motors (param. 8117)	ACS 400 digital inputs	NDIO module 1	NDIO module 2	0	DI1: free DI2: Motor 1 DI3-DI5 free	Not used	Not used	1	DI1: free DI2: Motor 1 DI3: Motor 2 DI4-DI5 free			2	DI1: free DI2: Motor 1 DI3: Motor 2 DI4: Motor 3 DI5: free			3	DI1: free DI2: Motor 1 DI3: Motor 2 DI4: Motor 3 DI5: Motor 4		
	Interlock signals																																																
No of aux. motors (param. 8117)	ACS 400 digital inputs	NDIO module 1	NDIO module 2																																														
0	DI1: Motor 1 DI2-DI5 free	Not used	Not used																																														
1	DI1: Motor 1 DI2: Motor 2 DI3-DI5 free																																																
2	DI1: Motor 1 DI2: Motor 2 DI3: Motor 3 DI4-DI5 free																																																
3	DI1: Motor 1 DI2: Motor 2 DI3: Motor 3 DI4: Motor 4 DI5 free																																																
	Interlock signals																																																
No of aux. motors (param. 8117)	ACS 400 digital inputs	NDIO module 1	NDIO module 2																																														
0	DI1: free DI2: Motor 1 DI3-DI5 free	Not used	Not used																																														
1	DI1: free DI2: Motor 1 DI3: Motor 2 DI4-DI5 free																																																
2	DI1: free DI2: Motor 1 DI3: Motor 2 DI4: Motor 3 DI5: free																																																
3	DI1: free DI2: Motor 1 DI3: Motor 2 DI4: Motor 3 DI5: Motor 4																																																

Code	Description																																																
	<p>3 = DI3</p> <p>Interlocks function is in use. Depending on the number of motors, the digital inputs are reserved for the interlock signals according to following table.</p> <table><tr><th></th><th colspan="3">Interlock signals</th></tr><tr><th>No of aux. motors (param. 8117)</th><th>ACS 400 digital inputs</th><th>NDIO module 1</th><th>NDIO module 2</th></tr><tr><td>0</td><td>DI1-DI2: free DI3: Motor 1 DI4-DI5 free</td><td>Not used</td><td>Not used</td></tr><tr><td>1</td><td>DI1-DI2: free DI3: Motor 1 DI4: Motor 2 DI5: free</td><td></td><td></td></tr><tr><td>2</td><td>DI1-DI2: free DI3: Motor 1 DI4: Motor 2 DI5: Motor 3</td><td></td><td></td></tr><tr><td>3</td><td>DI1-DI2: free DI3: Motor 1 DI4: Motor 2 DI5: Motor 3</td><td>DI1: Motor 4 DI2: Unused</td><td>Not used</td></tr></table> <p>4 = DI4</p> <p>Interlocks function is in use. Depending on the number of motors, the digital inputs are reserved for the interlock signals according to following table.</p> <table><tr><th></th><th colspan="3">Interlock signals</th></tr><tr><th>No of aux. motors (param. 8117)</th><th>ACS 400 digital inputs</th><th>NDIO module 1</th><th>NDIO module 2</th></tr><tr><td>0</td><td>DI1-DI3: free DI4: Motor 1 DI5 free</td><td>Not used</td><td>Not used</td></tr><tr><td>1</td><td>DI1-DI3: free DI4: Motor 1 DI5: Motor 2</td><td></td><td></td></tr><tr><td>2</td><td>DI1-DI3: free DI4: Motor 1 DI5: Motor 2</td><td>DI1: Motor 3 DI2: unused</td><td></td></tr><tr><td>3</td><td>DI1-DI3: free DI4: Motor 1 DI5: Motor 2</td><td>DI1: Motor 3 DI2: Motor 4</td><td>Not used</td></tr></table>		Interlock signals			No of aux. motors (param. 8117)	ACS 400 digital inputs	NDIO module 1	NDIO module 2	0	DI1-DI2: free DI3: Motor 1 DI4-DI5 free	Not used	Not used	1	DI1-DI2: free DI3: Motor 1 DI4: Motor 2 DI5: free			2	DI1-DI2: free DI3: Motor 1 DI4: Motor 2 DI5: Motor 3			3	DI1-DI2: free DI3: Motor 1 DI4: Motor 2 DI5: Motor 3	DI1: Motor 4 DI2: Unused	Not used		Interlock signals			No of aux. motors (param. 8117)	ACS 400 digital inputs	NDIO module 1	NDIO module 2	0	DI1-DI3: free DI4: Motor 1 DI5 free	Not used	Not used	1	DI1-DI3: free DI4: Motor 1 DI5: Motor 2			2	DI1-DI3: free DI4: Motor 1 DI5: Motor 2	DI1: Motor 3 DI2: unused		3	DI1-DI3: free DI4: Motor 1 DI5: Motor 2	DI1: Motor 3 DI2: Motor 4	Not used
	Interlock signals																																																
No of aux. motors (param. 8117)	ACS 400 digital inputs	NDIO module 1	NDIO module 2																																														
0	DI1-DI2: free DI3: Motor 1 DI4-DI5 free	Not used	Not used																																														
1	DI1-DI2: free DI3: Motor 1 DI4: Motor 2 DI5: free																																																
2	DI1-DI2: free DI3: Motor 1 DI4: Motor 2 DI5: Motor 3																																																
3	DI1-DI2: free DI3: Motor 1 DI4: Motor 2 DI5: Motor 3	DI1: Motor 4 DI2: Unused	Not used																																														
	Interlock signals																																																
No of aux. motors (param. 8117)	ACS 400 digital inputs	NDIO module 1	NDIO module 2																																														
0	DI1-DI3: free DI4: Motor 1 DI5 free	Not used	Not used																																														
1	DI1-DI3: free DI4: Motor 1 DI5: Motor 2																																																
2	DI1-DI3: free DI4: Motor 1 DI5: Motor 2	DI1: Motor 3 DI2: unused																																															
3	DI1-DI3: free DI4: Motor 1 DI5: Motor 2	DI1: Motor 3 DI2: Motor 4	Not used																																														

Code	Description																								
5 = DI5	<p>Interlocks function is in use. Depending on the number of motors, the digital inputs are reserved for the interlock signals according to following table.</p> <table><tr><th></th><th colspan="3">Interlock signals</th></tr><tr><th>No of aux. motors (param. 8117)</th><th>ACS 400 digital inputs</th><th>NDIO module 1</th><th>NDIO module 2</th></tr><tr><td>0</td><td>DI1-DI4: free DI5: Motor 1</td><td>Not used</td><td>Not used</td></tr><tr><td>1</td><td>DI1-DI4: free DI5: Motor 1</td><td>DI1: Motor 2 DI2: Unused</td><td>Not used</td></tr><tr><td>2</td><td>DI1-DI4: free DI5: Motor 1</td><td>DI1: Motor 2 DI2: Motor 3</td><td>Not used</td></tr><tr><td>3</td><td>DI1-DI4: free DI5: Motor 1</td><td>DI1: Motor 2 DI2: Motor 3</td><td>DI1: Motor 4 DI2: Unused</td></tr></table>		Interlock signals			No of aux. motors (param. 8117)	ACS 400 digital inputs	NDIO module 1	NDIO module 2	0	DI1-DI4: free DI5: Motor 1	Not used	Not used	1	DI1-DI4: free DI5: Motor 1	DI1: Motor 2 DI2: Unused	Not used	2	DI1-DI4: free DI5: Motor 1	DI1: Motor 2 DI2: Motor 3	Not used	3	DI1-DI4: free DI5: Motor 1	DI1: Motor 2 DI2: Motor 3	DI1: Motor 4 DI2: Unused
	Interlock signals																								
No of aux. motors (param. 8117)	ACS 400 digital inputs	NDIO module 1	NDIO module 2																						
0	DI1-DI4: free DI5: Motor 1	Not used	Not used																						
1	DI1-DI4: free DI5: Motor 1	DI1: Motor 2 DI2: Unused	Not used																						
2	DI1-DI4: free DI5: Motor 1	DI1: Motor 2 DI2: Motor 3	Not used																						
3	DI1-DI4: free DI5: Motor 1	DI1: Motor 2 DI2: Motor 3	DI1: Motor 4 DI2: Unused																						
6 = EXTERNAL IO	<p>Interlocks function is in use. All interlock signals are taken through external I/O modules. Depending on the number of motors, the digital inputs are reserved for the interlock signals according to following table.</p> <table><tr><th></th><th colspan="3">Interlock signals</th></tr><tr><th>No of aux. Motors (param. 8117)</th><th>ACS 400 digital inputs</th><th>NDIO module 1</th><th>NDIO module 2</th></tr><tr><td>0</td><td>DI1-DI5: free</td><td>DI1: Motor 1 DI2: Unused</td><td>Not used</td></tr><tr><td>1</td><td>DI1-DI5: free</td><td>DI1: Motor 1 DI2: Motor 2</td><td>Not used</td></tr><tr><td>2</td><td>DI1-DI5: free</td><td>DI1: Motor 1 DI2: Motor 2</td><td>DI1: Motor 3 DI2: Unused</td></tr><tr><td>3</td><td>DI1-DI5: free</td><td>DI1: Motor 1 DI2: Motor 2</td><td>DI1: Motor 3 DI2: Motor 4</td></tr></table> <p>Interlock signals are active low, i.e. interlock is active when corresponding interlock signal is absent. If start command is given when the interlock signal of the speed regulated motor is active, the ACS 400 will not start, and will show alarm 30 (INTERLOCK) on the control panel.</p> <p>Each Interlock circuit should be wired as follows:</p> <ol style="list-style-type: none">1. A contact of the On/Off switch of the motor must be wired to the Interlock circuit. PFC logic detects if a motor is switched off. The logic does not try to start the switched-off motor; the next available motor is started instead.2. A contact of the motor thermal relay (or another protective device in the motor circuit) must be wired to the Interlock input. PFC logic detects if the thermal relay is activated. The motor is stopped.		Interlock signals			No of aux. Motors (param. 8117)	ACS 400 digital inputs	NDIO module 1	NDIO module 2	0	DI1-DI5: free	DI1: Motor 1 DI2: Unused	Not used	1	DI1-DI5: free	DI1: Motor 1 DI2: Motor 2	Not used	2	DI1-DI5: free	DI1: Motor 1 DI2: Motor 2	DI1: Motor 3 DI2: Unused	3	DI1-DI5: free	DI1: Motor 1 DI2: Motor 2	DI1: Motor 3 DI2: Motor 4
	Interlock signals																								
No of aux. Motors (param. 8117)	ACS 400 digital inputs	NDIO module 1	NDIO module 2																						
0	DI1-DI5: free	DI1: Motor 1 DI2: Unused	Not used																						
1	DI1-DI5: free	DI1: Motor 1 DI2: Motor 2	Not used																						
2	DI1-DI5: free	DI1: Motor 1 DI2: Motor 2	DI1: Motor 3 DI2: Unused																						
3	DI1-DI5: free	DI1: Motor 1 DI2: Motor 2	DI1: Motor 3 DI2: Motor 4																						



Code	Description
8121	<p>REG BYPASS CTRL</p> <p>Regulator by-pass control provides a simple control mechanism without a PID regulator. By-pass control is needed in special applications only. Example is given in Figure 59 and Figure 60.</p> <p>0 = NO Process PID regulator is in use.</p> <p>1 = YES The process PID regulator is bypassed. The signal connected to the PID Controller actual value pin (parameter 4006 ACTUAL VAL SEL) is used as the PFC frequency reference. The automatic start and stop of constant speed motors is referred to this actual value signal instead of the output of the PID regulator.</p> <div data-bbox="244 384 938 807" data-label="Diagram"> </div> <p>Figure 59 Regulator bypass control. The capacity of the pumping station (outlet flow) follows the measured inlet flow.</p> <div data-bbox="244 922 991 1404" data-label="Figure"> <p>a: No auxiliary motors running b: One auxiliary motor running c: Two auxiliary motors running</p> </div> <p>Figure 60 The relation between the control signal and the frequency of the controlled motor in a three-motor system.</p>

Code	Description
8122	<p>PFC START DELAY</p> <p>Sets the start delay for all the motors in the system. The delay works as follows:</p> <ol style="list-style-type: none"> 1. The contactor that connects the speed regulated motor to ACS 400 is switched on (by a ACS 400 relay output). 2. PFC Start Delay is waited. 3. Speed regulated motor is energised and normal PFC operation starts. Auxiliary motors are started. <p>Caution! There should always be PFC Start Delay set if the motors are equipped with star-delta starters. The PFC Start Delay must be set longer than the time setting of the star-delta starter: After the motor is switched on by the relay output of the ACS 400 there must be enough time for the star-delta starter to first switch to star-connection and then back to delta-connection before the ACS 400 inverter starts switching.</p>

Standard Serial Communication

Overview

The ACS 400 can be connected to an external control system using the standard Modbus fieldbus connection.

The ACS 400 can receive all of its control information either from the Modbus fieldbus, or the control can be distributed between the fieldbus and other available control locations, e.g. digital/analogue inputs and the drive control panel.

The ACS 400 has two serial communication channels (or ports), Channel 0 and Channel 1. Channel 1 is the standard Modbus fieldbus connection. Communication settings of Channel 1 can be configured by the user. To control the ACS 400 via Modbus, ACS 400 must be parameterised to accept control commands and/or frequency references from Channel 1. Channel 0 is reserved for drive control panels ACS-PAN and ACS100-PAN, and for the DriveWindow PC tool.

Optional serial communication features

ACS 400 can also be connected to number of other fieldbuses using special fieldbus adapter modules. These adapters are connected using an optical DDCS link (DDCS=Distributed Drives Control System). For more information on these options, contact your supplier.




Figure 61 Standard serial communication features of ACS 400.




Figure 62 Structure of a fieldbus system.

Earthing and Termination

RS485 Bus

The RS485 network should not be directly earthed at any point. All the devices on the network should be well earthed using their corresponding earthing terminals.

As always, the earthing wires should not form any closed loops, and all the devices should be earthed to a common earth.

The RS485 network must be terminated using 120 Ω resistors at both ends of the network. Use jumper J2 to connect or disconnect the termination resistors.

The termination should not be done on the intermediate stations on the network as shown in Figure 63.



Figure 63 Termination for the RS485 link.



The connections may only be made with the drive disconnected from the power source.

Activating Modbus Protocol

As a factory setting, Channel 1 is not operational. To activate standard Modbus protocol for Channel 1, set parameter 5005 PROTOCOL SEL to 2 (STD MODBUS).

After this single modification, the ACS 400 is ready to communicate via Channel 1 using the default communication settings (given in Table 18), making parameter read and write possible.

Following sections describe how to configure the ACS 400 for more sophisticated communication and control.

Table 18 Default communication settings of Channel 1.

Station number	Communication speed	Parity bit	Stop bits	Number of data bits
1	9600 bps	none	two	8

Note! Protocol must be reactivated after the communication settings are changed.

Communication settings

Communication settings define the communication speed, parity checking, number of stop bits and fault functions. These settings for Channel 1 are defined using parameters in groups 50 COMMUNICATION and 52 STANDARD MODBUS.

Default communication settings for Channel 1 are listed in Table 18. To be able to communicate with the master device, the ACS 400 must use the same communication speed and parity settings as the master.

Further information on all the parameters and their alternative settings is given in chapter “ACS 400 Complete Parameter List” on page 55.

Table 19 Communication parameters.

Code	Parameter Name	Alternative Settings	Default Setting	Function/Information
Group 52 STANDARD MODBUS				
5201	STATION NUMBER	1 - 247	1	Slave number for ACS 400 in Modbus network.
5202	COMM SPEED	3 = 300 bps ... 192 = 19200 bps	96 (9600 bits/s)	Communication speed.
5203	PARITY	0 = NONE 1 = EVEN 2 = ODD	0 (NONE)	Parity and stop bit setting.
Group 50 COMMUNICATION				
5003	COMM FAULT TIME	0.1 - 60.0 s	1.0 s	Time limit for communication loss detection.
5004	COMM FAULT FUNC	0 = NOT SEL 1 = FAULT 2 = CONST SP 7 3 = LAST SPEED	0 (NOT SEL)	Operation in case communication with the master device is lost.
5005	PROTOCOL SEL	0 = NOT SEL 1 = DDCS 2 = STD MODBUS 3 = STD MDB+DDCS	0 (NOT SEL)	Communication protocol selection. Normally must be set to STD MODBUS.

Control Locations

The ACS 400 drive can receive control information from multiple sources, including digital I/O, analogue I/O, keypad, and Modbus fieldbus.

To control the ACS 400 via the serial communication channel 1 (Modbus fieldbus), it must be parameterised to accept control commands and/or frequency references from this channel. In addition, ACS 400 must be in remote control.

The necessary parameters and their usage are listed in Table 20. Note especially, that before any control commands can be given through serial communication channel 1, parameter 5006 COMM COMMANDS value must be set to STD MODBUS.

Further information on all the parameters and their alternative settings is given in chapter “ACS 400 Complete Parameter List” starting page 55.

Table 20 Parameters for control command source selection.

Code	Parameter Name	Alternative Settings	Setting for Standard Modbus	Function/Information
Group 50 COMMUNICATION				
5006	COMM COMMAND	0 = NOT SEL 1 = STD MODBUS, 2 = DDCS	1 (STD MODBUS)	Defines the serial communication channel for the controlling commands (start, stop, direction and reference). Must be set to 1 (STD MODBUS).
Group 10 COMMAND INPUTS				
1001	EXT1 COMMANDS	0 = NOT SEL 1 = DI1 ... 10 = COMM	10 (COMM)	Enables the Control Word (except bit 11) when EXT1 is selected as control location.
1002	EXT2 COMMANDS	0 = NOT SEL 1 = DI1 ... 10 = COMM	10 (COMM)	Enables the Control Word (except bit 11) when EXT2 is selected as control location.
1003	DIRECTION	1 = FORWARD 2 = REVERSE 3 = REQUEST	3 (REQUEST)	Enables rotation direction control as defined by parameters 1001 and 1002.
Group 11 REFERENCE SELECT				
1102	EXT1/EXT2 SEL	1 = DI1 ... 8 = COMM	8 (COMM)	Enables external control location EXT1/EXT2 selection by Control Word bit 11.
1103	EXT REF1 SELECT	0 = KEYPAD 1 = AI1 ... 8 = COMM 9 = COMM+AI1 10 = COMM*AI1	8 (COMM), 9 (COMM+AI1) or 10 (COMM*AI1)	Fieldbus reference 1 is used when EXT1 is selected as control location. See section References below for information on the alternative settings.

Code	Parameter Name	Alternative Settings	Setting for Standard Modbus	Function/Information
1106	EXT REF2 SELECT	0 = KEYPAD 1 = AI1 ... 8 = COMM 9 = COMM+AI1 10 = COMM*AI1	8 (COMM), 9 (COMM+AI1) or 10 (COMM*AI1)	Fieldbus reference 2 is used when EXT2 is selected as control location. See section References below for information on the alternative settings.
Group 16				
SYSTEM CONTROLS				
1601	RUN ENABLE	0 = NOT SEL 1...5 = DI1 ... DI5 6 = COMM	6 (COMM)	The run enable signal is given through serial communication (Control Word bit 3).
1604	FAULT RESET SEL	0 = KEYPAD ONLY 1...5 = DI1 ... DI5 6 = START/STOP 7 = COMM	7 (COMM)	Fault reset is executed through serial communication (Control Word bit 7).

Output signal source selection

It is possible to control both the relay outputs 1 and 2, as well as the analogue output from the serial communication channel 1.

Relay outputs can be controlled in the following way:

Step 1: Configure the ACS 400 to *supervise* the value of any of the parameters 131-133 using parameters in group 32 SUPERVISION.

Step 2: Configure a relay output 1 or 2 to respond to the status of one of the supervised parameters.

The selected relay can now be turned on or off by writing to supervised parameter (131-133) *some* value that is either above or below the given supervision limits.

Refer to Table 21 for more information on required parameter settings. With the given settings, writing any value 100 - 255 to parameter 131 SER LINK DATA 1 causes the relay output 1 to *activate*. Writing any value 0 - 99 to parameter 131 causes the relay output 1 to *deactivate*.

Refer to Table 22 for information on analogue output control.

Table 21 Relay output control.

Code	Parameter Name	Alternative Settings	Setting for Standard Modbus	Function/Information
Group 01				
OPERATING DATA				
0131	SER LINK DATA 1	0 - 255	-	Controlling data for the relay outputs.
0132	SER LINK DATA 2	0 - 255	-	

Code	Parameter Name	Alternative Settings	Setting for Standard Modbus	Function/Information
Group 14 RELAY OUTPUTS				
1401	RELAY OUTPUT 1	0 = NOT SEL ... 7 = SUPRV1 OVER 8 = SUPRV1 UNDER 9 = SUPRV2 OVER 10 = SUPRV2 UNDER ... 31 = STARTED	e.g. 7 (SUPRV1 OVER)	Relay output 1 function. With the given setting, the relay 1 is activated when supervised parameter 1 (given by parameter 3201) is above the limit given by parameter 3203.
1402	RELAY OUTPUT 2	As above	e.g. 7 (SUPRV1 OVER)	Relay output 2 function. See above.
Group 32 SUPERVISION				
3201	SUPERV 1 PARAM	102 - 137	e.g. 131 (SERIAL LINK DATA 1)	Number of supervised parameter 1. Any parameter of the group 1 OPERATING DATA.
3202	SUPERV 1 LIM LO	0 - 255	e.g. 100	Lower supervision limit for supervised parameter 1.
3203	SUPERV 1 LIM HI	0 - 255	e.g. 100	Upper supervision limit for supervised parameter 1.
3204	SUPERV 2 PARAM	102 - 137	e.g. 132 (SERIAL LINK DATA 2)	Number of supervised parameter 1. Any parameter of the group 1 OPERATING DATA.
3205	SUPERV 2 LIM LO	0 - 255	e.g. 100	Lower supervision limit for supervised parameter 2.
3206	SUPERV 2 LIM HI	0 - 255	e.g. 100	Upper supervision limit for supervised parameter 2.

Table 22 Analogue output control.

Code	Parameter Name	Alternative Settings	Setting for Standard Modbus	Function/Information
Group 01 OPERATING DATA				
0133	SER LINK DATA 3	0 - 255	-	Controlling data for the analogue output.
Group 15 ANALOGUE OUTPUT				
1501	AO CONTENT	102 - 137	e.g. 133	Directs the contents of parameter 133 to the analogue output.
1503	AO CONTENT MAX		255	Analogue output scaling: upper limit (20 mA) reached when value 255 written to parameter 133.

Diagnostic Counters

Diagnostic counters can be used for debugging the Modbus system.

Counters will roll over from 65535 to 0. The counter values are stored to permanent memory when power is disconnected.

Counters can be reset from the control panel by pressing the UP and DOWN buttons simultaneously when in parameter set mode, or by writing a zero from the serial communication channel 1.

Note! Parameters 5206 - 5212 are displayed in hexadecimal format by the control panel.

Table 23

Code	Name	Range	User
Group 52			
STANDARD MODBUS			
5206	BAD MESSAGES	0 - 65535	
5207	GOOD MESSAGES	0 - 65535	
5208	BUFFER OVERRUNS	0 - 65535	
5209	FRAME ERRORS	0 - 65535	
5210	PARITY ERRORS	0 - 65535	
5211	CRC ERRORS	0 - 65535	
5212	BUSY ERRORS	0 - 65535	
5213	SER FAULT MEM 1	0 - 3	
5214	SER FAULT MEM 1	0 - 3	
5215	SER FAULT MEM 3	0 - 3	

Communication

This chapter describes the Modbus communication on ACS 400 drives.

Introduction to Modbus

Modbus is a serial, asynchronous protocol. The Modbus protocol does not specify the physical interface. Typical physical interface is RS485.

Modbus is designed for integration with Modicon PLCs or other automation devices, and the services closely correspond to the PLC architecture. The ACS 400 drive 'looks like' a Modicon PLC on the network.

If detailed information regarding the Modicon Modbus protocol is required, contact your ABB supplier for a copy of Modbus Protocol Guide.

Register Read and Write

The ACS 400 has all drive parameter, control and status information mapped into a 4xxxx register area. This holding register area can be read from an external device, and an external device can modify the register values by writing to them.

There are no setup parameters for mapping the data to the 4xxxx register. The mapping is predefined and corresponds directly to the ACS 400 parameter grouping.

All parameters are available for both reading and writing. The parameter writes are verified for correct value, and for valid register addresses. Some parameters never allow writes (including Group 1 actual values), some allow only zero write (including Group 1 fault memories), some parameters allow write only when the drive is stopped (including Group 99 setup variables), and some can be modified at any time (including e.g. Group 22 acceleration and deceleration ramp times).

Note! Parameter writes through Channel 1 (Standard Modbus) are always volatile i.e. modified values are not automatically stored to permanent memory. Parameter 1607 PARAM. SAVE can be used to save all altered values.

Register Mapping

The drive parameters are mapped to the 4xxxx area so that:

- 40001 – 40099 are reserved for drive control registers
- 40101 – 40199 is reserved for the actual values (parameter group 1)
- 40201 – 40299 is reserved for parameter group 2
- 40301 – 40399 is reserved for fault and alarm information
- ... other parameter groups
- 49901 – 49999 is reserved for the start-up data

Register addresses 4GGPP are shown in Table 24. In this table GG is the group number, and PP is the parameter number within the group.

Table 24 Parameter mapping.

4GGPP	GG	PP
40001 – 40006	00 Drive control registers	01 Control word 02 Reference 1 03 Reference 2 04 Status word 05 Actual value 1 06 Actual value 2
40102 – 40130	01 OPERATING DATA	02 SPEED ... 30 OLDEST FAULT
41001 – 41003	10 COMMAND INPUTS	01 EXT1 COMMANDS 02 EXT2 COMMANDS 03 DIRECTION
41101 – 41108	11 REFERENCE SELECT	01 KEYPAD REF SEL ... 08 CONST SPEED 7
...
49901 – 49908	99 START-UP DATA	02 APPLIC MACRO ... 08 MOTOR NOM SPEED

The register addresses between the groups are invalid. No reads or writes are allowed for these addresses. If there is an attempt to read or write outside the parameter addresses, the Modbus interface will return an exception code to the controller.

Exception Codes

The ACS 400 supports the standard Modbus exception codes. These are shown in Table 25.

Table 25 Exception codes.

Code	Name	Meaning
01	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the slave. ACS 400: Unsupported Command
02	ILLEGAL DATA ADDRESS	The data address received in the query is not an allowable address for the slave. ACS 400: Address outside groups
03	ILLEGAL DATA VALUE	A value contained in the query data field is not an allowable value for the slave. ACS 400: Value outside min.-tax limits ACS 400: Parameter is read-only ACS 400: Message is too long ACS 400: Parameter write not allowed when start is active ACS 400: Parameter write not allowed when factory macro is selected

Function Codes

The ACS 400 supports the Modbus function codes given in Table 26. If any other function codes are used ACS 400 returns an exception response with error code 01 (illegal function).

Table 26 Function codes.

Code	Description
03	Read holding registers
06	Preset single register
16 (10 Hex)	Preset multiple registers

The Control Word and the Status Word

Holding registers: 40001 (Control Word), 40004 (Status Word)

The Control Word (CW) is the principal means for controlling the drive from a fieldbus system. It is effective when

- The drive is in external (remote) control and the controlling commands are received through serial communication channel (set by parameters 1001 EXT1 COMMANDS, 1002 EXT2 COMMANDS and 1102 EXT1/EXT2 SEL), and
- Serial communication channel that is used for the controlling is Standard Modbus (parameter 5006 COMM COMMANDS is set to 1 (STD MODBUS)).

The Control Word (detailed in Table 27) is sent by the fieldbus master station to the drive. The drive switches between its states according to the bit-coded instructions of the Control Word. See also state machine on page 132.

The Status Word (SW) is a word containing status information, sent by the drive to the master station. The composition of the Status Word is explained in Table 29.

Note! Operation of Control Word and Status Word conforms to ABB Drives Profile with the exception of Control Word bit #10 (REMOTE_CMD), which is not used by the ACS 400.

Table 27 The Control Word. See also the state machine on page 132.

Bit	Value	Description
0	1	Enter READY TO OPERATE
	0	Emergency OFF. Ramp to stop according to parameter 2203 DECELER TIME 1. Enter OFF1 ACTIVE ; proceed to READY TO SWITCH ON unless other interlocks (OFF2, OFF3) are active.
1	1	Continue operation (OFF2 inactive)
	0	Emergency OFF, coast to stop. Enter OFF2 ACTIVE ; proceed to SWITCH-ON INHIBITED .
2	1	Continue operation (OFF3 inactive)
	0	Emergency stop. Drive ramps to stop according to parameter 2205 DECELER TIME 2. Enter OFF3 ACTIVE ; proceed to SWITCH-ON INHIBITED .
3	0 -1	Enter OPERATION ENABLED (Note that also the Run enable signal must be present on a digital input – see parameter 1601 RUN ENABLE.
	0	Inhibit operation. Enter OPERATION INHIBITED
4		Unused.
5	1	Normal operation. Enter RAMP FUNCTION GENERATOR: ACCELERATOR ENABLED
	0	Halt ramping (Ramp Function Generator output held)
6	1	Normal operation. Enter OPERATING
	0	Force Ramp Function Generator input to zero.
7	0 - 1	Fault reset (enter SWITCH-ON INHIBITED)
	0	(Continue normal operation)
8 to 10		Unused
11	1	Select external control location 2 (EXT2)
	0	Select external control location 1 (EXT1)
12 to 15		Unused

Example on Using the Control Word

The following example shows how to use the Control Word to start the drive. When the power is connected for the first time, the state of the drive (see the state machine in Figure 64) is NOT READY TO SWITCH ON. Control Word is used to step through the state machine states until OPERATING state is reached, meaning that the drive is running and follows the given reference.

Table 28 Using the Control Word.

	Control Word Value	Description
Step 1	CW = 0000 0000 0000 0110 <div style="display: flex; justify-content: space-around; width: 100%;"> <div style="text-align: center;"> bit 15</div> <div style="text-align: center;"> bit 0</div> </div>	When this value is written, drive state changes to READY TO SWITCH ON.
Step 2		Wait at least 100 ms before proceeding.
Step 3	CW = 0000 0000 0000 0111	When this value is written, drive state changes to READY TO OPERATE.
Step 4	CW = 0000 0000 0000 1111	When this value is written, the drive starts, but will not accelerate. Drive state changes to OPERATION ENABLED.
Step 5	CW = 0000 0000 0010 1111	When this value is written, the ramp function generator (RFG) output is released. Drive state changes to RFG: ACCELERATOR ENABLED.
Step 6	CW = 0000 0000 0110 1111	When this value is written, the ramp function generator (RFG) input is released. Drive state changes to OPERATING. Drive will accelerate to the given reference and will follow the reference.

This example assumes that the ACS 400 is in remote control, that external control place 1 (EXT1) is the active control place (as selected by parameter 1102), and that EXT1 start and stop commands are received through serial communication (parameter 1001).

Table 29 The Status Word.

Bit	Value	Description
0	1	READY TO SWITCH ON
	0	NOT READY TO SWITCH ON
1	1	READY TO OPERATE
	0	OFF1 ACTIVE
2	1	OPERATION ENABLED
	0	Not ready (OPERATION INHIBITED)
3	0 - 1	FAULT
	0	No fault
4	1	OFF2 inactive
	0	OFF2 ACTIVE
5	1	OFF3 inactive
	0	OFF3 ACTIVE
6	1	SWITCH-ON INHIBITED
	0	
7	1	Alarm is active. See the Diagnostics section for a list of relevant alarms.
	0	No alarm
8	1	OPERATING . Actual value equals reference value (= is within tolerance limits).
	0	Actual value differs from reference value (= is outside tolerance limits)
9	1	Drive control location: REMOTE
	0	Drive control location: LOCAL
10	1	The value of first supervised parameter equals to or is greater than supervision limit. Refer to Group 32 Supervision.
	0	The value of first supervised parameter is below supervision limit
11	1	External control location 2 (EXT2) selected
	0	External control location 1 (EXT1) selected
12	1	Run Enable signal received
	0	No Run Enable signal received
13 to 15		Unused

References

References are 16-bit words comprising a sign bit and a 15-bit integer. A negative reference (indicating reversed direction of rotation) is formed by calculating the two's complement from the corresponding positive reference value.

Reference 1

Holding Register: 40002

Reference 1 can be used as the frequency reference REF1 for the ACS 400. The signal source of external reference 1 (REF1) must be set to COMM and external control location 1 (EXT1) must be activated. Refer to parameters 1103 EXT REF 1 SELECT and 1102 EXT1/EXT2 SEL.

Reference 2

Holding Register: 40003

Reference 2 can be used as the frequency reference REF2 for the ACS 400. The signal source of external reference 2 REF2 must be set to COMM and External control location 2 (EXT2) must be activated. Refer to parameters 1106 EXT REF 2 SELECT and 1102 EXT1/EXT2 SEL.

Fieldbus Reference Scaling

Fieldbus references are scaled as follows:

Reference 1: $20000 \hat{=} \text{EXT REF1 MAX (Hz, parameter 1105)}$. Scaling Parameter 1104 EXT REF1 MIN is not used.

Reference 2: $10000 \hat{=} \text{EXT REF2 MAX (\%, parameter 1108)}$. Scaling Parameter 1107 EXT REF2 MIN is not used.

Fieldbus Reference

Fieldbus reference is selected by setting a reference selection parameter – 1103 EXT REF1 SELECT or 1106 EXT REF2 SELECT – to COMM, COMM+AI1 or COMM*AI1. The latter two enable correction of the fieldbus reference using analogue input AI1. The following table explains these selections. Note that the analogue input value is a percentage value (0-100 %) which can be seen in parameter 0118 AI1.

Table 30 Correcting the fieldbus reference through analogue input.

Parameter Setting	Effect of AI1 Value on Fieldbus Reference
COMM	None
COMM+AI1	Corrected fieldbus reference = given fieldbus reference + analogue input AI1 value
COMM*AI1	Corrected fieldbus reference = given fieldbus reference * analogue input AI1 value / 100

Example of the effect of AI1 value on fieldbus reference.

Assume that 2008 MAXIMUM FREQ = 50 Hz

Assume that fieldbus reference 1 is 5000 (corresponding to 25 % of full scale) and voltage at AI1 is 3 V (corresponding to 30 % of full scale).

1. If setting COMM+AI1 is used, then corrected fieldbus reference is $25 \% + 30 \% = 55 \%$ or 27.5 Hz.
2. If setting COMM*AI1 is used, then corrected fieldbus reference is $25 \% * 30 \% / 100 \% = 7.5 \%$ or 3.75 Hz.

Actual Values

Actual values are read-only values containing information on the operation of the drive. Actual values are 16-bit words containing sign bit and a 15-bit integer. A negative value is given as two's complement of the corresponding positive value.

Actual Value 1


Holding Register: 40005

Actual output frequency. Scaling: $5000 \hat{=} 50$ Hz.

Actual Value 2

Holding Register: 40006

Actual output current. Scaling: $10 \hat{=} 1$ A.



*This state transition occurs also if the fault is reset from any other source (e.g. digital input).

Figure 64 The state machine for evaluation of start and stop signals.

Fault and Alarm Status

The ACS 400 provides fault and alarm status words for the external control system. These data words are accessible only through the serial communication link but not from the control panel.

Fault and alarm status words are located in parameter group 3. The group also contains copies of the Control Word and Status Word. Group 3 parameters are of read-only type; however, both alarm words can be reset by writing a zero to them.

Table 31 Fault and alarm status words.

Code	Name	Description
301	MAIN COMMAND WORD	Read-only copy of the Control Word. See page 127.
302	MAIN STATUS WORD	Read-only copy of the Status Word. See page 129.
305	FAULT WORD 1	Fault information. When a fault is active, the corresponding bit is set. Bit descriptions are given in Table 32.
306	FAULT WORD 2	Fault information. When a fault is active, the corresponding bit is set. Bit descriptions are given in Table 32.
308	ALARM WORD 1	Alarm information. When an alarm is active, the corresponding bit is set. Bits remain set until whole alarm word is reset by writing 0 to it. See Table 33.
309	ALARM WORD 2	Alarm information. When an alarm is active, the corresponding bit is set. Bits remain set until whole alarm word is reset by writing 0 to it. See Table 33.

Table 32 Bit descriptions for fault words 1 and 2. See also the Diagnostics section for more information about faults and fault codes.

Bit #	Fault Word 1	Fault Word 2
0	Overcurrent	Underload
1	DC overvoltage	Reserved
2	ACS 400 overtemperature	DDCS link
3	Fault current	Reserved
4	Output overload	
5	DC undervoltage	
6	Analogue input 1 fault	
7	Analogue input 2 fault	Hardware error
8	Motor overtemperature	
9	Panel loss	
10	Parameters inconsistent	
11	DC bus ripple too large	
12	Motor stall	
13	Serial communication loss	
14	External fault	
15	Output earth fault	

Table 33 Bit descriptions for ALARM WORD 1 and ALARM WORD 2. See also the Diagnostics section for more information about alarms and alarm codes.

Bit #	Alarm Word 1	Alarm Word 2
0	Overcurrent controller alarm	Overload alarm
1	Overvoltage controller alarm	Autoreset alarm
2	Undervoltage controller alarm	PID sleep alarm
3	Direction lock alarm	PFC autochange alarm
4	Serial communication loss	PFC interlock alarm
5	Modbus exception	Reserved
6	Analogue input 1 loss	
7	Analogue input 2 loss	
8	Panel loss	
9	ACS 400 overtemperature	
10	Motor overtemperature	
11	Underload	
12	Motor stall alarm	
13	DDCS link	
14	Reserved	
15	Reserved	

Diagnostics

General

This chapter describes the various diagnostic displays of the ACS-PAN and ACS100-PAN control panels and lists the most common causes for the particular display. If the fault cannot be cured by the given instructions, contact an ABB service representative.

Caution! Do not attempt any measurement, parts replacement or other service procedure not described in this manual. Such action will void guarantee, endanger correct operation, and increase downtime and expense.

Alarm and Fault displays

The seven-segment display unit of ACS100-PAN indicates alarms and faults using codes “ALxx” or “FLxx”, where xx is the corresponding alarm or fault code. The alphanumeric display of ACS-PAN control panel shows the alarm and fault codes together with a short message.

Alarms 1-7 arise from button operation. Green LED blinks for codes greater than or equal to 10. The faults are indicated by red LED.

The alarm and fault messages disappear when MENU, ENTER or the arrow buttons of control panel are pressed. The message will reappear after a few seconds if the keypad is not touched and the alarm or fault is still active.

Last three fault codes are stored into parameters 0128 - 0130. These fault memories can be cleared from the control panel by pressing UP and DOWN buttons simultaneously in parameter set mode.

Fault Resetting

Faults that are indicated by a red blinking LED are reset by turning the power off for a while. Other faults (indicated by red static LED) can be reset either from the control panel, by digital input or serial communication, or switching the supply voltage off for a while. When the fault has been removed, the motor can be started.

The ACS 400 can be configured to automatically reset certain faults. Refer to parameter group 31 AUTOMATIC RESET.

Warning! If an external source for start command is selected and it is active, the ACS 400 may start immediately after fault reset.

Warning! All electrical installation and maintenance work described in this chapter should only be undertaken by a qualified electrician. The Safety Instructions on the first pages of this manual must be followed.

Table 34 Alarms

Alarm Code	Display	Description
1 *	OPERATION FAILED	Parameter upload or download failed. The software versions of the drives may not be compatible. Software version can be seen from parameter 3301 SOFTWARE VERSION.
2 *	START ACTIVE	Control panel function is not allowed while start is active.
3 *	LOCAL/REMOTE	Control panel function is not allowed in current control mode (local or remote). Control mode is local when LOC is displayed and remote mode when REM is displayed on the control panel.
5 *	BUTTON DISABLED	Control panel function is denied for any of the following reasons: <ul style="list-style-type: none"> START/STOP button is interlocked from digital input. This can happen with certain digital input configurations. Refer to chapter Application Macros. REVERSE button is locked because shaft direction is fixed by parameter 1003 DIRECTION. The drive is in remote control mode and START/STOP and REVERSE buttons are not followed.
6 *	PARAM/LOCAL LOCK	Control panel function is not allowed: <ul style="list-style-type: none"> Parameter 1602 PARAMETER LOCK denies parameter editing Parameter 1605 LOCAL LOCK denies local control mode.
7 *	FACTORY MACRO	Control panel function is not allowed: Factory macro is selected and denies the parameter modifications. Factory macro is intended for applications where there is no control panel available.
10	OVERCURRENT	Overcurrent controller is active.
11	OVERVOLTAGE	Overvoltage controller is active.
12	DC UNDERVOLTAGE	Undervoltage controller is active.
13	DIRECTION LOCK	Rotation direction if fixed by parameter 1003 DIRECTION.
14	SERIAL COMM LOSS	Serial communication through Standard Modbus Channel is lost. <ul style="list-style-type: none"> Check connections between external control system and the ACS 400. Refer to parameters 5003 COMM FAULT TIME and 5004 COMM FAULT FUNC.
15 *	MODBUS EXCEPTION	Exception response is sent through Standard Modbus channel. The bus master may be sending queries which cannot be processed by the ACS 400. Refer to "Standard Serial Communication" section. Last three exception response codes are stored into parameters 5213 - 5215.
16	AI1 LOSS	Analogue input 1 loss. Analogue input 1 value is less than MINIMUM AI1 (1301). See also parameter 3001 AI<MIN FUNCTION.
17	AI2 LOSS	Analogue input 2 loss. Analogue input 2 value is less than MINIMUM AI2 (1306). See also parameter 3001 AI<MIN FUNCTION.
18	PANEL LOSS	Panel communication loss. Control panel is disconnected when <ul style="list-style-type: none"> Drive is in local control mode (LOC is shown in the control panel display), or Drive is in remote control mode (REM) and is parameterised to accept start/stop, direction or reference from the panel. Refer to parameters in groups 10 COMMAND INPUTS and 11 REFERENCE SELECT. See also parameter 3002 PANEL LOSS.
19	ACS400 OVERTEMP	ACS 400 overtemperature condition. This alarm is given when the temperature reaches 95% of the trip limit.
20	MOTOR OVERTEMP	Motor overtemperature condition as estimated by the ACS 400. Refer to parameters 3004 – 3008.
21	UNDERLOAD	Motor load is too low. Check for a problem in the driven equipment. Refer to parameters 3013 – 3015.
22	MOTOR STALL	Motor is operating in the stall region. This may be caused by excessive load or insufficient motor power. Refer to parameters 3009 – 3012.

Alarm Code	Display	Description
23	DDCS COMM LOSS	DDCS communication loss has been detected. <ul style="list-style-type: none"> • Check the status of the fieldbus adapter. Refer to appropriate fieldbus adapter manual. • Check the DDCS option module and optical fibres. • Check connections between external control system and fieldbus adapter. Refer to "DDCS Option module manual" and parameters 5003 – 5006.
24		Reserved.
25		Reserved.
26	OUTPUT OVERLOAD	Inverter overload condition. The ACS 400 output current exceeds the ratings given on page 25 of this manual.
27 *	AUTOMATIC RESET	ACS 400 is about to perform automatic fault reset operation. As a result, the drive may start after the reset operation. Refer to parameter group 31 AUTOMATIC RESET.
28 *	PID SLEEP	PID sleep function is active. The drive may accelerate when PID sleep function is deactivated. Refer to parameters 4018 SLEEP SELECTION, 4013 PID SLEEP DELAY, 4014 PID SLEEP LEVEL and 4015 WAKE-UP LEVEL.
29 *	AUTOCHANGE	The autochange function of Pump-Fan Control block is active. Refer to parameter group 81 PFC CONTROL and the appendix for more information.
30	INTERLOCK	Pump-Fan Control interlocks are active. The ACS 400 cannot start any motor (when Autochange is used), or the ACS 400 cannot start the speed regulated motor (when Autochange is not used).

* This alarm will not cause relay output RO1 (RO2) to activate when the relay output is configured to indicate alarm condition in general. (Parameter 1401 RELAY OUTPUT 1 (1402 RELAY OUTPUT 2) has value 5 (ALARM) or 13 (FLT/ALARM)).

Table 35 Faults.

Fault Code	Display	Description
1	OVERCURRENT	Output current is excessive. <ul style="list-style-type: none"> • Motor load may be too high • Acceleration time may be too short (parameters 2202 ACCELER TIME 1 and 2204 ACCELER TIME 2). • Motor or motor cable is faulty or connected wrong.
2	DC OVERVOLTAGE	Intermediate circuit DC voltage is excessive. <ul style="list-style-type: none"> • Check mains for static or transient overvoltages • Deceleration time may be too short (parameters 2203 DECELER TIME 1 and 2205 DECELER TIME 2) • Brake chopper (if present) may be underdimensioned
3	ACS400 OVERTEMP	ACS 400 heat sink temperature is excessive. Temperature trip limit is 95 °C. <ul style="list-style-type: none"> • Check air flow and fan operation. • Check motor power against unit power.
4 **	SHORT CIRCUIT	Fault current. Possible reasons for this fault are: <ul style="list-style-type: none"> • There is a short-circuit in the motor cable(s) or motor • Supply disturbances
5	OUTPUT OVERLOAD	Inverter overload condition. The ACS 400 output current exceeds the ratings given on page 25 of this manual.
6	DC UNDERVOLTAGE	Intermediate circuit DC voltage is not sufficient. <ul style="list-style-type: none"> • Mains phase may be missing • Fuse may be blown
7	ANALOGUE INPUT 1	Analogue input 1 loss. Analogue input value is less than MINIMUM AI1 (1301). See also parameter 3001 AI<MIN FUNCTION.
8	ANALOGUE INPUT 2	Analogue input 2 loss. Analogue input value is less than MINIMUM AI2 (1306). See also parameter 3001 AI<MIN FUNCTION.
9	MOTOR OVERTEMP	Motor overtemperature condition as estimated by the ACS 400. Refer to parameters 3004 – 3008.
10	PANEL LOSS	Panel communication loss. Control panel is disconnected when the drive is receiving start, stop and direction commands from the panel. <ul style="list-style-type: none"> - Drive is in local control mode (LOC is shown in the control panel display), or - Drive is in remote control mode (REM is shown) and is parameterised to accept start/stop, direction or reference from the panel. Refer to parameters in groups 10 COMMAND INPUTS and 11 REFERENCE SELECT. See also parameter 3002 PANEL LOSS.
11	PARAMETERING	Parameter values are inconsistent: <ul style="list-style-type: none"> • MINIMUM AI1 > MAXIMUM AI1 (parameters 1301, 1302) • MINIMUM AI2 > MAXIMUM AI2 (parameters 1304, 1305) • MINIMUM FREQ > MAXIMUM FREQ (parameters 2007, 2008) • PFC block tries to use IO extension module (NDIO) but the DDCS link is not parameterised properly
12	MOTOR STALL	Motor stall. This may be caused by excessive load or insufficient motor power. Refer to parameters 3009 – 3012.
13	SERIAL COMM LOSS	Serial communication through Standard Modbus Channel is lost. <ul style="list-style-type: none"> • Check connections between external control system and the ACS 400. • Refer to parameters 5003 COMM FAULT TIME and 5004 COMM FAULT FUNC.
14	EXTERNAL FAULT SIGNAL	External fault is active. See parameter 3003 EXTERNAL FAULT.
15 **	OUTPUT EARTH FAULT	Earth fault. The load on the incoming mains system is out of balance. <ul style="list-style-type: none"> • There may be a fault in the motor or motor cable. • Motor cable may be too long.

16 **	DC BUS RIPPLE	<ul style="list-style-type: none"> • Ripple voltages on the DC bus are too large. • Mains phase may be missing • Fuse may be blown
17	UNDERLOAD	Motor load is too low. Check for a problem in the driven equipment. Refer to parameters 3013 – 3015.
18		Reserved
19	DDCS LINK	<p>Problem with DDCS link.</p> <ul style="list-style-type: none"> • Check the DDCS option module and the optic fibres. • Check the status of the fieldbus adapter. Refer to appropriate fieldbus adapter manual. • Check connections between external control system and fieldbus adapter. • Alternatively, check the status of the IO extension modules (NDIO), required by PFC block. <p>Refer also to “DDCS Option Module Manual” and parameters 5004 – 5007.</p>
20 - 26 **	HARDWARE ERROR	Hardware error. Contact supplier.
Full display blinking (ACS100-PAN) “COMM LOSS” (ACS-PAN)		Serial link failure. Bad connection between the control panel and the ACS 400.

**** Note!** These faults are indicated by a red blinking LED and are reset by turning the power off for a while.

Appendix A

Local Control vs. Remote Control

The ACS 400 can be controlled from two remote control locations or from the control panel. Figure 65 below shows the ACS 400 control locations.

The selection between local control (**LOC**) and remote control (**REM**) can be done by pushing the MENU and ENTER buttons simultaneously when ACS100-PAN is used, and by pushing the LOC/REM button when ACS-PAN is used.




Figure 65 Control locations.

Local Control

The control commands are given explicitly from the control panel when the ACS 400 is in local control.

Parameter 1101 KEYPAD REF SEL is used to select keypad reference, which can be either REF1 (Hz) or REF2 (%). If REF1 (Hz) is selected, the type of reference is frequency and it is given to the ACS 400 in Hz. If REF2 (%) is selected, the reference is given in per cent.

If PID Control macro or PCF macro is used, reference REF2 is fed directly to the PID controller as percentage. Otherwise, reference REF2 (%) is converted to frequency so that 100 % corresponds to MAXIMUM FREQ (parameter 2008).

Remote Control

When the ACS 400 is in remote control (**REM**), the commands are given primarily through digital and analogue inputs, although commands can be given also through the control panel or serial communication.

Parameter 1102 EXT1/EXT2 SELECT selects between the two external control locations EXT1 and EXT2.

For EXT1, the source of the Start/Stop/Direction commands is defined by parameter 1001 EXT1 COMMANDS, and the reference source is defined by parameter 1103 EXT REF1 SELECT. External reference 1 is always a frequency reference.

For EXT2, the source of the Start/Stop/Direction commands is defined by parameter 1002 EXT2 COMMANDS, and the reference source is defined by parameter 1106 EXT REF2 SELECT. External reference 2 can be a frequency reference, or a process reference, depending on the application macro selected.

In remote control, constant speed operation can be programmed by parameter 1201 CONST SPEED SEL. Digital inputs can be used to select between the external frequency reference and seven configurable constant speeds (1202 CONST SPEED 1... 1208 CONST SPEED 7).




Figure 66 Selecting control location and control source.

Internal Signal Connections for the Macros




Figure 67 The control signal connections of the ABB Standard, Alternate and Premagnetise macros.




Figure 68 The control signal connections of the PID Control macro.

Appendix B

ACS 400 Pump and Fan Control (PFC) Macro

Introduction

The Pump and Fan Control (PFC) macro can operate a pump (or fan or compressor) station with one to four parallel pumps. The control principle of a two-pump station is as follows:

- The motor of the pump no. 1 is connected to the ACS 400. The capacity of the pump is controlled by varying the motor speed.
- The motor of the pump no. 2 is connected direct on-line. The pump can be switched on and off by the ACS 400 when necessary.
- The process reference and actual value are fed to the ACS 400 PID controller. The PID controller adjusts the speed (frequency) of the first pump such that the process actual value follows the reference. When the frequency reference of the process PID controller exceeds the limit set by the user, the PFC macro automatically starts the second pump. When the frequency falls below the limit set by the user, the PFC macro automatically stops the second pump.
- Using the digital inputs of the ACS 400, an interlocking function can be implemented; the PFC macro detects if a pump is switched off and starts the other pump instead.
- The PFC macro makes automatic pump alternation possible. Thus each pump can be run with an equal duty time. For more information on the alternation system and the other useful features such as Sleep function, Constant reference value, Reference steps and Regulator by-pass, see parameter group 40, 41 and 81 parameter descriptions.

As default when PFC macro is selected, ACS 400 receives process reference (setpoint) through analogue input 1, process actual value through analogue input 2 and Start/Stop commands through digital input 1. The interlocks are connected to digital input 4 (speed regulated motor) and digital input 5 (constant speed motor). Run Enable signal is received through the digital input 2 and PFC control is activated/deactivated through the digital input 3. The default output signal is given through the analogue output (frequency).

Normally the automatic Pump and Fan Control is bypassed when the ACS 400 is in local control (LOC is shown on the control panel display). In this case, process PID controller is not in use and the constant speed motors are not started. However, by selecting value 2 (REF2 (%)) for parameter 1101 KEYPAD REF SEL PFC reference can be given from the control panel in local control.




Figure 69 Operation Diagram for the Pump and Fan Control (PFC) Macro. With the default settings, automatic pump alternation is not in use.




Figure 70 In this example the automatic pump alternation is in use.




Figure 71 The control signal connections of the Pump and Fan Control (PFC) macro.

PID Controller

The ACS 400 has an internal PID controller which is in use when PFC control macro is selected. Key features of the PID controller are:

- PID sleep function to stop the regulation when the output of PID controller falls below preset limit; recovery when the process actual value falls below preset limit.
- Programmable sleep and wake-up delays. Sleep mode can also be activated through a digital input.
- Two PID parameter sets, selectable through a digital input.
- PID controller parameters are in groups 40 and 41.

Relay Outputs

The ACS 400 has two programmable relay outputs. Relay output 1 and 2 operation is configured by parameters 1401 RELAY OUTPUT 1 and 1402 RELAY OUTPUT 2. Value 29 (PFC) allocates the relay output for Pump and Fan Control block. This is the default setting for both relay outputs when PFC macro is selected.

Adding More I/O to ACS 400

When Pump and Fan control is used, the ACS 400 is capable of using optional I/O extension modules (NDIO). These modules provide additional relay outputs and digital inputs. I/O extensioning is needed

- When the standard relay outputs of the ACS 400 (RO1 and RO2) are needed for other purposes and/or number of auxiliary motors is large, and
- When the standard digital inputs of the ACS 400 (DI1 - DI5) are needed for other purposes and/or number of interlock signals (auxiliary motors) is large.

I/O extension modules are connected to the ACS 400 via a DDCS fibre optic link. An optional DDCS communication module is needed to use DDCS.

There can be either one or two NDIO modules on the DDCS link. Each NDIO module contains two digital inputs and two relay outputs.

Setting up NDIO modules

Refer to the Installation and Start-up Guide of the NDIO module for installation instructions. After installation, the communication between the ACS 400 and NDIO modules is set up as follows:

- Set the module node numbers using the DIP switches located inside the modules. Refer to NDIO module manual for details. Module node number must be 5 if only one NDIO module is used. Node numbers must be 5 and 6 if two NDIO modules are used.
- Connect power to NDIO modules.
- Activate DDCS protocol by setting parameter 5005 PROTOCOL SEL to 1 (DDCS).
- Tell the ACS 400 that extended I/O is used by setting parameter 5007 DDCS BUS MODE to 2 (EXTENDED IO). Communication between the ACS 400 and the NDIO module(s) is now operating.

Alternation Switchgear

PFC autochange operation (set by parameters 8118 AUTOCHNG INTERV and 8119 AUTOCHNG LEVEL) requires dedicated alternation switchgear which is controlled through the relay outputs of the ACS 400. Contact your nearest ABB supplier for more information.



ABB Industry Oy
P.O. Box 184
00381 Helsinki
FINLAND
Telephone +358-10-222 000
Telefax +358-10-222 2681

3AFY 64036947 R0125 REV A

EN

Effective: 25.5.1999

© 1999 ABB Industry Oy

Subject to change without prior notice.