GE Consumer & Industrial Power Protection



VAT300

GP AC Drive User Manual



GE imagination at work



GE Consumer & Industrial

GE AC SPEED CONTROL EQUIPMENT VAT300 200V System 0.75 to 45 kW Normal Duty 400V System 0.75 to 475 kW Normal Duty INSTRUCTION MANUAL

NOTICE

- 1. Read this manual thoroughly before using the VAT300, and store in a safe place for reference.
- 2. Make sure that this manual is delivered to the final user.

GE Consumer & Industrial

Contents

Preface	9	iii
PRECA	UTIONS FOR SAFETY	iv
<name< th=""><th>s of each part></th><th> viii</th></name<>	s of each part>	viii
Ohanta	nd Delivery benestion and Ctonego	
Chapte	r 1 Delivery inspection and Storage	1-1
1-1	Delivery inspection and storage	1-1
1-2	Details of rating nameplate and type display method	1-1
Chapte	r 2 Installation and Wiring	2-1
2-1	Installation environment	2-1
2-2	Installation and wiring method	
2-3	Precautions for power supply and motor wiring	
2-4	Precautions for wiring to the control signal	2-16
Chapte	r 3 Test Operation and Adjustment	3-1
3-1	Flow of test operation	3-2
3-2	Preparation before turning power ON	3-3
3-3	Control modes	3-4
3-4	Automatic tuning and test operation	3-5
Chante	r 4 Operation Banel	1_1
	Outline of operation panel types and functions	4 -1
 /2	Various operations and displays when LCD panel is connected	
4-2 1_3	Various operations and displays when LED panel is connected	4 -0
4-J 1 1	Customizing block B. C parameter	1 25
4-4	Changing modes	4-27
Chapte	r 5 Control Input/Output	5-1
5-1	Input/output terminal function	5-1
5-2	Control input/output circuit	5-2
5-3	Programmable sequence input function (PSI)	5-3
5-4	Programmable sequence output function (PSO)	5-8
5-5	Sequence input logic	5-9
5-6	Changing of terminal functions	5-10
5-7	Programmable input function (PI)	5-12
5-8	Programmable output function (P0)	5-16
5-9	Selecting the setting data	5-20
Chanta	r 6 Control Eurotions and Parameter Sottings	6_1
	Monitor parameters	0-1
6_2	Block-A parameters	0-1 6_8
6-3	Block-R parameters	0-0 6_10
6_1	Block-C parameters	6_12
6.5	Block-U parameters	6_61
0-0 6_6	Function explanation	0-01 6_77
67	Setting the overload mode	6.171
6_R	Adjusting the IM vector control speed control related parameters	6-173
0-0 6_0	Adjusting the PM motor control system parameters	6-179
0-0	Auguoting the Fill motor control system parameters	

6-10	Operating the auxiliary drive motor	6-186
6-11	Built-in PLC Function.	6-189
6-12	Explanation of standard serial and Modbus communication	6-196
6-13	ROM revisions	6-229
Chapter	7 Options	7-1
7-1	Outline of options	7-1
7-2	Built-in PCB option	7-5
7-3	Dynamic braking (DB) option	7-7
7-4	ACL and DCL	7-11
7-5	EMI filter	7-19
Chapter	8 Maintenance and Inspection	8-1
8-1	Inspection items	8-1
8-2	Measuring devices	8-4
8-3	Protective functions	8-5
8-4	Troubleshooting with fault display	8-6
8-5	Troubleshooting with no fault display	8-15
Chanta	0 Compatible Standarda	0.1
	9 Compatible Standards	9-1
9-1	UL/CUL Standards	9-1
9-2	CE Marking	9-5
Append	ix 1 Type Description System	A-1
Append	ix 2 Outline Dimension Drawings	A-10
Append	ix 3 Fault Codes	Δ-12
Append	ix 4. Display Messages	A-14
Append	ix 5. Segment LED Display	A-15
, ppond		
Revisio	n history	R-1

Preface

Thank you for purchasing the "GE AC Speed Control Equipment VAT300". VAT300 is a highly functional inverter that is easy to use.

Please read this manual thoroughly before use, and keep the manual at hand for later reference. Also make sure that this manual is delivered to the final users.

WARNING

ALWAYS READ THIS MANUAL THOROUGHLY BEFORE USING THE VAT300.

THIS INVERTER CONTAINS HIGH VOLTAGE CIRCUITS THAT MAY BE FATAL TO HUMANS. USE EXTREME CAUTION DURING INSTALLATION. MAINTENANCE MUST BE PERFORMED BY QUALIFIED TECHNICIANS, AND ALL POWER SOURCES MUST BE DISCONNECTED BEFORE ANY MAINTENANCE. SUFFICIENT NOTICE MUST BE GIVEN TO THE GENERAL OPERATORS AND WORKERS BEFORE STARTING.

• ELECTRIC SHOCK MAY OCCUR IF THE FOLLOWING POINTS ARE NOT OBSERVED.

(1) DO NOT OPEN THE FRONT COVER WHILE THE POWER IS ON.

- (2) A CHARGE STILL REMAINS IN THE INVERTER WHILE THE INDICATOR IS LIT EVEN IF THE POWER HAS BEEN TURNED OFF. DO NOT OPEN THE FRONT COVER IN THIS CASE. WAIT AT LEAST 10 MINUTES AFTER THE INDICATOR GOES OUT.
- (3) DO NOT CONTACT THE ELECTRICAL CIRCUIT WHILE THE "CHARGE" LED ON THE UNIT IS LIT. PERFORM SERVICING, ETC., AFTER WAITING AT LEAST 10 MINUTES AFTER THE LAMP GOES OUT.
- (4) ALWAYS GROUND THE INVERTER CASE. THE GROUNDING METHOD MUST COMPLY WITH THE LAWS OF THE COUNTRY WHERE THE INVERTER IS BEING INSTALLED.
- THE INVERTER MAY BE DESTROYED BEYOND REPAIR IF THE FOLLOWING POINTS ARE NOT OBSERVED.
 - (1) OBSERVE THE INVERTER SPECIFICATIONS.
 - (2) CONNECT ADEQUATE CABLES TO THE INPUT/OUTPUT TERMINALS.
 - (3) ALWAYS KEEP THE INVERTER INTAKE/OUTTAKE PORTS CLEAN, AND PROVIDE ENOUGH VENTILATION.
 - (4) ALWAYS OBSERVE THE CAUTIONS LISTED IN THIS INSTRUCTION MANUAL.
- THERE MAY BE SOURCES OF NOISE AROUND THIS INVERTER AND MOTOR DRIVEN BY THIS INVERTER. CONSIDER THE POWER SUPPLY SYSTEM, INSTALLATION PLACE AND WIRING METHOD BEFORE INSTALLATION.
 INSTALL THIS INVERTER AWAY FROM DEVICES THAT HANDLE MINUTE SIGNALS, SUCH AS MEDICAL EQUIPMENT IN PARTICULAR. ALSO SEPARATE THE DEVICES ELECTRICALLY, AND TAKE SUFFICIENT NOISE MEASURES.
- TAKE SUFFICIENT SAFETY MEASURES WHEN USING THIS INVERTER FOR PASSENGER TRANSPORTATION, SUCH AS IN LIFTS (ELEVATORS).
- PRODUCT LIFE MAY DECREASE WHEN APPLIED IN HIGH TEMPERATURE ENVIRONMENTS, OR IN SPECIFIC APPLICATIONS WITH FREQUENT CURRENT OVERLOADS LIKE ELEVATORS, CRANES, ETC.
 IN SUCH APPLICATIONS, COUNTERMEASURES LIKE DERATING THE VAT300, LIMITING CURRENTS AT STARTING OR STOPPING, OR LOWERING CARRIER FREQUENCY ARE NEEDED. PLEASE ASK YOUR DEALER FOR SPECIFIC DETAILS.

PRECAUTIONS FOR SAFETY

Items to be observed to prevent physical damage or property damage and to ensure safe use of this product are noted on the product and in this instruction manual.

- Please read this instruction manual and enclosed documents before starting operation to ensure correct usage. Thoroughly understand the device, safety information and precautions before starting operation. After reading, always store this manual where it can be accessed easily.
- The safety precautions are ranked as "DANGER" and "CAUTION" in this instruction manual.



: When a dangerous situation may occur if handling is mistaken leading to fatal or major injuries.

: When a dangerous situation may occur if handling is mistaken leading to medium or minor injuries, or physical damage.

Note that some items described as

CAUTION may lead to major results depending on the

situation. In any case, important information that must be observed is described.

• This instruction manual is written on the premise that the user has an understanding of the inverter. Installation, operation, maintenance and inspection of this product must be done by a qualified person. Even qualified persons must undergo periodic training.

Qualified refers to satisfying the following conditions.

- The person has thoroughly read and understood this instruction manual.
- The person is well versed in the installation, operation, maintenance and inspection of this product, and understands the possible dangers.
- The person is informed on matters related to starting, stopping, installation, locks and tag displays, and has been trained in the operation and remedies.
- o The person has been trained on the maintenance, inspection and repairs of this product.
- o The person has been trained on protective tools used to ensure safety.

1. Transportation and installation

•	Always transport the product with an appropriate amount according to the products weight.
•	Failure to observe this could lead to injuries. Install the inverter, dynamic braking unit and resistor, and other peripheral devices on
	non-combustible material such as metal.
•	Failure to observe this could lead to fires.
	Failure to observe this could lead to fires.
•	Do not hold the front cover while transporting the product.
•	Do not let conductive materials such as screws or metal pieces and inflammable materials such as oil enter the product.
	Failure to observe this could lead to fires.
•	Install the product in a place that can withstand the weight of the product, and follow the instruction manual
	Failure to do so could lead to injuries from dropping.
•	Do not install and operate an inverter that is damaged or that has missing parts.
•	Always observe the conditions described in the instruction manual for the installation environment. Failure to observe this could lead to faults.
2	Wiring

2. Wiring

•	 Always turn the device's input power OFF before starting wiring. Failure to do so could lead to electric shocks or fires. Carry out grounding that complies with the standards of the country where the inverter is being installed. Failure to do so could lead to electric shocks or fires. When using the PM motor, even if the inverter is stopped, the voltage will be generated at the output terminal (U, V, W) during rotation. Always carry out wiring while the motor is stopped. Failure to do so could lead to electric shocks or injuries. Wiring must always be done by a qualified electrician. Failure to observe this could lead to electric shocks or fires. 						
•	Always install the device before starting wiring. Failure to do so could lead to electric shocks or injuries. Prepare a breaker such as an MCCB or fuses that matches the capacity for the inverter's power supply side. Failure to do so could lead to fires.						
•	Do not connect an AC power supply to the output terminals (U, V, W). Failure to observe this could lead to injuries or fires. Confirm that the product's rated voltage and frequency match the power supply voltage and frequency. Failure to do so could lead to injuries or fires. Install an overheating protection device on the dynamic braking unit and resistor, and shut off the power with this fault signal. Failure to do so could lead to fires in the event of abnormal overheating. Do not directly connect a resistor to the DC terminals (between L+1, L+2, and L–). Failure to observe this could lead to fires. Tighten the terminal screws with the designated tightening torque.						

- ٠
- Correctly connect the output side (U, V, W). Failure to do so could cause the motor to rotate in reverse and the machine to be damaged. Always correctly connect when using the encoder. The signal polarity specifications differ according to the encoder. Refer to sections 3-4-2 (4) and 3-4-3(1) on test operation, and adjust the signal polarity with the parameter settings (C50, C51). Failure to observe this could lead to reverse rotation or abnormal acceleration of the motor, and to injuries or machine damage injuries or machine damage.

3. Operation



- The heat sink and dynamic braking resistor are heated to high temperatures, so never touch them. Failure to observe this could lead to burns.
- Do not block the inverter's ventilation holes. Failure to observe this could lead to fires.
- The inverter operation can easily be set from low speeds to high speeds, so confirm that the operation is within the tolerable range for the motor or machine before making settings. Failure to do so could lead to injuries.
- Prepare holding brakes when necessary. Holding is not possible with the inverter's brake functions. Failure to do so could lead to injuries.
- Confirm the operation of the motor as a single unit before operating the machine.
 Failure to do so could lead to injuries or machine damage due to unforeseen movements.
 Always prepare a safety backup device so that the machine is not placed in a hazardous situation when an error occurs in the inverter.

Failure to do so could lead to injuries or machine damage or fires.

4. Maintenance, inspection and part replacement

•	Always wait at least 10 minutes after turning the input power OFF before starting inspections. Wait at least 10 minutes after turning the input power OFF before starting work. Make sure that the displays on the operation panel have gone out before removing the front cover. Remove the front cover, and confirm that the "CHARGE" LED on the unit has gone out. Also check that the voltage between terminals L+1 or L+2 and L– is 15V or less before starting the inspections. (Check with the "CHARGE" LED if the unit is not provided with the L– terminal.) Failure to observe this could lead to electric shocks. Maintenance, inspections and part replacement must be done by a designated person. (Remove all metal accessories such as watches, bracelets, etc., before starting the work.) (Always use an insulation measure tool.) Failure to observe this could lead to electric shocks and injuries. Always turn the power OFF before inspecting the motor or machine. A potential is applied on the motor terminal even when the motor is stopped. Failure to do so could lead to electric shocks and injuries. Do not use parts other than those designated for the replacement parts. Contact your inverter dealer for replacement parts. Failure to observe this could lead to fires.



• Vacuum the inverter with a vacuum cleaner to clean it. Do not use water or organic solvents. Failure to observe this could lead to fires or damage.

5. Others



• Never modify the product. Failure to observe this could lead to electric shocks or injuries.



• Dispose of this product as industrial waste.

<Names of each part>





Chapter 1 Delivery Inspection and Storage

1-1 Delivery inspection and storage

- (1) Remove the inverter from the packaging, and check the details on the rating nameplate to confirm that the inverter is as ordered. The rating nameplate is on the left side of the unit.
- (2) Confirm that the product has not been damaged.
- (3) If the inverter is not to be used for a while after purchasing, store it in a place with no humidity or vibration in the packaged state.
- (4) Always inspect the inverter before using after storing for a long period. (Refer to 8-1.)

1-2 Details of rating nameplate and type display method



(1) The following details are listed on the rating nameplate.

(Note 1) Refer to Chapter 9 for details on UL Instruction.

(2) Using the above type as an example, the type is displayed as follows:



Chapter 2 Installation and Wiring



2-1 Installation environment

Observe the following points when installing the inverter.

- (1) Install the inverter vertically so that the cable lead-in holes face downward.
- (2) Make sure that the ambient temperature is -10° C to 50° C. (Refer to Appendix 1.)
- (3) Avoid installation in the following environment.





(4) Ensure ventilation space around the inverter. (Refer to Fig. 2-1.)



For N018K5, X030K0 and smaller

50mm



Fig. 2-1

2-2 Installation and wiring method

Installation and wiring for the N018K5S and X030K0 and below, and the wiring for the N022K0 and X037K0 and above are carried out with the front cover removed. The operation panel is fixed with the latches for the operation panel mounting holder, so the front cover can be removed with the operation panel attached.

To remove the operation panel, securely hold the panel with a thumb on the lower side and another finger on the top side as shown in Fig. 2-2-a, and pull the panel forward and off. To mount the operation panel, hold it the top and bottom sides with five fingers, and press the panel on horizontally. Confirm that the operation panel is securely fixed with the latches for the operation panel mounting holder.

The operation panel mounting holder opens and closes with the right side as a base point as shown in Fig. 2-2-b. When wiring to the control terminal block, open the left side of the main body case outward, and open the folder to 90°. When closing after wiring, confirm that the jaw on the left end of the holder is securely fit into the hole on the main body case.



(1) N018K5S, X030K0 and smaller (Fig. 2-2-c)

Fix the VAT300 at four places when installing. The lower two installation sections are notched. Remove the front cover, and wire to the main circuit and control terminal block.



Fig. 2-2-c

(2) N022K0, X037K0 and larger (Fig. 2-2-d)

Fix the VAT300 at four places when installing. The VAT300 mass is more than 25kg, so installation by two workers is recommended. When two workers are installing the unit, they should confirm each step with signals. Wire in the same manner as step (1).



Fig. 2-2-d

Δ

2-3 Precautions for power supply and motor wiring

• • •	Always turn the device's input power OFF before starting wiring. Failure to do so could lead to electric shocks or fires. Carry out grounding that complies with the standards of the country where the inverter is being installed. Failure to do so could lead to electric shocks or fires. When using the PM motor, even if the inverter is stopped, the voltage will be generated at the output terminal (U, V, W) during rotation. Always carry out wiring while the motor is stopped. Failure to do so could lead to electric shocks or injuries. Wiring must always be done by a qualified electrician. Failure to observe this could lead to electric shocks or fires. Always install the device before starting wiring. Failure to do so could lead to electric shocks or injuries. Prepare a breaker such as a Molded Case Circuit Breaker(MCCB) or fuse that matches the capacity for the inverter's power supply side. Failure to do so could lead to fires.
•	Do not connect an AC power supply to the output terminals (U, V, W). Failure to observe this could lead to injuries or fires. Confirm that the product's rated voltage and frequency match the power supply voltage and frequency. Failure to do so could lead to injuries or fires. Install an overheating protection device on the dynamic braking resistor, and shut off the power with an error signal.

- Failure to do so could lead to fires in the event of abnormal overheating.
- Do not directly connect a resistor to the DC terminals (between L+1, L+2 and L–).
 Failure to observe this could lead to fires.
- Tighten the terminal screws with the designated tightening torque. Failure to do so could lead to fires.
- Correctly connect the output side (U, V, W).
 Failure to observe this could lead to reverse rotation of the motor, and to injuries or machine damage.
- · Always correctly connect when using the encoder.

The signal polarity specifications differ according to the encoder. Refer to sections 3-4-2 (4) and 3-4-3(1) on test operation, and adjust the signal polarity with the parameter settings (C50, C51). Failure to observe this could lead to reverse rotation or abnormal acceleration of the motor, and to injuries or machine damage.

Refer to Fig. 2-3-a and wire the main circuits for the power supply and motor, etc. Always observe the following precautions for wiring.



There is a risk of electric shocks.

The VAT300 has a built-in electrolytic capacitor, so a charge will remain even when the inverter power is turned OFF. Always observe the followings before carrying out wiring work.

- Wait at least 10 minutes after turning the power OFF before starting work. Make sure that the displays on the operation panel have gone out before removing the cover.
- After removing the cover, confirm that the "CHARGE" LED in the unit has gone out. Also check that the voltage between terminals L+1 or L+2 and L– is 15V or less before starting the wiring work. (Check with the "CHARGE" LED if the unit is not provided with the L– terminal.)



(a) N018K5, X022K0 and smaller

(b) N022K0 to N045K0, X030K0 to X055K0







Fig. 2-3-a Example of main circuit wiring

(Note 1) Configuration of inverter's main circuit

The inverter input terminals are L1, L2 and L3. The output terminals to the motor are U, V and W. Do not connect the power supply to the U, V, W terminals. Incorrect wiring will lead to inverter damage or fires.

The VAT300 main circuit configuration is largely divided into three types according to the capacity zone.

(1) The first type is the N011K0/X015K0 and smaller capacities. The L+1 and L+2 terminals are located in the step before the pre-charge circuit. The DB circuit is built-in, and the use of the built-in DB resistor can be selected with options. The use of the built-in EMI filter can also be selected with options. Note that the external EMI filter must be used for the N007K5 and N011K0 capacity. With the N011K0/X015K0 and smaller capacity, the L+2 and L- terminals for connecting

the PWM converter are provided as a standard. Contact the inverter dealer when using the PWM converter.

- (2) The second type is the N015K0, N018K5/X018K5, and X022K0 capacities. The L+1 and L+2 terminals are located in the step after the pre-charge circuit. The DB circuit is built-in, but the DB resistor must be prepared by the customer. With the X018K5 and X022K0 capacities, the use can be selected with the built-in EMI filter options. Use an external EMI filter with the N015K0 and N018K5 capacities.
- (3) The third type is the N022K0/X030K0 and larger capacities. The L+1 and L+2 terminals are located in the step after the pre-charge circuit. The built-in DCL can be selected as an option. A standalone DCL can also be selected. With the X030K0, the use of the built-in EMI filter can be selected with options. Use an external EMI filter with the N022K0/X037K0 and larger capacities.



*1) Incompatible with N007K5 and N011K0

(1) N011K0/X015K0 and smaller capacities





*3) Only standalone type is available for X030K0*4) Only compatible with X030K0

(3) N022K0/X030K0 and larger capacities

(Note 2) Wire size

Use wires having the wire size shown in Table 2-3-a and Table 2-3-b for the main circuit wiring shown in Fig. 2-3-a.

Table 2-3 gives the screw sizes, applicable wire sizes and tightening torque for the main circuit terminal shown in Fig. 2-3-b.

		Power supply, motor, DCL wiring				Dynamic braking wiring					
Inverter type VAT300 U3S_		Terminal	Wire size		Tightening torque		Terminal	Wire size		Tightening torque	
		screw size	AWG	mm²	N•m	lb-in	screw size	AWG	mm²	N • m	lb-in
Ν	1000K7	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
Ν	1001K5	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
Ν	1002K2	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
Ν	1004K0	M4	10	5.3	1.8	15.9	M4	14	2.1	1.8	15.9
Ν	1005K5	M4	8	8.4	1.8	15.9	M4	14	2.1	1.8	15.9
Ν	1007K5	M5	8	8.4	3.0	26.5	M5	14	2.1	3.0	26.5
N	1011K0	M5	6	13.3	3.0	26.5	M5	14	2.1	3.0	26.5
N	1015K0	M6	3	26.7	4.5	39.8	M6	14	2.1	4.5	39.8
N	1018K5	M8	2	33.6	9.0	79.7	M8	12	3.3	9.0	79.7
N	1022K0	M8	1	42.4	9.0	79.7	M8	10	5.3	9.0	79.7
N	1030K0	M8	1/0×2P	53.5×2P	9.0	79.7	M8	10	5.3	9.0	79.7
Ν	1037K0	M10	1/0×2P	53.5×2P	10.0	88.5	M5 (L-) M10 (L+2)	6	13.3	2.0 28.9	17.4 255.7
Ν	1045K0	M10	1/0×2P	53.5×2P	10.0	88.5	M5 (L-) M10 (L+2)	6	13.3	2.0 28.9	17.4 255.7
×	(000K7	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
X	(001K5	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
×	(002K2	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
×	(004K0	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
×	(005K5	M4	12	3.3	1.8	15.9	M4	14	2.1	1.8	15.9
×	(007K5	M4	10	5.3	1.8	15.9	M4	14	2.1	1.8	15.9
×	(011K0	M4	8	8.4	1.8	15.9	M4	14	2.1	1.8	15.9
X	(015K0	M5	8	8.4	3.0	26.5	M5	14	2.1	3.0	26.5
X	(018K5	M5	6	13.3	2.0	17.4	M5	14	2.1	2.0	17.4
×	(022K0	M5	6	13.3	2.0	17.4	M5	14	2.1	2.0	17.4
×	(030K0	M6	4	21.2	4.5	39.8	M6	12	3.3	4.5	39.8
×	(037K0	M8	2	33.6	9.0	79.7	M8	10	5.3	9.0	79.7
×	(045K0	M8	1	42.4	9.0	79.7	M8	6	13.3	9.0	79.7
×	(055K0	M8	1/0	53.5	9.0	79.7	M8	6	13.3	9.0	79.7
×	(075K0	M10	1/0×2P	53.5×2P	28.9	255.7	M10	6	13.3	28.9	255.7
×	(090K0	M10	1/0×2P	53.5×2P	28.9	255.7	M10	6	13.3	28.9	255.7
X	(110K0	M10	1/0×2P	53.5×2P	28.9	255.7	M10	6	13.3	28.9	255.7
X132	Power supply	M10	3/0×2P	85.0×2P	28.9	255 7	M10	6	13 3	28.9	255 7
K0	Motor		2/0×2P	67.4×2P	2010			Ū.		_0.0	
×	(160K0	M10	4/0×2P	107.2×2P	28.9	255.7	M10	6	13.3	28.9	255.7
X200K0		M10	300×2P	152×2P	28.9	255.7	M10	6	13.3	28.9	255.7
×	(250K0	M16	400×2P	203×2P	125	1106	M16	4	21.2	125	1106
X315	Power supply	M16	300×4P	152×4P	125	1106	M16	1	21.2	125	1106
K0	Motor		4/0×4P	107.2×4P	120	1100	IVI I O	4	Z1.Z	120	1100
X400 K0	Power supply Motor	M16	400×4P 350×4P	203×4P 177×4P	125	1106	M16	4	21.2	125	1106
×	(475K0	M16	400×4P	203×4P	125	1106	M16	4	21.2	125	1106

Table 2-3-a Terminal and applicable wire (for normal-duty)

		Power supply, motor, DCL wiring				Dynamic braking wiring					
Inverter type VAT300-□		Terminal	Wire size		Tightening torque		Terminal	Wire size		Tightening torque	
		screw size	AWG	mm²	N•m	lb-in	screw	AWG	mm²	N • m	lb-in
1	N000K7	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
1	N001K5	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
1	N002K2	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
1	N004K0	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
1	N005K5	M4	10	5.3	1.8	15.9	M4	14	2.1	1.8	15.9
1	N007K5	M5	8	8.4	3.0	26.5	M5	14	2.1	3.0	26.5
1	N011K0	M5	8	8.4	3.0	26.5	M5	14	2.1	3.0	26.5
1	N015K0	M6	6	13.3	4.5	39.8	M6	14	2.1	4.5	39.8
1	N018K5	M8	3	26.7	9.0	79.7	M8	14	2.1	9.0	79.7
1	N022K0	M8	2	33.6	9.0	79.7	M8	12	3.3	9.0	79.7
1	N030K0	M8	1	42.4	9.0	79.7	M8	10	5.3	9.0	79.7
1	N037K0	M10	1/0×2P	53.5×2P	10.0	88.5	M5 (L-) M10 (L+2)	10	5.3	2.0 28.9	17.4 255.7
1	N045K0	M10	1/0×2P	53.5×2P	10.0	88.5	M5 (L-) M10 (L+2)	6	13.3	2.0 28.9	17.4 255.7
)	X000K7	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
)	X001K5	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
)	X002K2	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
)	X004K0	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
)	X005K5	M4	14	2.1	1.8	15.9	M4	14	2.1	1.8	15.9
)	X007K5	M4	12	3.3	1.8	15.9	M4	14	2.1	1.8	15.9
)	X011K0	M4	10	5.3	1.8	15.9	M4	14	2.1	1.8	15.9
)	X015K0	M5	8	8.4	3.0	26.5	M5	14	2.1	3.0	26.5
)	X018K5	M5	8	8.4	2.0	17.4	M5	14	2.1	2.0	17.4
)	X022K0	M5	6	13.3	2.0	17.4	M5	14	2.1	2.0	17.4
)	X030K0	M6	6	13.3	4.5	39.8	M6	14	2.1	4.5	39.8
)	X037K0	M8	4	21.2	9.0	79.7	M8	12	3.3	9.0	79.7
)	X045K0	M8	2	33.6	9.0	79.7	M8	10	5.3	9.0	79.7
2	X055K0	M8	1	42.4	9.0	79.7	M8	6	13.3	9.0	79.7
2	X075K0	M10	1/0	53.5	28.9	255.7	M10	6	13.3	28.9	255.7
)	X090K0	M10	1/0×2P	53.5×2P	28.9	255.7	M10	6	13.3	28.9	255.7
)	X110K0	M10	1/0×2P	53.5×2P	28.9	255.7	M10	6	13.3	28.9	255.7
2	X132K0	M10	1/0×2P	53.5×2P	28.9	255.7	M10	6	13.3	28.9	255.7
X160	Power supply	M10	3/0×2P	85.0×2P	28.0	255.7	M10	6	12.2	28.0	255.7
K0	Motor	WITO	2/0×2P	67.4×2P	20.9	255.7	IVI I O	0	15.5	20.9	255.7
)	X200K0	M10	4/0×2P	107.2×2P	28.9	255.7	M10	6	13.3	28.9	255.7
)	X250K0	M16	300×2P	152×2P	125	1106	M16	6	13.3	125	1106
X315K0		M16	400×2P	203×2P	125	1106	M16	4	21.2	125	1106
X400	Power supply	M40	300×4P	152×4P	105	1100	M40	A	01.0	105	1100
K0	Motor	IVI 16	4/0×4P	107.2×4P	125	1106	IVI 16	4	21.2	125	1106
X475	Power supply	M16	400×4P	203×4P	125	1106	M16	4	21.2	125	1106
K0	Motor	WITO	350×4P	177×4P	120	1100	WITO	-	21.2	120	1100

 Table 2-3-b
 Terminal and applicable wire (for heavy-duty)

(Note 3) Breaker for wiring

Install a Molded Case Circuit Breaker(MCCB), fuse or magnetic contact (MC) on the inverter's power supply side. Refer to Table 7-1-b and select the MCCB or Fuses.

When using as a UL/cUL Standard certified product, install the UL certified fuse as explained in section 9-1.

(Note 4) Selection of power voltage for auxiliary equipment power supply

For the 400V Series (X075K0 and larger), switch the auxiliary equipment power supply selection connector according to the rated voltage of the power being used. If the following settings do not apply to the power voltage being used, select the closest power voltage.

For 380V to 415V, short circuit across JP-1

For 416V to 460V, short circuit across JP-2

For 461V to 480V, short circuit across JP-3 (factory setting state)



(Note 5) Power voltage/frequency

Prepare the power supply to match the following power voltage and frequency.

Voltage system	Туре	Power voltage	Frequency
L series	N000K7 to N011K0	200 to 240V ± 10%	50/60Hz ± 5%
	N015K0 to N045K0	200 to 230V ± 10%	50/60Hz ± 5%
H series	X000K7 to X475K0	380 to 480V ± 10%	50/60Hz ± 5%

(Note 6) Power supply capacity

Make sure that capacity of the transformer used as the inverter's power supply is within the following range. (For 4% impedance transformer)

Heavy-duty rating (N045K0, X055K0 and smaller) 500kVA or less

Heavy-duty rating (X075K0 and larger), Normal-duty Capacity that is 10-times or less inverter capacity

If the above values are exceeded, install an ACL on the inverter's input side. (Refer to Table 7-1-b.)

(Note 7) Noise measures

The inverter will generate high harmonic electromagnetic noise, so using the following noise measures is recommended.

- a) Insert an EMC filter on the input side of the inverter. Refer to Table 7-1-b and select the EMC filter. A unit with built-in noise filter is available as an option.
- b) Keep the length of the wire between the EMC filter and inverter as short as possible, and wire it as far away from the noise filter's power supply side.
- c) Use a shield cable for the inverter and motor wiring, and connect the shield to the inverter's 🕀 terminal and motor grounding terminal. Note that if the cable is long, the higher harmonic leakage current may increase, the overcurrent limit function may malfunction, and in extreme cases, the current detector in the unit could be damaged. In this case, lower the carrier frequency as low as possible, and increase the inverter capacity as required.
- d) Separate the main circuit wiring from the control circuit wiring. Do not place the wires in the same conduit, lay them in parallel or bundle them, etc. If the wires must be laid in parallel, separate them by 30cm or more, and pass each through a metal conduit. If the wires need to be intersected, make sure that they intersect at a right angle.

(Note 8) Inverter output

- a) Do not insert a power factor improvement capacitor on the output side of the inverter.
- b) When inserting a magnetic contactor on the output side of the inverter, prepare a sequence control circuit so that the magnetic contactor will not open and close when the inverter runs.
- c) Directly connect the motor to the inverter's load. Do not connect relay it through a transformer or Slidac, etc.

(Note 9) Grounding

Always ground the inverter unit grounding terminal and the ground. Ground according to the regulations of the country where the inverter is being used.

(Note 10) Inverter output surge voltage (For 400V series)

If the wiring between the inverter and motor is long (20m or more), the surge voltage applied on the motor will increase, and the motor insulation could deteriorate. In this case, lower the carrier frequency as low as possible (4kHz or less), and use a motor with reinforced insulation for inverter drive, or connect a surge absorber dedicated for the inverter output.

(Note 11) DCL

Always short circuit across L+1 and L+2 when not using the DCL. (Factory setting state) When connecting the optional DCL, connect it to L+1 and L+2. Always remove the short-circuit bar at this time. Twist the wiring to DCL, and keep it as short as possible.

(Note 12) DB (Dynamic Braking) unit (N022K0, X030K0 or more)

When connecting the optional DB unit, follow Fig. 2-3-a (b) (c) and connect the L+2 and L–. The DB unit and inverter unit will both be damaged if the connection is incorrect. Twist the wiring to the DB unit, and keep it as short as possible (3m or less). Refer to Section 7-3 for details.

(Note 13) DB resistor protection

When using the thermal relay(76D) or the optional DB unit, use the overload detection reply of the DB unit in order to protect the DB unit and the inverter unit. For the details, please refer to section 7-3.

(Note 14) Installation of surge absorber

Install a surge absorber on the magnetic contactor and relay coils installed near the inverter.

(Note 15) L- terminal

N015K0,N018K5,X018K0 and X022K0 doesn't mount L- terminal.

(a) N000K7 to N011K0 X000K7 to X015K0 (b) X018K5, X022K0



(c) N015K0







Fig. 2-3-b Terminal block wiring

(d) X030K0





(h) X075K0, X090K0





Fig. 2-3-b (cont.) Terminal block wiring

(j) X160K0, X200K0



(k) X250K0





Fig. 2-3-b (cont.) Terminal block wiring

2-4 Precautions for wiring to the control signal

- (1) When wiring (control circuit wiring) to the control terminal block, separate the main circuit wiring (terminals L1, L2, L3, L+1, L+2, L–, B, U, V, W) and the other drive wires and power wires. Do not place the wires in the same conduit, lay them in parallel or bundle them, etc.
- (2) Use a 0.13 to 0.8mm² wire for wiring to the control circuit. In this case, tighten TB1 and TB2 with a 0.6N·m tightening torque. The TB3 tightening torque must be 0.25N·m.
- (3) The length of the sequence input/output contact wire must be 30m or less.
- (4) The sequence output PSO3 can output the pulse output (max.: 6kHz) by changing DS1-4 and setting the pulse output.When using the speed detection option, do not set the pulse output if using the pulse output function provided with the option.
- (5) Use a twisted pair wire or twisted pair shield wire for wiring to the analog signal circuit such as the setters and meter. (Refer to Fig. 2-4-a.) Connect the shield wire to the TB1 COM terminal of the VAT300. The wire length must be 30m or less.
- (6) The analog output is dedicated for the indicators such as the speedometer and ammeter. It cannot be used for control signals such as the feedback control.
- (7) RY24 and RY0 are designed exclusively for the drive's internal sequence circuits. These are not designed to supply power to any external devices.
- (8) After wiring, always check the mutual wiring.
 - At this time do not carry out a megger check or buzzer check on the control circuit.
 - Are there any wire scraps or foreign matter left around the terminals?
 - Are any screws loose?
 - Is the wiring correct?
 - Is any terminal contacting any other terminal?
 - Is the setting of the EL-BIT and the dip switch correct?



(Notes)

Fig. 2-4-a

- Four COM terminals are internally connected.
- 2. No connection shall be made between RY0, COM and 0VOP since this section is insulated.
- 3. This diagram is an example of the sink logic connection.
- 4. RY24 and RY0 must not be shorted.
- 5. P10 and COM must not be shorted.





- 1) Control terminal TB1,TB2
 - The terminal block is laid out in two rows.
 - Terminal screw size is M3.

2) Dip switches DS1

No.	OFF	ON	Signal	
1	OPEN	120Ω	Standard serial terminator changeover	All switches are
2	V1	1	Al1 voltage, current changeover	set to OFF as the
3	V2	12	Al2 voltage, current changeover	default.
4	PS03	PULSE	Sequence output, pulse train output changeover	

3) EL-BIT W1,W2,W3,W4

No.	1	2	Signal	
W1	SINK	SOURCE	PSI1 \sim 6 sink, source changeovers	All EL-BITs are
W2	SINK	SOURCE	PSI7 sink, source changeover	set to 1 as the
W3	voltage	current	AO1 voltage, current changeover	delault.
W4	voltage	current	AO2 voltage, current changeover	

- 4) Standard serial or Modbus transmission CN2 (Connector type: 4-pole modular, Hirose Electric TM3P-44P or equivalent)
 - A signal level is based RS-485. The terminus resistance (120Ω) can set up on/off in DS1-1. ((DS1-1=120Ω): Connected, (DS1-1=OPEN): Not connected)
 - The direction of a signal is based on VAT300.
 - 5VOP and 0VOP are not designated to supply power externally.

Terminal No.	Signal
1	DATA+
2	DATA-
3	0VOP
4	5VOP





Outline drawing of connector

5) Standard serial or Modbus transmission TB3

- CN2 and TB3 DATA+, DATA- and 0VOP are connected in the PCB.
- The terminal size is M2.
- The applicable wire size is AWG26 to AWG16.

Terminal No.	Symbol	Signal	Wire neeling size
1	D+	DATA+	
2	D-	DATA-	
3	SG	0VOP	l → _{5mm}

Notes for moving Operation panel holder

Do not raise the operation panel holder with an angle of larger than 90°, so that the holder should not be fallen off.



Fig. 2-4-c

If the operation panel holder should be taken off, push the hinges of the holder lightly and insert them into the original positions.



Chapter 3 Test Operation and Adjustment

• A p F • N F • N F • S n g	Always install the front cover before turning the input power ON. Never remove the cover while the power is ON. There are sections in the front PCB that are charged with high voltages. Failure to observe this could lead to electric shocks. Never touch the switches with wet hands. Failure to observe this could lead to electric shocks. Never touch the inverter's terminals while the inverter power is ON even if the operation is stopped. Failure to observe this could lead to electric shocks. Never touch the inverter's terminals while the inverter power is ON even if the operation is stopped. Failure to observe this could lead to electric shocks. Selection of the retry function could lead to unexpected restarting when alarm stops. The machine may start suddenly if the power is turned ON when the automatic start function is selected. Do not go near the machine.
() F • T s F • T ir a F	Design the machine so that physical safety can be ensured even if the machine restarts.) Failure to do so could lead to injuries. The machine may not stop when a stop command is issued if the deceleration stop function is selected and the overvoltage/overcurrent limit function is activated. Prepare a separate emergency stop switch. Failure to do so could lead to injuries. The unit will not suddenly restart even if the alarm is reset with the operation signal input, however, n order to prevent unexpected operation, ensure that the operation signal is no longer being input, and reset the alarm. Failure to do so could lead to injuries.
 T F T A F C F A W F A A F A A<	The heat sink and resistor are heated to high temperatures, so never touch them. Failure to observe this could lead to burns. Do not block the inverter's ventilation holes. Failure to observe this could lead to fires. The inverter operation can easily be set from low speeds to high speeds, so confirm that the operation is within the tolerable range for the motor or machine before making settings. Failure to do so could lead to injuries. Prepare holding brakes when necessary. Holding is not possible with the inverter's brake functions. Failure to do so could lead to injuries. Confirm the operation of the motor as a single unit before operating the machine. Failure to do so could lead to injuries or machine damage due to unforeseen movements. Always prepare a safety backup device so that the machine is not placed in a hazardous situation when an error occurs in the inverter. Failure to do so could lead to injuries or machine damage or fires.

 When using the 400V Series (X075K0 or higher) set the power changeover connector on the transformer auxiliary PCB according to the power voltage.
 Failure to do so could lead to fires. The VAT300 has various setting items. Some of these include settings that must be made according to the power supply and motor before actually starting operation.

The methods for the VAT300 basic test operation and adjustment are explained in this section.

3-1 Flow of test operation

Carry out test operation according to the flow shown in Fig. 3-1. The procedures above the dotted line in Fig. 3-1 are explained in this section.







3-2 Preparation before turning power ON

Always confirm the following points before turning ON the power after completing wire.

- (1) Remove the coupling and belt coupling the motor and machine, so that the machine can be run as a single unit.
- (2) Confirm that the power supply wire is correctly wired to the input terminals (L1, L2, L3).
- (3) With the 400V Series (X075K0 or higher), there are some sections in the inverter which operate with an AC power supply, such as fan and magnetic contactor. In this case, set the power changeover connector on the transformer auxiliary PCB according to the power voltage.

If this connector is not set correctly, the fan and magnetic contactor could burn.

For 380V to 415V, short circuit across JP-1

For 416V to 460V, short circuit across JP-2

For 461V to 480V, short circuit across JP-3 (factory setting state)

(4) Make sure that the power voltage and frequency are within the tolerable range.

Voltage system	Туре	Power voltage	Frequency
200V series	N000K7 to N011K0	200 to 240V ± 10%	50/60Hz ± 5%
	N015K0 to N045K0	200 to 230V ± 10%	50/60Hz ± 5%
400V series	X000K7 to X475K0	380 to 480V ± 10%	50/60Hz ± 5%

(5) Refer to section 2-3, and correctly connect the main circuit wiring.

(6) Securely fix the motor with the specified method.

(7) Make sure that none of the terminal section screws are loose.

- (8) Make sure that there is no short circuit state in the terminals caused by wire scraps, etc.
- (9) Always correctly install the front cover and outer cover before turning the power ON.
- (10) Assign an operator, and make sure that the operator operates the switches.



Make sure that there is no abnormal noise, smoke or odors at this time. If any abnormality is found, turn the power OFF immediately.

3 – 3

3-3 Control modes

With the VAT300, four control modes and two overload modes can be selected. These are set with the parameter C30-0 (control mode selection). Refer to the Appendix Table 1 Table of control specifications for details.

* C30-0 is set with a 2-digit value (f0, f1). Refer to section 3-4 for the setting methods.

(1) Control modes

There are four VAT300 motor control modes. Refer to the following table, and select the mode which suits the application.

Control mode	Explanation	C30-0 f0
1) V/f control	The voltage - frequency ratio is controlled.	1
2) IM speed sensor-less vector control	The IM is vector-controlled without a speed sensor. The speed can be controlled.	2
 IM vector control with speed sensor 	The IM is vector-controlled with a speed sensor. This mode is used when a fast speed response or torque response is required. The speed detection option 1 is required. (Note 1)	3
 PM motor control with sensor 	The PM motor is vector-controlled. The motor can be operated at a higher efficiency than IM. A speed detection option which matches the sensor (encoder) being used is required. (Note 1)	4

(Note 1) : Refer to Table 7-1-a (Chapter 7) for details on the speed detection options.

(2) Device overload mode selection

The following two modes can be selected according to the load being used. If the load and device capacity do not differ, the device could be overloaded. Refer to the following table, and select the mode that matches the load being used.

Control mode	Explanation	C30-0 f1
1) Normal-duty setting	Select this when the maximum load rate in respect to the rated load is low. The overload standard will be 120% of the motor's rated current for one minute.	1
2) Heavy-duty setting	Select this when the maximum load rate in respect to the rated load is high. The overload standard will be 150% of the motor's rated current for one minute.	2

3-4 Automatic tuning and test operation

Automatic tuning measures the constants of the connected motor, and automatically adjusts the parameters so that the system is used to the fullest.

The VAT300 automatic tuning function performs differ measurements for each of the four control modes. Carry out automatic tuning each time the motor being used or the applicable control mode is changed. The automatic tuning mode is set with parameter B19-0 (automatic tuning selection).

Control mode	Automatic tuning mode
V/f control	B19-0 = 1,2
 IM speed sensor-less vector control 	B19-0 = 3, 4, 5
 IM vector control with speed sensor 	B19-0 = 1, 3, 4, 5
 PM motor control with sensor 	B19-0 = 6, 7

B19-0	Name
1	Simple adjustment mode
2	V/f control high-function adjustment mode
3	Vector control basic adjustment mode
4	Vector control expanded adjustment mode
5	No-load voltage operation mode
6	Encoder phase adjustment mode (Note 1)
7	Magnetic pole position estimation mode (Note 2)

Carry out parameter initialization and automatic tuning as shown in the following flow chart. Refer to Chapter 4 for details on changing the parameters and operating the operation panel.

An adjustment mode dedicated for elevators (with brakes) is provided for the PM motor vector control with speed sensor. Refer to section 3-4-4 when using this mode for elevator applications. Refer to section 3-4-3 when using for applications other than elevators.

(Note 1) B19-0=6 : The encoder phase adjustment mode automatically adjusts the parameters which set the phase angle between the encoder Z phase pulses and PM motor U-phase coil. The motor circuit constants are not adjusted automatically.
 (Note 2) B19-0=7 : The magnetic pole position estimation mode is used to adjust the PM motor control magnetic pole position estimation function. This mode does not automatically adjust the parameters.



Fig. 3-4 Selection of automatic tuning mode
3-4-1 V/f control (C30-0 f0 = 1) automatic tuning and test operation

(1) Automatic tuning (V/f control mode)

The following two modes can be selected for the V/f control automatic tuning. Using B19-0 (automatic tuning selection), select the automatic tuning mode that matches the working conditions.

1) B19-0 = 1: Mode 1: simple adjustment mode (Execution time: approx. 10 seconds)

The basic parameters, such as boost voltage and brake voltage, are adjusted without rotating the motor.

The following parameters shown in Table 3-4-1-a are automatically adjusted by executing Mode 1.

Applicable mode	Parameter No.	Name
	A02-2	Manual torque boost setting
C30-0 f0 = 1	A03-0	DC brake voltage
B19-0 = 1	B02-0, 1	R1: Primary resistance
	B02-4, 5	Lσ: Leakage inductance

Table 3-4-1-a

2) B19-0 = 2: Mode 2: V/f control high-function adjustment mode (Execution time: approx. 1 minute)

The parameters related to the slip compensation and max. torque boost are adjusted while rotating the motor.

The magnetic saturation characteristics are measured at the voltage boost, and are adjusted to match the max. torque boost.

The following parameters shown in Table 3-4-1-b are automatically adjusted by executing Mode 2.

Table 3-4-1-b

Applicable mode	Parameter No.	Name
	A02-2	Manual torque boost setting
	A03-0	DC brake voltage
C30-0 f0 = 1	B02-0, 1	R1: Primary resistance
B19-0 = 2	B02-4, 5	Lσ: Leakage inductance
	A02-5	Slip compensation gain
	A02-6	Max. torque boost gain

- (Note 1) When the V/f control mode (C30-0 f0 = 1) is selected, modes other than B19-0=1, 2 cannot be used. If B19-0 is set incorrectly, set it again.
- (Note 2) If the base frequency of the motor is applied on a motor exceeding 120Hz, select Mode 1 (B19-0 = 1). Adjust the slip compensation gain (A02-5) and max. torque boost gain (A02-6) manually.

Precautions for executing V/f control automatic tuning

- Even when Mode 1 is executed, the motor may rotate due to vibration, etc.
- If the vibration is large, press the $\binom{\text{stop}}{O}$ key immediately to stop operation.
- With Mode 2, the motor will automatically start rotating.
- Always check the safety on the load side before executing automatic tuning, regardless of the Mode 1 or 2 setting.
- During automatic tuning, the motor may rotate, so always confirm safety before starting automatic tuning.
- If the automatic tuning function does not end correctly, always turn the inverter power OFF before investigating or confirming the operation.
- Automatic tuning can be started only in the local operation mode (when "LCL" LED on operation panel is ON). Confirm that the "LCL" LED is ON.
- If the motor has an unstable frequency band, automatic tuning may not end normally. In this case, the maximum torque boost function cannot be used.
- If the load is less than 10% and the fluctuation does not occur, automatic tuning can be carried out with the load and machine connected. However, the performance may not be complete.
- Always carry out automatic tuning before using the maximum torque boost function.
- The contact output FLT will function if the automatic tuning does not end correctly. In equipment that uses this contact, keep the operation of the related devices in mind.

(2) Automatic tuning operation procedures (V/f control mode)

Carry out V/f mode automatic tuning with the following procedures. Refer to Chapter 4 for details on using the operation panel.





1) Preparation

Separate the motor and load, machine, etc., and confirm the safety on the load side.

2) Turning the power ON and starting VAT300

Turn the power ON. (For U30 V24OP1)

After carrying out an initial check of the operation panel for approx. 5 seconds, the display changes as shown on the right. The "LCL" LED also turns ON.

(For U30 V24OP2)

All LEDs on the numeric display will turn ON for a short time, "AAA-A" and "AFF " will and then " appear.

The "LCL" and "Hz" LEDs will also turn ON.

3) Selecting the control mode

- Set A05-2 to 1. (Set the hardware option function display ON.)
- Set the control mode selection: C30-0 f1 f0.

This parameter must be set first. (Note 1)

V/f control mode is to be used, so set C30-0 f0 = 1.

Set c30-0 f1 f0 as shown below according to the load.

Normal-duty setting: C30-0 f1 f0 = 1 1

Heavy-duty setting: C30-0 f1 f0 = 2 1

(Note 1) The default value is set to V/f control and Normal-duty setting (C30-0=11).

There are some parameters which will change automatically when C30-0 is changed, so also set this first.

4) Initialization of motor constants

Input the motor rating parameters. Set the parameters shown in Table 3-4-1-c. Automatic tuning will automatically change the parameters, so it is recommended to write down the values set in Table 3-4-1-a or Table 3-4-1-b. Table 3-4-1-c

Applicable mode	Parameter No.	Name
	B00-0 B00-1	Rated input voltage setting Max/base frequency simple

-			
	B00-0	Rated input voltage setting	[No.]
	B00-1	Max/base frequency simple setting	[Hz]
	B00-2	Motor rated output	[kW]
C30-0 f0 = 1	B00-3	Rated output voltage	[V]
B19-0 = 1, 2	B00-4	Max. frequency (Note 1)	[Hz]
,_	B00-5	Base frequency (Note 1)	[Hz]
	B00-6	Motor rated current	[A]
	B00-7	Carrier frequency	

(Note 1) The max. frequency cannot be set below the base frequency, and the base frequency cannot be set above the max. frequency.

5) Selecting and executing the automatic tuning mode

Select the automatic tuning mode and execute automatic tuning.

• The operation panel's operation mode must be set to "Local" to execute automatic tuning.

STOP O SFT Make sure that the "LCL" LED is ON. If not, press the) + keys, and confirm that the "LCL" LED turns ON.

- Set A05-0 to 1. (Set the expanded setting display ON.)
- · Using B19-0 (automatic tuning selection), select the automatic tuning mode according to the working conditions. Refer to section 3-4-1 (1) for details on the automatic tuning mode.
- The automatic tuning standby state will be entered when the $\left(\frac{LL}{SET}\right)$ key is pressed.



- During the automatic tuning standby state and the automatic tuning execution state, the LCL LED will flicker.
- STOP • To exit the automatic tuning standby state, press the kev.

6) Starting automatic tuning

REV key is pressed according to the required Automatic tuning will start when the key or rotation direction.

To stop, press the key or input the emergency stop signal (EMS) from the terminal block.

* Once automatic tuning starts, all panel operations other than the

keys (knobs with U30V24OP1) are disabled until the operation ends.

7) During automatic tuning execution

The progression state can be confirmed with D22-0.



The steps required for tuning are indicated (lit).

The finished steps are indicated (lit). The step currently being executed is indicated with a flicker.

Normal completion of automatic tuning

When the automatic tuning ends normally, the "LCL" LED will change from a flicker to a stable light. The "RUN" LED will change from a flicker to the OFF state. Refer to section 3-4-1 (1) for the adjustment items.

9) Abnormal completion of automatic tuning

If automatic tuning ends abnormally, the "FLT" LED will turn ON and a message will appear. Investigate and check according to the error codes. Refer to section 3-4-5 for details on the error codes.

(3) Test operation (V/f control mode)

When finished with automatic tuning, test run the isolated motor, and make sure that there are no errors.

An example for when the maximum frequency (B00-4) and base frequency (B00-5) are 50Hz is given below.

Use the following procedures to test the operation with the operation panel. Refer to Chapter 4 for details on using the operation panel.

CAUTION

To prevent incorrect operation during the test operation, make sure that signals are not input into the sequence input terminal.

1) To enable operation with the operation panel, confirm that the "LCL" LED is ON. If not, press the LOL

+ ((0)	keys,	and	confirm	that	the	"LCL"	LED	turns	ON.
-----	-----	-------	-----	---------	------	-----	-------	-----	-------	-----

2) Set speed setting input point selection: C02-0= 3 (panel fixed).

CAUTION

The motor will rotate with the next step.

Confirm the safety around the motor before starting the next step.

3) Press the $\binom{RST}{MOD}$ and display D00-0 on the monitor. Then press the $\binom{FWD}{I}$ key. Operation will start. The "FWD" lamp will turn ON, and the display will change from "OFF" to a value display. The value will gradually increase, and after several seconds, will change to "10.00". This is because as the factory settings, the direct setting frequency (A00-0) is set to 10Hz and the acceleration ramp time 1 (A01-0) is set to 10sec.

CHECK

- 1. Did the motor run?
- 2. Is the run direction correct? Check the wiring and operation if abnormal.
- 3. Is the rotation smooth?
- 4) Press the $\binom{\text{REV}}{1}$ key and confirm that the motor runs in reverse.

(Note) Do not carry out this step if a load which cannot be run in reverse is connected.

- 5) Press the $\binom{\text{STOP}}{O}$ key and stop the motor.
- 6) Press the $\binom{FWD}{I}$ key. The motor will forward run at the output frequency 10Hz.

Change the frequency to 50Hz with the following operation.

- 7) Press the (RST) key several times. The Display will alternate between "**BBB-B**" and "**BBB-B**" (with the U30V24OP1, the section of "A00-section of "A00-section") section of "A00-section".
- 8) Press the $\left(\frac{LQ}{SET}\right)$ key once.

The display will stop at "**IDDD**", and the last digit will flicker. (With the U30V24OP1, the flicker will move to the 2nd decimal digit of the frequency display.)

This completes the preparation for changing the output frequency. The digit to change can be moved with the (<) key. The output frequency can be incremented/decremented with the

keys (keys (knobs with U30V24OP1).

- 9) Move the digit with the (key, and using the key (knob with U30V24OP1), raise the frequency to "50.00Hz". Then, press the $\left(\frac{LQ}{SET}\right)$ key. The output frequency will rise to 50Hz.

(Note) The operation panel frequency change operation is set to "Change in real time"

(C11-2=1) with the factory shipment settings. Thus, even if the $\left(\frac{LQ}{SEI}\right)$ key is not pressed,

the frequency will change in real time using the $(\blacktriangle)(\triangledown)$ keys (knobs with U30V24OP1).

When the $\left(\frac{La}{ST}\right)$ key is pressed, the current setting value will be saved.

A 10-second acceleration and 20-second deceleration ramp time are set as defaults. The motor will slowly increase its speed to the set value.
When making a setting (using the 🔺 🛡 keys, or 🔗 🌀 knobs with
(U30-V24OP1), check that the motor operates correctly at each increment of approx. 10Hz.
10) Press the $\begin{pmatrix} RST \\ MOD \end{pmatrix}$ key several times, and display D00-0. When the output frequency ("D00-display) reaches 50Hz, press the $\begin{pmatrix} STOP \\ O \end{pmatrix}$ key.
The display will decrease to "0.00" in several seconds. The "FWD" or "REV" LED will flicker to two seconds while the DC-brake is applied and the motor will stop.
11) Press the $\begin{pmatrix} REV \\ I \end{pmatrix}$ key, and test the reverse run at 50Hz.
(Note) Do not carry out this step if a load which cannot be run in reverse is connected.

This completes the test operation with the operation panel. After this, refer to Chapter 4 and carry out the settings and adjust the load operation to match the user's application.

3-4-2 IM speed sensor-less vector control (C30-0 $f_0 = 2$) and IM vector control with speed sensor (C30-0 $f_0 = 3$) automatic tuning test operation

(1) Before automatic tuning

When using IM vector control with speed sensor, the speed detection option is required in addition to the VAT300 standard unit.

When using the IM vector control with speed sensor, use with FWD, F.RUN as forward run and Rev, R.RUN as reverse run.

With the VAT300, the counterclockwise rotation (CCW) looking from the motor shaft is defined as forward run, and clockwise rotation (CW) is defined as reverse run.



Fig. 3-4-2-a Definition of VAT300 motor rotation direction

Refer to Table 3-4-2-a, and confirm that the speed detection option compatible with the encoder in use has been prepared. Refer to Chapter 7 for details on the speed detection option.

Table 3-4-2-a

Encoder type	Speed detection option (Instruction Manual No.)		
1) Complementary output method	U30V24DN1 (PCST-3453)		
2) Line driver output method	U24V24DN2 (PCST-3454)		

(2) Outline of automatic tuning (IM vector control mode)

The following four modes can be selected for the IM speed sensor-less vector control or IM vector control with speed sensor automatic tuning.

Using B19-0 (automatic tuning selection), select the automatic tuning mode according to the load conditions. (Note 1)

 B19-0 = 1: Mode 1: simple adjustment mode (Execution time: approx. 10 seconds) (Note 1) The basic parameters for IM vector control with speed sensor are automatically adjusted without rotating the motor.

The following parameters shown in Table 3-4-2-b are automatically adjusted by executing Mode 1.

Applicable mode	Parameter No.	Name
	B01-9	No-load output voltage
	B02-0, 1	R1 : Primary resistance
$C_{30-0} = 3$	B02-2, 3	R2': Secondary resistance (Note 2)
B19-0 = 1	B02-4, 5	Lσ : Leakage inductance
	B02-6, 7	M' : Excitation inductance (Note 2)

Table 3-4-2-b

 B19-0 = 3: Mode 3: Vector control basic adjustment mode (Execution time: approx. 30 seconds) The motor is rotated and the basic parameters for vector control are automatically adjusted. The following parameters shown in Table 3-4-2-c are automatically adjusted by executing Mode 3.

Applicable mode	Parameter No.	Name
	B01-9	No-load output voltage
	B02-0, 1	R1 : Primary resistance
$C_{30-0}[0] = 2, 3$	B02-2, 3	R2': Secondary resistance
B19-0 = 3	B02-4, 5	$L\sigma$: Leakage inductance
	B02-6, 7	M' : Excitation inductance

Table 3-4-2-c

 B19-0 = 4: Mode 4: Vector control extended adjustment mode (Execution time: approx. 1 minute) This mode is selected to carry out constant output range operation.

The following parameters in Table 3-4-2-d are automatically adjusted by executing Mode 4.

Applicable mode	Parameter No.	Name
	B01-9	No-load output voltage
	B02-0, 1	R1 : Primary resistance
	B02-2, 3	R2': Secondary resistance
$C_{30-0} 0 = 2, 3$	B02-4, 5	$L\sigma$: Leakage inductance
B19-0 = 4	B02-6, 7	M' : Excitation inductance
	B33-0 to 7	M variable reference speed table
	B34-0 to 7	M variable compensation table

Table 3-4-2-d

- * When carrying out constant output operation, the fluctuation compensation for the excitation inductance is adjusted in this mode, however, the motor will rotate to the maximum speed during automatic tuning, so special attention must be paid to safety.
- 4) B19-0=5: Mode 5: No-load voltage operation mode (Execution time; approx. 10 seconds) This mode automatically calculates and adjusts the motor's no-load voltage from the motor rated constants given in Table 3-4-2-f. When mode 5 is executed, the Table 3-4-2-e parameters are automatically adjusted.

Use this mode when the motor rated constants cannot be set with the motor design materials, etc.

Fable 3-4-2-e	•
---------------	---

Applicable mode	Parameter No.	Name
C30-0 f0 = 2 B19-0 = 5	B01-9	No-load output voltage

Table 3-4-2-f

Parameter No.	Name
B02-0, 1	R1 : Primary resistance
B02-2, 3	R2': Secondary resistance
B02-4, 5	$L\sigma$: Leakage inductance
B02-6, 7	M' : Excitation inductance

(Note 1) In the IM vector control mode (C30-0 10 = 2, 3), modes other than B19-0=1, 3, 4 or 5 cannot be used. If B19-0 is set incorrectly, set it again. When using IM speed sensor-less vector control, the simple adjustment mode (mode 1) cannot be used.

- **(Note 2)** In the simple adjustment mode (mode 1), the excitation inductance is estimated using the motor rated value, so there could be an error in the output voltage. In applications which require a high actual output torque accuracy in respect to the torque command (within $\pm 10\%$ of the rated output torque), make the following adjustments after automatic tuning.
 - Carry out rated speed operation with a 10% or less load, and adjust B02-6, 7 (M': excitation inductance) so that B01-9 (no-load output voltage) and output voltage (D03-1) match.
 - 2) Carry out rated speed operation with a 100% load, and adjust B02-2, 3 (secondary resistance) so that the rated voltage (B01-3) and output voltage (D03-1) match.

Refer to section 3-4-2(6) for details.



Precautions for executing IM speed sensor-less vector control or IM vector control with speed sensor automatic tuning

- Always check the safety around the motor before starting automatic tuning.
- The motor could vibrate or start running.

The motor will automatically start rotating during automatic tuning.

- If the vibration is large during automatic tuning, press the \bigcirc^{SLOP} key immediately and stop the operation.
- Separate the motor from the load and machine, etc., and carry out automatic tuning with the isolated motor.

Automatic tuning can be performed with a non-fluctuating load of 10% or less or if a machine is connected. However, if the applications require an accurate actual output torque in respect to the torque command, a sufficient performance may not be attained.

- The contact output FLT will function if the automatic tuning does not end correctly. In equipment that uses this contact, keep the operation of the related devices in mind.
- Automatic tuning cannot be used if the load is 10% or more or if the load fluctuates. Refer to the motor design materials, etc., and input the R1: primary resistance, R2': secondary resistance, Lσ: leakage inductance and M': excitation inductance. Then, when automatic tuning for the B19-0=5 no-load voltage operation mode is performed, the no-load voltage (B01-9) will be automatically set and operation with vector control will be possible. (Refer to section 6-6 Function explanation B02-0 to 9 Motor circuit constants for details on calculating R2', Lσ and M'.)
- If the automatic tuning function does not end correctly, always turn the inverter power OFF before investigating or confirming the operation.

(3) Automatic tuning operation procedures (IM vector control mode)

Carry out automatic tuning with the following procedures. Refer to Chapter 4 for details on using the operation panel.



Fig. 3-4-2-b IM speed sensor-less vector control and IM vector control with speed sensor automatic tuning procedures

1) Preparation

Separate the motor and load, machine, etc., and confirm the safety on the load side.

When using the IM vector control with speed sensor mode, make sure that the speed detection option PCB is correctly mounted on the control PCB, and that the encoder signal cable is correctly connected to the speed detection option.

2) Turning the power ON and starting VAT300

Turn the power ON.

(In the case of U30V24OP1)

After carrying out an initial check of the operation panel for approx. 5 seconds, the display changes as shown on the right. The "LCL" LED also turns ON.

(In the case of U30V24OP2)

All LEDs on the numeric display will turn ON for a short time, and

then "- - - - ", " $\partial \partial \partial \partial - \partial \partial$ " and " $\partial F F$ " will appear. The "LCL" and "Hz" LEDs will also turn ON.



(Note) When the power is turned ON next (after setting C30-0 f0 = 2, 3), "D00-2" will appear on the numeric display, and the "Hz" LED will not turn ON. This is because the mode is set to the IM vector control mode.

3) Selecting the control mode

- Set A05-2 to 1. (Set the hardware option function display ON.)
- Set the control mode selection: C30-0 f1 f0. This parameter must be set first. (Note 1)

Tabele 3-4-2-g

	Normal-duty setting	Heavy-duty setting
IM speed sensor-less vector control	C30-0 = 1 2	C30-0 = 2 2
IM vector control with speed sensor	C30-0 = 1 3	C30-0 = 2 3

(Note 1) The default value is set to V/f control and Normal-duty setting (C30-0=11), so always change C30-0.

There are some parameters which will change automatically when C30-0 is changed, so also set this first.

4) Initialization of motor ratings and constants

Input the motor rating parameters. Set the parameters shown in Table 3-4-2-h. Automatic tuning automatically changes the parameters, so the setting value shown in Table 3-4-2-b to f should be written down according to the automatic tuning mode being used.

Table 3-4-2-h		
Parameter No.	Name	
B01-0	Rated input voltage setting	[No.]
B01-1	Motor rated output	[kW]
B01-2	No. of motor poles	[Pole]
B01-3	Rated output voltage	[V]
B01-4	Max. speed	[min ⁻¹]
B01-5	Base speed	[min ⁻¹]
B01-6	Motor rated current	[A]
B01-7	Carrier frequency	
B01-8	No. of encoder pulses	[P/R] :(Note 1)

* The max. speed cannot be set below the base speed, and the base speed cannot be set above the max. speed.

(Note 1) Always input B01-8 when using the vector control mode with speed sensor.

Set the motor circuit constant parameters shown in Table 3-4-2-i only when using the automatic tuning mode 5. Refer to the motor design documents and calculate and set these parameters.

Table	3-4-2-i
-------	---------

Parameter No.	Name
B02-0, 1	R1 : Primary resistance
B02-2, 3	R2': Secondary resistance
B02-4, 5	Lσ : Leakage inductance
B02-6, 7	M' : Excitation inductance

5) Setting the ASR and ACR parameters

When performing automatic tuning, do not change the ASR (speed control) and ACR (current control) parameters shown in Table 3-4-2-j from the default values.

Table 3-4-2-j			
Parameter No.	Name	Standard value	
A10-0	ASR response	10.0 [rad/s]	
A10-1	Machine time constant	1000 [s]	
A10-2	Integral time constant compensation coefficient	100 [%]	
A10-3	ASR drive torque limiter	100 [%]	
A10-4	ASR regenerative torque limiter	100 [%]	
A11-0	ACR response	1000 [rad/s]	
A11-1	ACR time constant	20.0 [ms]	

Use the following expression and set A10-1: machine time constant according to the inertia of the isolated PM motor being used. The machine time constant (Tm) refers to the time required to accelerate to the base rotation speed from the zero speed at the rated torque.

Tm [ms] = $10.97 \times J [kg \cdot m^2] \times (Nbase [min^{-1}])^2 / Power[W]$

J : Total inertia $[kg \cdot m^2]$ (= $1/4 \times GD^2 [kg \cdot m^2]$)

Nbase : Base rotation speed [min⁻¹]

Power: Motor rated output [W]

6) Setting the encoder parameter

The parameters to be set are listed in Table 3-4-2-k. IM vector control with speed sensor mode

Table 3-4-2-k

Parameter No.	Name
C50-1	2-phase, 1-phase encoder selection
C50-2	Encoder AB phase advance direction

(1) C50-1: 2-phase, 1-phase encoder selection

Set the number of signals (2-phase, 1-phase) of the encoder to be used.

C50-1=1: Select this for an encoder which outputs a 2-phase signal (A, B phase) which has a 90° phase difference.

The rotation direction can be judged, and stable speed control can be realized even at low speeds.

C50-1=2: Select this when using an encoder which outputs a 1-phase signal.

Connect the input signal to the A or B phase input, and leave the other phase unconnected. The 1-phase pulse signal validates functions which convert into 2-phase signals.

In the 1-phase signal mode, the rotation direction is recognized as the operation command direction. Forward run and reverse run cannot be determined.

In low-speed ranges, the speed detection error may occur because of chattering. When using low-speed operation or forward/reverse operation, use the 2-phase encoder.



2-phase oscillator

Fig. 3-4-2-c 2-phase, 1-phase encoder selection

- (Note 1) When 1-phase input is selected, the speed detection direction (sign) is determined by the operation direction.
- (Note 2) When 1-phase input is selected and ACR control is being conducted with IM vector control with speed sensor, the direction is recognized with the rotation direction indicated in (Note 1). Pay attention to the acceleration direction.

(2) C50-2: Encoder AB phase advance direction selection

With the VAT300, the rotation in the counterclockwise direction (CCW) looking from the motor shaft is defined as forward run, and in the clockwise direction (CW) is defined as reverse run. Determine this parameter's setting value according to the phase relation of the encoder AB phase signals during forward run.





7) Selecting and executing the automatic tuning mode

- Select the automatic tuning mode and execute automatic tuning.
- The operation panel's operation mode must be set to "Local" to execute automatic tuning.

Make sure that the "LCL" LED is ON. If not, press the $\binom{\text{LLL}}{\text{SET}}$ + $\binom{\text{STOP}}{O}$ keys, and confirm that the "LCL" LED turns ON.

- Set A05-0 to 1. (Set the expanded setting display ON.)
- Using B19-0 (automatic tuning selection), select the automatic tuning mode according to the working conditions. Refer to section 3-4-2 (2) for details on the automatic tuning mode.
- The automatic tuning standby state will be entered when the $\left(\frac{112}{SET}\right)$ key is pressed.
- During the automatic tuning standby state and the automatic tuning execution state, the "LCL" LED will flicker.
- To exit the automatic tuning standby state, press the $\binom{MP}{O}$ key.

8) Starting automatic tuning

Automatic tuning will start when the	(FWD)) key or (ight) key is pressed according to the required
rotation direction.			

To stop, press the $\binom{MP}{O}$ key or input the emergency stop signal (EMS) from the terminal block.

* Once automatic tuning starts, all panel operations other than operations other than the $\begin{pmatrix} STOP \\ O \end{pmatrix}$

knobs with U30V24OP1) are disabled until the kevs or operation ends.

9) During automatic tuning execution

The progression state can be confirmed with D22-0.



Upper level : The steps required for tuning are indicated (lit). Lower level : The finished steps are indicated (lit).

The step currently being executed is indicated with a flicker.

10) Normal completion of automatic tuning

When the automatic tuning ends normally, the "LCL" LED will change from a flicker to a stable light. The "RUN" LED will change from a flicker to the OFF state. Refer to section 3-4-2 (2) for the automatically adjusted items.

11) Abnormal completion of automatic tuning

If automatic tuning ends abnormally, the "FLT" LED will turn ON and a message will appear. Investigate and check according to the error codes. Refer to section 3-4-5 for details on the error codes.

(4) Test operation (IM vector control mode)

When finished with steps (1) to (3), test the isolated motor and check for abnormalities. An example for when the maximum speed (B01-4) and base speed are 600min⁻¹ is given below. The procedures for test operation using the operation panel are explained below. Refer to Chapter 4 for details on using the operation panel.



To prevent incorrect operation during the test operation, make sure that signals are not input into the sequence input terminal.

- 1) To enable operation with the operation panel, confirm that the "LCL" LED is ON. If not, press the $\left(\frac{\text{LCL}}{\text{SET}}\right) + \left(\frac{\text{STOP}}{O}\right)$ keys, and confirm that the "LCL" LED turns ON.
- 2) Set speed setting input point selection: C02-0= 3 (panel fixed).

- The motor will rotate with the next step. Confirm the safety around the motor before starting the next step.
- The moment of inertia differs for isolated motor operation and load (machine) operation. Set the machine time constants (A10-1) according to the motor and load. The motor will vibrate if
 - the settings are too high.
- 3) Press the $\binom{\text{IST}}{\text{MDD}}$ and display D00-2 on the monitor. Then press the $\binom{\text{FWD}}{I}$ key.

The "FWD" lamp will turn ON, and the display will change from "OFF" to a value display. The value will gradually increase, and after several seconds, will change to "300.0". This is because as the factory settings, the direct setting frequency (A00-2) is set to 300min⁻¹ and the acceleration ramp time -1 (A01-0) is set to 10sec.

CHECK

- 1. Did the motor run?
- 2. Is the run direction correct? Check the wiring and operation if abnormal.
- 3. Is the rotation smooth?
- 4) Press the $\binom{\text{REV}}{1}$ key and confirm that the motor runs in reverse.

(Note) Do not carry out this step if a load which cannot be run in reverse is connected.

- 5) Press the $\binom{\text{STOP}}{O}$ key and stop the motor.
- 6) Press the $\binom{FWD}{I}$ key. The motor will forward run at 300min⁻¹.

Change the frequency to 600min⁻¹ with the following operation.

- 7) Press the (BT)/(MO) key several times. The Display will alternate between "**BOO D**" and "**BOOD**" (with the U30V24OP1, the **2** section of "A00-**2**: 300.0min⁻¹" will flicker).
- 8) Press the $\left(\frac{LCL}{SET}\right)$ key once.

The display will stop at "**GOOG**", and the last digit will flicker. This completes preparation for changing the motor speed. The digit to be changed can be moved with the \checkmark key. The speed can be increased or lowered with the \checkmark keys (\bigcirc knobs with U30V24OP1).

- 9) Move the digit with the key, and using the key (knob with U30V24OP1), raise the frequency to "600.0"min⁻¹. Then, press the $\underbrace{\textcircled{}}_{\mathbb{SET}}$ key. The motor speed will gradually increase to 600min⁻¹.
 - (Note) The operation panel frequency change operation is set to be changed (C11-2=1) in real time at the factory shipment settings, and therefore the output frequency is changed in
 - real time using the () weys () keys () knobs with U30V24OP1), without having to press the () key.

When the $\left(\frac{LL}{SET}\right)$ key is pressed, the current setting value will be saved.

A 10-second acceleration and 20-second deceleration ramp time are set as defaults. The motor will slowly increase its speed to the set value.
When making a setting (using the \checkmark v keys, or \checkmark knobs with U30V24OP1), check that the motor operates correct at each increment of approx. 100min ⁻¹ .

10) When the motor speed (D00-2 display) increases to 600min⁻¹, press the $\binom{\text{STOP}}{O}$ key.

The display will decrease to "0.0" in several seconds. The "FWD" or "REV" LED will flicker for two seconds while the DC-brake is applied and the motor will stop.

11) Press the $\binom{\text{REV}}{I}$ key, and test the reverse run at the maximum speed.

(Note) Do not carry out this step if a load which cannot be run in reverse is connected.

This completes the test operation with the operation panel.

(5) Manual adjustment when torque accuracy is required (IM vector control mode)

In applications which require a high actual output torque accuracy in respect to the torque command (within $\pm 10\%$ of the rated output torque), the following manual adjustments may be required.

- 1) Adjusting the exciting inductance when performing automatic tuning with B19-0=1
 - When there is no constant output range

Run the motor at the base speed with no load (10% load or less), and adjust B02-6, 7 so that the no-load output voltage (B01-9) attained with automatic tuning and the output voltage (monitor D03-1 if measurement with rectified voltmeter is difficult) approximately match. In the same manner, the motor must be run at the base speed with 100% load, and the secondary resistance (B02-2, 3) adjusted so that the rated voltage (B01-3) and output voltage (monitor D03-1 if measurement with rectified voltmeter is difficult) approximately match. If the setting value of secondary resistance (B02-2,3) is made to increase during operation, output voltage will decrease. Moreover, if the setting value of secondary resistance (B02-2,3) is made to decrease during operation, output voltage will increase.

• When there is a constant output range When running with a constant output range, the M fluctuation compensation must be adjusted. Set the speed table (B33-0 to 7) beforehand. The speed table should be set as shown below except in special cases.

Parameter No.	Recommended setting values
B33-0	B33-1 × (1/2)
B33-1	Base speed : Same setting value as B01-5
B33-2	
B33-3	
B33-4	Set so that B33-1 to B33-7 are at an equal pitch
B33-5	
B33-6	
B33-7	Maximum speed : Same setting value as B01-4

Run the motor at the base speed with no load (10% load or less), and adjust B02-6, 7 so that the no-load output voltage (B01-9) attained with automatic tuning and the output voltage (monitor D03-1 if measurement with rectifying voltmeter is difficult) approximately match. The motor must be run at the base speed with 100% load, and the secondary resistance (B02-2, 3) adjusted so that the rated voltage (B01-3) and output voltage (monitor D03-1 if measurement with rectified voltmeter is difficult) approximately match. In the same manner, adjust the M fluctuation compensation coefficient (B34-2 to 7) so that the output voltage matches the no-load voltage (B01-9) at each speed in B33-2 to 7. B34-0, 1 is the M fluctuation compensation coefficient at the B33-0, 1 speed, and normally is approx. 100%. This does not need to be adjusted except in special cases.

- * If manual adjustment is difficult after the simple adjustment mode, execute automatic tuning with the automatic tuning mode 3, 4 (B19-0=3, 4). Note that the motor will rotate in this mode.
- 2) Adjusting the IM speed sensor-less vector control (when C30-0 f_{0} = 2 mode is selected) When using IM speed sensor-less vector control, the following items must be adjusted.
 - Adjusting the ASR response

The ASR control response must be set to approx. 5rad/s for IM speed sensor-less vector control. Adjust ASR response (A10-0) to below the default value. Refer to section (3) for details on adjusting this item.

• Finely adjusting the primary resistance

Carry out test operation at the minimum speed to be used in the no-load (only inertial load) state, and finely adjust the primary resistance value. Adjust the primary resistance value (D02-0, 1) so that the speed amplifier output (D11-4) is approximately zero during forward run. Make sure that the output is not a negative value. In rare cases, if the output is a minus value, the operation may not stop because of the regenerative limiter (B31-3, 4, 5, 6).

(Note 1) The primary resistance value mantissa section (B02-0) can be changed during operation, but the B02-1 exponential section cannot be changed during operation.

• Finely adjusting the leakage inductance and exciting inductance

After automatic tuning, run the motor with a rated load at the motor's rated speed, and adjust the leakage inductance (B02-4, 5) and exciting inductance (B02-6, 7) so that the output voltage (D03-1) is approximately the same as the rated voltage. (If a rated load cannot be set, adjust so that the voltage matches the load.) If the output voltage drops during the load operation, increase the leakage inductance [mH] in increments of 10% (+ Δ L[mH]), and decrease the exciting inductance by - Δ L[mH]. If an overcurrent, etc., occurs in low-speed ranges after the above adjustment, decrease the above Δ L adjustment amount, or adjust the ACR response (A11-0, 1).

(Note 2) The B02-4 and B02-6 mantissa section can be changed during operation, but the B02-5, and B02-7 exponential section cannot be changed during operation.

- Adjusting the speed estimation Confirm that the motor speed % display (D00-3) is stable (±1% or less) during test operation. If not stable, adjust the speed estimation proportional gain (B31-1) and speed estimation integral gain (B31-2).
- 3) Adjusting ASR

Adjust the control parameters to match the user's system.

The main adjustment parameters are explained below.

 A10-0: ASR response : Set the speed control response with a [rad/s] unit. If the speed tracking is slow, increase this value. If this is set to high, the motor speed will hunt.
 A10-1: Machine time constant 1 : Set the time required to accelerate from zero to the base speed at the rated torque.

Tm [ms] = $10.97 \times J [kg m^2] \times (Nbase[min^{-1}])^2 / Power [W]$

J : Total inertial [kg·m²] (= $1/4 \times GD^2$ [kg·m²])

- Nbase : Base speed [min⁻¹]
- Power: Motor rated output [W]
- A10-2: Integral time constant compensation coefficient:

Increase the compensation coefficient if overshooting is large during speed control.

- A10-3: ASR drive torque limiter : Increase this value when drive torque is required.
- A10-4: ASR regenerative torque limiter:

Increase this value when regenerative torque is required.

Refer to Section 6-8 for details on adjusting these parameters.

(Note) When the test operation of the isolated motor is finished, the parameter A10-1: machine time constant setting is set to match the isolated motor's inertia. After connecting the motor to the load, always reset this parameter to match the inertia of the user's machine.

After this, refer to Chapter 4 and carry out the settings and adjust the load operation to match the user's application.

Refer to Section 6-8 for details on adjusting the vector control system parameters.

3-4-3 Automatic tuning and test operation for PM motor with sensor control (C30-0 f0 =4)



When using the PM motor with sensor control, use with FWD, F.RUN as forward run and Rev, R.RUN as reverse run.

With the VAT300, the counterclockwise rotation (CCW) looking from the motor shaft is defined as forward run, and clockwise rotation (CW) is defined as reverse run.



Fig. 3-4-3-a Definition of VAT300 motor rotation direction

Table 3-4-3-a

Refer to Table 3-4-3-a, and confirm that the speed detection option compatible with the encoder in use has been prepared. Refer to Chapter 7 for details on the speed detection option.

Encoder type	Speed detection option (Instruction Manual No.)	
1) A, B, Z phase + U, V, W phase signals	U30V24DN3 (PCST-3482)	
2) A, B, Z phase + serial absolute signals	U30V24DN2 (PCST-3481)	
3) A, B, Z phase + U, V, W phase signals (reduced-wiring type)	U30V24DN2 (PCST-3481)	
4) Sine wave signal	U30V24DN4 (PCST-3483)	

- 1) A, B, Z phase + U, V, W phase signals This incremental encoder outputs the A, B, Z phase and U, V, W phase pulse signals.
- 2) A, B, Z phase + serial absolute signals This encoder outputs the A, B, Z phase pulse signals and serial absolute signal.
- A, B, Z phase + U, V, W phase signals (reduced-wiring type) With this encoder, the output signals are the same as the 1) type, but there are three output signal wires, and the A, B, Z phase and U, V, W phase output signals can be interchanged.
- 4) Sine wave signal This encoder outputs a multi-cycle (i.e., 2048 cycle) 2-phase sine wave signals SIN, COS (equivalent to A, B phases) with one rotation, and outputs the Z-phase pulse and 1-cycle 2-phase sine wave signals SIN and COS with one rotation.

This automatic tuning must be carried out with the motor isolated from the load and machine. If mechanical brakes are applied on the motor, make sure that the brakes can be released during automatic tuning.

(2) Outline of automatic tuning (PM motor control mode)

This automatic tuning is a function with automatically adjusts the phase angle (C51-4) of the encoder Z phase pulse and PM motor U phase coil. Automatic tuning in the PM motor control mode does not have the PM motor circuit constant measurement function. The number of encoder pulses and the encoder signal type selection must be set.

When C51-4 is automatically adjusted with this automatic tuning function, the phase does not need to be adjusted when installing this encoder onto the PM motor. Even if the adjustment has been completed, it should be readjusted to increase the adjustment accuracy.

B19-0=6: Mode 6: PM motor control encoder phase adjustment mode (Execution time: approx. 7 sec.)





(Note) When using the PM motor with sensor control (C30-0 f_0 = 4), the automatic tuning function will not start even if B19-0 = 0 to 5 is selected.



(3) Automatic tuning operation procedures (PM motor control mode)

Adjust the magnetic pole position estimation function with the following procedure. Refer to Chapter 4 for details on using the operation panel.



Fig. 3-4-3-c Procedures for automatically tuning the encoder phase for PM motor control

1) Preparation (Before turning the power ON)

Separate the motor and load, machine, etc., and confirm the safety on the load side. Confirm at the speed detection option PCB is correctly mounted on the control PCB, and that the encoder signal wire is correctly connected to the speed detection option. Refer to the instruction manual of the speed detection option being used for details on connecting the encoder signal wire.

2) Turning the power ON and starting VAT300

Turn the power ON.

(In the case of U30V24OP1)

After carrying out an initial check of the operation panel for approx. 5 seconds, the display changes as shown on the right. The "LCL" LED also turns ON.



(In the case of U30V24OP2)

All LEDs on the numeric display will turn ON for a short time, and then "**---**, "**diff** and "**off** "will appear. The "LCL" and "Hz" LEDs will also turn ON.

(Note) When the power is turned ON next (after setting C30-0 f0 =4), "D00-2" will appear on the display, and the "Hz" LED will not light. This is because the mode is set to the PM motor vector control mode.

3) Selecting the control mode

- Set A05-2 to 1. (Set the hardware option function display ON.)
- Set the control mode selection: C30-0 f1 f0.
- This parameter must be set first. (Note 1)

PM motor with sensor control mode is to be used, so set C30-0 fO = 4.

Set c30-0 f1 f0 as shown below according to the load.

Normal overload setting: C30-0 f1 f0 = 1 4

Heavy overload setting : C30-0 f1 f0 = 2 4

(Note 1) The default value is set to V/f control and normal overload setting (C30-0=11), so always change C30-0.

There are some parameters which will change automatically when C30-0 is changed, so also set this first.

- (Note 2) If the fault "SP-5" occurs when the C30-0 setting is changed, the following causes can be considered.
 - The speed detection option is not mounted correctly.
 - The encoder signal wire is not connected correctly, or is broken.
 - Turn the inverter power OFF and check the state.

4) Initialization of motor rating and motor constants

Input the parameters required for PM motor control. Set the parameters shown in Table 3-4-3-b.

Table 3	3-4-3-b
---------	---------

Parameter No.	Name			
B01-0	Rated input voltage setting	[No.]		
B01-1	Motor rated output	[kW]		
B01-2	No. of motor poles	[Pole]		
B01-3	Rated output voltage	[V]		
B01-4	Max. speed	[min–1]		
B01-5	Base speed	[min_1]		
B01-6	Motor rated current	[A]		
B01-7	Carrier frequency			
B01-8	No. of encoder pulses	[P/R]		
B03-0	R1: PM motor primary resistance (Mantissa section)	[mΩ]		
B03-1	R1: PM motor primary resistance (Exponent section)			
B03-2	Ld: PM motor d axis inductance (Mantissa section)	[mH]		
B03-3	Lq: PM motor q axis inductance (Mantissa section)	[mH]		
B03-4	Ld, Lq: PM motor inductance (Exponent section)			

* The max. speed cannot be set below the base speed, and the base speed cannot be set above the max. speed.

5) Setting the ASR and ACR parameters

When performing automatic tuning, do not change the ASR (speed control) and ACR (current control) parameters shown in Table 3-4-3-c from the default values. Note that A10-1 must be set to the value obtained with the following expression.

Parameter No.	Name	Standard value
A10-0	ASR response	10.0 [rad/s]
A10-1	Machine time constant	1000 [s]
A10-2	Integral time constant compensation coefficient	100 [%]
A10-3	ASR drive torque limiter	100 [%]
A10-4	ASR regenerative torque limiter	100 [%]
A20-0	ACR response	1500 [rad/s]
A20-1	ACR time constant	10.0 [ms]

Table 3-4-3-c

Use the following expression and set A10-1: machine time constant according to the inertia of the isolated PM motor being used. The machine time constant (Tm) refers to the time required to accelerate to the base rotation speed from the zero speed at the rated torque.

Tm [ms] = $10.97 \times J [kg \cdot m^2] \times (Nbase [min^{-1}])^2 / Power [W]$

J : Total inertia [kg•m²] (= $1/4 \times GD^2$ [kgf•m²])

Nbase : Base rotation speed [min⁻¹]

Power: Motor rated output [W]

The parameters shown in Table 3-4-3-d are used for automatic tuning. Set these parameters to the default values when executing automatic tuning.

Table	3-4-3-d

Parameter No.	Name	Standard value
A03-2	DC brake current	50 [%]

6) Setting the encoder parameters

Four types of encoders can be used with the VAT300 PM motor with sensor control. The types and corresponding speed detection options are shown in Table 3-4-3-e.

Table 3	3-4-3-е
---------	---------

Encoder type	Speed detection option (Instruction Manual No.)
1) A, B, Z phase + U, V, W phase signals	U30V24DN3
2) A, B, Z phase + serial absolute signals	U30V24DN2
 A, B, Z phase + U, V, W phase signals (reduced-wiring type) 	U30V24DN2
4) Sine wave signal	U30V24DN4

The parameters must be set to match the encoder being used.

The parameters which must be set for each encoder are shown below.

1) A, B, Z phase + U, V, W phase signals

Parameter No.	Name		
C50-2	Encoder AB advance direction selection		
C50-3	Encoder ABZ pulse type selection		
C51-0	Encoder selection		
C51-1	AB phase-Z phase type selection		
C51-2	Encoder Z signal reversal		
C51-3	Encoder UVW advance direction selection		
C51-4	Z-IN \rightarrow U phase winding phase angle		
C51-5	$Z-IN \rightarrow U$ phase angle		
C51-6	Encoder UVW pulse type selection		

3) A, B, Z phase + U, V, W phase signals (reduced-wiring type)

Parameter No.	Name
C50-2	Encoder AB advance direction selection
C50-3	Encoder ABZ pulse type selection
C51-0	Encoder selection
C51-1	AB phase-Z phase type selection
C51-2	Encoder Z signal reversal
C51-3	Encoder UVW advance direction selection
C51-4	Z-IN \rightarrow U phase winding phase angle
C51-5	Z-IN \rightarrow U phase angle
C51-6	Encoder UVW pulse type selection
C51-7	UVW measurement start wait time
C51-8	UVW measurement time
C51-9	ABZ measurement start wait time

2) A, B, Z phase + serial absolute signals

Parameter No.	Name		
C50-2	Encoder AB advance direction selection		
C50-3	Encoder ABZ pulse type selection		
C51-0	Encoder selection		
C51-1	AB phase-Z phase type selection		
C51-2	Encoder Z signal reversal		
C51-4	Z-IN \rightarrow U phase winding phase angle		
C51-5	$Z\text{-IN} \rightarrow U$ phase angle		

4) Sine wave signal

Parameter No.	Name
C50-2	Encoder AB advance direction selection
C50-3	Encoder ABZ pulse type selection
C51-0	Encoder selection
C51-1	AB phase-Z phase type selection
C51-2	Encoder Z signal reversal
C51-4	Z-IN \rightarrow U phase winding phase angle
C51-5	$Z-IN \rightarrow U$ phase angle

(Note) C51-4: Z-IN \rightarrow U phase winding phase angle is automatically adjusted with automatic tuning. Refer to section 6-6 and set only when automatic tuning cannot be executed. The method for setting each parameter is shown below. Set these in order. When automatic tuning is executed, the parameters in Table 3-4-3-f are automatically changed, so the setting values should be noted down.

Table 3-4-3-f

Applicable mode Parameter No.		Name	
B19-0 = 6 C51-4		$Z-IN \rightarrow U$ phase winding phase angle	

[1] C51-0: Encoder selection

Select the type of encoder signal to be used.

- =1 : A, B, Z phase + U, V, W phase signals
- =2 : A, B, Z phase + serial absolute signals
- =3 : A, B, Z phase + U, V, W phase signals (reduced-wiring type)
- =4 : Sine wave signal
- [2] C50-2: Encoder AB advance direction selection

With the VAT300, the rotation in the counterclockwise direction (CCW) looking from the motor shaft is defined as forward run, and in the clockwise direction (CW) is defined as reverse run. Determine this parameter's setting value according to the phase relation of the encoder AB phase signals during forward run.



Fig. 3-4-2-d Encoder AB advance direction selection

(Note) If C50-2 is set to 2, set C50-3 to 0.

- [3] C51-1 : AB phase-Z phase type selection
- [4] C51-2 : Encoder Z signal reversal

With the VAT300, the four patterns shown in Fig.-3-4-3-e are estimated for the A, B and Z phase pulse encoder signals.

C51-1 is set based on the phase relation of the A phase signal's rising edge and the Z phase signal. With this setting and at a time of reverse running, the A phase signal's down edge during the Z phase being high is the zero point.

To generate the A phase signal rising edge when the Z phase signal is High (Fig. (a)), set C51-1 to 0. In this case, the A phase signal rising edge will be the zero point (magnetic pole position). In all other cases, set C51-1 to 1. In this case, the Z phase signal's rising edge will be the zero point. (Fig. (b)). In this case, the Z phase rising edge is the zero point even at a time of the reverse running.

If the Z phase signal needs to be reversed to match the following signal definition, set C51-2 to 1.



Fig. 3-4-3-e A, B and Z phase pulse encoder signals

(Note) If C51-2 is set to 1, set C50-3 to 0.

[5] C50-3 : Encoder ABZ pulse type selection

Only when using an encoder with signal specifications that cannot be handled with the C50-2 and C51-2 settings, set C50-3 to reverse or interchange the signals. The signal conversion circuit will function with the combination shown in the table below according to the C50-3 setting value.

(Note) Set C50-3 to 0 (no signal reversal/interchange) when C50-2 and C51-2 have been set.

A phase signal B phase signal Z phase signal

C50-3 setting value	A-IN forward/ reverse run	B-IN forward/ reverse run	Z-IN forward/ reverse run	AB inter- change	
0	-	-	-		
1	Reverse	-	-		
2	-	Reverse	-	No	
3	Reverse	Reverse	-	inter-	
4	-	_	Reverse	change	Reverse
5	Reverse	-	Reverse		A-IN1 AB interchange
6	-	Reverse	Reverse		A phase sigr
7	Reverse	Reverse	Reverse		\square
8	_	_	_		Z-IN Z phase sign
9	Reverse	_	-		
10	-	Reverse	-		
11	Reverse	Reverse	-	AB inter- change	Fig. 3-4-3-f Signal conversion circuit
12	-	-	Reverse		
13	Reverse	-	Reverse		
14	-	Reverse	Reverse		
15	Reverse	Reverse	Reverse		

- [6] C51-3 : Encoder UVW advance direction selection
- [7] C51-6 : Encoder UVW pulse type selection

Set these parameters when using an A, B, Z phase + U, V, W phase signal or wire-reduced type A, B, Z phase + U, V, W phase signal encoder.

When using the wire-reduced type A, B, Z phase + U, V, W phase signal encoder, the VAT300 defines the first signal input in the A, B, Z phase signal wire as the U, V, W phase signals respectively.

Refer to the following figure and set C51-3 according to the phase relation of the encoder's U, V, W phase signals during forward run (CCW rotation).



Fig. 3-4-3-g Relation of UVW signal phases

Only when using an encoder with signal specifications that cannot be handled with the C51-3 setting, refer to the following figure and table, and set C51-6 to reverse the signals.

(Note) Set C51-6 to 0 (no interchange) when C51-3 is set to 2.

C51-6 setting value	U-IN forward/ reverse run	V-IN forward/ reverse run	W-IN forward/ reverse run
0	-	-	-
1	Reverse	-	-
2	-	Reverse	-
3	Reverse	Reverse	-
4	Ι	Ι	Reverse
5	Reverse	-	Reverse
6	-	Reverse	Reverse
7	Reverse	Reverse	Reverse



[8] C51-5 : Z-IN \rightarrow U phase angle

1) For A, B, Z phase + U, V, W phase signal or wire-reduced type A, B, Z phase + U, V, W phase signal

If there is a phase difference between the Z phase pulse and U phase pulse of the encoder being used, set that phase difference in C51-5.

If there is no phase difference between the Z phase pulse and U phase pulse, set "0°".



Fig. 3-4-3-i Encoder Z phase and U, V, W phase signals (during CCW rotation)

2) For A, B, Z phase + serial absolute

Only when there is a phase difference between the Z phase pulse and serial absolute signal zero point, set that phase difference with an angle unit.



Fig. 3-4-3-j Encoder Z phase and serial absolute signal (during CCW rotation)

- 3) For sine wave signal
 - Set the phase of the sine wave signal generated by the Z phase pulse of the encoder in use in C51-5.



Fig. 3-4-3-k Encoder Z phase and sine wave signal (during CCW rotation)

(9) Setting the parameters for the wire-reduced type A, B, Z phase + U, V, W phase signal encoder When using a wire-reduced type A, B, Z phase + U, V, W phase signal encoder, set the parameters shown below according to the specifications of the encoder in use.

Name
UVW measurement start wait time
UVW measurement time
ABZ measurement start wait time

The A, B, Z phase signal wires have a high impedance (hereafter, HI-Z) when the encoder power is turned ON. Set the UVW signal measurement start time in C51-7 based on the time that all three wires are released from the high impedance state.

Set the UVW signal measurement end time in C51-8 based on the UVW signal measurement start time (C51-7).

(If the UVW signal cannot be measured before this time elapses, the fault "SP-6" will be output.) Set the time to wait before starting control with the ABZ signal in C51-9 based on the UVW signal measurement end time (C51-8).

(Note) The timer runs at a 2ms cycle, so all times set here must be as even umber.



Fig. 3-4-3-I Output signals for wire-saving type encoder

7) Selecting and executing the automatic tuning mode

Select the automatic tuning mode and execute automatic tuning.

- The operation panel's operation mode must be set to "Local" to execute automatic tuning. Make sure that the "LCL" LED is ON. If not, press the $\begin{pmatrix} ILL \\ SET \end{pmatrix}$ + $\begin{pmatrix} STOP \\ O \end{pmatrix}$ keys, and confirm that the "LCL" LED turns ON.
- Set A05-0 to 1. (Set the expanded setting display ON.)
- Set B19-0 (automatic tuning selection) to 6.
- The automatic tuning standby state will be entered when the $\left(\frac{LL}{ST}\right)$ key is pressed.
- During the automatic tuning standby state and the automatic tuning execution state, the "LCL" LED will flicker.
- To exit the automatic tuning standby state, press the $\binom{STOP}{O}$ key.

8) Starting automatic tuning

Automatic tuning will start when the (I) key or (I) key is pressed according to the required rotation direction.

To stop, press the $\binom{STOP}{O}$ key or input the emergency stop signal (EMS) from the terminal block.

* Once automatic tuning starts, all panel operations other than the $\binom{STOP}{O}$, $\binom{RT}{MO}$ and (\blacktriangle)

keys (knobs with U30V24OP1) are disabled until the operation ends.

(Note) If mechanical brakes are applied on the motor, make sure that the brakes can be released during automatic tuning.

9) During automatic tuning execution

The progression state can be confirmed with D22-0.

(For U30 V24OP1) (For U30V24OP2) Upper level : Lower level :

Upper level : The steps required for tuning are indicated (lit).

The finished steps are indicated (lit). The step currently being executed is indicated with a flicker.

10) Normal completion of automatic tuning

When the automatic tuning ends normally, the "LCL" LED will change from a flicker to a stable light. The "RUN" LED will change from a flicker to a stable light.

11) Abnormal completion of automatic tuning

If automatic tuning ends abnormally, the "FLT" LED will turn ON and a message will appear. Investigate and check according to the error codes. Refer to section 3-4-5 for details on the error codes.

(4) Test operation (PM motor control mode)

After completing steps (1) to (3) above, perform test operation with the isolated motor, and make user there are no abnormalities.

An example for when the maximum speed (B01-4) and base speed are 600min⁻¹ is given below.

Use the following procedures to test the operation with the operation panel.

Refer to Chapter 4 for details on using the operation panel.



To prevent incorrect operation during the test operation, make sure that signals are not input into the sequence input terminal.

- 1) To enable operation with the operation panel, confirm that the "LCL" LED is ON. If not, press the $\left(\frac{\Pi}{ST}\right) + \left(\frac{\Gamma}{ST}\right)$ keys, and confirm that the "LCL" LED turns ON.
- 2) Set speed setting input point selection: C02-0= 3 (panel fixed).



The motor will rotate with the next step. Confirm the safety around the motor before starting the next step.

3) Press the $\binom{\text{KST}}{\text{MD}}$ and display D00-2 on the monitor. Then press the $\binom{\text{FWD}}{\text{I}}$ key. Operation will start. The "FWD" lamp will turn ON, and the display will change from "OFF" to a value display. The value will gradually increase, and after several seconds, will change to "300.0". This is because as the factory settings, the direct setting frequency (A00-2) is set to 300min⁻¹ and the acceleration ramp time 1 (A01-0) is set to 10sec.

CHECK

- 1. Did the motor run?
- 2. Is the run direction correct? Check the wiring and operation if abnormal.
- 3. Is the rotation smooth?

4) Press the $\binom{\text{REV}}{I}$ key and confirm that the motor runs in reverse.

(Note) Do not carry out this step if a load which cannot be run in reverse is connected.

5) Press the $\begin{pmatrix} \text{STOP} \\ O \end{pmatrix}$ key and stop the motor.

The operations for changing the speed during motor rotation are started next.

- 6) Press the $\binom{FWD}{I}$ key. The motor will forward run at the output frequency 300min⁻¹.
- 7) Press the (BT)/(MO) key several times. The Display will alternate between "**BOOD**" and "**BOOD**" (with the U30V24OP1, the **2** section of "A00-**2**: 300.0min⁻¹" will flicker).
- 8) Press the $\left(\frac{LCL}{SET}\right)$ key once.

The display will stop at " \exists \exists \vdots \vdots and the last digit will flicker. This completes preparation for changing the motor speed. The digit to be changed can be moved with the \bullet key. The speed can be increased or lowered with the \bullet keys

knobs with U30V24OP1).

- 9) Move the digit with the key, and using the key (key (knobs with U30V24OP1), raise the frequency to "600.0"min⁻¹. Then, press the key. The motor speed will increase to 600min⁻¹.
 - (Note) The operation panel motor speed change operation is set to be changed (C11-2=1) in real time at the factory shipment settings, and therefore the motor speed is changed in

real time using the (A) v keys (v knobs with U30V24OP1), without having to press the (II) key.

When the $\left(\begin{array}{c} \text{LL} \\ \text{SET} \end{array} \right)$ key is pressed, the current setting value will be saved.

A 10-second acceleration and 20-second deceleration ramp time are set as defaults. The motor will slowly increase its speed to the set value.		
Carry out the setting operations (key, key, knobs with U30V24OP1) at an approx. 100min ⁻¹ interval.		

10) When the motor speed (D00-2 display) increases to 600min⁻¹, press the $\binom{\text{STOP}}{O}$ key.

The D00-2 display will drop to "0.0" in several seconds. The "FWD" or "REV" LED will flicker for two seconds while the DC-brake is applied and the motor will stop.

This is because the default setting is A03-1=2.0 and A03-2=50 (DC brake setting).

11) Press the $\binom{\text{REV}}{I}$ key, and test the reverse run at the maximum speed.

(Note) Do not carry out this step if a load which cannot be run in reverse is connected.

This completes the test operation with the operation panel.

After this, refer to Chapter 4 and carry out the settings and adjust the load operation to match the user's application.

Refer to Section 6-9 for details on adjusting the PM motor vector control system parameters.

(Note) When the operation of the isolated motor ends, the parameter A10-1: machine time constant setting matches the motor unit's inertia. Refer to Section 6-8 and reset this parameter to match the inertia of the user's machine.

3-4-4 Magnetic pole position estimation function and test operation for PM motor with sensor control (C30-0 f0 = 4)

This function can be used only with a system that drives a PM motor and which the motor is locked with mechanical brakes when stopped. Refer to Section 3-4-3 for all other cases.			
(1) Before adjusting magnetic pole position estimation function For PM motor with sensor control, the speed detection option is required in addition to the VAT30 standard unit. When using the PM motor control mode, use with EWD, E RUN as forward run and Rev. B RUN at the PM motor control mode.)0		

When using the PM motor control mode, use with FWD, F.RUN as forward run and Rev, R.RUN as reverse run.

With the VAT300, the counterclockwise rotation (CCW) looking from the motor shaft is defined as forward run, and clockwise rotation (CW) is defined as reverse run.



Reverse run (CW)



Fig. 3-4-4-a Definition of VAT300 motor rotation direction

Refer to Table 3-4-4-a, and confirm that the speed detection option compatible with the encoder in use has been prepared. Refer to Chapter 7 for details on the speed detection option.

Table 3-4-4-a				
Encoder type	Speed detection option (Instruction Manual No.)			
A, B, Z phase signals	U30V24DN1 (PCST-3480) U30V24DN2 (PCST-3481) U30V24DN3 (PCST-3482) U30V24DN4 (PCST-3483)			

(2) Outline of magnetic pole position estimation function

The magnetic pole position estimation function is a special function for driving the PM motor with an incremental encoder has only the A, B, Z phase signals instead of the U, V, W signals or absolute value signals. This function searches for the stopped PM motor's magnetic pole position in approx. two seconds when starting operation for the first time after turning the power ON.

After the motor starts running, the estimated magnetic pole position information is used for several rotations until the encoder's correct Z phase signal is detected. Once the Z phase signal is detected, the motor runs using that Z phase signal as a reference. If a fault occurs, the magnetic pole position is estimated again when operation starts again.

It may be necessary to adjust the magnetic pole position estimation function depending on the PM motor being used. When B19-0 is set to 7, the magnetic pole position estimation adjustment mode which executes the magnetic pole position estimation operation only once is enabled. Adjust the magnetic pole position estimation with this mode before starting the motor operation.

(Note) The parameters are not automatically adjusted just by setting B19-0 to 7 and pressing the $\begin{pmatrix} FWD \\ I \end{pmatrix}$

and $\begin{pmatrix} \Pi \\ I \end{pmatrix}$ keys. This mode executes magnetic pole position estimation operation just once for adjustment purposes.


(3) Adjusting magnetic pole position estimation function

Carry out automatic tuning with the following procedures. Refer to Chapter 4 for details on using the operation panel.



Fig. 3-4-4-b Procedures for adjusting magnetic pole position estimation function for PM motor control

1) Preparation (Before turning the power ON)

Confirm that the motor is locked with mechanical brakes. Confirm at the speed detection option PCB is correctly mounted on the control PCB, and that the encoder signal wire is correctly connected to the speed detection option. Refer to the instruction manual of the speed detection option being used for details on connecting the encoder signal wire.



(Note) When the power is turned ON next (after setting C30-0 f0 = 4), "D00-2" will appear on the display, and the "Hz" LED will not light. This is because the mode is set to the PM motor vector control mode.

3) Selecting the control mode

- Set A05-2 to 1. (Set the hardware option function display ON.)
- Set the control mode selection: C30-0 f1 f0. This parameter must be set first.

PM motor with sensor control mode is to be used, so set C30-0 f0 = 4.

Set c30-0 f1 f0 as shown below according to the load.

Normal overload setting: C30-0 f1 f0 = 1 4

Heavy overload setting : C30-0 f1 f0 = 2 4

- (Note 1) The default value is set to V/f control and normal overload setting (C30-0=11), so always change C30-0.
- (Note 2) If the fault "SP-5" occurs when the C30-0 setting is changed, the following causes can be considered.
 - The speed detection option is not mounted correctly.
 - The encoder signal wire is not connected correctly, or is broken
 - Turn the inverter power OFF and check the state.

4) Initialization of motor rating and motor constants

Input the parameters required for PM motor control. Set the parameters shown in Table 3-4-4-b.

Parameter No.	N	ame	
B01-0	Rated input voltage setting	[No.]	
B01-1	Motor rated output	[kW]	
B01-2	No. of motor poles	[Pole]	
B01-3	Rated output voltage	[V]	
B01-4	Max. speed	[min ⁻¹]	
B01-5	Base speed	[min ⁻¹]	
B01-6	Motor rated current	[A]	
B01-7	Carrier frequency		
B01-8	No. of encoder pulses	[P/R]	
B03-0	R1: PM motor primary resistan	ce (Mantissa section)	[mΩ]
B03-1	R1: PM motor primary resistance (Exponent section)		
B03-2	Ld: PM motor d axis inductance (Mantissa section) [mH]		
B03-3	Lq: PM motor q axis inductance (Mantissa section) [mH]		
B03-4	Ld, Lq: PM motor inductance (Exponent section)		

Table 3-4-4-b

* The max. speed cannot be set below the base speed, and the base speed cannot be set above the max. speed.

5) Setting the ASR and ACR parameters

Do not change the ASR (speed control) and ACR (current control) parameters shown in Table 3-4-4-c from the default values before adjusting the magnetic pole position. Note that A10-1 must be set to the value obtained with the following expression.

Parameter No.	Name	Standard value
A10-0	ASR response	10.0 [rad/s]
A10-1	Machine time constant	1000 [s]
A10-2	Integral time constant compensation coefficient	100 [%]
A10-3	ASR drive torque limiter	100 [%]
A10-4	ASR regenerative torque limiter	100 [%]
A20-0	ACR response	1500 [rad/s]
A20-1	ACR time constant	10.0 [ms]

Table 3-4-4-c

Refer to the following expression, and set the A10-1: machine time constant setting to match the inertia of the entire load connected with the PM motor. The machine time constant (Tm) refers to the time required to accelerate to the base rotation speed from the zero speed at the rated torque.

Tm [ms] = $10.97 \times J [kg \cdot m^2] \times (Nbase [min^{-1}])^2 / Power [W]$

: Total inertia [kg•m²] (= $1/4 \times GD^2$ [kgf•m²])

Nbase : Base rotation speed [min⁻¹]

Power : Motor rated output [W]

6) Setting the encoder parameters

The encoder parameters shown in Table 3-4-4-d must be set.

Parameter No.	Name
C50-2	Encoder AB advance direction selection
C50-3	Encoder ABZ pulse type selection
C51-0	Encoder selection
C51-1	AB phase-Z phase type selection
C51-2	Encoder Z signal reversal
C51-4	7-IN \rightarrow U phase winding phase angle

Table 3-4-4-d

The method for setting each parameter is shown below. Set these in order.

[1] C51-0: Encoder selection

Use the default value when using the magnetic pole position estimation function.

[2] C50-2: Encoder AB advance direction selection

With the VAT300, the rotation in the counterclockwise direction (CCW) looking from the motor shaft is defined as forward run, and in the clockwise direction (CW) is defined as reverse run. Determine this parameter's setting value according to the phase relation of the encoder AB phase signals during forward run.





(Note) If C50-2 is set to 2, set C50-3 to 0.

- [3] C51-1 : AB phase-Z phase type selection
- [4] C51-2 : Encoder Z signal reversal

With the VAT300, the four patterns shown in Fig.-3-4-3-c are estimated for the A, B and Z phase pulse encoder signals.

C51-1 is set based on the phase relation of the A phase signal's rising edge and the Z phase signal. With this setting and at a time of reverse running, the A phase signal's down edge during the Z phase being high is the zero point.

To generate the A phase signal rising edge when the Z phase signal is High (Fig. (a)), set C51-1 to 0. In this case, the A phase signal rising edge will be the zero point (magnetic pole position). In all other cases, set C51-1 to 1. In this case, the Z phase signal's rising edge will be the zero point. (Fig. (b)). In this case, the Z phase rising edge is the zero point even at a time of the reverse running.

If the Z phase signal needs to be reversed to match the following signal definition, set C51-2 to 1.





(Note) If C51-2 is set to 1, set C50-3 to 0.

[5] C50-3 : Encoder ABZ pulse type selection

Only when using an encoder with signal specifications that cannot be handled with the C50-2 and C51-2 settings, set C50-3 to reverse or interchange the signals.

The signal conversion circuit will function with the combination shown in the table below according to the C50-3 setting value.

(Note) Set C50-3 to 0 (no signal reversal/interchange) when C5-2 and C51-2 have been set.

C50-3 setting value	A-IN forward/ reverse run	B-IN forward/ reverse run	Z-IN forward/ reverse run	AB inter- change	
0	-	_	-		
1	Reverse	_	-		
2	_	Reverse	_	No	
3	Reverse	Reverse	_	inter-	
4	_	_	Reverse	change	Reverse
5	Reverse	_	Reverse		A-IN1 AB interchange
6	_	Reverse	Reverse		A phase sign
7	Reverse	Reverse	Reverse		B phase sign
8	_	_	_		Z-IN Z phase sign
9	Reverse	_	_		
10	_	Reverse	_		
11	Reverse	Reverse	-	AB inter-	Fig. 3-4-4-e Signal conversion circuit
12	_	_	Reverse	change	
13	Reverse	_	Reverse	1 -	
14	_	Reverse	Reverse		
15	Reverse	Reverse	Reverse	1	

[6] C51-4: Z-IN \rightarrow U phase winding phase angle

This can be automatically adjusted with automatic tuning when the motor can be run in an isolated state without a load connection. Release the external brakes, and refer to Section 3-5-3 and carry out step 7 and following of the Fig. 3-4-3-c flow chart.

In other cases, this parameter is adjusted after the magnetic pole position estimation function has been adjusted. Proceed to adjustment of the magnetic pole position estimation.

7) Adjusting the magnetic pole position estimation function The magnetic pole position estimation function is adjusted.

- [1] Select the magnetic pole position estimation mode with the magnetic pole position estimation selection (B39-0 f0).
 When the magnetic pole position estimation function is used, normally f0 = 2 should be selected. If the motor has a reverse inductance (Ld<Lq), select f0 = 3. (Refer to Section 6-9 for an explanation on the PM motor circuit constant.) Select f0 = 3, when not using a magnetic pole position estimation function, or when you stop use.

When the magnetic pole position estimation function starts normally, the operation will end in approx. two seconds.

(Note) The parameters are not automatically adjusted just by setting B19-0 to 7 and pressing

the $\begin{pmatrix} FWD \\ I \end{pmatrix}$ and $\begin{pmatrix} REV \\ I \end{pmatrix}$ keys. This mode executes magnetic pole position estimation operation just once for adjustment purposes.

[3] Adjust the magnetic pole position estimation function

The parameters required for adjusting the magnetic pole position estimation function are shown in Table 3-4-4-e. The parameters which indicate the magnetic pole position estimation results are shown in Table 3-4-4-f.

Table 3-4-4-e			
Parameter No.		Name	
B39-1	Magnetic pole positio	n estimation voltage	
B39-2	Magnetic pole position estimation time		
B39-3	Voltage error correction current		
A20-0	ACR response	(PM motor control)	
A20-1	ACR time constant	(PM motor control)	

Table 3-4-4-f

Parameter No.	Name	Adjustment reference
D16-0	Characteristic amount during magnetic pole position estimation 1	Adjust to 120% or more.
D16-1	Characteristic amount during magnetic pole position estimation 2	Adjust to 120% or more.
D16-2	Magnetic pole position estimation current	Make sure the current does not exceed 120%. If too high, the inverter could stop with an overcurrent (OCT) fault.
D16-3	Magnetic pole position estimation error	Adjust to within 10°.

If B39-1, 2 (magnetic pole position estimation voltage) is increased, D16-0, 1 will increase. Adjust to match the adjustment reference conditions given in Table 3-4-4-f.

When D16-0, 1 is at the adjustment reference value, normally, the D16-3 value will be within the adjustment reference range.

If B39-1, 2 is too large, the noise during estimation will increase. If the generated noise is too large, decrease D39-1, 2 within the range that the adjustment reference given in Table 3-4-4-f is satisfied.

To decrease B39-1, 2, first decrease B39-1. If the noise is still large even after B39-1 is decreased by 20%, then decrease B39-2.

If D16-0 to 3 do not stabilize even after carrying out the magnetic pole position estimation operation repeatedly, it might stabilize by increasing B39-3 by approx. 20%. However, normally B39-3 can be set to the default value without problem.

If the magnetic pole position estimation function operation takes more than two seconds, ACR must be adjusted. Increase A20-0 (ACR response) or decrease A20-1 (ACR time constant) so that the magnetic pole position estimation operation ends in approx. two seconds.

If the magnetic pole position estimation results are not stable for any reason, the magnetic pole position estimation function cannot be used. Use an encoder with a magnetic pole position detection signal, such as a UVW signal or serial absolute signal. Refer to Section 3-5-3, set the encoder, and carry out test operation.

- [4] When finished adjusting the magnetic pole position estimation function, return the setting to B19-0=0.
 - (Note 1) When the magnetic pole position estimation adjustment mode is carried out with B19-0 set to 7, the SFP (magnetic pole position established) flag is set so the magnetic pole position will not be estimated the next item operation is set. B19-0 must be returned to 0.
 - (Note 2) After setting these parameters, do not move the encoder fixed onto the motor, or interchange the motor's U, V, W phase wires.

(4) Setting the parameters for the external brake function, etc.

1) Setting the external brake control function

The external brakes can be turned ON and OFF following the inverter's internal sequence. The external brake function has various wait time settings and interlock functions. This function is set. The parameters which need to be set are shown in Table 3-4-4-g.

Name
External brake selection
Brake open wait time (LB)
Acceleration start wait time (BL)
Brake close wait time (DB)
RUN error judgment time at brake closed
Brake answer error judgment time

Table	3-4-4-a
Table	J-1-1-3

[1] B46-0: External brake selection

Set B46-0 10 to 2 to use the external brake control function. When B46-0 11 is set to 2, the interlock function using IDET is enabled. If IDET does not turn ON when the brakes are released (immediately after LB), the motor will stop with a fault "IO-C". Set the control mode for the acceleration wait time (LB, BL) with B46-0 12. When 12 is set to 1, the normal operation mode is enabled. When 12 is set to 2, the DC brake mode is enabled.

- [2] B46-1: Brake open wait time (LB) Set the time to wait (LB) from RUN to brake open.
- [3] B46-2: Acceleration start wait time (BL) Set the wait time (LB) from brake open to start of acceleration.
 If brake answer is enabled (B46-5≠0.0sec) set the time after brake answer. If brake answer is disabled (B46-5=0), set the time from the brake open command.
 When using normal operation mode setting, the program settings will not be changed during BL, and instead the settings prior to BL will be held.
- [4] B46-3: Brake close wait time (DB) Set the wait time (DB) from time from ZSP (zero speed) ON to brake close.
- [5] B46-4: RUN error judgment time at brake closed If RUN does not turn OFF at the time set in D46-4 after the brakes are closed, the host controller will judge that there is an error, and will stop the motor with the external brake RUN error (IO-D) fault. RUN error judgment can be turned OFF by setting 0.0sec.
- [6] B46-5: Brake answer error judgment time If brake command (MBRK) and brake answer (MBRK_ans) do not match for longer than the time set in B46-5, it will be judged as an external brake fault, and the motor will stop with the external brake answer error (IO-E) fault. Brake answer error judgment can be turned OFF by setting 0.0sec.



An example of the external brake sequence is shown below.





(b) Example of external brake sequence when using DC brake (B46-0 f2=2) and no brake answer (B46-5=0.0.)

Fig. 3-4-4-f Example of external brake sequence

External brake control (B46) is sequenced with magnetic pole position estimation function. The external brake control starts after the magnetic pole position estimation is completed. Thus, the magnetic pole position estimation time does not need to be considered for the external brake function.

2) Setting the external brake control sequence

- [1] The J1 setting must be turned ON to use external brake control or the other sequence functions. Set C00-5 to 2.
- [2] Set the external brake signal (MBRK) sequence output function. Refer to the following table, and set "27" for the parameter corresponding to the output terminal being used. Set "-27" to reverse the signal.

Control PCB output terminal	Corresponding parameter
RC-RA	C13-2
PS01	C13-3
PS02	C13-4
PS03	C13-5
FA-FC	C13-6

[3] Set the external rake answer signal (MBRK_ans) sequence input function. Refer to the following table and set the value corresponding to the input terminal (control PCB PSI1 to 11) in C04-E. Set a negative value to reverse the signal.

Control PCB input terminal	C04-E setting value (Note 2)
PSI1	1
PSI2	2
PSI3	3
PSI4	4
PSI5	5
PSI6	6
PSI7	7
PSI8 (Note 1)	8
PSI9 (Note 1)	9
PSI10 (Note 1)	10
PSI11 (Note 1)	11

(Note 1) PSI8 to 11 are the relay option PCB's sequence input terminals. Prepare the relay option to use these.

(Note 2) Do not set C04-E to "0" or "16". The MBRK_ans signal input will be fixed to OFF or fixed to ON.

3) Setting the ACR reverse run prevention function

If the motor must not rotate in the reverse direction of the run command, set the reverse run detection error level in C24-7. If the motor rotates in the reverse direction, it will stop with a fault. Set this parameter as a percentage of the error detection level speed using the base speed as 100%. This function is invalid when "0" is set.

(5) Setting the C51-4: Z-IN \rightarrow U phase winding phase angle parameter

In the PM motor control mode, the C51-4: Encoder Z-IN \rightarrow U phase winding phase angle parameter must be set. Set this parameter.

If the settings up to this point have not been completed, refer to the previous section and complete the settings.

(Note) This can be automatically adjusted with automatic tuning when the motor can be run in an isolated state. Release the external brakes, and refer to Section 3-4-3 and carry out step 7 and following of the Fig. 3-4-3 flow chart. This step can be skipped if the parameter is set with automatic tuning.

This parameter must be set only once at the very start of operation.

After setting this parameter, do not move the encoder fixed onto the motor, or interchange the motor's U, V, W phase wires.

1) The motor must be rotated to set this parameter.

First, set the speed and ramp time parameters required for rotating the motor. Refer to Table 3-4-4-h and set each parameter.

Parameter No.	Name	Setting method
A00-2	Direct setting speed	Set the motor speed with a [min ⁻¹] unit.
A01-0	Acceleration ramp time	Set the acceleration time from stop to maximum
A01-1	Deceleration ramp time	speed, and the deceleration time from maximum speed to stop.

Table	3-4-4-h
IGNIO	• • • •



- 3) Set B39-0 f1 to 2. With this setting, the encoder's Z phase is not used, and the motor is run with the estimated magnetic pole phase. Start and stop in this mode.
- Set the speed with the operation panel. Set the speed setting input point selection C02-0 to 3 (panel fixed). Set the motor speed in A00-2.
- 5) Open the external brakes to rotate the motor.
- 6) Input the forward run command.

To issue the command from the operation panel, press the $\binom{FWD}{I}$ key.

7) Input the stop command, and stop the motor.

To issue the command from the operation panel, press the $\binom{\text{STOP}}{O}$ key.

- 8) After stopping, set the value displayed at D26-0 in C51-4.
- 9) Set B39-0 f1 to 1. The mode will return to the normal operation mode.

(6) Test operation

When finished with automatic tuning, test run the isolated motor, and make sure that there are no errors.

Use the following procedures to test the operation with the operation panel.

Refer to Chapter 4 for details on using the operation panel.

When issuing the run/stop commands from the operation panel (local operation mode), confirm that "LCL" is ON. When using sequence input (remote operation mode), confirm that "LCL" on the

operation panel is OFF. Press the $\left(\frac{LL}{SET}\right)$

 $\binom{10P}{O}$ keys to change the operation mode.

 Set the speed from the operation panel. Set speed setting input point selection: C02-0= 3 (panel fixed). Set the motor speed in A00-2.



The motor will run. Confirm the safety around the motor before starting the next step.

- 2) Open the external brakes to rotate the motor.
- 3) Press the $\binom{\mathbb{RT}}{\mathbb{MD}}$ key to display the D00-2 on the monitor, and then input the forward run command

To issue the command from the operation panel, press the $\binom{FWD}{I}$ key.

The "FWD" lamp will turn ON, and the display will start increasing from " $\mathbf{5}\mathbf{5}\mathbf{5}$ ". Confirm the speed with D00-2, and make sure that it is equal to the A00-2 setting value.

	Л СНЕСК		
1. 2. 3.	Did the motor run? Is the run direction correct? Check the wiring and operation if abnormal. Is the rotation smooth?		
4)	Input a reverse run command and confirm that the motor runs in reverse.		
	To issue the command from the operation panel, press the $\binom{REV}{I}$ key.		
5)	Input the stop command, and stop the motor.		
	To issue the command from the operation panel, press the $\begin{pmatrix} \text{STOP} \\ O \end{pmatrix}$ key.		
The	operations for changing the speed during motor rotation are started next.		
6)	Input the forward run command.		
	To issue the command from the operation panel, press the $\begin{pmatrix} FWD \\ I \end{pmatrix}$ key.		
7)	Press the $\begin{pmatrix} BT \\ MD \end{pmatrix}$ key several times. Set so that " ABD - C " and the current speed setting value appear alternately on the display (with the U30V24OP1, the 2 section of "A00- 2 : current speed setting value min ⁻¹ " will flicker).		
8)	Press the $\begin{pmatrix} LCL \\ SET \end{pmatrix}$ key once.		
	The display will stop at the current setting value, and the first decimal digit will flicker. This completes preparation for changing the motor speed. The digit to be changed can be move with the 🔦 key. The speed can be increased or lowered with the 🔺 💌 key		
	(knobs with U30V24OP1).		
9)	Change the A00-2 setting value and press the $\begin{pmatrix} \text{LCL} \\ \text{SET} \end{pmatrix}$ key. Display D00-2 and confirm that the motor speed has changed to the set value.		
	(Note) The operation panel frequency change operation is set to be changed (C11-2=1) in re time at the factory shipment settings, and therefore the output frequency is changed		
	real time using the 🔺 🛡 keys (🔿 🏷 knobs with U30V24OP1), witho		
	having to press the $\left(\frac{LCL}{SET} \right)$ key.		
	When the $\begin{pmatrix} III \\ SET \end{pmatrix}$ key is pressed, the current setting value will be saved.		
A 1 will Cha	0-second acceleration and 20-second deceleration ramp time are set as defaults. The motor slowly increase its speed to the set value. (When the set value is not changed) ange the A00-2 setting value with an interval of 10% or less of the maximum speed. (Use the		
) 🔍 keys or 🔿 🏹 knobs with U30V24OP1.)		

10) Confirm that the motor speed (D00-2 display) is the same as the setting value, and then input the

stop command. Press the $\binom{STOP}{O}$ key when using the operation panel.

The display will decrease to "0.0" in several seconds. The "FWD" or "REV" LED will flicker for two seconds while the DC-brake is applied and the motor will stop.

This completes the test operation.

(Note) When the test operation ends, the parameter A10-1: machine time constant setting matches the motor unit's inertia. Refer to Section 6-8 and reset this parameter to match the inertia of the user's machine.

(7) Other functions of magnetic pole position estimation

1) Magnetic pole position estimation retry function

If the characteristics amount measured during magnetic pole position estimation do not reach the reference value, the magnetic pole position estimation will be retried. The retry conditions are shown in Table 3-4-4-i.

The estimation is retried up to three times. If the reference is not reached after three retries, the operation will stop with a fault (ATT-9).

If this fault occurs, adjust the magnetic pole position estimation function again.

Parameter No.	Name	Adjustment reference
D16-0	Characteristic amount during magnetic pole position estimation 1	110% or less
D16-1	Characteristic amount during magnetic pole position estimation 2	110% or less
D16-3	Magnetic pole position estimation error	20° or more

Table 3-4-4-i

2) Sequence output

The magnetic pole position setting flag can be sequence output. If C13-2 to 6 is set to 40 (FPOS), when the magnetic pole position is set the output will turn ON from the control PCB terminal corresponding to each parameter. If C13-2 to 6 is set to -40, a signal with the sequence logic reversed will be output.

Whether to output the sequence output RUN signal during the magnetic pole position estimation period can be selected with parameter B39-0 $\boxed{3}$. (ON when 1 is set, OFF when 2 is set.)



Fig. 3-4-4-g Sequence outputs related to magnetic pole position estimation

(8) Other settings and adjustments

This completes the adjustment of the magnetic pole position estimation function, setting of the external brake control function, and test operation.

Refer to Chapter 4 and set or adjust the sequence, etc., to match the user's application. Refer to Section 6-9 for details on adjusting the PM motor vector control system parameters.

3-4-5 Automatic tuning error messages

If automatic tuning ends abnormally, the following message will appear. Investigate and confirm the state following the error code.

E00:ATT-n (for U30V24OP1), 日ヒーロ (for U30V24OP2) n: Automatic tuning step

No.	Cause and remedy
n=1	The motor may not be connected correctly. Check the connection.
	The B00 and B01 parameters may not be set correctly. Check the parameter setting.
	The motor with the special circuit constants may be applied. Change B19-1and B19-2 parameters.
n=2	The B00 and B01 parameters may not be set correctly. Check the parameter setting.
n=3	The load and machine may not be separated. Separate the load and machine. Lengthen the acceleration time (A01-0). Lengthen the deceleration time (A01-1). If the motor vibrates, adjust the torque stabilizing gain (B18-2).
n=4	The load and machine may not be separated. Separate the load and machine. If the motor vibrates, increase the torque stabilizing gain (B18-2).
n=5	When the motor does not stop Increase the acceleration/deceleration time (A01-0, A01-1). When the motor does stop The B00 and B01 parameters may not be set correctly. Check the parameter setting.
n=6	The B00 and B01 parameters may not be set correctly. Check the parameter setting.
n=8	Indicates that the output voltage did not stabilize for 1 second or more during magnetic pole position estimation for the PM motor. Adjust the magnetic pole position estimation voltage (B39-1) and magnetic pole estimation time (B39-2).
n=9	Indicates that the PM motor magnetic pole estimation did not end normally even after retrying three times. Adjust the magnetic pole position estimation voltage (B39-1) and magnetic pole estimation time (B39-2).

Chapter 4 Operation Panel

4-1 Outline of operation panel types and functions

There are two types of operation panels which can be used with the VAT300, the LCD panel U30V24OP1 and LED panel U30V24OP2. The configuration of the operation panels are indicated below.

LCD panel (U30V24OP1)



The functions of each section are shown in Table 4-1.

- A protective sheet is attached to the surface of the panel when shipped. Peel of this sheet before starting use.
- When peeling the protective sheet, press the knob lightly so that it should not be dropped.
- Do not drop the panel. The panel could break if strong impact is applied.
- If the display does not appear even when the inverter power is turned ON, the cable between the panel and inverter might not be connected properly. Check the connection.
- When using the operation panel away from the inverter by using an extension cable, do not place objects on the panel. The connector section could be damaged.

Sta	tus indications l	EDs		
	FWD (Forward)	The drive is rur the forward dire	ning in ection.	When both LEDs flicker simultaneously, it indicates that DC Brake or pre-excitation is in action. If only the "FWD" or "REV" LED is flickering, this indicates that a command in the reverse direction has been
	REV (Reverse)	The drive is rur the reverse dire	ning in ection.	received, and the drive is decelerating. Refer to section 4-1-3 for the relation with the operation keys.
	FLT (Fault)	The drive has o Turns OFF who signal is input.	letected en the (a fault and has stopped. D + (I)
	LCL (Local)	The drive is in t REV and STOF controlled from between Local Change this se	he Local only). V the term and Ren	Mode and can be operated from the Operation Panel (FWD, When LED is off, the drive is in the Remote Mode and can be inal block (sequence input signals). To change Modes note, press \bigcirc + \bigcirc . ile operation is stopped.
Uni	it indication LED	s (LED panel d	edicate	d)
	Hz·A·%	Indicates the un	it of the p	parameter value shown on the display.
Mir	nus polarity indi	cation LED (LE	D panel	dedicated)
		Lights when the	e numbei	on the display is a minus number.
Ор	eration keys			
	FWD	Starts the drive	in the for	ward direction. (in Local Mode only)
	REV Starts the drive in the reverse direction. (in Local Mode only)		verse direction. (in Local Mode only)	
	STOP	Stops the drive. The motor will either coast to a stop or ramp down to a stop as selected on C00-1.		
When this key is held down for two seconds or longer during operation, the will coast to stop regardless of Local Mode or Remote Mode.		own for two seconds or longer during operation, the motor less of Local Mode or Remote Mode.		
	(STOP) + (LCL) SET	Changes control Modes from Local to Remote, or vice-versa. When the drive is in Local Mode, "LCL" LED is on. The drive is default set so that a Local/Remote selection is disabled while the drive is running. Even while the drive is at a stop, this selection cannot be made if operating commands such as RUN, JOG, etc., are being received at the terminal. This lock can be released with Parameter C09-2.		
	$\binom{\text{STOP}}{\text{O}} + \binom{\text{RST}}{\text{MOD}}$	If these keys are pressed simultaneously when the FLT LED is ON, the FLT LED will turn OFF. (Fault is reset.)		
Par	rameter operatio	n keys · Parar	neter op	eration knob
	(RST) MOD	Changes the block No. mode displayed on the indicator in the following order each time the key is pressed: Monitor \rightarrow Parameter A \rightarrow Parameter B \rightarrow Parameter C \rightarrow Utility Mode U.		
	(LCL) SET)	Fixes Paramete	r numbe	r or set its values.
		Param. Select	When m parame No. sele	nain & sub-No. selection method (C11-7=2) is selected for ter setting method, moves from sub-No. selection to main ection.
		Valve change	Moves t	he digit to increment or decrement.

Table 4-1 (1)	Functions and operations of	each operation panel section
---------------	-----------------------------	------------------------------

1

Pa	Parameter increase/decrease key, parameter increase/decrease knob				
	or O	Increases the parameter No. or parameter setting value.			
	▼ or ♥	Decreases the parameter No. or parameter setting value.			
		When the parameter is being set with the sub-No. selection method (C11-7=1), increases the parameter's main No.			
		When the parameter is being set with the sub-No. selection method (C11-7=1), decreases the parameter's main No.			
Ор	Operations dedicated for LED panel				
Held down Increases the parameter No. or setting value at a fast		Increases the parameter No. or setting value at a fast speed.			
	Held down	Decreases the parameter No. or setting value at a fast speed.			

Table 4-1 (2)	Functions and operations of each operation panel section
---------------	--

4-1-1 Data display section on each panel

Each value display is explained in this section.

The LCD panel displays the characters, parameters and setting values with a 5*8 dot, 16-digit * 2-line LCD.

The LCD panel's LCD section is expressed with the following box in this manual.



The LED panel displays the parameters and setting values with a 7-segment 5-LED + sign display LED. The LED panel's 7-segment section is expressed with the following display in this manual.





Fig 4-1-2 Relation of panel key, RUN operation and FWD, REV

4-1-3 Selecting the operation method

Two operation methods can be selected with the operation panel by setting the parameters. The parameters to be set and the operation methods are explained below.

C11-7: Operation panel operation method selection

- =1: Sub-No. selection method
 - Increase or decrease the parameter's sub-No. with the \mathbf{A} keys or \mathbf{A} .

If the sub-No. exceeds the maximum value or minimum value, the main No. will increase or decrease by 1.

This method is easy to use when holding the panel in hand and operating. * This method is the default method.

=2: Main & sub-no. selection method

The parameter is set by setting both the main No. and sub-No.

After entering the main No., press the $\frac{1}{3}$ key to enter the sub-No. selection.

If the sub-No. exceeds the maximum value or minimum value, the number will loop within the sub-No.

4-1-4 Panel display at power ON

(1) LCD operation panel (U30V24OP1)

The following display appears when the power is turned ON.



With either operation panel, the initial operation mode (C11-0) at power ON and the initially displayed parameters can be set (C11-3). In the above example, C11-0 is set to 1, and C11-3 is set to 0.00.0.



4-2 Various operations and displays when LCD panel is connected

The various LCD panel operations and displays are displayed. First, the various operation methods and displayed for the sub-No. selection method (C11-7=1) are explained.

4-2-1 Details of data display section

The outline of the Main screen is shown below.



The parameter numbers are categorized in the following manner in this manual.



4-2-2 Operating and displaying the character display section

The character display section starts left scrolling after two seconds. When the last character is displayed, the display remains for two seconds, and then the first display appears.



The character display can be selected from five languages, English, French, Italian, Spanish or German. Change the language with the parameter C11-4 setting value.

The default language is English.

Refer to section 4-2-5 Setting value operation and display for details on changing the setting value.

4-2-3 Operating and displaying parameter numbers

The flicking character can be displayed. The parameter No. will increase when the parameter increase/decrease knob is turned to the right, and will decrease when the knob is turned to the left.



Only the parameter No. is displayed when the parameter increase/decrease knob is being turned. The setting value appears 0.1s after the knob is stopped. The characters on the upper line will start to scroll at the same time.



4-2-4 Changing the block No.

If the $\binom{\text{RST}}{\text{MOD}}$ key is pressed when the parameter No. is displayed or when setting the setting value, the block will change in the order of D \rightarrow A \rightarrow B \rightarrow C \rightarrow U \rightarrow D.



4-2-5 Operating and displaying setting values

If the $\binom{LLL}{SET}$ key is pressed when the Block- A, B, C or U is displayed, the operation will shift to the setting value setting.

The flickering character moves to the setting value side.



When setting the setting value, the value can be increased and decreased by turning the parameter increase/decrease knob.



When the (4) key is pressed, the digit to be changed (flickering character) can be moved one digit to the left.

If the (•) key is pressed when the flickering character is at the top digit, it will move to the last digit.



When the setting value has been decided, press the $\left(\frac{LLL}{SET}\right)$ key again to enter the setting value. The character to be changed will also move to the parameter No.



Current display

Moves to parameter No. selection

To return to the parameter No. selection without changing the parameter with setting value setting, press the $\left(\frac{RST}{MOD}\right)$ key.

The display will change to the next block No. If the parameter for which the setting value was being changed is moved to, the setting value will return to the original value.

Note that the value will not return for A00-0: direct frequency setting and A00-2: direct speed setting.



4-2-6 Operating and displaying parameter numbers with main and sub-No. selection method

An example of operations when C11-7=2: main & sub-No. selection method is explained in this section.



With this method, if the digit to be changed (flickering character) is at the parameter number's sub-No. and the parameter increase/decrease knob is turned, the main No. will not change, and only the sub-No. will change.

To move from the sub-No. selection to the main No., press the () key. The digit to be changed will move to the main No.

If the parameter increase/decrease knob is turned when the digit to be changed is at the main No., the main No. will be changed.

To move from the main No. selection to the sub-No. selection, press the $\frac{LLL}{SET}$ key. The digit to be changed will move to the sub-No.

If the $\binom{LLL}{SET}$ key is pressed again when the sub-No. is selected, the display will change to the setting value setting.

Refer to section 4-2-5 operating and displaying the setting value, and set the setting value.

4-2-7 Displaying the sequence

With the LCD panel, the D04-0 to 3: sequence input and D04-4 to 7: sequence output are displayed as shown below. The D04-4: Sequence output 1 is shown as a display example.



- O and | indicate the status of the corresponding sequence.
 - O: Sequence OFF
 - | : Sequence ON

O and | are updated immediately when the sequence status changes. **Example** : Start of operation (Sequence output: RUN, ATN ON)



Sequence status-	

4-2-8 Displaying the fault history

When the parameter is set to D20-0 and the $\binom{LLL}{SET}$ key is pressed, the fault history display will appear. To return to the parameter selection from the fault history display status, press the $\binom{LLL}{SET}$ key again, or press the $\binom{RST}{MO}$ key.



If the parameter increase/decrease knob is turned in the fault history display status, the numbers will loop between E00 and E37, and the fault corresponding to the number will display. Refer to section 4-3-7 Fault history display for details on E00 to E37.



4-2-9 Operating and displaying during Block-A, B, C parameter change list selection

If the $\binom{\text{LUL}}{\text{SET}}$ key is pressed when the parameter is set to D20-2, the Block-A, B, C parameter change list will appear.

Press the $\binom{\text{RST}}{\text{MOD}}$ key to return to the parameter selection from the Block-A, B, C parameter change list display.



If the parameter increase/decrease knob is turned while the Block-A, B, C parameter change list is displayed, the parameters which were set or changed after power ON will appear in sequence.

If the $\binom{LCL}{SET}$ key is pressed in this state, the display will change to parameter setting value setting.

The setting value can be changed in this state.

If the $\left(\frac{LCL}{SET}\right)$ key is pressed again, the change list will reappear.

If the parameter increase/decrease knob is pressed to the last of the changed parameters, "D.CHG: D.END" will appear.

If the parameter increase/decrease knob is pressed further, the first parameter will appear.



4-2-10 Displaying the LCD panel dedicated sequence characters

If the $\binom{\text{LUL}}{\text{SET}}$ key is pressed when the parameter is set to D20-3 or 4, the sequence input or output display will appear. The parameter No. and target are shown below.

D20-3 : Sequence input

D20-4 : Sequence output

The D20-4 sequence output is explained as an example in the following section. The operations are the same for D20-3 and 4.

To return to parameter selection, press the $\binom{LLL}{SET}$ key or $\binom{RST}{MOD}$ key.



If the parameter increase/decrease knob is turned while the sequence details are displayed, the display will move up and down.



Refer to Chapter 6 List of Parameters for the names of the displayed sequences.

The ON and OFF status is updated immediately when the sequence status changes. **Example** : Start of operation (Sequence output: RUN is ON)



4-2-11 LCD panel display at fault occurrence, and resetting methods

When a fault occurs in the inverter, the following type of display will appear on the LCD panel.



When a fault occurs, the inverter operation stops, and the "FLT" LED on status display LED turns On. At the same time, the head "E00" for the fault history and the fault code appear on the LCD panel. The cause of the fault is indicated at the fault code displayed at E00 to E07.

Refer to Appendix Table 3 Fault codes for details on the fault codes.

In the above figure, an undervoltage occurred during constant speed operation and a fault occurred. If the parameter increase/decrease knob is turned while the history is displayed, the fault details can be displayed in the range of E00 to E37.

To return to the normal parameter selection from the fault history display, press the $\binom{\text{RST}}{\text{MOD}}$ key.

Resetting a fault:

Refer to the details of E00 to E07 in the fault history display and the Appendix Table 3 Fault code table, and remove the cause of the fault.

The FLT LED will turn OFF when the $(0)^{\text{transform}}$ keys are pressed or the sequence input RESET is turned ON.

Refer to Chapter 5 section 5-3 Programmable sequence input function (PSI) for details on resetting the fault with the sequence input RESET.

The display in this case is shown below.



When the fault is reset, the LCD panel display will return to the D monitor parameter from the fault history state.

Confirm that the cause of the fault has been removed, and then resume operation.

4-3 Various operations and displays when LED panel is connected

The various LED panel operations and displays are displayed. First, the various operation methods and displayed for the sub-No. selection method (C11-7=1) are explained.

4-3-1 Operating and displaying the parameter No.

The methods for operating the parameter No. are shown below. Refer to Table 4-1 for details on the key functions.



When operating with the sub-No. selection method, the decimal point dot for the third digit from the right turns ON while the key is pressed to indicate that the main No. is being changed. Press the $\binom{\text{ILL}}{\text{SET}}$ key to check the parameter No. with the monitor display.

4-3-2 Operating and displaying the setting value

Refer to Sections 6-2 to 6-5, for the details of the Block-A, B and C parameters.

<keys></keys>	<display, led="" unit=""></display,>	<explanation></explanation>		
Change the Parameter: B00-4 maximum output frequency (Fmax) from 50.0 to 60.0				
DET	88000 A %	(In Monitor Mode)		
(RST)	888.38. ^{Hz} %	Changes to the Block-A Parameter setting Mode.		
	88888	Changes to the Block-B Parameter setting Mode.		
Three times		Increase the parameter No. from parameter B00-0 to B00-4.		
(LCL) SET	\$\$0.00 A %	The display will alternate between Parameter Number B00-4 and the present setting value 50.00.		
	850.08 ^{HZ} %	Enable the value to be changed. The preset setting value will display.		
Three times	8.5000 Å %	Press three times to move the flicker to the digit that is to be changed. (Note: Parameter B00-4 cannot be changed while the		
		inverter is running.)		
	888888 ^{Hz} %	Change the flicker digit from 5 to 6.		
SET	$\begin{array}{c} 88800 \\ 4 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1$	Fix the data. Changing of Parameter B00-4 to 60.0 will be completed.		
	80039. ^{Hz} %	The display will alternate between parameter No.: B00-4 and current setting value: 60.00.		

<keys></keys>	<display, led="" unit=""></display,>	<explanation></explanation>
Change the parame	eter A03-1 (DC Breaking	Time) from 2.0 (default value) to 3.5.
	BBBBBB ^{MZ} ^A %	(In B00-4 Parameter Setting Mode)
RST	88888	Changes to the Block-C Parameter Setting Mode.
(RST MOD)	88888	Changes to the Utility Mode. (For future use)
(RST MOD	888888 ^{HZ} *	Changes to the Monitor Mode.
(RST MOD	888388 ^{Hz} ^A %	Changes to the Block-A Parameter Setting Mode.
	888888 ^{HZ} ^A %	
+	888.88	Increase the Parameter Block Number from A00-0 to A03-1.
	80880. A	
	88888	The display will alternate between Parameter Number
	↑ ↑ 8.8.8.8 .8	A03-1 and the present value 2.0.
SET	8.8.8.8.8	Enable the value to be changed. The preset setting value will display.
Five times	8.8.8.8.8	Change the flicker digit from 0 to 5.
	8.8.8.8.8	Move the flickering digit to the digit to be changed
	88885	Change the flicker digit from 2 to 3.
LCL SET	88835	Fix the data. Changing of parameter A03-1 to 3.5 will be completed.
	80388	The display will alternate between the Parameter Number A03-1 and the present value. (Parameter Number Changing Mode.)

(Note) If the BBA (RUN) display appears when changing from the parameter No. to the setting No. change state, the parameter is one that can be changed only while the inverter is stopped.

4-3-3 Operating the monitor parameters with the main & sub-No. selection method

An example of the operations when the main & sub-No. selection method (C11-7=2) is selected is given below.

<keys></keys>	<display, led="" unit=""></display,>	<explanation></explanation>	
After viewing the ou with a [Hz] unit is d	After viewing the output current with a [%] unit, the parameter which displays the output frequen with a [Hz] unit is displayed.		
	880.00 A %	D00-0 : Output frequency	
	888.88 A %	Changes to the main No. selection.	
	889988 ^{HZ} %	The main No. increases.	
	882.88 ^{Hz} %	The main No. increases.	
	808.58 . %	Changes to the sub-No. selection.	
	888.58 , ^{Hz} ∳	The sub-No. increases. D02-1 is displayed.	
	$\begin{bmatrix} 88835 \\ 4 \end{bmatrix}_{4}^{Hz}$	After one second, the display will show the output current as a percentage.	
	882.88 ^{Hz} %	The main No. decreases.	
	80130 *	The main No. decreases.	
	$\begin{array}{c} \textbf{\textbf{\textbf{B}}} \textbf{\textbf{B}} \textbf{\textbf{B}} \textbf{\textbf{B}} \textbf{\textbf{B}} \textbf{\textbf{B}} \textbf{\textbf{B}} \textbf{\textbf{A}} \\ \textbf{\textbf{A}} \\ \textbf{\textbf{\textbf{M}}} \end{array}$		
	88008 ^{Hz} %	After one second, the display will show the output frequency as Hz.	

When operating the parameters with the main & sub-No. selection method, the third decimal dot turns ON while the parameter is selected to differentiate between the sub-No. selection method. Press the $\binom{IEL}{SET}$ key to check the parameter No. during the monitor display. **4-3-4** Changing the Block-A, B, C parameters with main & sub-No. selection method Refer to Sections 6-2 to 6-5, for the details of the Block-A, B and C parameters.

<keys></keys>	<display, led="" unit=""></display,>	<explanation></explanation>
Change the parame	eter A03-1 (DC Breaking	Time) from 2.0 (default value) to 3.5.
$\left(\begin{array}{c} RST\\ MOD \end{array} \right)$	80050 ^{Hz} %	(In D00-0 Parameter Setting Mode)
	888888 ^{Hz} ^A %	Changes to the Block-A Parameter Setting Mode.
	80088 ^{Hz} %	Changes to the main No. selection.
	BBBB ^{HZ} ^A %	The main No. increases.
	888.88	The main No. increases.
	80388 ^{Hz} %	The main No. increases.
	80880. ^{Hz}	Changes to the sub-No. selection.
	88888	The sub-No. increases.
	\downarrow \uparrow	
(8.8.8.8	The display will alternate between Parameter Number A03-1 and the present value 2.0.
	8.8.8.8.8	Enable the value to be changed. The preset setting value will display.
Five times	8.8.8.8.8	Change the flicker digit from 0 to 5.
	8.8.8.8.8	Move the flickering digit to the digit to be changed
	8.8.8.8.5	Change the flicker digit from 2 to 3.
LCL SET	88835	Fix the data. Changing of parameter A03-1 to 3.5 will be completed.
	88888	The display will alternate between the Parameter Number A03-1 and the present value. (Parameter Number Changing Mode.)

(Note) If the HUR (RUN) display appears when changing from the parameter No. to the setting No. change state, the parameter is one that can be changed only while the inverter is stopped. With the main & sub-No. selection method, if the sub-No. increases from the maximum state or decreases from the minimum state, it will lop within the same main No. The operation is summarized in the following figure. (D10: Simple PLC monitor is shown as an

example.)

Press the \bigcirc key to return to the main No. selection.

Press the $\left(\frac{LL}{SET}\right)$ key to move to the setting value setting.



4-3-5 Changing the block No.

The operation panel block No. will change between five modes each time the $\binom{\text{RST}}{\text{MOD}}$ key is pressed. The monitor mode D20-0, 1, 2 is the entry to the extended monitor mode.



4-3-6 Displaying the sequence

With the LED panel, the D04-0 to 3: sequence input and D04-4 to 7: sequence output are displayed as shown below. The D04-4: Sequence output 1 is shown as a display example.



Sequence OFF (OFF) Sequence ON (ON) Not a target (always OFF)

When the corresponding sequence turns ON, the vertical segment on the LED panel turns ON. The decimal point LED flickers at a one-second cycle.

Each segment is updated as soon as the sequence status changes.

4-3-7 Fault History Display

Refer to Appendix Table 3 Fault Code Table for the fault codes and details.

<keys></keys>	<display, led="" unit=""></display,>	<explanation></explanation>
(800-0. A %	(d00-0 will display in the Monitor Mode.)
	088888	Select Monitor Parameter d20-0.
	↓ [8888]	The [ERR] symbol will display after one second.
LCL SET	E888	Enter the Faulty History Reference Mode by pressing the $\binom{LCL}{SET}$ key.
(88888	The fault history number (E00 to E37) and the fault code will display alternately.
	8888	Refer to the contents of the fault buffer by pressing the keys.
	$\downarrow \uparrow$	
$\left(\begin{array}{c} \hline \text{RST} \\ \hline \text{MOD} \end{array} \right) \text{ or } \left(\begin{array}{c} \hline \text{LCL} \\ \hline \text{SET} \end{array} \right)$	88880 . ↓	End the Fault history Mode and return to the Monitor Mode by pressing the $\frac{RST}{MOD}$ key or $\frac{LCL}{SST}$ key.
	88883	The [ERR] symbol will display after one second.

Fault sequence	Fault history No.	Display	Explanation
Fault 1	E00	5-30	Primary fault (overcurrent)
(The latest)	E01	10-4	Secondary fault (retry over)
	E02	52.24	Output frequency at fault
	E03	1049	Output current at fault
	E04	404	DC voltage at fault
	E05		Hardware detection fault at fault
	E06	13582.	Cumulative power ON time at fault
	E07	9284	Cumulative run time at fault
Fault 2	E10	5 - <u>0</u> U	Primary fault (undervoltage)
	E11		Secondary fault (none)
	E12	60.00	Output frequency at fault
	E13	8 70	Output current at fault
	E14	DI 5	DC voltage at fault
	E15		Hardware detection fault at fault (no display)
	E16	8632.	Cumulative power ON time at fault
	E17	3657	Cumulative run time at fault
Fault 3	E20		
	E21		
	E22	0.00	"" indicates that a fault is not recorded. The frequency value, voltage value, current
	E23	0.0	value, cumulative power ON time and
	E24	Û.	fault is recorded.
	E25		* E00 to E37 are all or 0 in the default state.
	E26	a	
	E27	8	
Fault 4	E30		
	E31		
	E32	0.00	
	E33	0.0	
	E34	C.	
	E35		
	E36	<u>a</u>	
	E37	<u>a</u>	

The fault history display has the following type of configuration. The faults up to the previous faults are listed as display examples.

4-3-8 Operations and display when Block-A, B, C parameter change list is selected

Monitor parameter D20-2 is an entry into the Block-A, B, C parameter change list mode. In this change list mode, only the Block-A, B, C parameters which differ from the default values can be referred to and changed.

<keys></keys>	<display, led="" unit=""></display,>	<explanation></explanation>		
An example of referring to the change list and changing C14-0 (A01 output gain) is shown below.				
	88850 A %	(Monitor mode initial display)		
	88088	The block No. and parameter No. increases from parameter D00-0 to D20-2.		
	\downarrow	Refer to sections 4-3-3 or 4-3-5 for these operations.		
LCL	88888	One second after D20-2 is selected, "LST" will appear.		
SET	88888	The change list mode is entered when the $\frac{1}{38T}$ key is pressed.		
	\downarrow \uparrow			
	8.8.8.8.9	The number of the parameter (A03-1) which has been changed from the first setting value and the current setting value will alternately display.		
	$\begin{array}{c c} \bullet \bullet$	Next, the changed parameter will appear.		
	88088 ^{HZ} %	The parameters which differ from the setting values can be displayed in order by pressing the (▲) key.		
	88888			
	\downarrow \uparrow	Display parameter: C14-0 (A01 output gain).		
LCL SET	88889			
	88888	Select parameter C14-0. The setting value change status will be entered.		
	88885			
LCL SET	88885	Set the data. Change parameter C14-0 to 0.95.		

<keys></keys>	<display, led="" unit=""></display,>	<explanation></explanation>
	€8838 ↓ ↑ 88895	The parameter No. and current setting value will alternately display.
	$\begin{array}{c} \bullet \bullet$	The parameters which differ from the setting values can be displayed in order by pressing the (key.
	88680	d.CHG and d.END will alternately display to indicate the end of the change list. When the (
RST MOD	 <i>88888.</i> ↓	display from the start. If the $\begin{pmatrix} BT \\ WD \end{pmatrix}$ key is pressed in the parameter change state, the change list display mode will end. The monitor parameter selection status will be entered. ("LST" will appear after one second.)
	88888	
4-3-9 LED panel display at fault occurrence, and resetting methods

When a fault occurs in the inverter, the following type of display will appear on the LED panel.



When a fault occurs, the inverter stops operation, and the "FLT" status display LED on the panel will turn ON.

At the same time, the head "E00" for the fault history and the fault code appear on the LED panel. The cause of the fault code displayed at E00 to E07 is saved.

Refer to Appendix Table 3 Fault codes for details on the fault codes.

In the above figure, an overvoltage occurred during constant speed operation and a fault occurred.

If the \bigcirc keys are pressed while the history is displayed, the fault details can be displayed in the range of E00 to E37.

To return to the normal parameter selection from the fault history display, press the $\binom{RST}{MOD}$ key.

Resetting a fault:

Refer to the details of E00 to E07 in the fault history display and the Appendix Table 3 Fault code table, and remove the cause of the fault.

The FLT LED will turn OFF when the \bigcirc + w keys are pressed or the sequence input RESET is turned ON.

Refer to Chapter 5 section 5-3 Programmable sequence input function (PSI) for details on resetting the fault with the sequence input RESET.

The display in this case is shown below.



When the fault is reset, the LED panel display will return to the D monitor parameter from the fault history state.

Confirm that the cause of the fault has been removed, and then resume operation.

4-4 Customizing block-B, C parameter

Block-B, C parameters can be assigned to any Block-A Parameter in the range of A04-0 to A04-7, and can be read and changed in the Block-A Parameter Setting Mode.

To use this function, set parameter No. to be displayed in A04-0 to 7 in parameter C10-0 to 7. The case for the V/f control (C30-0 f0 = 1) of control selection (C30-0:f0) is shown below. The operation example applies when the LED panel is connected.



An example of selecting the custom parameter and changing the selected custom parameter setting value is given on the following page.

<keys></keys>	<display, led="" unit=""></display,>	<explanation></explanation>
Register parameter	B10-0 on Parameter C10	0-0 (Custom Setting).
	88888	(Mode and Parameter Number Change to C10-0)
LCL	↓ ↑ 8.888.8	The display shows Parameter C10-0. (Setting value 1.9F.F is the initial setting, and indicates that nothing has been selected.)
	88888	The C10-0 setting value setting is started by pressing the $\binom{\text{LCL}}{\text{SET}}$ key.
	88888	Set the parameter B10-0 sub-No. to "0".
	88888	The flickering digit will move when the (key is pressed.
LCL SET	88888 ↓ ↑	Set so that the high-order digit is block No. 10. When the $\binom{LCL}{SET}$ key is pressed, the data will be set, and the parameter selection screen will appear.
	88888	(Note) For parameter C, set as 2.xx.x.
Change parameter	B10-0 that has been assi	igned to A04-0.
	800.30. Nz	Enter the Block-A Parameter Setting Mode.
	88888	The Custom Parameter Number A04-0 will display.
LCL SET	↓ ↑ 88880	The display will alternate between Parameter Number A04-0 and the value of Parameter Number B10-0 (Acceleration cushion time 2). Parameter Number A04-0 is the same value as that of Parameter Number B10-0.
	8.8.888	When the $\frac{\text{(LL)}}{\text{SET}}$ key is pressed, the B10-0 setting value setting state will be entered.
(LCL) SET	88888	Change the value.
	88885	When the $\frac{LLL}{SET}$ key is pressed, the data will be set, and the parameter selection screen will appear.
	↓ ↑ 888888	

Note) If an undefined parameter No. such as the default 1.9F.F is set for C10-n, it will be interpreted that a custom setting has not been made, and the A04-n display will be automatically set.

4-5 Changing modes

The parameters used differ according to the control mode (C30-0:f0).

The parameters include the V/f control, the IM vector control (sensor-less, with sensor) and the PM motor control with sensor.

These parameters are divided into the block No. (mode), main No. and sub-No. for each function.

4-5-1 V/f control (C30-0 f0 = 1) mode

The configuration of the parameters is shown in Fig. 4-5-1.



(Continued on next page)

Fig. 4-5-1 (1) Parameter configuration



(Continued on next page)





(Note) At the default setting, only the basic functions are displayed. The extended function, software option function, hardware option function parameters are skipped. Thus, to change these parameters, change parameter A05-0 to 2 (parameter B, C block skip setting), so that the target parameters are displayed.

Fig. 4-5-1 (3) Parameter configuration

4-5-2 IM speed sensor-less vector control (C30-0 f0 = 2), IM vector control with speed sensor (C30-0 f0 = 3)

The configuration of the parameters is shown in Fig. 4-5-2.



(Continued on next page)

Fig. 4-5-2 (1) Parameter configuration

4. Operation Panel



(Continued on next page)

Fig. 4-5-2 (2) Parameter configuration



(Note) At the default setting, only the basic functions are displayed. The extended function, software option function, hardware option function parameters are skipped. Thus, to change these parameters, change parameter A05-0 to 2 (parameter B, C block skip setting), so that the target parameters are displayed.

Fig. 4-5-2 (3)	Parameter	configuration
----------------	-----------	---------------

4-5-3 PM motor control mode with sensor (C30-0 f0 = 4)

The configuration of the parameters is shown in Fig. 4-5-3.



Fig. 4-5-3 (1) Parameter configuration



(Continued on next page)

Fig. 4-5-3 (2) Parameter configuration

4. Operation Panel



(Note) At the default setting, only the basic functions are displayed. The extended function, software option function, hardware option function parameters are skipped. Thus, to change these parameters, change parameter A05-0 to 2 (parameter B, C block skip setting), so that the target parameters are displayed.

Fig. 4-5-3 (3) Parameter configuration

Chapter 5 Control Input/Output

5-1 Input/output terminal function

The terminal block and input/output functions related to control are as shown in Tables 5-1.

Table 5-1	Terminal block functions ((TB1,	TB2)
-----------	----------------------------	-------	------

	Symbol	Name	Features
nput	PSI1 to PSI7	Programmable input	These commands can be arbitrarily led to the input signal circuit in the control PCB through sequence input selective setting (C03 to C06). The pulse train input uses input terminal PSI7.
Sequence i	RY0, RY24	Sequence input common	These are common terminals for sequence input signals. There are two kinds for the change of the sink / source logic. RY24 and RY0 must not be shorted.
og input	AI1, 2	Programmable input	These are the analog input terminal in which the voltage input of the range of 0 to 10V and the current input of the range of 0 to 20mA are possible. These signals can be arbitrarily led to the input signal circuit in the control PCB through analog input selective setting (C07). Al1: Set C12-0 to 1 and DIP SW (DS1-2) to OFF for Voltage input. Set C12-0 to 2 and DIP SW (DS1-2) to ON for Current input. Al2 :Set C12-4 to 1 and DIP SW (DS1-3) to OFF for Voltage input. Set C12-4 to 2 and DIP SW (DS1-3) to ON for Current input. The converter resolution is 12 bits.
All3	AI3		This is the analog input terminal in which the voltage input of the range of -10 to 10V is possible. This signal can be arbitrarily led to the input signal circuit in the control PCB through analog input selective setting (C07). The analog/digital converter resolution is 12 bits within the range of -10 to +10V.
	СОМ	Analog input common	This is the common terminal for AI1, AI2 and AI3 signals.
	P10	AI1 or AI2 source	This is a terminal for supplying a power supply to an analog input VR. This terminal is connected to 15V power supply through 750-ohm resistance.
Analog output	A01, A02	Programmable output	 These are the analog output terminals for meter, and are switched to a voltage output and a current output. Arbitrary internal signals can be outputted by setup of an output terminal function (C13-0, C13-1). AO1: Set W3 to 1 and set C14-7 to 1 or 2 for Voltage output. Set W3 to 2 and set C14-7 to 3 for Current output. AO2: Set W4 to 1 and set C14-8 to 1 or 2 for Voltage output. Set W4 to 2 and set C14-8 to 3 for Current output. The converter resolution is 10 bits.
	COM	Analog output common	This is the common terminal for the AO1 and AO2 signals.
	RA, RC	Programmable output (1a contact)	This is a relay contact output. Internal signals can be output with the C13-2 setting.
outpu	FA, FB, FC	Programmable output (1c contact)	This is a relay contact output. Internal signals can be output with the C13-6 setting.
Sequence	PSO1 to PSO3	Programmable output (Open collector)	This is the open collector output. Internal signals can be output with the C13-3,4,5 setting.
	PSOE	Open collector output common	These are the common terminals for the PSO1, 2 and 3 signals.

5-2 Control input/output circuit

Examples of the control input/output circuit wiring are shown in table 5-2. The precautions must be observed during wiring.

Function	Example of wirings		Precautions
Sequence input	(a) Sink logic (b) Source logic	1.	Wiring must not be longer than 30m.
	RY24V 30m or less RY24V 30m or less 4.7k to the state of the state o	2.	The allowable leakage current is 0.5mA.
		3.	Use a minute current contact.
	(SINK)	4.	Do not connect to the analog input/output.
	(W1 is for PSI1 to PSI6, W2 is dedicated for PSI7.)	5.	The sink/source logic can be changed with W1 and W2. (1: Sink 2: Source)
Analog input and P10 output	+15V P10 750Ω Ο	1.	Use 2kΩ/2W rating setter for the external variable resistor. (Only when using AI1 or AI2)
	$2k\Omega$ $2W$ $2W$ 510Ω $10k\Omega$ $0S1-2$ $0V$ $30m \text{ or less } $	2.	The AI1 and AI2 input mode is changed with the DIP switch (DS1) and parameter. Check the DIP switch setting before turning the power ON. The default setting is OFF (voltage mode).
		3.	The maximum input rating for AI1, AI2 and AI3 (voltage mode) is 10.5V (±10.5V for AI3). (Internal impedance: approx. 20kΩ)
		4.	The maximum input rating for AI1 and AI2 (current mode) is 0 to 20.5mA. (Internal impedance: approx. $500k\Omega$)
		5.	Use a shielded wire shorter than 30m for the signal wire.
	i <i>g</i> i ♥ov	6.	For shield connections connect the screen to VAT300's terminal COM.
		7.	Do not connect to the sequence input/output circuit.
Analog output	Voltage mode selection	1.	Use a 10V full scale (impedance $10k\Omega$ or more) meter (voltage mode selection). Note) The maximum output current is 1mA.
	W3,W4 VAmp W3,W4 VAmp W3,W4 VAmp		Use a 20mA full scale (impedance 500Ω or less) meter (current mode selection).
			The mode is changed with the EL-BIT connector (W3, W4) and parameter.
		4.	Use a shielded wire shorter than 30m for the signal wire.
	W3,W4 V Amp	5.	For shield connections, open the mate side, and connect VAT300 side to COM.
	30m or less 0V		
	(W3: for A01, W4: for A02)		

Table 5-2 Control input/output circuit

Function	Example of wirings	Precautions
Sequence output (Relay output)	PA	 Use within the rated range shown below. To comply with UL/CE, use at 30VAC/DC or less.
	<u> </u>	RUN FLT
	^{RC} @	Rated capacity (resistance load)250VAC 3A 30VDC250VAC 30VDC30VDC 3A5A (NO) 3A (NC)
		$ \begin{array}{ c c c c c } \hline Rated capacity \\ (induction load) \end{array} \begin{array}{ c c c c } 2A & 3A (NO) \\ cos\phi=0.4 & 1.8A (NC) \\ cos\phi=0.7 \end{array} $
		Max. voltage 277VAC 250VAC 30VDC 150VDC
	₩ ₩	Max. current 3A 5A (NO) 3A (NC)
	30m or less	Switching750VA1250VA(NO)capacity90W750VA (NC)
		2. The wire must be shorter than 30m.
Sequence output (Open collector	max. 50mA PSO1~3	 To drive an inductive load, such as a coil, insert the free wheeling diode shown in the drawing.
output)		2. Keep the wiring length to 30m or less.
	30m or less PSOE	3. Use within the following rating range. 30VDC, 50mA

Table 5-2 Control input/output circuit (continued)

5-3 Programmable sequence input function (PSI)

The sequence signal's input points include the base PCB terminal block input, panel and transmission data sent from the host controller.

The reset signals (RESET) are all input at logical OR from the input point, and the emergency stop signal (EMS) is input at the logical OR of the terminal block and serial transmission data.

For the other sequence signals, the input point can be determined with the input point changeover command (COP) or system parameter settings (J1, J2) from the operation panel.

The sequence input from the basic PCB terminal block is a 7-point programmable sequence input. For the programmable input, the function can be selected from Table 5-3 and randomly assigned. By connecting the relay interface option (U30V24RY0), extension up to eleven points is possible. The programmable input terminals are PSI1 to PSI7. When extended, the terminals are PSI1 to PSI11. The default settings are as shown below.

Symbol	Setting
PSI1	Forward run
PSI2	Reset signal
PSI3	Emergency stop
PSI4	Reverse run
PSI5	Forward jogging
PSI6	Reverse jogging
PSI7	None

Default settings

The programmable input signal functions are given in Table 5-3.

The general control block diagram of the IM speed sensor-less vector control and the IM vector control with speed sensor is shown in Fig.5-3.



Fig. 5-3 Block diagram for IM vector control

5 -4 5. Control Input/Output

Table 5-3 Programmable sequence input functions (1)

Connection of PSI1 to PSI11 is possible. Note that PSI8 to PSI11 are options. The connection is done with data Nos.: C03 to C06 $\,$

Symbol	Name			Functio	on	
F RUN	Forward run	This is th LCL LEC also be इ	ie forward rui) is not ON). selected. (C0	n command for th The operation co 0-0)	ne remote operation mode (whe mmand or self-hold mode can	n
EMS	Emergency Stop	This stop operatior decelera fault (FL	s all run com n, the operati tion stop or c T). (C00-4)	imands when sto on stops. The op coast to stop. This	pped. If turn ON during eration can be stopped with ran s signal can also be output as a	np 1
R RUN	Reverse run	This is a (C00-0=:	command fo 2) is available	r reverse run. A c e in the run/revers	command of reverse run mode se mode.	
F JOG	Forward jogging	These ar	re jogging cor	mmands. If this s	ignal is ON while RUN is OFF,	
R JOG	Reverse jogging	operation within the coast-sto	within the control circuit. For stoppage, either ramp down stop or coast-stop is available. (C00-2)			
HOLD	Hold	This is a mode (C this signa signal tu	stop signal g 00-0=3) durir al turned off. rned on.	enerated when the operating r Input of F RUN o	he setting is to be the self-hold mode. The VAT300 stops with or R RUN can be held with this	
BRAKE	DC brake	DC brake In the ca torsion w	e can be ope se of PM mo vill occur acc	rated with this sig tor control, DC ex ording to the load	gnal. xcitation takes place. Shaft I torque.	
RESET	Fault reset	This rese can be ti	ets the fault surned OFF a	tate. The fault ound operation resu	Itput (FLT LED ON, FAULT relayumed with this signal.	ıy)
СОР	Serial transmission selection	The sequence commands from serial transmission are validated. By selecting the control changeover method (C00-6), the input point of the auxiliary operation sequence during COP ON can be selected.				of
		'	COP	C00-6	Input point	i
		'		1	Terminal block input	
		'		2	Serial transmission input	
		For reset transmis	tting and eme sion are both	ergency strop, the	e terminal block and serial of the C00-6 setting.	
CSEL	Ramp selection	Accel./decel. ramp performance is switched over. Accel./decel. time 2 (B10-0, 1) is available with ON, and accel./decel. time 1 (A01-0, 1) is available with OFF.				
I PASS	Ratio interlock bypass	Ratio inte	erlock operat	ion is bypassed.		
CPASS	Ramp bypass	The ram	p function is	bypassed.		
PIDEN	PID control selection	The PID	control is val	idated.		

Symbol	Name	Function				
AFS1	Speed setting 1 selection	The frequency (speed) setting is carried out with the input selected with C07-0.				
AFS2	Speed setting 2 selection	The frequency (speed) setting is carried out with the input selected with C07-1.	When inputs are entered			
AFS3	Speed setting 3 selection	The frequency (speed) setting is carried out with the input selected with C07-2.	simultaneously, setting is selected in accordance with			
PROG	Program function enable	Used for multiple setting. Selection of 8 steps (PROG0~PROG7) is made with S0~S3, SE.	following preference order. JOG>CFS>PLS_IN>PROG> AFS3> AFS2>AFS1			
CFS	Serial communication setting select	Selects settings from the serial or parallel transmission option.				
S0 to S3 SE	Program setting selection	When PROG is ON, the program frequent (B11-0~7). The BCD/Direct input mode ca	cy (speed) 0~7 are selected an be selected with B11-8.			
FUP	Frequency (speed) increase	The currently selected direct frequency (s program frequency (speed) setting 0 to 7	peed) setting (A00-0) or (B11-0~7) is increased or			
FDW	Frequency (speed) decrease	decreased. When the ON state continues, the frequer incremented/decremented with the curren	ncy is tly valid ramp rate.			
BUP	Ratio interlock bias increase	When IVLM is ON and the BUP, BDW ON	I state continues, the			
BDW	Ratio interlock bias decrease	sequential ratio bias will increase/decreas rate.	e at the currently valid ramp			
IVLM	Ratio interlock bias increase/ decrease selection	The auxiliary drive setting is validated with this signal. This operation is				
AUXDV	Auxiliary drive selection	The auxiliary drive setting is validated with valid during the inverter stopping.	n this signal. This operation is			
PICK	Pick-up	While this signal is ON, pick-up operation or R RUN is ON.	is effected as soon as F RUN			
MBRK_ans	External brake answer	Inputs an answer in response to the exter	nal brake command.			
PRST	STP reset	Inputs the pattern operation reset signal w frame operation.	hen performing spinning			
S5 to S7	Digital torque bias 0 to 4	Selects a digital torque bias value (B16-1	to 5) by inputting.			
AUXSW0	Auxiliary drive No. selection L	Using the input, select the parameter to be	e applied from the four			
AUXSW1	Auxiliary drive No. selection H	auxiliary drive operation control paramete	rs.			
PLS_IN	Pulse train input selection	This validates the pulse train input.				
OCLLV1	OCL level setting 1	The overcurrent limit level 2 (B18-7) is val operation.	idated during main drive			
OCLLV2	OCL level setting 2	The overcurrent limit level 3 (B18-8) is val operation.	idated during main drive			

Table 5-3 Programmable sequence input functions (2)

Symbol	Name	Function
E.FLT1 to 8	External fault	This function is valid only when input from the terminal block. When turned ON, a fault will occur. If turned ON during operation, a fault will occur, and the operation will stop. Only coast to stop can be selected for the stopping method. Even if this input when a fault has already occurred, the input will be invalid.
EXC	Pre-excitation	Pre-excitation operation takes place. Pre-excitation operation refers to establishing only the flux in the motor without generating toque. If torque is required immediately from the start of operation, use pre-excitation operation beforehand to establish the flux in the motor.
ACR	ACR	ACR operation is selected.
PCTL	P Control	ASR control is changed from the PI control to the P control.
LIM1	Drive torque limiter changeover	The drive torque limiter reduction setting by the analog input or serial transmission is validated.
LIM2	Regenerative torque limiter changeover	The regenerative torque limiter reduction setting by the analog input or serial transmission is validated.
МСН	Machine time constant changeover	During ASR operation, ASR gain is changed over. Machine time constant 2 (B15-0) is available with ON, and machine time constant 1 (A10-1) is available with OFF.
RF0	0 setting	The speed setting is changed to 0min ⁻¹ .
DROOP	Drooping changeover	Drooping function is validated. (B13-5)
DEDB	Dead band setting	The dead band setting of ASR is validated. (B14-0)
TRQB1	Torque bias setting 1	The torque bias input 1 is valid.
TRQB2	Torque bias setting 2	The torque bias input 2 is valid.

Table 5-3	Programmable	sequence	input	functions	(3))
-----------	--------------	----------	-------	-----------	-----	---

5-4 Programmable sequence output function (PSO)

As a standard, the sequence outputs include five points (1c contact output: one point, 1a contact output: one point, open collector output: three points). The signals shown in Table 5-4 can be randomly output from the five channels. By connecting the relay or PC interface option (U30V24RY0, U30V24PI0), extension up to nine points is possible. The standard programmable output terminals are FA-FB-FC, RA-RC and PSO1 to PSO3. The default settings are shown on the right. When extended, the terminals are the four points PSO4A-PSO4B-PSO4C to PSO7A-PSO7B- PSO7C for the U20V24PI0. With the U20V24PI0 the two points PSO4.

Default values

Terminal symbol	Setting
FA-FB-FC	Fault
RA-RC	Run
PSO1-PSOE	Ready (1)
PSO2-PSOE	Current detection
PSO3-PSOE	Frequency (speed) attainment

U30V24RY0. With the U30V24PI0, the two points PSO4 and PSO5 have been added.

Symbol	Name	Function
RUN	Run	This turns ON during running, jogging or DC braking. Turning ON or OFF during pre-excitation can be selected. At C00-7=1, run output is ON during pre-excitation . At C00-7=2, run output is OFF during pre-excitation .
FLT	Fault	This turns ON during a fault.
MC	Charge completed	This turns ON when the DC main circuit voltage reaches a voltage higher than the MC ON level.
RDY1	Ready (1)	This turns ON when there is no fault, EMS is not activated, pre-charging is complete and the encoder signal is detected (only in PM motor control with sensor mode).
RDY2	Ready (2)	This turns ON when there is no fault, pre-charging is complete and the encoder signal is detected (only in PM motor control with sensor mode).
LCL	Local	This turns ON when the operation mode is local (operation from the operation panel).
REV	Reverse run	V/f: This turns ON while the output frequency is reverse running. VEC, PM: This turns ON while the motor is reverse running.
IDET	Current detection	This turns ON when the output current reaches the detection level (C15-1) or higher.
ATN	Frequency (speed) attainment	This turns ON when the output frequency (speed) reaches the set frequency (speed). The detection reach width is set with C15-0.
SPD1	Frequency(speed) detection (1)	This turns ON when the output frequency (speed) absolute value reaches a frequency(speed) higher than the speed set with the detection level (C15-2).
SPD2	Frequency(speed) detection (2)	This turns ON when the output frequency (speed) absolute value reaches a frequency(speed) higher than the speed set with the detection level (C15-3).
COP	Transmission selection	This turns ON when serial transmission operation is selected.
EC0~EC3	Specific fault output	This turns ON when the fault set up by C15-6,7,8,9 occurs.
ACC	Acceleration	This turns ON during acceleration.
DCC	Deceleration	This turns ON during deceleration.
AUXDV	Auxiliary drive selection	This turns ON when the auxiliary drive parameter setting is validated by the sequence input AUXDV.
ALM	Minor fault	This turns ON during a minor fault.
FAN	Fan control	This turns ON during running, jogging, pre-excitation and DC braking. A three minute off delay is provided, so even if the above operations turn OFF, this control will not turn OFF for three minutes. This is used for external fan control.
ASW	Automatic start wait	When C08-0 is selected and the automatic start function is used, this will turn ON while waiting for automatic start.
ZSP	Zero speed	This turns ON when the output frequency (speed) absolute value is below the level set with zero speed (C15-4).
LL MT	PID lower limit output	This turns ON when the feedback value exceeds the lower limit value (<b43-4) control.<="" during="" pid="" td=""></b43-4)>
ULMT	PID upper limit output	This turns ON when the feedback exceeds the upper limit value (>B43-3) during PID control.
Doff-End	Doff-End alarm output	This turns ON only at the point going back the set time (B60-5) from the moment auto stoppage is engaged after completing the final step when performing spinning frame operation.
MBRK	External brake output	Outputs an external brake command.
DVER	Speed deviation error	This turns ON during a speed deviation error.
BPF	Stoppage deceleration output	This turns ON when the DC voltage is the set value (B12-1) or under during automatic braking on power failure function.
RDELAY	Run delay answer	This signal delays(C15-5) the turning OFF of the sequence output RUN.
MPO1 to 8	Multi-pump output	Output signal for multi-pump control
PLC1 to 8	Built-in PLC output	Sequence output signal of Built-in PLC

 Table 5-4
 Programmable sequence output functions

(Note) "ON" indicates that the contact is closed when + is set, and the contact is open when - is set.

5-5 Sequence input logic





5-6 Changing of terminal functions

The programmable input terminals (PSI1 to PSI11) can be connected to arbitrarily internal commands. The internal state can be connected to the programmable output terminal (FA-FB-FC, RA-RC and PSO1 to PSO7) to lead in the ON/OFF signals.

5-6-1 Sequence input terminal assignment and monitoring

The parameters can be assigned to the terminal block as shown in Fig. 5-6-1-a according to the parameter Nos. C03 to C06. Each internal signal can be fixed to ON (set value to 16) or OFF (set value to 0). Fig. 5-6-1-b shows the case when the ON state of each internal signal is shown on the D04 monitor. This monitoring is performed with D04-0 to 3. F RUN, R RUN, F JOG and R JOG are displayed with a combination of RUN, REV and JOG converted into an internal command.



Fig. 5-6-1-a Assignment of sequence input

Fig. 5-6-1-b Sequence input monitor

5-6-2 Sequence output terminal assignment and monitoring

The ON/OFF of the internal signals can be output to the FA-FB-FC, RA-RC and PSO1 to 7 terminals as shown in Fig. 5-6-2-a with the parameter Nos. C13-2 to 6 and C33-0 to 3. The ON/OFF of each signal can be monitored as shown in Fig. 5-6-2-b. This monitoring is executed with D04-4, 5,6, 7.



Fig. 5-6-2-a Assignment of sequence output

Note) "ON" indicates that the contact is closed when + is set, and the contact is open when - is set.

5-7 Programmable input function (PI)

5-7-1 Types of analog inputs

As a standard, there are three channels for the analog input. Each analog input can be connected to the internal setting signals shown in Table 5-7-1 by using the programmable input function.

	Setting range (Note1)(Note3)		ote1)(Note3)	
	Al	l, 2	AI3	
Signal name	Voltage mode	Current mode		Function
	0~10V 0~5V 1~5V	4~20mA 0~20mA	–10~10V –5~5V 1~5V	
Speed setting 1 Speed setting 2 Speed setting 3	0~1	00%	-100~100%	This is the speed setting. The + polarity is the forward run setting, and the – polarity is the reverse run setting. If the analog input is selected with the speed setting,
			0~100%	the speed setting can be changed between 1, 2 and 3 with the sequence input (AFS1,AFS2,AFS3).
Ratio interlock bias setting	0~1	00%	-100~100% 0~100%	This is the bias setting for the sequential ratio operation.
Traverse center frequency setting	0~1	00%	(0~10V) 0~5V 0~100% (Note 2) 0~100%	This is the center frequency setting for traverse operation.
PID feedback	0~1	00%	(0~10V) 0~5V 0~100% (Note 2) 0~100%	This can be used as the feedback input to configure a feedback loop. Do not use the programmable analog output (AO1,AO2) as the PID feedback signal.
Torque setting	0~3	00%	-300~300% 0~300%	This is the torque setting for ACR operation. The + polarity is the forward run direction torque, and the – polarity is the reverse run direction torque. The torque setting can be limited by using the torque limiter (A11-2, 3).
Drive torque limiter reduction setting	0~1	00%	(0~10V 0~5∨) 0~100% (Note 2) 0~100%	The drive torque limit (A10-3 or A11-2) is multiplied using 0V to +10V as 0 to 100%, and the limit value is reduced. This function is valid when the drive limiter changeover (LIM1) is turned ON with the sequence input.
Regenerative torque limiter reduction setting	0~1	00%	(0~10V) 0~5V 0~100% (Note 2) 0~100%	The regenerative torque limit (A10-4 or A11-3) is multiplied using 0V to +10V as 0 to 100%, and the limit value is reduced. This function is valid when the regenerative limiter changeover (LIM2) is turned ON with the sequence input.
Torque bias 1 setting	0~3	00%	-300~300% 0~300% 0~300%	This is added to ASR output during ASR operation, or to the torque setting during ACR operation. This function is valid when the torque bias 1 (TRQB1) is turned ON with the sequence function.
Analog torque bias setting	0~1	00%	-100~100% 0~100%	This is the torque bias setting when the auto torque bias selection (B16-0) is analog.

 Table 5-7-1
 Types of internal setting signals assigned to analog input

(Note 1) Select each analog input mode with C12-0 to A. (Note 2) Al3 : The setting is limited to 0% during the -10 to 0V and -5 to 0V input. (Note 3) Setting range/Resolution : Al1, 2 (Voltage input mode) 0 to 10V/12 bit, Al1, 2 (Current input mode) 0 to 20mA/12 bit, Al3 -10V to 10V/12 bit The resolution is reduced according to setting range. Example) Al1 (Voltage input mode) 0 to 5V/11 bit

Example 5-1) Set as shown below for voltage input mode 0 to 10V.

AI1 : C12-0=1 (voltage input mode selection) C12-1=1 (0 to 10V selection) DIP switch DS1-2 OFF AI2 : C12-4=1 (voltage input mode selection) C12-1=1 (0 to 10V selection) DIP switch DS1-3 OFF

Example 5-2) Set as shown below for current input mode 4 to 20mA

Al1: C12-0=2 (Current input mode selection), C12-2=1 (4 to 20mA selection), DIP switch DS1-2 ON Al2: C12-4=2 (Current input mode selection), C12-2=1 (4 to 20mA selection), DIP switch DS1-3 ON

5-7-2 Setting the analog input

The analog input can be assigned to the random internal setting signals given in Table 5-7-1 by setting parameter C07-0 to A as shown in Fig. 5-7-2.

Set the number corresponding to the analog input (AI1, AI2, AI3) in C07-0 to A. Set "0" for the internal setting signals that are not to be used.



(Note) The torque setting is 300% when C07-6 is 1.

Fig. 5-7-2 Analog input assignment

The sequential ratio operation can be carried out in respect to speed settings 1 to 3. (Refer to 6-6, B06.)

5-7-3 Pulse train input

The pulse train input is one channel and uses input terminal PSI7. When using the pulse train input function, PSI7 cannot be used as the sequence input.

The settings and precautions for the control PCB used with the pulse train input function are given below.

- 1) Set the EL-BIT connector W2 to source logic (2 side) before turning ON the power.
- 2) Connect the pulse train signal to PSI7 and the common to RY0.
- 3) Keep the pulse train input signal voltage at a High level of 20V or more and the Low level of 5V or less.
- 4) Keep the pulse train input signal frequency at 10kHz or less.

The pulse train input can be connected to the internally set signals shown in Table 5-7-3 using the programmable input function.

Signal name	Setting method	Setting range	Eunction
Oignai name	Octaing method	F_1Hz to F_2Hz	T directori
Speed setting	C02-0 = 5	0 to 100%	This is the speed setting.
Traverse center frequency setting	C02-1 = 5	0 to 100%	This is the center frequency setting for traverse operation.
Torque setting	C02-2 = 5	0 to 300%	This is the torque setting for ACR operation. The torque setting can also be limited with the torque limiter (A11-2, 3).

 Table 5-7-3
 Types of internally set signals for assigning pulse train input

- (Note 1) These signals cannot be used at the same time. Set only one of C02-0 to C02-2 to "5" when using the pulse train input function.
- Refer to Fig.5-7-3-a and set the setting range (F_1Hz to F_2Hz) with parameters C12-C and C12-D.
- (Note 2) When assigning to the torque setting, the maximum setting input value is 300%.
- (Note 3) If a frequency less than F_1Hz or more than F_2Hz is input, the speed setting and traverse center frequency will be limited to 0 to 100%, and the torque setting will be limited to 0 to 300%.



Input frequency [Hz]

Fig. 5-7-3-a

The pulse train input circuit diagram in shown in Fig. 5-7-3-b.

After the pulse train input signal frequency is detected with the frequency detector, the LPF processed value is set as the setting input. Set this LFP time constant with C12-E. If C12-E is set to "0", the LPF process will be invalid.

If the pulse train signal is not detected for the time set in C12-F, it will be judged that the pulse train input signal has turned OFF, and the setting input value will be set to "0".

Set the C12-F setting time larger than (1/F1)[s].



Fig. 5-7-3-b Pulse train input circuit diagram

5-8 Programmable output function (PO)

5-8-1 Types of analog outputs

As a standard, there are 2 channels for the analog output.

The voltage output and current output can be selected for AO1 and AO2 by setting parameter C14-7, 8 and EL-BIT W3, W4. The output resolution is 0 to 10V/10bit for the voltage output and 0 to 20mA/10bit for the current output.

The default setting is shown below.

Default Settings			
Terminal symbol		Setting	
AO1	Output frequency	0 to 10V voltage output mode	
AO2	Output current (Motor)	0 to 10V voltage output mode	

Default settings

Example 5-3) Set as shown below for voltage output mode 0 to 10V.

AO1: C14-7=1 (0 to 10V voltage output mode selection), Set W3 to 1 (voltage mode) AO2: C14-8=1 (0 to 10V voltage output mode selection), Set W4 to 1 (voltage mode)

Example 5-4) Set as shown below for current output mode 4 to 20mA

AO1: C14-7=3 (4 to 20mA output mode selection), Set W3 to 2 (current mode) AO2: C14-8=3 (4 to 20mA output mode selection), Set W4 to 2 (current mode)

5-8-2 Setting the analog output

A following internal data can be output to AO1, AO2 terminals with parameters C13-0 and 1 as shown in Fig. 5-8-2. Set the number corresponding to the internal data in C13-01, 1. If the gain needs to be adjusted, set C14-0, 1 appropriately. Signed data can be output by setting the offset voltage with C14-3, 4 and setting the offset current with C14-5, 6.



Fig. 5-8-2 Analog output assignment

5-8-3 Pulse train output

The pulse train output is one channel, and uses the terminal block output PS03. When using the pulse train output function, PS03 cannot be used as a sequence output. Note that when this function is used, the speed detection option I pulse division function (C50-0) cannot be used.

The settings and precautions for the control PCB used with the pulse train output function are given below.

- 1) Turn the DIP switch (DS1-4) ON before turning the power ON.
- 2) Connect the PS03 to the device while observing the precautions for the sequence output (open collector output).
- 3) Set PS03 terminal output selection to OFF fixed (C13-5=0).
- 4) The maximum output frequency is 6kHz (25°C). Use the falling edge.
- 5) Faults could occur if the DS1-4 and C13-5 settings are mistaken.

The settings for using the pulse train output function are shown below.

1) Enable the pulse train output function.

Parameter No.	Name	Function	
C13-B	Pulse train output function	=1 : Pulse train output function=2 : Pulse train output function	Valid Invalid

2) Set PS03 terminal output selection to OFF fixed (C13-5=0).

3) Select the internal data to be output as a pulse train with C13-E as shown in Fig. 5-8-3-a.



Fig. 5-8-3-a Pulse train output assignments

4) Refer to Fig. 5-8-3-b, and set the frequency of the pulses output with C13-C, D. To output the absolute value of the internal data, set C13-F to 2.





(Note) The output pulse frequency range is 0.1 to 10kHz. A pulse less than 0.1Hz cannot be output even during reverse run. When outputting from the sequence output PS03, only a pulse frequency of 6kHz or less (25°C, maximum current = 50mA) can be output. Set C13-C, D to 6000Hz or less.

Parameter No.	Name	Function	
C13-F	Output parameter absolute value operation selection	=1 : Internal data absolute value operation function=2 : Internal data absolute value operation function	Valid Invalid

5-9 Selecting the setting data

5-9-1 Speed setting

(1) Speed setting selection

The ten types of speed setting inputs shown below can be used. One of the ten types of inputs can be selected by setting a parameter or with the sequence input.

Setting input point	Setting data	Explanation
Analog	Analog speed setting 1 Analog speed setting 2 Analog speed setting 3	This is a setting value issued with an analog input.
Serial	Serial speed setting	 This is a setting value issued from the host computer with serial transmission. Setting is possible with the following serial transmission. Communication interface option (Type: U30V24SL0/1/2/3/4) Standard serial transmission •Modbus communication
Parallel	Parallel speed setting	This is a setting value issued from the host sequencer with parallel transmission. A PC interface option (type: U30V24PI0) is required.
Sequence	Pulse train speed setting	This is the setting value issued from the pulse train input.
	Panel speed setting	This is the setting value issued from the parameter (A00-0, 2).
	Panel jogging setting	This is a setting value issued from the parameter (A00-1, 3).
Panel	Traverse pattern operation	This is the traverse pattern operation setting value with parameter (B45-0 to 6).
	Pattern operation	This is the pattern operation setting value with parameter (B50-0 to B59-3).

(2) Speed setting selection sequence

The relation of the speed setting and changeover sequence is as shown below.



Fig. 5-9-1 Speed setting selection

5-9-2 Torque setting

(1) Torque setting selection

The following four types of torque setting inputs can be used. One of the four types of inputs can be selected by setting a parameter or with the sequence input.

Setting input point	Setting data	Explanation
Analog	Analog torque setting	This is a setting value issued from the analog input.
Serial	Serial torque setting	 This is a setting value issued from the host computer with serial transmission. Setting is possible with the following serial transmission. Communication interface option (Type: U30V24SL0/1/2/3/4) Standard serial transmission •Modbus communication
Sequence	Pulse train Torque setting	This is the setting value issued from the pulse train input.
Panel	Panel torque setting	This is a setting value issued from the parameter (B13-0).

(2) Torque setting selection sequence

The relation of the torque setting and changeover sequence is as shown below.



Fig. 5-9-2 Torque setting selection

5-9-3 Torque bias 1 setting

(1) Torque bias 1 setting selection

The following three types of torque bias 1 setting inputs can be used. One of the three types of inputs can be selected by setting a parameter or with the sequence input.

Setting input point	Setting data	Explanation
Analog	Analog torque bias 1 setting	This is a setting value issued from the analog input.
Serial	Serial torque bias 1 setting	 This is a setting value issued from the host computer with serial transmission. Setting is possible with the following serial transmission. Communication interface option (Type: U30V24SL0/1/2/3/4) Standard serial transmission •Modbus communication
Panel	Panel torque bias 1 setting	This is a setting value issued from the parameter (B13-2).

(2) Torque bias 1 setting selection sequence

The relation of the torque bias 1 setting and changeover sequence is as shown below.



Fig. 5-9-3 Torque bias 1 setting selection

5-9-4 Torque limiter setting

(1) Torque limiter reduction setting selection

The torque limiter can be set independently for the drive side and regeneration side in the ASR mode and ACR mode. The setting parameters are as shown below. If the emergency stop sequence is valid, the regeneration side limiter value will become the emergency stop limiter value.

- A10-3 : ASR drive torque limiter setting
- A10-4 : ASR regenerative torque limiter setting
- A10-5 : Emergency stop regenerative torque limiter setting
- A11-2 : ACR drive torque limiter setting
- A11-3 : ACR regenerative torque limiter setting

For each limiter input, the limiter value can be reduced by external or internal settings. The final limiter value is the results of multiplying the above panel setting values with the reduction ratio.

(1-1) External reduction setting

The limiter reduction setting input from an external source includes the following two types independently for the drive and regeneration.

One of the two types of inputs can be selected by setting a parameter or with the sequence input.

Setting input point	Setting data	Explanation
Analog	Analog drive torque limiter reduction setting	This is a setting value issued with an analog input. The drive torque limit (A10-3 or A11-2) is multiplied using 0V to +10V as 0 to 100%, and the limit value is reduced. This function is valid when the drive limiter changeover (LIM1) is turned ON with the sequence input.
	Analog regenerative torque limiter reduction setting	This is a setting value issued with an analog input. The regenerative torque limit (A10-4, A10-5 or A11-3) is multiplied using 0V to +10V as 0 to 100%, and the limit value is reduced. This function is valid when the regenerative limiter changeover (LIM2) is turned ON with the sequence input.
Serial	Serial driver torque limiter reduction setting	This is a setting value issued from the host computer with serial transmission. Setting is possible with the following serial transmission. • Communication interface option (Type: U30V24SL0/1/2/3/4) • Standard serial transmission •Modbus communication The data is set in the range of 0 to 100%, is multiplied with the drive torque limiter value (A10-3, A11-2), and the limiter value is reduced. This function is valid when the drive limiter changeover (LIM1) is turned ON with the sequence input.
	Serial regenerative torque limiter reduction setting	 This is a setting value issued from the host computer with serial transmission. Setting is possible with the following serial transmission. Communication interface option (Type: U30V24SL0/1/2/3/4) Standard serial transmission •Modbus communication The data is set in the range of 0 to 100%, is multiplied with the regenerative torque limiter value (A10-4, A10-5, A11-3), and the limiter value is reduced. This function is valid when the regenerative limiter changeover (LIM2) is turned ON with the sequence input.

(1-2) Internal reduction setting

When the double rating speed ratio setting (B13-4) is changed, the torque limiter reduction pattern will be generated as shown below, and will be multiplied with the drive torque limiter value (A10-3 or A11-2) and regenerative torque limiter value (A10-4, A10-5, A11-3).



(2) Torque limiter setting selection sequence

The relation of the torque limiter setting and changeover sequence is as shown below.







Fig. 5-9-4-b Regenerative torque limiter setting selection
5-9-5 Torque ratio 1 setting

(1) Torque ratio 1 setting selection

The following two types of torque ratio 1 setting inputs can be used. One of the two types of inputs can be selected by setting a parameter or with the sequence input.

Setting input point	Setting data	Explanation
Serial	Torque ratio 1 setting	This is a setting value issued from the host computer with serial transmission. Setting is possible with the Communication interface option (Type: U30V24SL0/1/2/3/4).
Panel	Panel torque ratio 1 setting	This is a setting value issued from the parameter (B13-1).

(2) Torque ratio 1 setting selection sequence

The relation of the torque ratio 1 setting and changeover sequence is as shown below.



Fig. 5-9-5 Torque ratio 1 setting selection

5-9-6 Torque ratio 2, torque bias 2 setting

(1) Torque ratio 2 setting selection

The following two types of torque ratio 2 setting inputs can be used. One of the two types of inputs can be selected by setting a parameter or with the sequence input.

Setting input point	Setting data	Explanation
Serial	Torque ratio 2 setting	This is a setting value issued from the host computer with serial transmission. Setting is possible with the Communication interface option (Type: U30V24SL0/1/2/3/4).
Panel	Panel torque ratio 2 setting	This is a setting value issued from the parameter (B13-3).

(2) Torque ratio 2 setting selection sequence

The relation of the torque ratio 2 setting and changeover sequence is as shown below.



Fig. 5-9-6 Torque ratio 2 setting selection

5-9-7 Machine time constant setting

(1) Machine time constant setting

The following three types of machine time constant setting inputs can be used. One of the three types of inputs can be selected by setting a parameter or with the sequence input.

Setting input point	Setting data	Explanation
Serial	Machine time constant	This is a setting value issued from the host computer with serial transmission. Setting is possible with the Communication interface option (Type: U30V24SL0/1/2/3/4).
Danal	Panel machine time constant –1	This is a setting value issued from the parameter (A10-1).
Fallel	Panel machine time constant –2	This is a setting value issued from the parameter (B15-0).

(2) Machine time constant setting and changeover sequence

The relation of the machine time constant setting and changeover sequence is as shown below.



Fig. 5-9-7 Machine time constant setting selection

5-9-8 ASR response setting

(1) ASR response setting selection

The following two types of ASR response setting inputs can be used. One of the two types of inputs can be selected by setting a parameter or with the sequence input.

Setting input point	Setting data	Explanation
Serial	ASR response setting	This is a setting value issued from the host computer with serial transmission. Setting is possible with the Communication interface option (Type: U30V24SL0/1/2/3/4).
Panel	Panel ASR response setting	This is a setting value issued from the parameter (A10-0).

(2) ASR response setting and changeover sequence

The relation of the ASR response setting and changeover sequence is as shown below.



Fig. 5-9-8 ASR response setting selection

Chapter 6 Control Functions and Parameter Settings

6-1 Monitor parameters

The monitor mode sequentially displays the frequency, power supply, etc., parameters recognized by the VAT300.

The symbols shown at the right of the list show the application of each parameter as shown below.

V/f : Indicates parameters that apply for V/f control (constant torque, variable torque) (C30-0: f0 = 1).

- VEC : Indicates parameters that apply for IM speed sensor-less vector control and IM speed vector control with sensor (C30-0: f0 = 2, 3).
- PM : Indicates parameters that apply for control mode with PM motor sensor (C30-0: f0 = 4).

Monitor parameters list

N	0	Parameter	Unit	Remarks	Ap	plicati	on
	J.		Unit	itemarks	V/f	VEC	РМ
D00) – C	Output frequency monitor					
	0	Output frequency in Hz	Hz	SFF will display when the gate is closed.			
	_	Outrast fragmentation 0/	0/	⊢⊢ displays while the DC brake is in action.	0	0	0
	1	Output frequency in %	%	PLI is displayed during pick up.			
	2	Motor speed in min ⁻¹	min ⁻¹	The forward run direction is displayed with the + polarity, and		~	~
	3	Motor speed in %	%	even when stopped.)		0	0
	4	Output frequency/motor speed random scale display		'hen V/f control operation (C30-0: f0 = 1) or auxiliary drive beration is selected, a value obtained by multiplying D00-0: utput frequency with the random scale display coefficient: 14-2 will be displayed. 'hen IM vector control or PM motor control (C30-0: f0 = 2 to is selected, a value obtained by multiplying D00-2: motor beed with the random scale display coefficient, C14-2 will be splayed. the value exceeds the range of -99999 to 99999, ☐ L1E ⊢ lib be displayed.		0	0
	5	Motor rotation speed	%	This displays the detected rotation speed for V/f or sensorless vector control in the case where the unit is equipped with a speed detection option.	0	0	0
D01	l – F	requency setting monitor	quency setting monitor				
	0	Set frequency in Hz	Hz	The currently selected frequency setting value is displayed.	0		
	1	Set frequency in %	%	The max. frequency is displayed as 100%.	0		
	2	Ramp function output speed	min ⁻¹	The set speed at ASR input point is displayed. The forward run direction is displayed with the + polarity, and the reverse run direction with the – polarity.		0	0
	3	Ramp function input speed	min ⁻¹	The set speed at the ramp function's input point is displayed. The forward run direction is displayed with the + polarity, and the reverse run direction with the – polarity.		0	0
	4	Set frequency/input speed /ramp function input Random scale display		When V/f control operation (C30-0: f0 = 1) or auxiliary drive operation is selected, a value obtained by multiplying D01-0: setting frequency with the random scale display coefficient: C14-2 will be displayed. When IM vector control or PM motor control (C30-0: f0 = 2 to 4) is selected, a value obtained by multiplying D01-3: input speed with the random scale display coefficient, C14-2 will be displayed. If the value exceeds the range of -99999 to 99999, $[], [], [], [], [], [], [], [], [], [], $	0	0	0
D02	2 – C	- Current monitor					
	0	Output current (Amps)	Α	GFF will display when the gate is closed.	0	0	0
	1	Output current (%)	%	The motor rated current is displayed as 100%.	0	0	0
	2	Overload (OLT-1) monitor	%	OL-1 functions when this value reaches 100%.	0	0	0
	3	Motor overload (OL-3) monitor	%	The OL-3 operates when at 100%.	0	0	0
	4	Heatsink temperature	°C	Depending on the capacity, OHT.1 functions at 95°C or 120°C or more.		0	0
	5	Torque current detection	%	The torque current detection value is displayed using the motor rated current as 100%.		0	0

Monitor parameters list

No.		Parameter	Unit	Remarks	Ap	plicati	on
•			Kendriko	V/f	VEC	PM	
D0	D02 – Current monitor						
	6	Excitation current detection	%	The excitation current's detection value is displayed using the motor rated current as 100%. With the PM motor control, the demagnetizing current is indicated with negative polarity.		0	0
	7	U phase output current amps	A	☐ F F will display when the gate is closed. The correct value is not displayed during pick-up or during automatic tuning.	0	0	0
	8	V phase output current amps	A	The correct value is not displayed during pick-up or during automatic tuning.	0	0	0
	9	W phase output current amps	A	 F F will display when the gate is closed. The correct value is not displayed during pick-up or during automatic tuning. 	0	0	0
D0	3 – V	oltage monitor			0		
	0	DC voltage	V	Displays the voltage of the DC link circuit in the main circuit.	0	0	0
	1	Output voltage (command)	V	Displays output voltage command. The display may differ from the actual output voltage. It depends on the power supply voltage. 급두두 will display when the gate is closed.	0	0	0
	2	Output power	kW	Displays the inverter's output power. $\Box \models \vdash$ will display when the gate is closed.	0	0	0
	3	Carrier frequency	kHz	The current carrier frequency is displayed.	0	0	0
D0	4 – S	equence status					
	0-3	Sequence status-Input 1 to 4		The ON/OFF state of the internal sequence data will display.	0	0	0
	4-7	Sequence status-Output 1 to 4		shown in the next page.	0	0	0
D0	5 – N	linor fault monitor					
	0	Minor fault monitor		The internal minor fault status will display. The correspondence of each LED segment and signal is shown in the next page.	0	0	0
	1	Hardware detection fault status		The status of the fault signal detected by the hardware is displayed.	0	0	0
D0	6 – P	attern run monitor					
	0	Step No. monitor		The current step No. will display.	0	0	0
	1	Remaining time monitor	S	The remaining time of current step will display	0	0	0
D0	7 – P	ump operation status mon	itor				
	0	Pump operation status monitor		This indicates the ON/OFF status of the pump. The correspondence of the LED segments and signals is shown below.	0		
	1	Current inverter drive pump No. monitor		This displays the number of the pump currently driven by the inverter.	0		
	2	Next ON pump No. monitor		0 is displayed when all pumps are ON.	0		
	3	Next OFF pump No. monitor		0 is displayed when all pumps are OFF.	0		
	4	Elapsed time		The main pump's operation time is displayed.	0		
D0	8 – A	nalog input random scale d	lisplay				
	0	Al1 input scale display (max. frequency/speed reference)		Value to which coefficient set at C14-9 displays for Al1 input. [OVER] displays if the coefficient exceeds the –99999. to 99999. range.	0	0	0
	1	Al2 input scale display Value to which coefficient set at C14-A displays for Al2 input. (max. frequency/speed reference) [OVER] displays if the coefficient exceeds the –99999. to 99999. range.		0	0	0	
	2	Al3 input scale display (max. frequency/speed reference)		Value to which coefficient set at C14-B displays for Al3 input. [OVER] displays if the coefficient exceeds the –99999. to 99999. range.	0	0	0





Monitor parameters list

No.		Parameter	Unit	Remarks	Ap	plicati	on
	0.			V/f	VEC	PM	
D08	3 – Ir	nput display					
-	3 4 5	Al1 input voltage display Al2 input voltage display Al3 input voltage display	V	The voltage on Al1, 2 and 3 terminals will be displayed in a unit of 0.01V. When the Al terminals are for current setting, "0" will be displayed.	0	0	0
-	6 7	Al1 input current display Al2 input current display	mA	The current on the Al1 and A2 terminals will be displayed in a unit of 0.01mA. When the AI terminals are for voltage setting, "0" will be displayed	0	0	0
- -	8 9	Al1 input display (in %) Al2 input display (in %)	%	The current or voltage on the Al1, 2 and 3 terminals will be displayed in % against 10V and 20mA as 100%.	0	0	0
-	В	Sequence input terminal status display		The input status of the sequence input terminals (PSI1~7) and the sequence input terminals on the option PCB (PSI8~11) will be displayed	0	0	0
	С	Speed detection signal input status display		Encoder signal input status will be displayed.	0	0	0
D10	0– Built-in PLC monitor						
	0	Built-in PLC display 1		The contents of address 32h for the built-in PLC memory are displayed.	0	0	0
	1	Built-in PLC display 2		The contents of address 32h for the built-in PLC memory are displayed.	0	0	0
	2	Built-in PLC display 3		The contents of address 32h for the built-in PLC memory are displayed.	0	0	0
	3	Built-in PLC display 4		The contents of address 32h for the built-in PLC memory are displayed.	0	0	0
D11	– T	orque setting monitor					
	0	Torque setting input monitor	%	The currently selected torque setting of the current control input points is selected.		0	0
	1	Analog torque setting monitor	%	The setting value input from the analog torque setting is displayed.		0	0
-	2	Serial communication torque setting monitor	%	The setting value input from the serial communication torque setting is displayed.		0	0
	3	Operation panel torque setting monitor	%	The torque set with the operation panel (B13-0) is displayed.		0	0
-	4	ASR output monitor	%	The ASR output is displayed.		0	0
	5	Torque setting monitor (after torque limiter)	%	The final torque command value after limiting with the torque limiter is displayed.		0	0
D12	2 – S	lip					
	0	Slip monitor	%	The slip is displayed as a percentage in respect to the base speed.		0	
D13	5 – S	TP run monitor					i
-	0	STP step No. monitor		SFF displays during stoppage.	0		
-	1	STP remaining pattern time monitor	min	Displays the time remaining until the end of the current pattern.	0		
	2	STP No. monitor		Displays the currently selected STP.	0		
-	3	STP average spindle frequency monitor	Hz	Displays the average frequency for each spindle.	0		
	4	STP hank count monitor		Displays the current Hank count. The display is limited at a maximum of 6553.5. This is cleared to zero when the power is turned OFF.	0		
	5	STP total patter operating time monitor	min	Displays the operation time until now. The display is limited at a maximum of 65535. This is cleared to zero when the power is turned OFF.	0		
D14	– A	utomatic torque bias					
	0	Automatic torque bias setting	%	Displays the currently set torque bias value at the analog/digital auto torque bias setting.		0	0
D15	5 – E	ctric angle monitor					
	0	Z-phase electric angle	o	The Z-phase electric angle is displayed. Use this to adjust the Z-phase when using magnetic pole position estimation.			0
D16	i – P	M tuning monitor					
	0	Judgment standard 1	%	The characteristics amount in the estimation results is displayed.			0
	1	Judgment standard 2	%	The characteristics amount in the estimation results is displayed.			0
	2	Judgment standard 3	%	The current measured for the N pole phase in the estimation results is displayed.			0
	3	Judgment standard 4	0	The error of the phase angles in the magnetic pole position estimate is displayed.			0

Note) D08-3 to D08-C available from the version 9457.0+9458.4

Monitor parameters list

No.		Parameter	Unit	Remarks	Ар	plicati	on
	J.		Unit		V/f	VEC	PM
D20) – E	xtended monitor					
	0	Fault history monitor		The fault history reference mode will display when <u>SET</u> is pressed.	0	0	0
	1	Minor failure past record indication		The minor fault history reference mode will display when SET is pressed.	0	0	0
	2	Parameter A, B and C modification list entry		The mode for referring to and changing parameters that differ from the default value will display SET is pressed.	0	0	0
	3	Sequence input display (dedicated for LCD panel)		The sequence input reference mode will display when SET is pressed. This parameter does not appear when the LED panel is connected.	0	0	0
	4	Sequence output display (dedicated for LCD panel)		The sequence output reference mode will display when <u>SET</u> is pressed. This parameter does not appear when the LED panel is connected.	0	0	0
D21	— N	laintenance monitor					
	0	Cumulative conductivity time	h.	The cumulative power ON time after product shipment will be counted and displayed.	0	0	0
	1	Cumulative run time	h.	The cumulative run time after product shipment will be counted and displayed.	0	0	0
	2	CPU version		Display for maker control.	0	0	0
	3	ROM version		Display for maker control.	0	0	0
D22	2 – A	utomatic tuning					
	0	Automatic tuning progression display		The progression state of automatic tuning is displayed. The correspondence of the LED's segments and signals is shown in the previous section.	0	0	
D30) – H	ardware monitor					
	0	Inverter type		This indicates the inverter type.	0	0	0
	1	Option PCB		Displays the mounted option PCB. The correspondence of the LED segments and signals is shown in the previous page.	0	0	0
	2	Field network option failure monitor 1 (status)		These parameters will be displayed when the field network optional PCB is installed. The segment corresponding to the	0	C	0
	3	Field network option failure monitor 2 (status)		error on the PCB will be turned on, and will be turned off when the error is eliminated.	~		-
	4	Field network option failure monitor 1 (latch)		optional PCB is installed. If transmission error is detected as failure (C34-1=2), the segment corresponding to the error on the PCB will be turned on, and will not be turned off even when the error is eliminated. The segment will be turned off		0	0
	5	Field network option failure monitor 2 (latch)		when the error is eliminated. The segment will be turned off by the failure reset. If transmission error is not detected as failure or is detected as minor failure, each segment will not be turned on.	-	-	-

Note) D30-2 to D30-5 available from the version 9457.0+9458.3





W phase V phase U phase A phase Z phase

Speed detection signal input status(D08-C)





6-2 Block-A parameters

The parameters used most frequently have been grouped in Block-A.

- V/f : Indicates parameters that apply for V/f control (constant torque, variable torque) (C30-0: f0 = 1).
- VEC : Indicates parameters that apply for IM speed sensor-less vector control and IM speed vector control with sensor (C30-0: f0 = 2, 3).
- PM : Indicates parameters that apply for control mode with PM motor sensor (C30-0: f0 = 4). *△ indicates a parameter which functions during auxiliary drive operation or when the V/f control is active during automatic tuning.
- RWE : Displays the parameters that can be changed during operation.

Reference page: The number of the page providing detailed explanations is indicated.

No.	Parameter	Min.	Max.	Default	Function	A	oplic	catio	n	Ref.
A 00	Fraguency cotting			(Unit)			VEC	PM	RWE	page
AUU -	Frequency setting		r	10.00	This is the frequency set from the	1				
0	Local frequency setting	setting 0.10 Max. (Hz) operation panel.		0			0	6-87		
1	Jogging frequency	0.10	quency	5.00 (Hz)	This is the frequency setting for jogging.	0			0	6-87
2	Local speed setting	-Max.	Max.	300. (min ⁻¹)	This is the speed set from the operation panel.		0	0	0	6-87
3	Jogging speed	speed	speed	100. (min ⁻¹)	This is the speed setting for jogging		0	0	0	6-87
A01 –	Acceleration/deceleratio	n time		· · · · ·	· · · · · · · · · · · · · · · · · · ·					
0	Acceleration time – 1	0.1	6000.0	10.0 (s)	The value can be displayed in units of 0.1 or 10 times as set on B10-5.	0	0	0	0	6-87
1	Deceleration time – 1	0.1	6000.0	20.0 (s)	The time to reach the max. frequency or max. speed from 0 is set.	0	0	0	0	6-87
A02 –	Torque boost			-						
0	Manual torque boost selection	1.	2.	2.	1: Disable = 2: Enable	0				6-88
1	Automatic torque boost selection	1.	2.	1.	1: Disable = 2: Enable	0				6-88
2	Manual torque boost setting	0.00	20.00	Inverter rating (%)	Set the boost voltage at 0Hz. This is automatically adjusted by the automatic tuning.	0			0	6-90
3	Square reduction torque setting	0.00	25.00	0.00 (%)	Set the reduced voltage at Base frequency/2.	0			0	6-90
4	R1 drop compensation gain	0.0	100.0	100.0 (%)	Set how much to compensate the voltage drop caused by R1 measured with automatic tuning.	0			0	6-90
5	Slip compensation gain	0.00	20.00	0.00 (%)	Set the motor's rated slip. This is automatically adjusted by the automatic tuning.	0			0	6-91
6	Maximum torque boost gain	0.00	50.00	0.00 (%)	This is automatically adjusted by the automatic tuning. The optimum boost amount for outputting the maximum torque is set.	0				6-91
A03 –	DC Brake			-						
0	DC braking voltage	0.01	20.00	Inverter rating (%)	This is automatically adjusted by the automatic tuning. When setting manually, monitor the output voltage and change the setting in increments of 1% or less.	0			0	6-87
1	DC braking time	0.0	20.0	2.0 (s)	Set the time to apply the DC brakes.	0	0	0	0	6-87
2	DC braking current	0.	150.	50. (%)	This is used instead of the DC brake voltage in the vector mode and PM mode. This is not adjusted with automatic tuning.		0	0	0	6-87

No.	Parameter	Min.	Max.	Default	Function	A	oplic	catio	on	Ref.
	_			(Unit)		V/f	VEC	PM	RWE	page
A04 –	Custom parameters		-	i		-	-	-	_	
0	Custom parameters – 0					0	0	0	0	6-91
1	Custom parameters – 1					0	0	0	0	6-91
2	Custom parameters – 2				Set the parameter Nos. to be displayed in	0	0	0	0	6-91
3	Custom parameters – 3				C10-0~7.	0	0	0	0	6-91
4	Custom parameters – 4				This block displays when the above	0	0	0	0	6-91
5	Custom parameters – 5				settings are not made.	0	0	0	0	6-91
6	Custom parameters – 6					0	0	0	0	6-91
7	Custom parameters – 7					0	0	0	0	6-91
A05 –	Parameter B and C indic	atory skip	2	1						
0	Parameter B and C extended setting	1.	2.	2.	= 1: Display, = 2: Skip	0	0	0	0	6-91
1	Parameter B and C software option function	1.	2.	2.	= 1: Display, = 2: Skip	0	0	0	0	6-91
2	Parameter B and C hardware option function	1.	2.	2.	= 1: Display, = 2: Skip	0	0	0	0	6-91
A10 –	ASR control constant 1									
0	ASR response	1.0	300.0	10.0 (rad/s)	The required ASR response radian frequency is set.		0	0	0	6-91
1	ASR machine time constant – 1	10.	20000.	1000 (ms)	The time to accelerate the motor and load's torque inertia to the base speed at the rated torque is set.		0	0	0	6-92
2	ASR integral time constant compensation coefficient	20.	500.	100. (%)	The compensation coefficient applied on the integral time constant of the speed regulator (ASR) is set.		0	0	0	6-92
3	ASR drive torque limiter	0.1	300.0	100.0 (%)	The limit values for the ASR drive side and		0	0	0	6-92
4	ASR regenerative torque limiter	0.1	300.0	100.0 (%)	regenerative side are set.		0	0	0	6-92
5	ASR emergency stop regenerative torque limiter	0.1	300.0	100.0 (%)	The ASR regenerative side limit value applied during the emergency stop mode is set.		0	0	0	6-92
A11 –	ACR control constant			-	-					
0	ACR response	100.	6000.	1000. (rad/s)	The ACR gain and time constant are set. This will affect the current response. If the gain is too low or too high, the current will become unstable, and the over current		0		0	6-92
1	ACR time constant	0.1	300.0	20.0 (ms)	protection will function. Normally adjust the response between 500 and 1000, and the time constant between 5 and 20ms.		0		0	6-92
2	ACR drive torque limiter	0.1	300.0	100.0 (%)	The ACR drive side and regenerative side		0	0	0	6-92
3	ACR regenerative torque limiter	0.1	300.0	100.0 (%)	limit values are set.		0	0	0	6-92
A20 –	ACR control constant (P	M)			-					
0	ACR response (PM)	100.	6000.	1500. (rad/s)	The ACR gain and time constant are set. This will affect the current response. If the gain is too low or too high, the current will become unstable, and the over current			0	0	6-93
1	ACR time constant (PM)	0.1	300.0	10.0 (ms)	protection will function. Normally adjust the response between 500 and 2000, and the time constant between 5 and 20ms.			0	0	6-93
2	d axis current command cushion time (PM)	0.1	100.0	2.0 (ms)	This is the cushion setting to prevent instability caused by overshooting, etc., when the current command changes suddenly.			0	0	6-93
3	q axis current command cushion time (PM)	0.1	100.0	2.0 (ms)	Set at how many ms to change the current command value equivalent to the motor rated current. Normally, a value 5ms or more is set.			0	0	6-93

6-3 Block-B parameters

The Block-B parameters are divided into the basic functions, extended functions and software option functions.

- V/f : Indicates parameters that apply for V/f control (constant torque, variable torque) (C30-0: f0 = 1).
- VEC : Indicates parameters that apply for IM speed sensor-less vector control and IM speed vector control with sensor (C30-0: f0 = 2, 3).
- PM : Indicates parameters that apply for control mode with PM motor sensor (C30-0: f0 = 4).
 *△ indicates a parameter which functions during auxiliary drive operation or when the V/f control is active during automatic tuning.

RWE : Displays the parameters that can be changed during operation.

Reference page: The number of the page providing detailed explanations is indicated.

No.	Parameter	Min.	Max.	Defau (Unit	IIT F)	Function Application Re									Ref.				
				(Onit	9									V/t	VEC	РМ	RWE	paye	
B00 –	Output rating (V/f contro	ol)																	
0	Rated input voltage setting (V/f control)	1.	7.	7	7. f	Select followi	t the rated ing table.	inp	ut voltage	fro	om	the		0				6-94	
							Small siz	ze (Note 1)			La	arge	size	e (No	ote	2)		
						Value	200V syst	em	400V syst	em		Value	200\	00V system			400V system		
						1	to 200\	/	to 380V	'		1	to	to 200V			to 380V		
		the output	s data is c	nangeo	а, П	2	to 200V	/	381 to 400	УC		2	to	200	V	38	1 to 4	400V	
		be chang	led to the s	same		3	201 to 22	0V	401 to 41	5V		3	201	to 2	20V	40	1 to 4	415V	
		value.				4	201 to 22	0V	416 to 440	УC		4	201	to 2	20V	41	6 to 4	440V	
						5	221 to 23	0V	441 to 460	УC		5	221	to 2	30V	44	1 to 4	460V	
						6	231 to 24	0V	461 to 480	УC		6	231	to 2	40V	46	1 to 4	480V	
						7	221 to 23	0V	381 to 400	JV		7	221	to 2	30V	38	1 to 4	400V	
	Max /basa fraguasay																1		
1	simple setting (V/f control)	0.	9.		1.	Select combi	t the outpu nation bel	it fre ow.	equency ra	atir	ng i	from t	he	0				6-94	
					/alu							مىراد	Ftr	a [F	171	Fn	av [H71	
					vaiu	Free setting on B00-4 and						5		-trq [Hz]			100		
					0	B00-5						6 6		60		70			
					1	50 50						7		60		80			
					2	60 60 50 60					8		60		90				
					3							9		60	60		120)	
					4		50		75										
2	Motor rated output (V/f control)	0.10	750.00	Inverte ratin	er - ng f	The m fregue	notor rated	ou	tput at the	ba	ase	!		0				6-94	
	(-	(KV)	v) ·		/D /												
3	Motor rated voltage (V/f control)	39.	480.	230 or 400 (\	L - - - - - - - - - - - - -	DC-AVR does not operate when The input voltage equals the out the base frequency. DC-AVR operates so that the se attained at the base frequency w to 39. When the rated input voltage set is changed, this data is also char rated input voltage value. This cannot be set above the rat						to 39. voltage tage is not se (B00- d to the nput	e at s et 0) e	0				6-95	
4	Max. frequency (Fmax) (V/f control)	Fbase or 3.00	Fbase *7 or 440.00	50.0 (Hz)0 z) \	When "B00-1" is a value other than 0, i						n 0, thi	is	0				6-95	
5	Base frequency (Fbase) (V/f control)	Fmax/7 or 1.00	Fmax or 440.00	50.0 (Hz)0 ^s z)	simple setting.										6-95			
6	Motor rated current (V/f control)	Inverter rating × 0.3	Inverter rating	Inverte ratin (A	er ⁻ ig o A) a	This is overcu analog	s the refere urrent limit g input and	enc :, Ol d ou	e value for LT, curren itput.	rth t%	ne 6 d	isplay	,	0				6-95	

Block-B parameters list

Note 1) Small size: N000K7 to N045K0, X000K7 to X055K0 Note 2) Large size: X075K0 to X475K0

No.	Parameter	Min.	Max.	Default		Fur	nction		Α	pplie	catio	on	Ref.	
Daa	Outrast and in a full second			(Unit)				V/f	VEC	PM	RWE	page		
7	Carrier frequency (Small size) (V/f control)	1.0	21.0	17.0	The no PWM c method This ca 1.0 to (Carri 15.1 t (Basic 18.1 t (Basic	ise can be low arrier frequer I, and changir tic noise gene n be changed 15.0: Monoto er frequency: o 18.0: Soft s c carrier frequ o 21.0: Soft s c carrier frequ	0			0	6-96			
7	Carrier frequency (Large size) (V/f control)	1.0	14.0	10.0	1.0 to (Carri 8.1 to (Basic 11.1 t (Basic	8.0: Monotor er frequency: 11.0: Soft so c carrier freque o 14.0: Soft s c carrier freque	ne sound meth 1.0 to 8.0kHz und method 1 lency: 2.1 to 5 sound method lency: 2.1 to 5	nod :) .0kHz) 2 .0kHz)	0			0	6-96	
B01 –	Output rating (Vector co	ntrol)							-	1				
0	Rated input voltage setting (Vector control)	1.	7.	7.	Select followin	the rated inpu ig table.	it voltage from	1 the		0	0		6-94	
					:	Small size (Note 1) Large						ote 2)		
					Value	200V system	400V system	Value 2	200V s	yste	m 40	00V s	system	
					1	1 to 200V to 380V 1						to 3	80V	
		When the	s data is c	hanged,	2	to 200V	381 to 400V	2	to 2	00V	3	81 to	400V	
		he chang	ed to the	Jala Will Same	3	201 to 220V	401 to 415V	3	201 to	220	/ 4	01 to	415V	
		value.		Samo	4	201 to 220V	416 to 440V	4	201 to	220	/ 4	16 to	440V	
					5	221 to 230V	441 to 460V	5	221 to	230	/ 4	41 to	460V	
					6	231 to 240V	461 to 480V	6	231 to	240	/ 4	61 to	480V	
					7	221 to 230V	381 to 400V	7	221 to	230	/ 3	81 to	400V	
1	Motor rated output (Vector control)	0.10	750.00	Inverter rating (KW)	The mo is set.	otor's rated ou	itput at the ba	se speed	1	0	0		6-94	
2	No. of motor poles (Vector control)	2.	32.	4.	Set the motor r	number of po ameplate.	oles indicated	on the		0	0		6-94	
3	Motor rated voltage (Vector control)	40.	480.	230. or 400. (V)	DC-AV at the b If the ra change rated in set high	R functions to ase frequence ated input volt d, this value i put voltage v ner than the ra	attain the ser y. age setting (E is also change alue. This car ated input volt	t voltage 301-0) is ed to the mot be age.		0	0		6-95	
4	Max. speed (Nmax) (Vector control)	150.	9999.	1800. (min ⁻¹)	The ma that is 4 In the c value 1 The ma number limited 180Hz	x. motor spectrum 4-times or less ase of PM mo .5 times or less ximum value of motor pol- where the syr (210Hz at PM	8	0	0		6-95			
5	Base speed (Nbase) (Vector control)	150.	Max. speed	1800. (min⁻¹)	The mo than thi vector o	otor base spects spects and the special special special special special special special spectral spect	en higher Iring		0	0		6-95		
6	Motor rated current (Vector control)	Inverter rating × 0.3	Inverter rating	Inverter rating (A)	The mo base sp	otor current du beed is set.	uring full load	at the		0	0		6-95	

Note 1) Small size: N000K7 to N045K0, X000K7 to X055K0 Note 2) Large size: X075K0 to X475K0

No.	Parameter	Min.	Max.	Default (Unit)	Function	A	oplie	Catio	on DWE	Ref.
B01 –	Output rating (Vector co	ntrol)		(0)		V/I	VEC	FIN		page
7	Carrier frequency (Small size) (Vector control)	1.0	21.0	17.0	The noise can be lowered by changing the PWM carrier frequency and control method, and changing the tone of the magnetic noise generated from the motor. This can be changed while running. 1.0 to 15.0: Monotone sound method (Carrier frequency: 1.0 to 15.0kHz) 15.1 to 18.0: Soft sound method 1 (Basic carrier frequency: 2.1 to 5.0kHz) 18.1 to 21.0: Soft sound method 2 (Basic carrier frequency: 2.1 to 5.0kHz)		0	0	0	6-96
7	Carrier frequency (Large size) (Vector control)	1.0	14.0	10.0	1.0 to 8.0: Monotone sound method (Carrier frequency: 1.0 to 8.0kHz) 8.1 to 11.0: Soft sound method 1 (Basic carrier frequency: 2.1 to 5.0kHz) 11.1 to 14.0: Soft sound method 2 (Basic carrier frequency: 2.1 to 5.0kHz)		0	0	0	6-96
8	No. of encoder pulses (Vector control)	30.	10000.	1000. (P/R)	The number of pulses per rotation of the encoder in use is set.		0	0		6-97
9	No-load output voltage (Vector control)	20.	500.	160. (V)	The motor terminal voltage during no-load at the base speed is set.		0	0		6-97
B02 –	Motor circuit constant									
0	R1: Primary resistance (IM: Mantissa section)	0.010	90999	Inverter rating (mΩ)	The motor circuit constant is set	0	0		0	6-97
1	R1: Primary resistance (IM: Exponent section	-3	4	Inverter rating		0	0			6-97
2	R2': Secondary resistance (IM : Mantissa section)	0.010	90999	1.000 (mΩ)	This combination means below		0		0	6-97
3	R2': Secondary resistance (IM: Exponent section)	-3	4	0.	R2' = $1.000 \times 10^{\circ} [m\Omega]$		0			6-97
4	Lo: Leakage inductance (IM: Mantissa section)	0.100	9.999	1.000 (mH)		0	0		0	6-97
5	Lo: Leakage inductance (IM: Exponent section)	-3	4	0.		0	0			6-97
6	M': Excitation inductance (IM: Mantissa section)	0.100	90999	1.000 (mH)	00 H)				0	6-97
7	M': Excitation inductance (IM: Exponent section)	-3	4	0.			0			6-97
8	Rm: Iron loss resistance (IM: Mantissa section)	0.100	90999	1.000 (mΩ)			0		0	6-97
9	Rm: Iron loss resistance (IM: Exponent section)	-3	5	0.			0			6-97

No.	Parameter	Min.	Max.	Default	Function		Ap	plic	atic)n	Ref.
	i aramotor			(Unit)	i anotion		V/f	VEC	PM	RWE	page
B03 –	Motor circuit constant (F	۲M)	_								
0	R1: PM motor winding resistance (Mantissa section)	0.001	9.999	1.000 (mΩ)	This combination means below				0	0	6-97
1	R1: PM motor winding resistance (Exponent section)	-1.	4.	0.	R1 = 1.000 × 10 ^υ [mΩ]				0	0	6-97
2	Ld: PM motor d axis inductance (Mantissa section)	0.001	9.999	1.000 (mH))				0	0	6-97
3	Lq: PM motor q axis inductance (Mantissa section)	0.001	9.999	1.000 (mH)	This combination means below Ld = 1.000 × 10 ⁰ [mH]				0	0	6-97
4	Ld, Lq: PM motor inductance (Exponent section)	-1.	4.	0.)				0	0	6-97
5	Rated torque electric current (PM)	20.0	200.0	100.0 (%/I1M)	The torque current (q axis current) ele required to generate the rated torque base speed is set as a ratio in respect the rated current.	ement at the t to			0		6-97
B05 –	Frequency skip										
0	Skip frequency - 1	0.10	440.00	0.10 (Hz)			0			0	6-98
1	Skip band - 1	0.00	10.00	0.00 (Hz)			0			0	6-98
2	Skip frequency - 2	0.10	440.00	0.10 (Hz)	The set frequency avoids the jump w	dth,	0			0	6-98
3	Skip band - 2	0.00	10.00	0.00 (Hz)	point.		0			0	6-98
4	Skip frequency - 3	0.10	440.00	0.10 (Hz)			0			0	6-98
5	Skip band - 3	0.00	10.00	0.00 (Hz)			0			0	6-98

No.	Parameter	Min.	Max.	Default	Function	A	oplic	catio	n	Ref.
	-			(Unit)		V/f	VEC	PM	RWE	page
B00 –	Gearing comparative set	ting		i	1					
0	Coefficient	-10.000	10.000	1.000		0	0	0	0	6-99
1	Analog speed setting-1: Bias (V/f)	-fmax*5 or -440.00	fmax*5 or 440.00	0.00 (Hz)	The coefficient and panel bias value for sequential ratio operation is set with the	0			0	6-99
	Analog speed setting-1	-Nmax*	Nmax*5		speed setting 1.					
2	Bias (Vector & PM)	5 or -9999.	or 9999.	0. (min ⁻¹)			0	0	0	6-99
3	Analog speed setting-2: Coefficient	-10.000	10.000	1.000		0	0	0	0	6-99
4	Analog speed setting-2: Bias (V/f)	-fmax*5 or -440.00	fmax*5 or 440.00	0.00 (Hz)	The coefficient and panel bias value for sequential ratio operation is set with the analog speed setting selected with C07-1:	0			0	6-99
5	Analog speed setting-2: Bias	-Nmax* 5 or	Nmax*5 or 9999	0. (min⁻¹)	Speed setting 2.		0	0	0	6-99
	Analog speed setting 3:	-9999.								
6	Coefficient	-10.000	10.000	1.000	0 0 The coefficient and panel bias value for sequential ratio operation is set with the analog speed setting selected with C07-2:			0	0	6-99
7	Analog speed setting-3: Bias (V/f)	-imax 5 or -440.00	or 440.00	0.00 (Hz)					0	6-99
8	Analog speed setting-3: Bias	-Nmax* 5 or	Nmax*5 or	0. (min ⁻¹)	Speed setting 3.		0	0	0	6-99
	(Vector & PM)	-9999.	9999.	()						
9	Serial speed setting: Coefficient	-10.000	10.000	1.000		0	0	0	0	6-99
А	Serial speed setting: Bias (V/f)	-tmax*5 or -440.00	fmax*5 or 440.00	0.00 (Hz)	The coefficient and panel bias value for sequential ratio operation are set for when	0			0	6-99
В	Serial speed setting: Bias (Vector & PM)	-Nmax* 5 or -9999.	Nmax*5 or 9999.	0. (min⁻¹)	senal speed setting is valid.		0	0	0	6-99
С	Pulse train input speed setting: Coefficient	-10.000	10.000	1.000		0	0	0	0	6-99
D	Pulse train input speed setting: Bias (V/f)	-fmax*5 or -440.00	fmax*5 or 440.00	0.00 (Hz)	The coefficient and panel bias value for sequential ratio operation are set for when	0			0	6-99
E	Pulse train input speed setting: Bias (Vector & PM)	-Nmax* 5 or -9999.	Nmax*5 or 9999.	0. (min ⁻¹)	pulse train input speed setting is valid.		0	0	0	6-99
B07 –	Upper/Lower limit setting	g								
0	Upper limit (V/f, main)	-440.00	440.00	440.00 (Hz)	The upper limit is larger than the lower	0			0	6-100
1	Lower limit (V/f, main)	-440.00	440.00	0.10 (Hz)	limit.	0			0	6-100
2	Upper limit (Vector&PM)	-9999.	9999.	7200. (min ⁻¹)	The upper limit is larger than the lower limit		0	0	0	6-100
3	Lower limit (Vector&PM)	-9999.	9999.	(min ⁻¹)			0	0	0	6-100
B10 –	Acceleration/deceleratio	n time se	tting				_	_		
0	Acceleration time - 2 setting	0.1	6000.0	10.0 (s)	 0.0 0.0 (s) selection is ON (CSEL=ON) is set. Set a time between 0 and the max. frequency or max. speed. 20.0 (s) with the time unit setting (B10-5). 		0	0	0	6-100
1	Deceleration time - 2 setting	0.1	6000.0	20.0 (s)			0	0	0	6-100
2	Acceleration time for jogging setting	0.1	6000.0	5.0 (s)	5.0 (s) The acceleration/deceleration time value when the JOG sequence (F JOG, R JOG is valid is set. Set a time between 0 and t max. frequency or max. speed.			0	0	6-100
3	Deceleration time for jogging setting	0.1	6000.0	5.0 (s)	The unit can be changed to $\times 0.1$ s, $\times 10$ s with the time unit setting (B10-5).	0	0	0	0	6-100

No.	Parameter	Min.	Max.	Default	F		Α	pplic	catio	on	Ref.	
-				(Unit)			V/f	VEC	PM	RWE	page	
B10 –	Acceleration/deceleratio	n time se	tting						_			
4	S-shape characteristics (Ts) acceleration and deceleration time setting	0.0	5.0	0.0 (s)	t to 1/2 or less o shape pattern is rameter.	of the ramp possible t	o time. by setting this	0	0	0	0	6-101
5	Acceleration and deceleration cushion time unit setting	1.	3.	1.	:(Standard) =2 e acceleration/d ting unit can be celeration/decele der range. This p celeration/ celeration ramp	2: ×0.1 =3 leceleratio changed l eration rar parameter time para	3: ×10 n ramp time by setting an np time with a will affect all meters.	0	0	0		6-101
6	S-shape ramp pass function setting	1.	3.	1.	: OFF =2: For : For RUN-OFF	r program	0	0	0	0		6-101
B11 –	Program frequency (spe	ed) settin	g									
0	Program frequency (speed) - 0 setting	0.00	100.00	10.00 (%)	lect as follows w For binary mo	vith S0, S1 • de (B11-8	, S2, S3 and =1)	0	0	0	0	6-102
					Sequence command Selected 0 SE S3 S2 S1 S0 frequency							
1	Program frequency	0.00	100.00	10.00	SE S3 S2	S1 S0	frequency	0	0	0	0	6-102
	(speed) - 1 setting			(%)	OFF	OFF OFF	B11-0					
2	Program frequency (speed) - 2 setting	0.00	100.00	10.00 (%)	* * OFF OFF ON ON	ONOFFONONOFFOFFOFFONOFFON	B11-2 B11-3 B11-4 B11-5 B11-6	0	0	0	0	6-102
3	Program frequency (speed) - 3 setting	0.00	100.00	10.00 (%)	SE and S3 are not u	ON ON used. ect mode	B11-7 (B11-8=2)	0	0	0	0	6-102
4	Program frequency (speed) - 4 setting	0.00	100.00	10.00 (%)	Sequence com SE S3 S2 DFF OFF OFF DFF OFF OFF DFF OFF OFF	S1S0OFFOFFOFFONONOFF	Selected frequency Previous values B11-0 B11-1	0	0	0	0	6-102
5	Program frequency (speed) - 5 setting	0.00	100.00	10.00 (%)	OFF OFF ON OFF ON OFF ON OFF OFF ON OFF OFF ON OFF OFF	OFF OFF OFF OFF OFF OFF OFF ON ON OFF	B11-2 B11-3 Previous values B11-4 B11-5	0	0	0	0	6-102
6	Program frequency (speed) - 6 setting	0.00	100.00	10.00 (%)	ON OFF ON ON ON OFF Then S0 to S3 are all e set between S0 and Il be held. If there are	OFF OFF OFF OFF OFF, or when of S3, the preve e no previous	B11-6 B11-7 a two or more vious values values	0	0	0	0	6-102
7	Program frequency (speed) - 7 setting	0.00	100.00	10.00 (%)	ecause the power has vill be set.	ON, etc., "0"	0	0	0	0	6-102	
8	Selection mode setting	1.	2.	1.	lect the program 11-0 to 7) and pi ection mode. : Binary mode 2: Direct select n	n frequenc rogram rar node	y setting np (B41, B42)	0	0	0		6-102

No.	Parameter	Min.	Max.	Default	Function	Α	oplic	catio	on	Ref.
D 4 0				(Unit)		V/f	VEC	РМ	RWE	page
B12 –	Automatic braking on po	ower failu	re setting	(Main)		i –				
0	Braking on power failure enable setting (Main)	1.	2.	1.	=1: C00-0, 1 compliant, =2: Decelerate stop at power failure	0	Δ	Δ	0	6-103
1	Power failure determination level setting (Main)	65.	90.	80. (%)	Sequence output: BPF turns ON when the DC voltage value is less than this level.	0	Δ	Δ	0	6-103
2	Deceleration ramp time-1 setting (Main)	0.1	6000.0	10.0 (s)	Motor decelerates from max. frequency value to 0Hz at the time set here.	0			0	6-103
3	Deceleration ramp time-2 setting (Main)	0.0	6000.0	10.0 (s)	Motor decelerates from max. frequency value to 0Hz at the time set here. When 0.0 is set, the motor decelerates at the deceleration ramp time -1.	0			0	6-103
4	Subtraction frequency setting (Main)	0.00	20.00	0.00 (Hz)	Subtraction is not executed when 0.00Hz is set. If the results of output frequency - subtraction frequency are 0 or less, the frequency is 0Hz and the brakes are applied.	0			0	6-103
5	Subtraction start frequency setting (Main)	0.00	Max fre- quency or 999.99	0.00 (Hz)	If the output frequency increases above this value, the motor decelerates from the results of output frequency - subtraction frequency. Subtraction is always executed when 999.99 is set. O Changeover is not executed between 0.00				0	6-103
6	Switching frequency setting (Main)	0.00	Max fre- quency	0.00 (Hz)	Changeover is not executed between 0.00 and the stopping frequency or less.	0			0	6-103
B13 –	Local setting									
0	Torque setting	-300.0	300.0	0.0 (%)	This is the torque setting from the operation panel. Set C02-2 to 3 when using this setting.		0	0	0	6-104
1	Torque ratio 1 setting	0.001	5.000	1.000	 Set C02-2 to 3 when using this setting. This is the torque setting from the operation panel. Set C02-3 to 3 when using this setting. 		0	0	0	6-104
2	Torque bias 1 setting	-300.0	300.0	0.0 (%)	This is the torque setting from the operation panel. Set C02-4 to 3 when using this setting.		0	0	0	6-104
3	Torque ratio 2 setting	-5.000	5.000	1.000	This is the torque setting from the operation panel. Set C02-5 to 3 when using this setting.		0	0	0	6-104
4	Double rating speed ratio setting	0.1	100.0	100.0 (%)	This sets the torque limiter reduction pattern changeover point. Set as a percentage in respect to the base speed.		0	0		6-104
5	Drooping setting	0.00	20.00	0.00 (%)	By adjusting this parameter, the torque-motor speed drooping characteristics can be achieved.		0	0	0	6-104
6	ASR gain compensation in constant power range	0.0	150.0	100.0 (%)	 (%) characteristics can be achieved. This sets the ASR gain compensation value at the max. speed. By adjusting this parameter, the ASR gain can be compensated in the constant pow range. If ASR hunting occurs in the sensor-less vector control's constant output range, se a smaller value. 		0	0	0	6-105
7	ACR gain compensation in constant power range	0.0	150.0	100.0 (%)	 This sets the ACR gain compensation value at the max. speed. By adjusting this parameter, the ACR ga can be compensated in the constant pov range. 		0	0	0	6-105
8	Linear torque limit 1 (at 100% torque)	0.	450.	400. (%)	The linear torque limiter for operation of the PM motor in the weak magnetic field range is set		0	0	0	6-105
9	Linear torque limit 2 (at 100% torque)	0.	450.	450. (%)	Refer to section 6-9-5 for details.		0	0	0	6-105

No.	Parameter	Min.	Max.	Default	Function	Ар	plic	atic	on Swit	Ref.
B14 _	ASP dead band setting			(Onit)		V/f	VEC	РМ	RWE	paye
014-	AOD dead band setting	0.0	100.0	0.0	The non-sensitive range of the ASR input			~	~	0.405
0	ASR dead band setting	0.0	100.0	(%)	is set.		0	0	0	6-105
B15 –	Machine time constant s	etting		-	<u> </u>					
0	Machine time constant setting 2	10.	20000.	1000. (ms)	The time to accelerate the motor and load's torque inertia to the base speed at the rated torque is set. This is valid when the sequence command machine time constant changeover is ON (MCH = ON).		0	0	0	6-105
B16 –	Automatic torque bias s	etting								
0	Automatic torque bias selection	0.	2.	0.	=0: Not used =1: Digital =2: Analog		0	0		6-106
1	Digital bias setting 0	-150.0	150.0	-100.0 (%)	These settings are selected according to the state of sequence input: S5, S6 and S7 (C05-0, 1, 2).		0	0		6-106
2	Digital bias setting 1	-150.0	150.0	-50.0 (%)	S7 S6 S5		0	0		6-106
3	Digital bias setting 2	-150.0	150.0	0.0 (%)	0 0 0 setting0 0 0 1 Setting1 0 1 0 Setting2		0	0		6-106
4	Digital bias setting 3	-150.0	150.0	50.0 (%)	0 1 1 Setting3 1 x x Setting4		0	0		6-106
5	Digital bias setting 4	-150.0	150.0	100.0 (%)			0	0		6-106
6	Bias direction selection	1.	2.	1.	Set the bias direction. =1: Clockwise drive direction =2: Counterclockwise drive direction		0	0		6-106
7	Analog bias voltage 0	-100.0	100.0	0.0 (%)	Set the input voltage lower limit value.		0	0		6-106
8	Analog bias voltage 1	-100.0	100.0	50.0 (%)	Set the input voltage at the balance point.		0	0		6-106
9	Analog bias voltage 2	-100.0	100.0	100.0 (%)	Set the input voltage upper limit value.		0	0		6-106
А	Output bias torque 0	-150.0	150.0	-100.0 (%)	Set the bias torque at the input voltage lower limit value.		0	0		6-106
В	Output bias torque 1	-150.0	150.0	100.0 (%)	Set the bias torque at the input voltage upper limit value.		0	0		6-106
B17 –	V/f middle point setting		r							
0	V/f middle point settina-Frequency 1	0.00	Max. frequency	0.00 (Hz)		0				6-107
1	V/f middle point setting-Voltage 1	0.0	200.0	0.0 (%)		0				6-107
2	V/f middle point setting-Frequency 2	0.00	Max. frequency	0.00 (Hz)	The following rule applies to each frequency.	0				6-107
3	V/f middle point setting-Voltage 2	0.0	200.0	0.0 (%)	-max≥trequency-5≥trequency-4≥trequency -3≥frequency-2≥frequency-1≥0	0				6-107
4	V/f middle point setting-Frequency 3	0.00	Max. frequency	0.00 (Hz)	excessive frequency will be set to the same value as the changed setting value.	0				6-107
5	V/f middle point setting-Voltage 3	0.0	200.0	0.0 (%)	Set the frequency value to 0.00 when using 4 points or less.	0				6-107
6	V/f middle point setting-Frequency 4	0.00	Max. frequency	0.00 (Hz)	Note that there is no need to set 0.00 from frequency -1.	0				6-107
7	V/f middle point setting-Voltage 4	0.0	200.0	0.0 (%)	voltage at the base frequency will be 100%, and the B17-A setting value V/f	0				6-107
8	V/f middle point setting-Frequency 5	0.00	Max. frequency	0.00 (Hz)	characteristics will be applied at the max. frequency value.	0				6-107
9	V/f middle point setting-Voltage 5	0.0	200.0	0.0 (%)		0				6-107
A	V/f middle point setting-Voltage Fmax	0.0	200.0	100.0 (%)		0				6-107
В	V/f middle point use selection	1.	2.	1.	=1: Function invalid =2: Function valid	0				6-107

No.	Parameter	Min.	Max.	Default	Function	A	oplic	catio	on	Ref.
				(Unit)		V/f	VEC	РМ	RWE	page
B18 –	Current limit									
0	Over current limit	50.	300.	125. (%)	The default value is 155. when heavy-duty is set.	0	0	0	0	6-109
1	Regenerative current limit	5.	300.	10. (%)	Set to 10% when not using the DBR option.	0	\bigtriangleup	\bigtriangleup	0	6-110
2	Torque stabilization gain	0.00	4.00	1.00	The disturbance symptoms which occur if the current abnormally vibrates after motor operation is suppressed. Increase or decrease by 0.05 units if the motor vibrates.	0	\bigtriangleup	\bigtriangleup	0	6-110
3	Current limit function gain	0.00	2.00	0.25	Decrease if current hunting occurs.	0	\bigtriangleup	\triangle	0	6-109
4	Current stabilization gain	0.00	2.00	0.25		0	\triangle	\bigtriangleup	0	6-109
5	Current stall prevention gain	0.00	2.50	1.00	Decrease if current hunting occurs.	0	\bigtriangleup	\bigtriangleup	0	6-109
6	Stall prevention time constant	10.	1001.	100.	Increase if current hunting occurs. P control will be applied if 1001 is set.	0	\bigtriangleup	\bigtriangleup	0	6-109
7	Drive current limit level 2	50.	300.	200. (%)	When sequence input: OCLLV1 is ON, this parameter value is selected for the overcurrent limit. This function is not applied on the auxiliary drive.	0	0	0	0	6-109
8	Drive current limit level 3	50.	300.	250. (%)	When sequence input: OCLLV2 is ON, this parameter value is selected for the overcurrent limit. This function is not applied on the auxiliary drive.	0	0	0	0	6-109
B19 –	Automatic tuning function	on								
0	Automatic tuning selection	0.	7.	0.	 =1: Basic adjustment =2: Extended adjustment for V/f Control =3: Basic adjustment for Vector Control =4: Extended adjustment for Vector Control =5: Calculation of no load voltage for Vector Control =6: Encoder phase adjustment (PM) =7: Flux position estimation 		0	0		6-110
1	Initial proportion compensation gain (Automatic tuning function)	0.	500.	100. (%)	When the motor with special circuit parameters is applied, the initial condition of automatic tuning is set. Change these value if auto tuning is completed incorrectly	0	0			6-110
2	Initial time constant compensation gain (Automatic tuning function)	0.	500.	100. (%)	and try to auto tuning again. Set these values to increase or decrease with 50% step.	0	0			6-110

No.	Parameter	Min.	Max.	Default		F		Α	ppli	catio	on	Ref.		
			-	(Unit)			-			V/f	VEC	PM	RWE	page
B20 –	Output rating (Auxiliary	drive 0)		-	1						i ——	i —		
0	Max./base frequency simple setting (Auxiliary drive 0)	0.	9.	1.	Sele com	ect the output f bination below	re v.	quency ra	ating from the	0	\triangle	\triangle		6-110
			Value	Ftrq [H	lz]	Fmax [Hz]	[Value	Ftrq [Hz]	Fm	ax [Hz]	1	
			0	Free set	ting o	on B20-4, 5		5	50		100			
			1	50		50		6	60		70			
			2	60		60		7	60		80			
			3	50		60		8	60		90		_	
			4	50		75		9	60		120			
										_				
1	Rated output voltage (Auxiliary drive 0)	40.	480.	230. or 400. (V)	DC- at the lf the chain rate set l	AVR functions ne base freque e rated input ve nged, this valu d input voltage higher than the		o attain th y. age settii s also ch alue. This ated inpu	e set voltage ng (B00-0) is anged to the s cannot be t voltage.	0	Δ			6-110
2	Max. frequency (Fmax_AU0) (Auxiliary drive 0)	Fbase _AU0 or 3.00	FBASE _AU0*7 or 440.00	50.00 (Hz)	Whe	en "B20-0" is a	l Vá	alue othe	r than 0, this	0		\bigtriangleup		6-110
3	Base frequency (Fbase_AU0) (Auxiliary drive 0)	Fmax _AU0/7 or 1.00	Fmax _AU0 or 440.00	50.00 (Hz)	sim	ple setting.	uı	line data	set in the	0				6-110
4	Motor rated current (Auxiliary drive 0)	Inverter rating × 0.3	Inverter rating	Inverter rating (A)	This over ana	s is the referent rcurrent limit, C log input and c	ce DL but	value foi T, curren put.	⁻ the t % display,	0	\bigtriangleup	\bigtriangleup		6-110
5	Carrier frequency (Small size) (Auxiliary drive 0)	1.0	21.0	17.0	Pof	or to ROO 7 for	de	staile on t	ho sottings	0	\bigtriangleup	\bigtriangleup	0	6-110
5	Carrier frequency (Large size) (Auxiliary drive 0)	1.0	14.0	10.0	IXen		u		ne seungs.	0	\bigtriangleup	\bigtriangleup	0	6-110
6	Start frequency (Auxiliary drive 0)	0.10	60.00	1.00 (Hz)	Ope whe	eration starts from the motor starts	on art	n this frec s.	luency value	0	\triangle	\triangle	0	6-110
7	Stop frequency (Auxiliary drive 0)	0.10	60.00	1.00 (Hz)	The freq valu	DC brakes are uency value is ie.	e a le	applied w ss than t	hen the his frequency	0	\bigtriangleup	\bigtriangleup	0	6-110
8	Upper limit (Auxiliary drive 0)	-440.00	440.00	440.00 (Hz)	Mak	e sure that the	e u	pper limi	t is greater	0	\triangle	\triangle	0	6-110
9	Lower limit (Auxiliary drive 0)	-440.00	440.00	0.10 (Hz)	thar	n the lower limi	t.			0	\triangle	\triangle	0	6-110
B21 –	Frequency setting (Auxi	liary drive	0)											
0	Local frequency setting (Auxiliary drive 0)	0.10	Fmax _AU0	10.00 (Hz)	This is the freque) panel.			set from	the operation	0	\triangle	\triangle	0	6-110
1	Frequency setting for jogging (Auxiliary drive 0)	0.10	Fmax _AU0	5.00 (Hz)) This is the freque			setting f	or jogging.	0			0	6-110
2	Acceleration time - 1 (Auxiliary drive 0)	0.1	6000.0	10.0 (s)	The with	unit can be ch the time unit s	nar set	nged to \times ting (B10	0.1s, ×10s -5).	0	\triangle	\triangle	0	6-110
3	Deceleration time - 1 (Auxiliary drive 0)	0.1	6000.0	20.0 (s)	The max	time to reach	the) is	e max. fre s set.	equency or	0	\triangle	\triangle	0	6-110

No.	Parameter	Min.	Max.	Default	Function	A	oplic	atic	on Dur	Ref.
B21 -	Frequency setting (Auxi	liary drive	0)	(onit)		V/f	VEC	РМ	RWE	page
4	Acceleration time - 2 (Auxiliary drive 0)	0.1	6000.0	10.0 (s)	This is the acceleration/deceleration ramp time setting made valid when the sequence command ramp 2 switch is ON (CSEL=ON).	0	\bigtriangleup	\bigtriangleup	0	6-110
5	Deceleration time - 2 (Auxiliary drive 0)	0.1	6000.0	20.0 (s)	Set a time between 0 and the max. frequency or max. speed. The unit can be changed to ×0.1s, ×10s with the time unit setting (B10-5).	0		\bigtriangleup	0	6-110
6	Acceleration time for jogging (Auxiliary drive 0)	0.1	6000.0	5.0 (s)	The acceleration/deceleration ramp time value when the JOG sequence (F JOG, R JOG) is valid is set. Set a time between 0 and the max.	0	\bigtriangleup	\bigtriangleup	0	6-110
7	Deceleration time for jogging (Auxiliary drive 0)	0.1	6000.0	5.0 (s)	The unit can be changed to ×0.1s, ×10s with the time unit setting (B10-5).	0	\bigtriangleup	\bigtriangleup	0	6-110
B22 –	Torque boost, DC Brake	, DC Brak	e setting,	Overcurr	rent setting, Overload setting (Auxiliary dri	ve 0)			
0	Manual torque boost setting (Auxiliary drive 0)	0.00	20.00	Inverter rating (%)	Set the boost voltage at 0Hz.	0	\bigtriangleup	\bigtriangleup	0	6-110
1	Square reduction torque setting (Auxiliary drive 0)	0.00	25.00	0.00 (%)	Set the reduced voltage at Base frequency/2.	0	\bigtriangleup	\bigtriangleup	0	6-110
2	DC braking voltage (Auxiliary drive 0)	0.01	20.00	Inverter rating (%)	When setting manually, monitor the output voltage and change the setting in increments of 1% or less.	0	\bigtriangleup	\bigtriangleup	0	6-110
3	DC braking time (Auxiliary drive 0)	0.0	20.0	2.0 (s)	Set the time to apply the DC brakes.	0	\bigtriangleup	\bigtriangleup	0	6-110
4	Over current limit (Auxiliary drive 0)	50.	300.	125. (%)	The default value is 155. when heavy-duty is set.	0	\bigtriangleup	\bigtriangleup	0	6-110
5	Regenerative current limit (Auxiliary drive 0)	5.	300.	10. (%)	Set to 10% when not using the DBR option.	0	\triangle	\bigtriangleup	0	6-110
6	Torque stabilization gain (Auxiliary drive 0)	0.00	4.00	1.00	Increase or decrease by 0.05 units if the motor vibrates.	0	\triangle	\bigtriangleup	0	6-110
7	Motor overload reference (Auxiliary drive 0)	50.0	105.0	100.0 (%)	When this data is changed, the B22-8, 9 data is limited to this value. Take care when decreasing and then increasing this value.	0	\bigtriangleup	\bigtriangleup		6-110
8	0Hz overload (Auxiliary drive 0)	20.0	105.0	100.0 (%)	The max. value is the B22-9 value.	0	\bigtriangleup	\bigtriangleup		6-110
9	0.7Base freq. overload (Auxiliary drive 0)	50.0	105.0	100.0 (%)	The min. value is the B22-8 value.	0	\bigtriangleup	\bigtriangleup		6-110
B23 –	Braking on power failure	e setting (Auxiliary	drive 0)		;;				
0	Braking on power deceleration ramp time-1 (Auxiliary drive 0)	0.1	6000.0	10.0 (s)	Set the deceleration time from the maximum frequency value to 0Hz.	0	\bigtriangleup	\bigtriangleup	0	6-110
1	Braking on power deceleration ramp time-2 (Auxiliary drive 0)	0.0	6000.0	10.0 (s)	Set the deceleration time from the maximum frequency value to 0Hz. Deceleration is performed at deceleration ramp time-1 when 0.0.	0	\bigtriangleup	\bigtriangleup	0	6-110
2	Braking on power subtraction frequency (Auxiliary drive 0)	0.00	20.00	0.00 (Hz)	No subtraction made when 0.00Hz. 0Hz and brake engaged when the result of output frequency – subtraction frequency is 0 or less.	0	\bigtriangleup	\supset	0	6-110
3	Braking on power subtraction start frequency (Auxiliary drive 0)	0.00	Fmax _AU0 or 999.99	0.00 (Hz)	If the output frequency is higher than this value, deceleration is performed from the result of output frequency – subtraction frequency. Subtraction is always performed when 999.9.	0			0	6-110
4	Braking on power switching frequency (Auxiliary drive 0)	0.00	Fmax _AU0	0.00 (Hz)	Switching is not performed when 0.00 to stoppage frequency or less.	0	\bigtriangleup	\bigtriangleup	0	6-110

No.	Parameter	Min.	Max.	Default		F		Α	pplie	catio	on	Ref.		
_				(Unit)						V/f	VEC	РМ	RWE	page
B24 –	Output rating (Auxiliary	drive 0)												
0	Max./base frequency simple setting (Auxiliary drive 0)	0.	9.	1.	Sele com	ect the output fr bination below	reo '.	quency ra	ating from the	0	\bigtriangleup	\bigtriangleup		6-110
			Value	Ftrg [H	lz]	Fmax [Hz]	Γ	Value	Ftra [Hz]	Fm	ax [Hz1	1	
			0	Free set	ting o	on B24-4, 5	ŀ	5	50		100			
			1	50		50		6	60		70			
			2	60		60		7	60		80			
			3	50		60		8	60		90			
			4	50		75	L	9	60		120			
1	Rated output voltage (Auxiliary drive 0)	40.	480.	230. or 400. (V)	DC- at th If the chai rate set I	AVR functions le base frequer e rated input vo nged, this value d input voltage nigher than the	to nc olt e i va ra	attain th y. age settir s also ch alue. This ated inpu	e set voltage ng (B00-0) is anged to the s cannot be t voltage.	0	Δ			6-110
2	Max. frequency (Fmax_AU1) (Auxiliary drive 0)	Fbase _AU1 or 3.00	FBASE _AU1*7 or 440.00	50.00 (Hz)	Whe	en "B24-0" is a	r than 0, this	0	Δ	\bigtriangleup		6-110		
3	Base frequency (Fbase_AU1) (Auxiliary drive 0)	Fmax _AU1/7 or 1.00	Fmax _AU1 or 440.00	50.00 (Hz)	simp	ble setting.	un	ine dala	set in the	0	Δ			6-110
4	Motor rated current (Auxiliary drive 0)	Inverter rating × 0.3	Inverter rating	Inverter rating (A)	This over anal	is the reference rcurrent limit, O log input and o	ce DL' ut	value for T, curren put.	⁻ the t % display,	0		\bigtriangleup		6-110
5	Carrier frequency (Small size) (Auxiliary drive 0)	1.0	21.0	17.0	(A) analog input and output.					0	\bigtriangleup	\bigtriangleup	0	6-110
5	Carrier frequency (Large size) (Auxiliary drive 0)	1.0	14.0	10.0	Reit		ue		ne seungs.	0	\bigtriangleup	\bigtriangleup	0	6-110
6	Start frequency (Auxiliary drive 0)	0.10	60.00	1.00 (Hz)	Ope whe	ration starts front in the motor states and the motor states and the motor states are states	om art	n this frec s.	luency value	0	\bigtriangleup	\bigtriangleup	0	6-110
7	Stop frequency (Auxiliary drive 0)	0.10	60.00	1.00 (Hz)	The freq valu	DC brakes are uency value is e.	e a le	pplied wi ss than ti	hen the his frequency	0	\bigtriangleup	\bigtriangleup	0	6-110
8	Upper limit (Auxiliary drive 0)	-440.00	440.00	440.00 (Hz)	Mak	e sure that the	e u	pper limit	t is greater	0	\triangle	\bigtriangleup	0	6-110
9	Lower limit (Auxiliary drive 0)	-440.00	440.00	0.10 (Hz)	thar	the lower limit	t			0	\bigtriangleup	\bigtriangleup	0	6-110
B25 –	Frequency setting (Auxi	liary drive	1)											
0	Local frequency setting (Auxiliary drive 1)	0.10	Fmax _AU1	10.00 (Hz)	This pan	is the frequent	су	set from	the operation	0	\triangle	\triangle	0	6-110
1	Frequency setting for jogging (Auxiliary drive 1)	0.10	Fmax _AU1	5.00 (Hz)	This	is the frequen	су	setting f	or jogging.	0		\bigtriangleup	0	6-110
_2	Acceleration time - 1 (Auxiliary drive 1)	0.1	6000.0	10.0 (s)	The with	unit can be cha the time unit s	ar et	iged to × ting	0.1s, ×10s	0	\triangle	\triangle	0	6-110
3	Deceleration time - 1 (Auxiliary drive 1)	0.1	6000.0	20.0 (s)	Set	a time betweer uency or max.) and the beed.	max.	0	\bigtriangleup	\bigtriangleup	0	6-110	

No.	Parameter	Min.	Max.	Default	Function	A	oplic	catio	on	Ref.
				(Unit)		V/f	VEC	РМ	RWE	page
B25 –	Frequency setting (Auxi	liary drive	- 1)	ŀ		1				
4	Acceleration time - 2 (Auxiliary drive 1)	0.1	6000.0	10.0 (s)	This is the acceleration/deceleration ramp time setting made valid when the sequence command ramp 2 switch is ON (CSEL=ON). Set a time between 0 and the max	0	\bigtriangleup	\bigtriangleup	0	6-110
5	Deceleration time - 2 (Auxiliary drive 1)	0.1	6000.0	20.0 (s)	frequency or max. speed. The unit can be changed to $\times 0.1$ s, $\times 10$ s with the time unit setting (B10-5).	0	\bigtriangleup		0	6-110
6	Acceleration time for jogging (Auxiliary drive 1)	0.1	6000.0	5.0 (s)	The acceleration/deceleration ramp time value when the JOG sequence (F JOG, R JOG) is valid is set. Set a time between 0 and the max.	0	\bigtriangleup	\bigtriangleup	0	6-110
7	Deceleration time for jogging (Auxiliary drive 1)	0.1	6000.0	5.0 (s)	frequency. The unit can be changed to ×0.1s, ×10s with the time unit setting (B10-5).	0	\bigtriangleup	\bigtriangleup	0	6-110
B26 –	Torque boost, DC Brake	, DC Brak	e setting,	Overcur	ent setting, Overload setting (Auxiliary dri	ve 1)			
0	Manual torque boost setting (Auxiliary drive 1)	0.00	20.00	Inverter rating (%)	Set the boost voltage at 0Hz.	0	\bigtriangleup	\bigtriangleup	0	6-110
1	Square reduction torque setting (Auxiliary drive 1)	0.00	25.00	0.00 (%)	Set the reduced voltage at Base frequency/2.	0	\bigtriangleup	\bigtriangleup	0	6-110
2	DC braking voltage (Auxiliary drive 1)	0.01	20.00	Inverter rating (%)	When setting manually, monitor the output voltage and change the setting in increments of 1% or less.	0	\bigtriangleup	\bigtriangleup	0	6-110
3	DC braking time (Auxiliary drive 1)	0.0	20.0	2.0 (sec)	Set the time to apply the DC brakes.	0	\bigtriangleup	\bigtriangleup	0	6-110
4	Over current limit (Auxiliary drive 1)	50.	300.	125. (%)	The default value is 155. when heavy-duty is set.	0	\bigtriangleup	\bigtriangleup	0	6-110
5	Regenerative current limit (Auxiliary drive 1)	5.	300.	10. (%)	Set to 10% when not using the DBR option.	0	\bigtriangleup	\bigtriangleup	0	6-110
6	Torque stabilization gain (Auxiliary drive 1)	0.00	4.00	1.00	Increase or decrease by 0.05 units if the motor vibrates.	0	\triangle	\triangle	0	6-110
7	Motor overload reference (Auxiliary drive 1)	50.0	105.0	100.0 (%)	When this data is changed, the B26-8, 9 data is limited to this value. Take care when decreasing and then increasing this value.	0	\bigtriangleup	\bigtriangleup		6-110
8	0Hz overload (Auxiliary drive 1)	20.0	105.0	100.0 (%)	The max. value is the B26-9 value.	0	\triangle	\bigtriangleup		6-110
9	0.7Base freq. overload (Auxiliary drive 1)	50.0	105.0	100.0 (%)	The min. value is the B26-8 value.	0	\triangle	\bigtriangleup		6-110
B27 –	Braking on power failure	e setting (Auxiliary	drive 1)		i				
0	Braking on power deceleration ramp time-1 (Auxiliary drive 1)	0.1	6000.0	10.0 (s)	Set the deceleration time from the maximum frequency value to 0Hz.	0	\bigtriangleup	\bigtriangleup	0	6-110
1	Braking on power deceleration ramp time-2 (Auxiliary drive 1)	0.0	6000.0	10.0 (s)	Set the deceleration time from the maximum frequency value to 0Hz. Deceleration is performed at deceleration ramp time-1 when 0.0.	0	\bigtriangleup	\bigtriangleup	0	6-110
2	Braking on power subtraction frequency (Auxiliary drive 1)	0.00	20.00	0.00 (Hz)	No subtraction made when 0.00Hz. 0Hz and brake engaged when the result z) output frequency – subtraction frequency 0 or less.		\bigtriangleup	\bigtriangleup	0	6-110
3	Braking on power subtraction start frequency (Auxiliary drive 1)	0.00	Fmax _AU1 or 999.99	0.00 (Hz)	If the output frequency is higher than this value, deceleration is performed from the result of output frequency – subtraction frequency. Subtraction is always performed when 999.99.	0	Δ	Δ	0	6-110
4	Braking on power switching frequency (Auxiliary drive 1)	0.00	Fmax _AU1	0.00 (Hz)	Switching is not performed when 0.00 to stoppage frequency or less.	0	\bigtriangleup	\bigtriangleup	0	6-110

No.	Parameter	Min.	Max.	Default		F		Α	pplie	catio	on	Ref.		
				(Unit)						V/f	VEC	РМ	RWE	page
B28 –	Output rating (Auxiliary	drive 2)									-			
0	Max./base frequency simple setting (Auxiliary drive 2)	0.	9.	1.	Sele com	ect the output finition below	reo v.	quency ra	ating from the	0	Δ	\triangle		6-110
			Value	Ftrq [H	lz]	Fmax [Hz]	ſ	Value	Ftrg [Hz]	Fm	ax [Hz]	1	
			0	Free set	ting o	on B28-4, 5		5	50		100	-		
			1	50		50		6	60		70			
			2	60		60		7	60		80			
			3	50		60		8	60		90			
			4	50		75	L	9	60		120			
1	Rated output voltage (Auxiliary drive 2)	40.	480.	230. or 400. (V)	DC- at th If the chai rate set I	AVR functions be base frequent e rated input vol- nged, this value d input voltage higher than the	e to nc olt e i e v e ra	o attain th y. age settii s also ch alue. This ated inpu	e set voltage ng (B00-0) is anged to the s cannot be t voltage.	0	\bigtriangleup	\bigtriangleup		6-110
2	Max. frequency (Fmax_AU2) (Auxiliary drive 2)	Fbase _AU2 or 3.00	FBASE _AU2*7 or 440.00	50.00 (Hz)	Whe	en "B28-0" is a	Va	alue othe	r than 0, this	0	\bigtriangleup	\bigtriangleup		6-110
3	Base frequency (Fbase_AU2) (Auxiliary drive 2)	Fmax _AU2/7 or 1.00	Fmax _AU2 or 440.00	50.00 (Hz)	sim	ble setting.	uı	ine dala	Set in the	0	\bigtriangleup	\bigtriangleup		6-110
4	Motor rated current (Auxiliary drive 2)	Inverter rating × 0.3	Inverter rating	Inverter rating (A)	This over anal	is the referent rcurrent limit, C log input and o	ce DL out	value foi T, curren put.	r the t % display,	0	\bigtriangleup	\bigtriangleup		6-110
5	Carrier frequency (Small size) (Auxiliary drive 2)	1.0	21.0	17.0	Pof	or to ROO 7 for	de	ataile on t	ho sottings	0	\bigtriangleup	\bigtriangleup	0	6-110
5	Carrier frequency (Large size) (Auxiliary drive 2)	1.0	14.0	10.0	Itek		uc		ne seungs.	0	\bigtriangleup	\bigtriangleup	0	6-110
6	Start frequency (Auxiliary drive 2)	0.10	60.00	1.00 (Hz)	Ope whe	eration starts from the motor states and the motor states and the motor states are states and the motor states and the motor states are state are states are	on art	n this frec s.	quency value	0	\triangle	\bigtriangleup	0	6-110
7	Stop frequency (Auxiliary drive 2)	0.10	60.00	1.00 (Hz)	The freq valu	DC brakes are uency value is e.	e a le	applied w ss than t	hen the his frequency	0	\bigtriangleup	\bigtriangleup	0	6-110
8	Upper limit (Auxiliary drive 2)	-440.00	440.00	440.00 (Hz)	Mak	e sure that the	e u	pper limi	t is greater	0	\triangle	\triangle	0	6-110
9	Lower limit (Auxiliary drive 2)	-440.00	440.00	0.10 (Hz)	than	the lower limit	t			0	\triangle	\triangle	0	6-110
B29 –	Frequency setting (Auxi	liary drive	2)											
0	Local frequency setting (Auxiliary drive 2)	0.10	Fmax _AU2	10.00 (Hz)	This is the freque panel.			set from	the operation	0	\triangle	\bigtriangleup	0	6-110
1	Frequency setting for jogging (Auxiliary drive 2)	0.10	Fmax _AU2	5.00 (Hz)	This	is the frequen	ю	setting f	or jogging.	0		\bigtriangleup	0	6-110
2	Acceleration time - 1 (Auxiliary drive 2)	0.1	6000.0	10.0 (s)	The with	unit can be ch the time unit s	nar set	nged to \times ting (B10	0.1s, ×10s -5).	0	\triangle	\triangle	0	6-110
3	Deceleration time - 1 (Auxiliary drive 2)	0.1	6000.0	20.0 (s)	The 0 is	time to reach t set.	the	e max. fre	equency from	0	\triangle	\bigtriangleup	0	6-110

No.	Parameter	Min.	Max.	Default	Function	Application		Ref.		
200	(A		2)	(Unit)		V/f	VEC	PM	RWE	page
B29 –	Frequency setting (Auxi	liary drive	2)	·		-				
4	Acceleration time - 2 (Auxiliary drive 2)	0.1	6000.0	10.0 (s)	This is the acceleration/deceleration ramp time setting made valid when the sequence command ramp 2 switch is ON (CSEL=ON).	0		\bigtriangleup	0	6-110
5	Deceleration time - 2 (Auxiliary drive 2)	0.1	6000.0	20.0 (s)	Set a time between 0 and the max. frequency or max. speed. The unit can be changed to $\times 0.1$ s, $\times 10$ s with the time unit setting (B10-5).	0	\bigtriangleup		0	6-110
6	Acceleration time for jogging (Auxiliary drive 2)	0.1	6000.0	5.0 (s)	The acceleration/deceleration ramp time value when the JOG sequence (F JOG, R JOG) is valid is set. Set a time between 0 and the max.	0	\bigtriangleup	\bigtriangleup	0	6-110
7	Deceleration time for jogging (Auxiliary drive 2)	0.1	6000.0	5.0 (s)	The unit can be changed to $\times 0.1$ s, $\times 10$ s with the time unit setting (B10-5).	0	\bigtriangleup	\bigtriangleup	0	6-110
B2A –	Torque boost, DC Brake	, Dc Brak	e setting,	Overcurr	ent setting, Overload setting (Auxiliary drive	ve 2)			
0	Manual torque boost setting (Auxiliary drive 2)	0.00	20.00	Inverter rating (%)	Set the boost voltage at 0Hz.	0	\bigtriangleup	\bigtriangleup	0	6-110
1	Square reduction torque setting (Auxiliary drive 2)	0.00	25.00	0.00 (%)	Set the reduced voltage at Base frequency/2.	0	\bigtriangleup	\bigtriangleup	0	6-110
2	DC braking voltage (Auxiliary drive 2)	0.01	20.00	Inverter rating (%)	When setting manually, monitor the output voltage and change the setting in increments of 1% or less.	0	\bigtriangleup	\bigtriangleup	0	6-110
3	DC braking time (Auxiliary drive 2)	0.0	20.0	2.0 (sec)	Set the time to apply the DC brakes.	0	\bigtriangleup	\bigtriangleup	0	6-110
4	Over current limit (Auxiliary drive 2)	50.	300.	125. (%)	The default value is 155. when heavy-duty is set.	0	\triangle	\bigtriangleup	0	6-110
5	Regenerative current limit (Auxiliary drive 2)	5.	300.	10. (%)	Set to 10% when not using the DBR option.	0	\triangle	\triangle	0	6-110
6	Torque stabilization gain (Auxiliary drive 2)	0.00	4.00	1.00	Increase or decrease by 0.05 units if the motor vibrates.	0	\bigtriangleup	\bigtriangleup	0	6-110
7	Motor overload reference (Auxiliary drive 2)	50.0	105.0	100.0 (%)	When this data is changed, the B2A-8, 9 data is limited to this value. Take care when decreasing and then increasing this value.	0	\bigtriangleup	\bigtriangleup		6-110
8	0Hz overload (Auxiliary drive 2)	20.0	105.0	100.0 (%)	The max. value is the B2A-9 value.	0	\bigtriangleup	\bigtriangleup		6-110
9	0.7Base freq. overload (Auxiliary drive 2)	50.0	105.0	100.0 (%)	The min. value is the B2A-8 value.	0	\bigtriangleup	\bigtriangleup		6-110
B2B –	Braking on power failur	e setting	(Auxiliary	drive 2)						
0	Braking on power deceleration ramp time-1 (Auxiliary drive 2)	0.1	6000.0	10.0 (s)	Set the deceleration time from the maximum frequency value to 0Hz.	0	\bigtriangleup	\bigtriangleup	0	6-110
1	Braking on power deceleration ramp time-2 (Auxiliary drive 2)	0.0	6000.0	10.0 (s)	Set the deceleration time from the maximum frequency value to 0Hz. Deceleration is performed at deceleration ramp time-1 when 0.0.	0	\bigtriangleup	\bigtriangleup	0	6-110
2	Braking on power subtraction frequency (Auxiliary drive 2)	0.00	20.00	0.00 (Hz)	No subtraction made when 0.00Hz. 0Hz and brake engaged when the result of output frequency – subtraction frequency is 0 or less.	0	\bigtriangleup	\bigtriangleup	0	6-110
3	Braking on power subtraction start frequency (Auxiliary drive 2)	0.00	Fmax _AU2 or 999.99	0.00 (Hz)	If the output frequency is higher than this value, deceleration is performed from the result of output frequency – subtraction frequency. Subtraction is always performed when 999.99.	0			0	6-110
4	Braking on power switching frequency (Auxiliary drive 2)	0.00	Fmax _AU2	0.00 (Hz)	Switching is not performed when 0.00 to stoppage frequency or less.	0	\bigtriangleup	\bigtriangleup	0	6-110

No.	Parameter	Min.	Max.	Default	Function						pplie	catio	o n	Ref.
				(Unit)		Function					VEC	PM	RWE	page
B2C -	Output rating (Auxiliary	drive 3)		·										
0	Max./base frequency simple setting (Auxiliary drive 3)	0.	9.	1.	Sele com	ect the output fr ibination below	re /.	quency ra	ating from the	0	Δ	\bigtriangleup		6-110
			Value	Ftrq [ŀ	lz]	Fmax [Hz]		Value	Ftrq [Hz]	Fm	ax [Hz]	7	
l	'		0	Free set	ting c	on B2C-4, 5	Ī	5	50		100		1	
l	'		1	50		50		6	60		70]	
l			2	60		60		7	60		80			
l			3	50		60		8	60		90			
l			4	50		75	L	9	60		120			
 		l												
1	Rated output voltage (Auxiliary drive 3)	40.	480.	230. or 400. (V)	DC- at th If the chai rate set i	AVR functions le base frequer e rated input von nged, this value d input voltage higher than the	e i e i e ra	o attain th y. age settir s also ch alue. This ated inpu	e set voltage ng (B00-0) is anged to the s cannot be t voltage.	0	Δ			6-110
2	Max. frequency (Fmax_AU3) (Auxiliary drive 3)	Fbase _AU3 or 3.00	FBASE _AU3*7 or 440.00	50.00 (Hz)	Whe	en "B2C-0" is a	a V th	alue othe	er than 0, this	0		\bigtriangleup		6-110
3	Base frequency (Fbase_AU3) (Auxiliary drive 3)	Fmax _AU3/7 or 1.00	Fmax _AU3 or 440.00	50.00 (Hz)	simp	be setting.				0				6-110
4	Motor rated current (Auxiliary drive 3)	Inverter rating × 0.3	Inverter rating	Inverter rating (A)	This over ana	is the reference rcurrent limit, C log input and o	ce DL out	value for T, curren put.	⁻ the t % display,	0	\bigtriangleup	\bigtriangleup		6-110
5	Carrier frequency (Small size) (Auxiliary drive 3)	1.0	21.0	17.0	Pof	er to B00-7 for	de	ataile on t	he settings	0	\bigtriangleup	\bigtriangleup	0	6-110
5	Carrier frequency (Large size) (Auxiliary drive 3)	1.0	14.0	10.0	itele		u		ne seungs.	0	\bigtriangleup	\bigtriangleup	0	6-110
6	Start frequency (Auxiliary drive 3)	0.10	60.00	1.00 (Hz)	Ope whe	ration starts from the motor starts	on art	n this frec s.	luency value	0	\triangle	\bigtriangleup	0	6-110
7	Stop frequency (Auxiliary drive 3)	0.10	60.00	1.00 (Hz)	The freq valu	DC brakes are uency value is ie.	e a le	applied wi ss than ti	hen the his frequency	0	\bigtriangleup	\triangle	0	6-110
8	Upper limit (Auxiliary drive 3)	-440.00	440.00	440.00 (Hz)	Mak	e sure that the	e u	pper limit	t is greater	0	\triangle	\bigtriangleup	0	6-110
9	Lower limit (Auxiliary drive 3)	-440.00	440.00	0.10 (Hz)	than	i the lower limit	t			0	\triangle	\bigtriangleup	0	6-110
B2D –	Frequency setting (Auxi	liary drive	e 3)											
0	Local frequency setting (Auxiliary drive 3)	0.10	Fmax _AU3	10.00 (Hz)	This pan	is the frequent	ю	set from	the operation	0	\triangle	\triangle	0	6-110
1	Frequency setting for jogging (Auxiliary drive 3)	0.10	Fmax _AU3	5.00 (Hz)	This	is the frequen	ю	setting f	or jogging.	0		\triangle	0	6-110
2	Acceleration time - 1 (Auxiliary drive 3)	0.1	6000.0	10.0 (s)	The with	unit can be chaine the time unit s	nar set	nged to × ting (B10	0.1s, ×10s ⊦5).	0	\triangle	\bigtriangleup	0	6-110
3	Deceleration time - 1 (Auxiliary drive 3)	0.1	6000.0	20.0 (s)	Set freq	a time betweer uency or max.	n (sp) and the beed.	max.	0	\triangle	\bigtriangleup	0	6-110

No.	Parameter	Min.	Max.	Default	Function			ation		Ref.
202			2)	(Unit)		V/f	VEC	PM	RWE	page
B2D –	Frequency setting (Auxi	liary drive	e 3)	i		i				
4	Acceleration time - 2 (Auxiliary drive 3)	0.1	6000.0	10.0 (s)	This is the acceleration/deceleration ramp time setting made valid when the sequence command ramp 2 switch is ON (CSEI = ON)	0	\bigtriangleup	\bigtriangleup	0	6-110
5	Deceleration time - 2 (Auxiliary drive 0)	0.1	6000.0	20.0 (s)	Set a time between 0 and the max. frequency or max. speed. The unit can be changed to $\times 0.1$ s, $\times 10$ s with the time unit setting (B10-5).	0	\bigtriangleup	\bigtriangleup	0	6-110
6	Acceleration time for jogging (Auxiliary drive 3)	0.1	6000.0	5.0 (s)	The acceleration/deceleration ramp time value when the JOG sequence (F JOG, R JOG) is valid is set. Set a time between 0 and the max	0	\bigtriangleup	\bigtriangleup	0	6-110
7	Deceleration time for jogging (Auxiliary drive 3)	0.1	6000.0	5.0 (s)	frequency. The unit can be changed to $\times 0.1$ s, $\times 10$ s with the time unit setting (B10-5).	0	\bigtriangleup	\bigtriangleup	0	6-110
B2E –	Torque boost, DC Brake	, DC Brak	e setting	, Overcur	rent setting, Overload setting (Auxiliary dri	ve 3)			
0	Manual torque boost setting (Auxiliary drive 3)	0.00	20.00	Inverter rating (%)	Set the boost voltage at 0Hz.	0	\bigtriangleup	\bigtriangleup	0	6-110
1	Square reduction torque setting (Auxiliary drive 3)	0.00	25.00	0.00 (%)	Set the reduced voltage at Base frequency/2.	0	\bigtriangleup	\bigtriangleup	0	6-110
2	DC braking voltage (Auxiliary drive 3)	0.01	20.00	Inverter rating (%)	This is automatically adjusted by the automatic tuning.	0	\bigtriangleup	\bigtriangleup	0	6-110
3	DC braking time (Auxiliary drive 3)	0.0	20.0	2.0 (s)	Set the time to apply the DC brakes.	0	\bigtriangleup	\bigtriangleup	0	6-110
4	Over current limit (Auxiliary drive 3)	50.	300.	125. (%)	The default value is 155. when heavy-duty is set.	0	\bigtriangleup	\bigtriangleup	0	6-110
5	Regenerative current limit (Auxiliary drive 3)	5.	300.	10. (%)	Set to 10% when not using the DBR option.	0	\bigtriangleup	\bigtriangleup	0	6-110
6	Torque stabilization gain (Auxiliary drive 3)	0.00	4.00	1.00	Increase or decrease by 0.05 units if the motor vibrates.	0	\bigtriangleup	\bigtriangleup	0	6-110
7	Motor overload reference (Auxiliary drive 3)	50.0	105.0	100.0 (%)	When this data is changed, the B2E-8, 9 data is limited to this value. Take care when decreasing and then increasing this value.	0	\supset	\bigtriangleup		6-110
8	0Hz overload (Auxiliary drive 3)	20.0	105.0	100.0 (%)	The max. value is the B2E-9 value.	0	\bigtriangleup	\bigtriangleup		6-110
9	0.7Base freq. overload (Auxiliary drive 3)	50.0	105.0	100.0 (%)	The min. value is the B2E-8 value.	0	\bigtriangleup	\bigtriangleup		6-110
B2F –	Braking on power failure	e setting (Auxiliary	drive 3)						
0	Braking on power deceleration ramp time-1 (Auxiliary drive 3)	0.1	6000.0	10.0 (s)	Set the deceleration time from the maximum frequency value to 0Hz.	0	\bigtriangleup	\bigtriangleup	0	6-110
1	Braking on power deceleration ramp time-2 (Auxiliary drive 3)	0.0	6000.0	10.0 (s)	Set the deceleration time from the maximum frequency value to 0Hz. Deceleration is performed at deceleration ramp time-1 when 0.0.	0			0	6-110
2	Braking on power subtraction frequency (Auxiliary drive 3)	0.00	20.00	0.00 (Hz)	No subtraction made when 0.00Hz. 0Hz and brake engaged when the result of output frequency – subtraction frequency is 0 or less.	0	\bigtriangleup	\bigtriangleup	0	6-110
3	Braking on power subtraction start frequency (Auxiliary drive 3)	0.00	Fmax _AU3 or 999.99	0.00 (Hz)	If the output frequency is higher than this value, deceleration is performed from the result of output frequency – subtraction frequency. Subtraction is always performed when 999.99.	0			0	6-110
4	Braking on power switching frequency (Auxiliary drive 3)	0.00	Fmax _AU3	0.00 (Hz)	Switching is not performed when 0.00 to stoppage frequency or less.	0	\bigtriangleup	\bigtriangleup	0	6-110

No.	Parameter	Min.	Max.	Default	Function	A	oplic	catic)n	Ref.
				(Unit)		V/f	VEC	PM	RWE	page
B30 –	Speed control extended	function	<u> </u>	<u> </u>						
0	Load torque observer gain (Speed control extended function)	0.0	200.0	0.0	Set the observer gain for the load torque observer. To increase the responsiveness of the external disturbance response characteristics, set a large gain. Note that if the gain is set too high, the output torque could hunt. When set to zero, the load torque observer will not function.		0	0	0	6-110
1	Model machine time constant (Speed control extended function)	10.	20000.	500. (ms)	Set the model machine time constant used by the load torque observer.		0	0	0	6-110
2	ASR proportional item change rate limit (Speed control extended function)	1.0	400.0	50.0 (%)	If the speed setting value or motor speed change suddenly, this will prevent the ASR's P item from suddenly changing.		0	0	0	6-110
3	Speed setting LPF time constant (Speed control extended function)	0.	1000.	0. (ms)	Overshooting can be suppressed by setting this to the filter time constant equivalent to the speed response.		0	0	0	6-111
4	Speed detection LPF time constant (Speed control extended function)	0.	1000.	2. (ms)	The speed detection noise is cut.	0 *1)	0	0	0	6-111
5	Speed detection LPF time constant for ASR (Speed control extended function)	0.	1000.	5. (ms)	Set the low path filter time constant used for the speed detection value input into the speed regulator.		0	0	0	6-111
6	Speed detection LPF time constant for compensation (Speed control extended function)	0.	1000.	20. (ms)	Set the low path filter time constant used for the speed detection value for constant output range compensation or iron loss compensation, etc.		0	0	0	6-111
7	Torque current command setting LPF time constant (Speed control extended function)	0.	1000.	0. (ms)	Set the low path filter time constant used for the torque current command.		0	0	0	6-111
8	LPF time constant for drooping (Speed control extended function)	0.	1000.	100. (ms)	Set the low path filter time constant used for drooping value input into the speed regulator.		0	0	0	6-111

*1) This parameter is used by simple ASR control.

No.	Parameter	Min.	Max.	Default (Unit)	Function	Application		Ref. page	
B31 –	Sensor-less control fund	ction		. ,	L				1.2
0	Flux observer gain (Sensor-less control function)	0.50	0.501.50This is the feedback gain for the flux observer.1.001.00If hunting occurs at the estimated speed in the high-speed operation range, adjust within the range of 1.2 to 0.9.						6-111
1	Speed estimated proportional gain (Sensor-less control function)	0.00	100.00	10.00 (%)	This is the proportional gain for the adaptive speed estimation mechanism. To increase the speed estimation response, set a large value. Note that if the value is too high, the speed estimation value will hunt.	c)	0	6-111
2	Speed estimated integral gain (Sensor-less control function)	0.00	100.0	0.10 (%)	This is the integral gain for the adaptive speed estimation mechanism. To increase the speed estimation response, set a large value. Note that if the value is too high, the speed estimation value will hunt.	c)	0	6-111
3	Regenerative compen- sation torque limiter 1 (Sensor-less control function)	0.1	100.0	10.0 (%)		C)	0	6-112
4	4 Regenerative compen- sation torque limiter 2 (Sensor-less control function) 0.1			20.0 (%)	The regenerative torque limiter can be changed in the low-speed area. The shaded section shows the operation range. If operation is unstable within the	C)	0	6-112
5	Regenerative compen- sation low-speed area setting 1 (Sensor-less control function)	0.1	100.0	10.0 (%)	shaded line range, set the parameter so that the unstable point is not within the shaded line area.	C)	0	6-112
6	Regenerative compen- sation low-speed area setting 2 (Sensor-less control function)	0.1	100.0	20.0 (%)		C)	0	6-112
Output torque B31-5 B31-6 B31-3 B31-4 B31-4 Regeneration direction Regeneration direction Regenerative torque limiter lever									

No.	Parameter	Min.	Max.	Default	Function			catic)n	Ref.
				(Unit)	Function		VEC	PM	RWE	page
B32 –	Vector control compensation	ation sele	ction • Ex	tended fu	unction control		,	, 	,,	
0	High-speed flux control gain	1.	50.	1.	 = 1: Disable = 2 to 50: Enable This is the control gain used for high-speed control of the secondary flux when starting operation. Use this to control the secondary flux at a high speed at the start of operation or during operation in a constant output range. High speed control is possible by increasing the gain, but if increased too high, the magnetizing current may hunt. 		0			6-112
1	Temperature compensation selection	1.	2.	1.	= 1: Disable = 2: Enable If torque accuracy is required when vector control with sensor is selected (C30-0: f0 = 3), or if speed accuracy is required when sensor-less vector control is selected (C30-0: f0 = 2), the parameter fluctuation of the primary resistance value and secondary resistance value caused by a rise in temperature can be compensated.		0			6-112
2	Voltage saturation compensation selection	1.	2.	1.	= 1: Disable = 2: Enable If the output voltage in control is larger than the voltage that can be output by the inverter, select this control to limit the exciting current to prevent the current or torque from hunting. Select this when raising the output voltage to near the input voltage, or when the input voltage changes. Note that if voltage saturation occurs, some torque ripple will occur. In this case, lower the B01-9 no-load voltage setting to avoid voltage saturation.		0		0	6-112
3	Iron loss compensation selection	1.	2.	1.	= 1: Disable = 2: Enable This compensates the torque error caused by iron loss. The iron loss resistance value (B02-8, 9) must be set.		0		0	6-113
4	ACR voltage model FF selection	1.	2.	2.	 = 1: Disable = 2: Enable The voltage fluctuation caused by the leakage inductance is feed forward controlled. The current regulator (ACR) response speed will be increased. Select this if the current hunts in the high-speed operation range during sensor-less control. 		0	0		6-113
5	ACR model voltage FF compensation	0.0	200.0	0.0 (%)	dq axis current non-interference voltage Set this when the ASR proportional gain is high. Set the value between approx. 50.0 and 80.0%.			0	0	6-113
6	ACR proportional section dead time compensating factor	0.0	200.0	0.0 (%)	If a 3ms cycle current vibration is generated at 120Hz or more, set a value between approx. 50.0 and 80.0%.			0	0	6-113

No.	Parameter	Min.	Max.	Default	Function Application				on	Ref.
				(Unit)		V/f V	EC	PM	RWE	page
B33 –	M fluctuation compensa	tion table	reference	e speed		<u>г</u>				
0	Table reference speed 0 (M fluctuation compensation)	100.	9999.	200 (min⁻¹)			0			6-113
1	Table reference speed 1 (M fluctuation compensation)	100.	9999.	400 (min⁻¹)			0			6-113
2	Table reference speed 2 (M fluctuation compensation)	100.	9999.	600 (min⁻¹)	This is the reference speed for changing		0			6-113
3	Table reference speed 3 (M fluctuation compensation)	100.	9999.	800 (min⁻¹)	the compensation amount according to the operation speed.		0			6-113
4	Table reference speed 4 (M fluctuation compensation)	100.	9999.	1000 (min ⁻¹)	If all of B34 is set to the default value (100.0), these will be automatically set when adjusted with automatic tuning mode		0			6-113
5	Table reference speed 5 (M fluctuation compensation)	100.	9999.	1200 (min ⁻¹)	4 (B19-0=4).		0			6-113
6	Table reference speed 6 (M fluctuation compensation)	100.	9999.	1400 (min⁻¹)			0			6-113
7	Table reference speed 7 (M fluctuation compensation)	100.	9999.	1600 (min⁻¹)			0			6-113
B34 –	M fluctuation compensation	tion								
0	M fluctuation compen- sation coefficient 0	50.0	150.0	100.0 (%)			0		0	6-113
1	M fluctuation compen- sation coefficient 1	50.0	150.0	100.0 (%)			0		0	6-113
2	M fluctuation compen- sation coefficient 2	50.0	150.0	100.0 (%)	This compensates the exciting inductance fluctuation according to the B33 table		0		0	6-113
3	M fluctuation compen- sation coefficient 3	50.0	150.0	100.0 (%)	Set the compensation table so that the output voltage is constant during no-load		0		0	6-113
4	M fluctuation compen- sation coefficient 4	50.0	150.0	100.0 (%)	operation through the entire operation range.		0		0	6-113
5	M fluctuation compen- sation coefficient 5	50.0	150.0	100.0 (%)	tuning mode 4 (B19-0 = 4).		0		0	6-113
6	M fluctuation compen- sation coefficient 6	50.0	150.0	100.0 (%)			0		0	6-113
7	M fluctuation compen- sation coefficient 7	50.0	150.0	100.0 (%)			0		0	6-113
B35 –	Voltage saturation preve	ention cor	trol cons	tant		<u> </u>				
0	Voltage saturation prevention current voltage allowance	0.0	100.0	10.0 (%/V1)				0	0	6-114
1	Largest voltage setting	50.0	200.0	100.0 (%/V1)				0	0	6-114
2	Weak field current limit value	10.0	200.0	50.0 (%/l1)	Refer to section 6-9 for details.			0	0	6-114
3	Voltage saturation prevention current proportional gain	0.01	99.99	0.10				0	0	6-114
4	Voltage saturation prevention control integral time constant	2.	1000.	10. (ms)				0	0	6-114

No.	Parameter	Min.	Max.	Default	Function	Application		on	Ref.
				(Unit)		V/f VI	C PM	RWE	page
B36 –	Field weakening electric	current t	able (PM	motor co	ntrol)	-	-	<u> </u>	
0	Field weakening electric current table 0 (at torque command 0%)	-100.0	100.0	0.0 (%/l1)			0	0	6-114
1	Field weakening electric current table 1 (at torque command 25%)	-100.0	100.0	0.0 (%/l1)			0	0	6-114
2	Field weakening electric current table 2 (at torque command 50%)	-100.0	100.0	0.0 (%/l1)			0	0	6-114
3	Field weakening electric current table 3 (at torque command 75%)	-100.0	100.0	0.0 (%/l1)	Refer to section 6-9 for details.		0	0	6-114
4	Field weakening electric current table 4 (at torque command 100%)	-100.0	100.0	0.0 (%/l1)			0	0	6-114
5	Field weakening electric current table 5 (at torque command 125%)	-100.0	100.0	0.0 (%/l1)			0	0	6-114
6	Field weakening electric current table 6 (at torque command 150%)	-100.0	100.0	0.0 (%/l1)			0	0	6-114
B38 –	Torque to Iq conversion	adjustme	nt coeffic	ient table	(PM)				
0	Torque to lq conversion adjustment coefficient (at ld command -100%)	0.	200.	100. (%/l1)			0	0	6-114
1	Torque to Iq conversion adjustment coefficient (at Id command -75%)	0.	200.	100. (%/l1)			0	0	6-114
2	Torque to Iq conversion adjustment coefficient (at Id command -50%)	0.	200.	100. (%/l1)			0	0	6-114
3	Torque to lq conversion adjustment coefficient (at ld command -25%)	0.	200.	100. (%/l1)).) Refer to section 6-9 for details.))		0	0	6-114
4	Torque to Iq conversion adjustment coefficient (at Id command 0%)	0.	200.	100. (%/l1)			0	0	6-114
5	Torque to Iq conversion adjustment coefficient (at Id command 25%)	0.	200.	100. (%/l1)			0	0	6-114
6	Torque to Iq conversion adjustment coefficient (at Id command 50%)	0.	200.	100. (%/l1)			0	0	6-114

No.	Parameter	Min.	Max.	Default (Unit)	Function	Application		Ref.		
B39 -	Pole position presumpti	on (PM)		(onit)		V/T	VEC	PIN	RWE	page
0	Pole presumption selection (PM)	11111.	2223.	1111.	 11111. f0=1: Magnetic pole position estimation OFF =2: Estimation with secondary phase =3: Estimation with primary phase (only special SPM) f1=1: Run at Z pulse reference =2: Run at estimation phase reference f2=1: Magnetic pole position estimation using sequence prohibited =2: Magnetic pole position estimation using sequence enabled f3=1: Sequence output during magnetic pole position estimation: RUN output invalid =2: Sequence output during magnetic pole position estimation: RUN output valid 			0	0	6-114
1	PM tuning voltage	10.	200.	50. (%)	Set the voltage amplitude for measurement. The motor's rated voltage is 100%.			0	0	6-114
_2	PM tuning time	2.	32.	4.	Set the voltage width for measurement.	<u> </u>		0	0	6-114
3	Voltage error correction current (PM)	0.	50.	10. (%)	Set the current amplitude for correcting the voltage error. The motor's rated voltage is 100%.			0	0	6-114
4	ACR response for magnetic pole position estimation	100.	6000.	1500. (rad/s)	Set the ACR gain and time constant for magnetic pole position estimation.			0	0	
5	ACR time constant for magnetic pole position estimation	0.1	300.0	10.0 (%)	This setting is applied even during PM motor circuit constant automatic tuning.			0	0	
B40 –	Software option function	<u>1</u>								
0	Function selection - 1 (Software option function)	1.	8.	1.	 = 1: Following functions are not used. = 2: Program ramp function use = 3: Pattern run use = 4: Traverse run use = 5: PID use = 6: PID, multi-pump control use (No main pump rotation) = 7: PID, multi-pump control use (Main pump rotation performed, 1-contact method) = 8: PID, multi-pump control use (Main pump rotation performed, 2-contact method) 	0	0	0		6-114
D 41 -	Acceleration ramp time			10.0	1					a 445
0	- 0	0.1	6000.0	(s)	-	0	0	0		6-115
1	Acceleration ramp time	0.1	6000.0	10.0 (s) 10.0		0	0	0	0	6-115
2	 – 2 Acceleration ramp time 	0.1	6000.0	(s) 10.0		0	0	0	0	6-115
4	- 3 Acceleration ramp time	0.1	6000.0	(s) 10.0	Select as follows with S0, S1, S2, S3 and SE.	0	0	0	0	6-115
5	Acceleration ramp time	0.1	6000.0	(s) 10.0		0	0	0	0	6-115
6	Acceleration ramp time	0.1	6000.0	(s) 10.0 (s)		0	0	0	0	6-115
7	Acceleration ramp time	0.1	6000.0	10.0 (s)	1	0	0	0	0	6-115

Block-B parameters (S/W option constants) list
No. Parameter Min. M				Max.	D	efault	Function				Application			Ref.					
						(Unit)								V/f	VEC	PM	RWE	page
B42 –	Program ramp – dec	elera	ation																
0	Deceleration ramp tim	ne	0	.1	6000.0)	20.0 (s)								0	0	0	0	6-115
1	Deceleration ramp tim	ne	0	.1	6000.0)	20.0 (s)								0	0	0	0	6-115
2	Deceleration ramp tim	ne	0	.1	6000.0)	20.0 (s)								0	0	0	0	6-115
3	Deceleration ramp tim	ne	0	.1	6000.0)	20.0 (s)	Select as	follow	vs witl	h S0	S1. S	2. S3	and	0	0	0	0	6-115
4	Deceleration ramp tim	ne	0	.1	6000.0)	20.0 (s)	SE.	E.							0	0	0	6-115
5	$\begin{array}{c c} 5 & \text{Deceleration ramp time} \\ -5 & -5 \end{array} \qquad 0.1 6000.0 \hline \end{array}$					20.0 (s)								0	0	0	0	6-115	
6	6Deceleration ramp time - 60.16000.0						20.0 (s)								0	0	0	0	6-115
7	$\begin{array}{c c} & & & & & & & & & & & & & & & & & & &$													0	0	0	0	6-115	
	(1) For binary mode (B11-8=1)								(2) Fo	r dire	ect se	lect n	node	(B11-8:	=2)				
	[Sequence		nce co	e command Selec		Select	ed	d Sequence command				Selecte	d					
	-	SE	S3	S2	S1	S0	ramp ti	me	SE	S3	S2	S1	S0	Previou	ne				
				OFF	OFF	OFF	B41-0 B42-0	5	OFF	OFF	OFF	OFF	OFF	values					
				OFF	OFF	ON	B41- ⁻ B42- ⁻	1	OFF	OFF	OFF	OFF	ON	В41-0 В42-0					
	The binery mode or			OFF	ON	OFF	B41-2	2	OFF	OFF	OFF	ON	OFF	B41-1 B42-1					
	direct input mode is			OFF	ON	ON	B41-3 B42-3	3 3	OFF	OFF	ON	OFF	OFF	B41-2 B42-2					
	selected with B11-8.	*	*	ON	OFF	OFF	B41-4	4	OFF	ON	OFF	OFF	OFF	B41-3 B42-3					
				ON	OFF	ON	B41-	5	ON	OFF	OFF	OFF	OFF	Previou values	IS S				
				ON	ON	OFF	B42-	5	ON	OFF	OFF	OFF	ON	B41-4 B42-4					
	ON ON ON					B42-0	7	ON	OFF	OFF	ON	OFF	B41-5 B42-5						
	l	* : SI	E and S3	B are n	lot used.		D42-	'	ON	OFF	ON	OFF	OFF	B41-6 B42-6					
									ON	ON	OFF	OFF	OFF	B41-7 B42-7					
									When and S3 becaus	S0 to S s, the pr se the p	3 are al evious ower ha	ll OFF, values as beer	or wher will be I turned	n two or m neld. If the ON, etc.,	ore a ere ar "0" v	re set e no p /ill be	t betw previo set.	een S us va	60 lues

No.	Parameter	Min.	Max.	Default	Function	A	oplic	atic	on	Ref.
D42	PID control			(Unit)		V/f	VEC	PM	RWE	page
D43 -	Proportional gain	0.01	10.00	1.00		0	\circ	0	0	6-116
		0.01	10.00	10.0	The control constant of the PID control is	0	0	0	0	0-110
1	Integral time constant	0.0	30.0	(s)	set.	0	0	0	0	6-116
2	Differential time constant	0.000	1.000	0.000 (s)		0	0	0	0	6-116
3	Upper limit	5.0	100.0	100.0 (%)	The maximum frequency and maximum	0	0	0	0	6-116
4	Lower limit	0.0	50.0	0.0 (%)	speed are 100%	0	0	0	0	6-116
5	Detected error determination start level	0.0	100.0	0.0 (%)	Error determination is commenced if the command value is this value or higher.	0	0	0	0	6-116
6	Detected error level	0.0	100.0	0.0 (%)	An error occurs if the detected value is this value or lower.	0	0	0	0	6-116
7	Detected error determination time	0.0	25.0	0.5 (s)	A breakdown (I0-B.) occurs if the error continues this length of time or longer.	0	0	0		6-116
8	Polarity reverse flag	1.	2.	1.	The command and detection polarity is reversed. =1: Normal =2: Reversed	0	0	0		6-116
9	PID operation method	11.	22.	11.	 f0: PID operation conditions =1: RUN and PIDEN AND conditions =2: PIDEN f1: RUN conditions =1: RUN operation (normal operation) =2: Stop occurs when the PID output reaches the lower limiter. 	0	0	0		6-116
А	Hysteresis when restarting operation	1.0	10.0	3.0 (%)	Set the PID output hysteresis width when restarting operation when B43-9=22.	0	0	0		6-116
B44 –	Multi-pump control									
0	No. of controlled pumps (Multi-pump control)	1.	8.	3.	Set the No. of pumps to be ON/OFF controlled.	0				6-118
1	Pump start holding time (Multi-pump control)	0.1	3600.0	60.0 (s)	If the time that the PID output is applied on the upper limiter is longer than this setting, the pump's ON control will be carried out.	0				6-118
2	Pump stop holding time (Multi-pump control)	0.1	3600.0	60.0 (s)	If the time that the PID output is applied on the lower limiter is longer than this setting, the pump's OFF control will be carried out.	0				6-118
3	Maximum continuous operation time (Multi-pump control)	0.0	168.0	8.0 (h)	If the pump's ON/OFF control is not carried out for longer than the time set here, the pumps will change from that operating to the longest to that operating the shortest so that the operation time of each pump is equal. Changing is prohibited when =0.0 is set.	0				6-118
4	Changeover time (Multi-pump control)	1.0	120.0	3.0 (s)	Set the time for changing from the pump that has been operating the longest to the pump that has been operating the shortest.	0				6-118
5	INV/main switching dead time setting (Multi-pump control)	0.2	10.0	1.0 (s)	Set the dead time for switching the INV and main power supply during main pump rotation.	0				6-118
6	Inverter control method at lower limit (Multi-pump control)	1.	2.	1.	Select whether to stop the INV or continue operation when the other auxiliary motor is stopped and the lower limit state is continued. =1: Stop =2: Continue running	0				6-118

No.	Parameter	Min.	Max.	Default	Function	Α	pplic	catio	on	Ref.
D 45	-			(Unit)		V/f	VEC	РМ	RWE	page
B45 –	Traverse run		i	20.00	Cat the contar frequency for traverse		1			
0	frequency (speed) (FH)	5.00	100.00	20.00	operation.	0	0	0	0	6-124
1	Traverse run: Amplitude (A)	0.1	20.0	10.0 (%)	Set the upper/lower peak frequency from the traverse center frequency.	0	0	0	0	6-124
2	Traverse run: Drop (D)	0.0	50.0	0.0 (%)	When a value other than 0.0 is set, the frequency is dropped by the set amount after reaching the peak.	0	0	0	0	6-124
3	Traverse run: Acceleration time (B)	0.5	60.0	10.0 (s)	Set the time from the lower peak to the upper peak.	0	0	0	0	6-124
4	Traverse run: Deceleration time (C)	0.5	60.0	10.0 (s)	Set the time from the upper peak to the lower peak.	0	0	0	0	6-124
5	Traverse run: Deviated traverse (X)	0.0	20.0	10.0 (%)	When sequence input: S0 is ON, the center frequency will increase by the set amount.	0	0	0	0	6-124
6	Traverse run: Deviated traverse (Y)	0.0	20.0	10.0 (%)	When sequence input: S1 is ON, the center frequency will decrease by the set amount.	0	0	0	0	6-124
B46 –	External brake control									
0	External brake selection (External brake selection)	111.	222.	111.	1 1 1. f0 = External brake function selection =1: OFF =2: ON f1= IDET interlock =1: OFF =2: ON f2 = Acceleration wait time =1: Program frequency output =2: DC brake output	0	0	0		6-126
1	Brake release wait time (LB) (External brake selection)	0.00	2.50	0.00 (s)	Set the wait time from the RUN command to the brake release command.	0	0	0	0	6-126
2	Acceleration start wait time (BL) (External brake selection)	0.00	2.50	0.00 (s)	Set the wait time from the point the brakes are released until the motor accelerates. If there is a brake answer (MBRK_ans), set from answer, and if none, set time from command.	0	0	0	0	6-126
3	Brake engage wait time (DB) (External brake selection)	0.00	2.50	0.00 (s)	Set the wait time (cumulative) from the point the frequency (speed) command value reaches the zero speed setting or below until the brake is engaged.	0	0	0	0	6-126
4	RUN error judgment time when engaging brake (External brake selection)	0.0	25.0	0.0 (s)	A fault stoppage occurs if ON for the RUN setting time or longer when engaging the brake. Error judgment is turned OFF at 0.00.	0	0	0	0	6-126
5	Brake answer error judgment time (External brake selection)	0.0	25.0	0.0 (s)	The brake command and brake answer do not match for the set time or longer, and a fault stoppage occurs. Error judgment is turned OFF at 0.00.	0	0	0	0	6-126
B47 –	Simple ASR control									
0	Simple ASR control selection	11.	22.	21.	2 1. f0: Simple ASR selection =1: OFF =2: ON f1: Integral mask processing when accelerating/decelerating =1: OFF =2: ON	0				6-128
1	Simple ASR proportional gain	0.00	10.00	0.10	Set with response for machine time constant of 1s.	0			0	6-128
2	Simple ASR integral time constant	0.00	10.00	1.00 (s)	Set the simple ASR integral time constant.	0			0	6-128
3	Proportional variation rate limit	0.01	50.00	1.00 (%)	Set the proportional variation rate control value.	0			0	6-128
4	Compensation torque limiter	0.1	300.0	100.0 (%)	Set the slippage compensation limit value.	0			0	6-128
5	Simple ASR pole count	2.	32.	4.	Set the motor pole count.	0				6-128
6	Simple ASR pulse count	30.	10000.	1000.	Set the encoder pulse count.	0				6-128

No		Parameter	Min.	Max.	Default	Function	A	oplic	catio	n	Ref.
					(Unit)		V/f	VEC	PM	RWE	page
B50	- 1	Pattern run step-0			i		i				
	0	Mode (Pattern run step-0)	0.	2.	0.	= 0: Stop = 1: Forward run = 2: Reverse run	0	0	0	0	6-129
	1	Frequency (speed) (Pattern run step-0)	0.00	100.00	10.00 (%)	Set the step 0 frequency. 100% is the max. frequency (speed).	0	0	0	0	6-129
:	2	Time (Pattern run step-0)	0.1	6000.0	1.0 (s)	Set the time for operating at this step.	0	0	0	0	6-129
B51	_	Pattern run step-1									
	0	Mode (Pattern run step-1)	0.	2.	0.	= 0: Stop = 1: Forward run = 2: Reverse run	0	0	0	0	6-129
	1	Frequency (speed) (Pattern run step-1)	0.00	100.00	10.00 (%)	Set the step 1 frequency. 100% is the max. frequency (speed).	0	0	0	0	6-129
:	2	Time (Pattern run step-1)	0.1	6000.0	1.0 (s)	Set the time for operating at this step.	0	0	0	0	6-129
B52	-	Pattern run step-2									
(0	Mode (Pattern run step-2)	0.	3.	0.	= 0: Stop = 1: Forward run = 2: Reverse run =3: Return	0	0	0	0	6-129
	1	Frequency (speed) (Pattern run step-2)	0.00	100.00	10.00 (%)	Set the step 2 frequency. 100% is the max. frequency (speed).	0	0	0	0	6-129
:	2	Time (Pattern run step-2)	0.1	6000.0	1.0 (s)	Set the time for operating at this step.	0	0	0	0	6-129
:	3	Return destination step (Pattern run step-2)	0.	1.	0.	If a value other than 0 is set, the operation will start from the designated step No. once this step is finished.	0	0	0	0	6-129
B53	_	Pattern run step-3			•						
(0	Mode (Pattern run step-3)	0.	3.	0.	= 0: Stop = 1: Forward run = 2: Reverse run =3: Return	0	0	0	0	6-129
	1	Frequency (speed) (Pattern run step-3)	0.00	100.00	10.00 (%)	Set the step 3 frequency. 100% is the max. frequency (speed).	0	0	0	0	6-129
:	2	Time (Pattern run step-3)	0.1	6000.0	1.0 (s)	Set the time for operating at this step.	0	0	0	0	6-129
;	3	Return destination step (Pattern run step-3)	0.	2.	0.	If a value other than 0 is set, the operation will start from the designated step No. once this step is finished.	0	0	0	0	6-129
B54	_	Pattern run step-4									
(0	Mode (Pattern run step-4)	0.	3.	0.	= 0: Stop = 1: Forward run = 2: Reverse run =3: Return	0	0	0	0	6-129
	1	Frequency (speed) (Pattern run step-4)	0.00	100.00	10.00 (%)	Set the step 4 frequency. 100% is the max. frequency (speed).	0	0	0	0	6-129
:	2	Time (Pattern run step-4)	0.1	6000.0	1.0 (s)	Set the time for operating at this step.	0	0	0	0	6-129
:	3	Return destination step (Pattern run step-4)	0.	3.	0.	If a value other than 0 is set, the operation will start from the designated step No. once this step is finished.	0	0	0	0	6-129
B55	-	Pattern run step-5			· · · · · · · · · · · · · · · · · · ·						
	0	Mode (Pattern run step-5)	0.	3.	0.	= 0: Stop = 1: Forward run = 2: Reverse run =3: Return	0	0	0	0	6-129
	1	Frequency (speed) (Pattern run step-5)	0.00	100.00	10.00 (%)	Set the step 5 frequency. 100% is the max. frequency (speed).	0	0	0	0	6-129
:	2	Time (Pattern run step-5)	0.1	6000.0	1.0 (s)	Set the time for operating at this step.	0	0	0	0	6-129
;	3	Return destination step (Pattern run step-5)	0.	4.	0.	If a value other than 0 is set, the operation will start from the designated step No. once this step is finished.	0	0	0	0	6-129

No.	Parameter	Min.	Max.	Default	Function	A	oplic	catio	on	Ref.
-				(Unit)		V/f	VEC	PM	RWE	page
B56 -	Pattern run step-6	i	i	i		i —				
0	Mode (Pattern run step-6)	0.	3.	0.	= 0: Stop = 1: Forward run = 2: Reverse run =3: Return	0	0	0	0	6-129
1	Frequency (speed) (Pattern run step-6)	0.00	100.00	10.00 (%)	Set the step 6 frequency. 100% is the max. frequency (speed).	0	0	0	0	6-129
2	Time (Pattern run step-6)	0.1	6000.0	1.0 (s)	Set the time for operating at this step.	0	0	0	0	6-129
3	Return destination step (Pattern run step-6)	0.	5.	0.	If a value other than 0 is set, the operation will start from the designated step No. once this step is finished.	0	0	0	0	6-129
B57 -	Pattern run step-7									
0	Mode (Pattern run step-7)	0.	3.	0.	= 0: Stop = 1: Forward run = 2: Reverse run =3: Return	0	0	0	0	6-129
1	Frequency (speed) (Pattern run step-7)	0.00	100.00	10.00 (%)	Set the step 7 frequency. 100% is the max. frequency (speed).	0	0	0	0	6-129
2	Time (Pattern run step-7)	0.1	6000.0	1.0 (s)	Set the time for operating at this step.	0	0	0	0	6-129
3	Return destination step (Pattern run step-7)	0.	6.	0.	If a value other than 0 is set, the operation will start from the designated step No. once this step is finished.	0	0	0	0	6-129
B58 -	Pattern run step-8									
0	Mode (Pattern run step-8)	0.	3.	0.	= 0: Stop = 1: Forward run = 2: Reverse run =3: Return	0	0	0	0	6-129
1	Frequency (speed) (Pattern run step-8)	0.00	100.00	10.00 (%)	Set the step 8 frequency. 100% is the max. frequency (speed).	0	0	0	0	6-129
2	Time (Pattern run step-8)	0.1	6000.0	1.0 (s)	Set the time for operating at this step.	0	0	0	0	6-129
3	Return destination step (Pattern run step-8)	0.	7.	0.	If a value other than 0 is set, the operation will start from the designated step No. once this step is finished.	0	0	0	0	6-129
B59 -	Pattern run step-9									
0	Mode (Pattern run step-9)	0.	3.	0.	= 0: Stop = 1: Forward run = 2: Reverse run =3: Return	0	0	0	0	6-129
1	Frequency (speed) (Pattern run step-9)	0.00	100.00	10.00 (%)	Set the step 9 frequency. 100% is the max. frequency (speed).	0	0	0	0	6-129
2	Time (Pattern run step-9)	0.1	6000.0	1.0 (s)	Set the time for operating at this step.	0	0	0	0	6-129
3	Return destination step (Pattern run step-9)	0.	8.	0.	If a value other than 0 is set, the operation will start from the designated step No. once this step is finished.	0	0	0	0	6-129
B60 -	Spinning frame operatio	n setting								
0	STP function selection (Spinning frame operation setting)	11.	22.	11.	1 1. f0= STP function selection = 1: Not selected =2: Selected f1= Operation mode after final step selection = 1: Operation stop = 2: FRQ SP operation	0				6-131
1	STP0 step count (Spinning frame operation setting)	0.	14.	14.	Set the step number to STP0.	0			0	6-131
2	STP1 step count (Spinning frame operation setting)	0.	14.	14.	Set the step number to STP1.	0			0	6-131
3	STP2 step count (Spinning frame operation setting)	0.	14.	14.	Set the step number to STP2.	0			0	6-131
4	STP3 step count (Spinning frame operation setting)	0.	14.	14.	Set the step number to STP3.	0			0	6-131
5	Doff-End alarm time (Spinning frame operation setting)	0.1	3000.0	1.0 (s)	Outputs alarm signal for the set time from completion of the final step until directly before stoppage.	0			0	6-131

No.	Parameter	Min.	Max.	Default	Function	Ap	oplic	atio	n	Ref.
B60 -	Spinning frame operatio	n setting		(Onit)		V/f	VEC	PM	RWE	paye
500		in setting	ŀ		1 = ×1, 2 = ×10					
6	STP time unit setting (Spinning frame operation setting)	1.	2.	1.	This is valid for the STP time (B63, 64, 67, 68, 71, 72, 75, 76) and Doff-End alarm time (B60-5).	0			0	6-131
7	Hank count gain (Spinning frame operation setting)	0.001	30.000	1.000	This is the Hank count calculation gain.	0			0	6-131
8	Hank count gain unit (Spinning frame operation setting)	1.	3.	1.	=1: ×1.0, =2: ×0.1, =3: ×10	0			0	6-131
9	FRQ_SP frequency setting (Spinning frame operation setting)	0.00	100.00	10.00 (%)	Set the frequency after the step is completed. This is valid when B60-0[f1]=2.	0			0	6-131
B61 –	STP0 frequency	1	1	1						
0	STP0 frequency 0	0.00	100.00	10.00 (%)	Set the STP0 step 0 frequency.	0			0	6-131
1	STP0 frequency 1	0.00	100.00	10.00 (%)	Set the STP0 step 1 frequency.	0			0	6-131
2	STP0 frequency 2	0.00	100.00	10.00 (%)	Set the STP0 step 2 frequency.	0			0	6-131
3	STP0 frequency 3	0.00	100.00	10.00 (%)	Set the STP0 step 3 frequency.	0			0	6-131
4	STP0 frequency 4	0.00	100.00	10.00 (%)	Set the STP0 step 4 frequency.	0			0	6-131
5	STP0 frequency 5	0.00	100.00	10.00 (%)	Set the STP0 step 5 frequency.	0			0	6-131
6	STP0 frequency 6	0.00	100.00	10.00 (%)	Set the STP0 step 6 frequency.	0			0	6-131
7	STP0 frequency 7	0.00	100.00	10.00 (%)	Set the STP0 step 7 frequency.	0			0	6-131
B62 –	STP0 frequency									
0	STP0 frequency 8	0.00	100.00	10.00 (%)	Set the STP0 step 8 frequency.	0			0	6-131
1	STP0 frequency 9	0.00	100.00	10.00 (%)	Set the STP0 step 9 frequency.	0			0	6-131
2	STP0 frequency 10	0.00	100.00	10.00 (%)	Set the STP0 step 10 frequency.	0			0	6-131
3	STP0 frequency 11	0.00	100.00	10.00 (%)	Set the STP0 step 11 frequency.	0			0	6-131
4	STP0 frequency 12	0.00	100.00	10.00 (%)	Set the STP0 step 12 frequency.	0			0	6-131
5	STP0 frequency 13	0.00	100.00	10.00 (%)	Set the STP0 step 13 frequency.	0			0	6-131
6	STP0 frequency 14	0.00	100.00	10.00 (%)	Set the STP0 step 14 frequency.	0			0	6-131
B63 –	STP0 time									
0	STP0 time 0	0.1	6000.0	1.0 (s)	Set the STP0 step 0 time.	0			0	6-131
1	STP0 time 1	0.1	6000.0	1.0 (s)	Set the STP0 step 1 time.	0			0	6-131
2	STP0 time 2	0.1	6000.0	1.0 (s)	Set the STP0 step 2 time.	0			0	6-131
3	STP0 time 3	0.1	6000.0	1.0 (s)	Set the STP0 step 3 time.	0			0	6-131
4	STP0 time 4	0.1	6000.0	1.0 (s)	Set the STP0 step 4 time.	0			0	6-131
5	STP0 time 5	0.1	6000.0	1.0 (s)	Set the STP0 step 5 time.	0			0	6-131
6	STP0 time 6	0.1	6000.0	1.0 (s)	Set the STP0 step 6 time.	0			0	6-131
7	STP0 time 7	0.1	6000.0	1.0 (s)	Set the STP0 step 7 time.	0			0	6-131

Block-B parameters	(S/W option constants) list
--------------------	-----------------------------

No.	Parameter	Min.	Max.	Default	Function	A	pplic	ation	۱	Ref.
D64	OTD0 time	<u> </u>	<u> </u>	(Unit)		V/f	VEC	PM RV	WE	page
B04 -		0.1	00000	1.0				T		0.404
0	STPU time 8	0.1	6000.0	(s)	Set the STPU step 8 time.	0	\square		5	6-131
1	STP0 time 9	0.1	6000.0	1.0 (s)	Set the STP0 step 9 time.	0		(С	6-131
2	STP0 time 10	0.1	6000.0	1.0 (S)	Set the STP0 step 10 time.	0		(С	6-131
3	STP0 time 11	0.1	6000.0	1.0 (s)	Set the STP0 step 11 time.	0		(С	6-131
4	STP0 time 12	0.1	6000.0	1.0 (s)	Set the STP0 step 12 time.	0		(Э	6-131
5	STP0 time 13	0.1	6000.0	1.0 (s)	Set the STP0 step 13 time.	0		(С	6-131
6	STP0 time 14	0.1	6000.0	1.0 (s)	Set the STP0 step 14 time.	0		(0	6-131
B65 -	STP1 frequency			·	·	·	·			
0	STP1 frequency 0	0.00	100.00	10.00 (%)	Set the STP1 step 0 frequency.	0		(Э	6-131
1	STP1 frequency 1	0.00	100.00	10.00 (%)	Set the STP1 step 1 frequency.	0		(Э	6-131
2	STP1 frequency 2	0.00	100.00	10.00 (%)	Set the STP1 step 2 frequency.	0		(Э	6-131
3	STP1 frequency 3	0.00	100.00	10.00 (%)	Set the STP1 step 3 frequency.	0		(С	6-131
4	STP1 frequency 4	0.00	100.00	10.00 (%)	Set the STP1 step 4 frequency.	0		(0	6-131
5	STP1 frequency 5	0.00	100.00	10.00 (%)	Set the STP1 step 5 frequency.	0		(0	6-131
6	STP1 frequency 6	0.00	100.00	10.00 (%)	Set the STP1 step 6 frequency.	0		(0	6-131
7	STP1 frequency 7	0.00	100.00	10.00 (%)	Set the STP1 step 7 frequency.	0		(С	6-131
B66 -	STP1 frequency									
0	STP1 frequency 8	0.00	100.00	10.00 (%)	Set the STP1 step 8 frequency.	0		(С	6-131
1	STP1 frequency 9	0.00	100.00	10.00 (%)	Set the STP1 step 9 frequency.	0		(Э	6-131
2	STP1 frequency 10	0.00	100.00	10.00 (%)	Set the STP1 step 10 frequency.	0		(С	6-131
3	STP1 frequency 11	0.00	100.00	10.00 (%)	Set the STP1 step 11 frequency.	0		(С	6-131
4	STP1 frequency 12	0.00	100.00	10.00 (%)	Set the STP1 step 12 frequency.	0		(С	6-131
5	STP1 frequency 13	0.00	100.00	10.00 (%)	Set the STP1 step 13 frequency.	0		(С	6-131
6	STP1 frequency 14	0.00	100.00	10.00 (%)	Set the STP1 step 14 frequency.	0		(О	6-131
B67 -	STP1 time				·					
0	STP1 time 0	0.1	6000.0	1.0 (s)	Set the STP1 step 0 time.	0	$\left[\right]$	(0	6-131
1	STP1 time 1	0.1	6000.0	1.0 (s)	Set the STP1 step 1 time.	0		(С	6-131
2	STP1 time 2	0.1	6000.0	1.0 (s)	Set the STP1 step 2 time.	0		(С	6-131
3	STP1 time 3	0.1	6000.0	1.0 (s)	Set the STP1 step 3 time.	0		(С	6-131
4	STP1 time 4	0.1	6000.0	1.0 (s)	Set the STP1 step 4 time.	0		(С	6-131
5	STP1 time 5	0.1	6000.0	1.0 (s)	Set the STP1 step 5 time.	0		(0	6-131
6	STP1 time 6	0.1	6000.0	1.0 (s)	Set the STP1 step 6 time.	0		(С	6-131
7	STP1 time 7	0.1	6000.0	1.0 (s)	Set the STP1 step 7 time.	0		(0	6-131

No.	Parameter	Min.	Max.	Default	Function	A	oplic	catio	on	Ref.
				(Unit)		V/f	VEC	PM	RWE	page
B68 –	STP1 time			1.0		1				
0	STP1 time 8	0.1	6000.0	(s)	Set the STP1 step 8 time.	0			0	6-131
1	STP1 time 9	0.1	6000.0	1.0 (s)	Set the STP1 step 9 time.	0			0	6-131
2	STP1 time 10	0.1	6000.0	1.0 (s)	Set the STP1 step 10 time.	0			0	6-131
3	STP1 time 11	0.1	6000.0	1.0 (s)	Set the STP1 step 11 time.	0			0	6-131
4	STP1 time 12	0.1	6000.0	1.0 (s)	Set the STP1 step 12 time.	0			0	6-131
5	STP1 time 13	0.1	6000.0	1.0 (s)	Set the STP1 step 13 time.	0			0	6-131
6	STP1 time 14	0.1	6000.0	1.0 (s)	Set the STP1 step 14 time.	0			0	6-131
B69 –	STP2 frequency									
0	STP2 frequency 0	0.00	100.00	10.00 (%)	Set the STP2 step 0 frequency.	0			0	6-131
1	STP2 frequency 1	0.00	100.00	10.00 (%)	Set the STP2 step 1 frequency.	0			0	6-131
2	STP2 frequency 2	0.00	100.00	10.00 (%)	Set the STP2 step 2 frequency.	0			0	6-131
3	STP2 frequency 3	0.00	100.00	10.00 (%)	Set the STP2 step 3 frequency.	0			0	6-131
4	STP2 frequency 4	0.00	100.00	10.00 (%)	Set the STP2 step 4 frequency.	0			0	6-131
5	STP2 frequency 5	0.00	100.00	10.00 (%)	Set the STP2 step 5 frequency.	0			0	6-131
6	STP2 frequency 6	0.00	100.00	10.00 (%)	Set the STP2 step 6 frequency.	0			0	6-131
7	STP2 frequency 7	0.00	100.00	10.00 (%)	Set the STP2 step 7 frequency.	0			0	6-131
B70 –	STP2 frequency									
0	STP2 frequency 8	0.00	100.00	10.00 (%)	Set the STP2 step 8 frequency.	0			0	6-131
1	STP2 frequency 9	0.00	100.00	10.00 (%)	Set the STP2 step 9 frequency.	0			0	6-131
2	STP2 frequency 10	0.00	100.00	10.00 (%)	Set the STP2 step 10 frequency.	0			0	6-131
3	STP2 frequency 11	0.00	100.00	10.00 (%)	Set the STP2 step 11 frequency.	0			0	6-131
4	STP2 frequency 12	0.00	100.00	10.00 (%)	Set the STP2 step 12 frequency.	0			0	6-131
5	STP2 frequency 13	0.00	100.00	10.00 (%)	Set the STP2 step 13 frequency.	0			0	6-131
6	STP2 frequency 14	0.00	100.00	10.00 (%)	Set the STP2 step 14 frequency.	0			0	6-131
B71 –	STP2 time									
0	STP2 time 0	0.1	6000.0	1.0 (s)	Set the STP2 step 0 time.	0			0	6-131
1	STP2 time 1	0.1	6000.0	1.0 (s)	Set the STP2 step 1 time.	0			0	6-131
2	STP2 time 2	0.1	6000.0	1.0 (s)	Set the STP2 step 2 time.	0			0	6-131
3	STP2 time 3	0.1	6000.0	1.0 (s)	Set the STP2 step 3 time.	0			0	6-131
4	STP2 time 4	0.1	6000.0	1.0 (s)	Set the STP2 step 4 time.	0			0	6-131
5	STP2 time 5	0.1	6000.0	1.0 (s)	Set the STP2 step 5 time.	0			0	6-131
6	STP2 time 6	0.1	6000.0	1.0 (s)	Set the STP2 step 6 time.	0			0	6-131
7	STP2 time 7	0.1	6000.0	1.0 (s)	Set the STP2 step 7 time.	0			0	6-131

Block-B parameters	(S/W option constants) list
--------------------	-----------------------------

No.	Parameter	Min.	Max.	Default	Function	A	pplic	atio	n	Ref.
B72	OTD2 time	<u> </u>	L	(Unit)		V/f	VEC	PM F	₹WE	page
B/2 -		0.1	00000	1.0						0.101
	STP2 time 8	0.1	6000.0	(s)	Set the STP2 step 8 time.	0	\square	\dashv	0	6-131
1	STP2 time 9	0.1	6000.0	1.0 (s)	Set the STP2 step 9 time.	0			0	6-131
2	STP2 time 10	0.1	6000.0	1.0 (s)	Set the STP2 step 10 time.	0	Ш		0	6-131
3	STP2 time 11	0.1	6000.0	1.0 (s)	Set the STP2 step 11 time.	0			0	6-131
4	STP2 time 12	0.1	6000.0	1.0 (s)	Set the STP2 step 12 time.	0			0	6-131
5	STP2 time 13	0.1	6000.0	1.0 (s)	Set the STP2 step 13 time.	0			0	6-131
6	STP2 time 14	0.1	6000.0	1.0 (s)	Set the STP2 step 14 time.	0			0	6-131
B73 -	- STP3 frequency			·			·			
0	STP3 frequency 0	0.00	100.00	10.00 (%)	Set the STP3 step 0 frequency.	0			0	6-131
1	STP3 frequency 1	0.00	100.00	10.00 (%)	Set the STP3 step 1 frequency.	0			0	6-131
2	STP3 frequency 2	0.00	100.00	10.00 (%)	Set the STP3 step 2 frequency.	0			0	6-131
3	STP3 frequency 3	0.00	100.00	10.00 (%)	Set the STP3 step 3 frequency.	0			0	6-131
4	STP3 frequency 4	0.00	100.00	10.00 (%)	Set the STP3 step 4 frequency.	0			0	6-131
5	STP3 frequency 5	0.00	100.00	10.00 (%)	Set the STP3 step 5 frequency.	0			0	6-131
6	STP3 frequency 6	0.00	100.00	10.00 (%)	Set the STP3 step 6 frequency.	0			0	6-131
7	STP3 frequency 7	0.00	100.00	10.00 (%)	Set the STP3 step 7 frequency.	0			0	6-131
B74 -	- STP3 frequency						·	`		
0	STP3 frequency 8	0.00	100.00	10.00 <u>(</u> %)	Set the STP3 step 8 frequency.	0			0	6-131
1	STP3 frequency 9	0.00	100.00	10.00 (%)	Set the STP3 step 9 frequency.	0			0	6-131
2	STP3 frequency 10	0.00	100.00	10.00 (%)	Set the STP3 step 10 frequency.	0			0	6-131
3	STP3 frequency 11	0.00	100.00	10.00 (%)	Set the STP3 step 11 frequency.	0			0	6-131
4	STP3 frequency 12	0.00	100.00	10.00 (%)	Set the STP3 step 12 frequency.	0			0	6-131
5	STP3 frequency 13	0.00	100.00	10.00 (%)	Set the STP3 step 13 frequency.	0			0	6-131
6	STP3 frequency 14	0.00	100.00	10.00 (%)	Set the STP3 step 14 frequency.	0			0	6-131
B75 -	STP3 time					<u> </u>				
0	STP3 time 0	0.1	6000.0	1.0 (s)	Set the STP3 step 0 time.	0	$\left[\ \right]$		0	6-131
1	STP3 time 1	0.1	6000.0	1.0 (s)	Set the STP3 step 1 time.	0			0	6-131
2	STP3 time 2	0.1	6000.0	1.0 (s)	Set the STP3 step 2 time.	0			0	6-131
3	STP3 time 3	0.1	6000.0	1.0 (s)	Set the STP3 step 3 time.	0			0	6-131
4	STP3 time 4	0.1	6000.0	1.0 (s)	Set the STP3 step 4 time.	0			0	6-131
5	STP3 time 5	0.1	6000.0	1.0 (s)	Set the STP3 step 5 time.	0			0	6-131
6	STP3 time 6	0.1	6000.0	1.0 (s)	Set the STP3 step 6 time.	0			0	6-131
7	STP3 time 7	0.1	6000.0	1.0 (s)	Set the STP3 step 7 time.	0			0	6-131

N	0	Parameter Min. Max. Default Function		Ap	oplic	ation	Ref.			
	0.	rarameter		Max.	(Unit)	T unction	V/f	VEC	PM RWI	page
B7	6 –	STP3 time								
	0	STP3 time 8	0.1	6000.0	1.0 (s)	Set the STP3 step 8 time.	0		0	6-131
-	1	STP3 time 9	0.1	6000.0	1.0 (s)	Set the STP3 step 9 time.	0		0	6-131
-	2	STP3 time 10	0.1	6000.0	1.0 (s)	Set the STP3 step 10 time.	0		0	6-131
	3	STP3 time 11	0.1	6000.0	1.0 (s)	Set the STP3 step 11 time.	0		0	6-131
	4	STP3 time 12	0.1	6000.0	1.0 (s)	Set the STP3 step 12 time.	0		0	6-131
	5	STP3 time 13	0.1	6000.0	1.0 (s)	Set the STP3 step 13 time.	0		0	6-131
	6	STP3 time 14	0.1	6000.0	1.0 (s)	Set the STP3 step 14 time.	0		0	6-131

6-4 Block-C parameters

The Block-C parameters are divided into the basic functions, extended functions and hardware option functions.

- V/f : Indicates parameters that apply for V/f control (constant torque, variable torque) (C30-0: f0 = 1).
- VEC : Indicates parameters that apply for IM speed sensor-less vector control and IM speed vector control with sensor (C30-0: f0 = 2, 3).
- PM : Indicates parameters that apply for control mode with PM motor sensor (C30-0: f0 = 4).
- * indicates a parameter which functions during auxiliary drive operation or when the V/f control is active during automatic tuning.

RWE : Displays the parameters that can be changed during operation.

Reference page: The number of the page providing detailed explanations is indicated.

No.	Parameter	Min.	Max.	Default	Function	A	pplie	catio	on	Ref.
				(Unit)		V/f	VEC	PM	RWE	page
C00 –	Control methods					1	1			
0	Run command method	1.	3.	1.	Run command method is set. = 1: F·RUN, R·RUN = 2: RUN, REV = 3: Self hold (Pulse inputs for F·RUN and R·RUN)	0	0	0		6-135
1	Run/stop methods	1.	2.	2.	Set the stopping method for RUN operation. = 1: Coast to stop = 2: Ramp down to stop	0	0	0		6-136
2	Jog stop method	1.	2.	2.	Set the stopping method for JOG operation. = 1: Coast to stop = 2: Ramp down to stop	0	0	0		6-136
3	Emergency stop (EMS) input logic	1.	2.	Emergency stop input logic is set. 1. = 1: Close to stop = 2: Open to stop Set the stopping method for the emergency		0	0	0		6-136
4	Emergency stop (EMS) mode	1.	3.	1.	Set the stopping method for the emergency stop. = 1: Coast to stop without a fault output = 2: Coast to stop with a fault output = 3: Ramp down to stop	0	0	0		6-136
5	Control source switchover method (J1 setting)	1.	2.	Set whether to validate the remote au operation sequence for the local oper mode. = 1: Disables = 2: Enables		0	0	0		6-137
6	Control source switchover method (J2 setting)	1.	2.	1.	Select the No. of auxiliary operation sequence input points when the COP command is ON. = 1: Terminal block input = 2: Serial input	0	0	0		6-137
7	Run contact output condition selection	1.	2.	1.	= 2: Serial input The conditions for turning the sequence RUN output ON are set. = 1: ON at pre-excitation = 2: OFF at pre-excitation		0	0		6-137
C01 –	Start/stop frequency									
0	Start frequency	0.10	Fmax or 60.00	1.00 (Hz)	When RUN is started, operation starts from this frequency.	0			0	6-87
1	Stop frequency (DC brake start)	0.10	Fmax or 60.00	1.00 (Hz)	The DC brakes are applied when the output frequency value is less than this frequency value.	0			0	6-87

No	No. Parameter Min. Max. Default Function				Ap	plic	atio	n	Ref.	
	i ulullotoi		maxi	(Unit)	i anonon	V/f	VEC	PM R	WE	page
C02 –	Various setting input set	lection								
0	Speed setting input points selection	1.	5.	4.	 = 1: Analog fixed = 2: Serial/parallel fixed = 3: Panel fixed = 4: Sequence = 5: Pulse train input fixed 	0	0	0		6-137
1	Traverse center frequency input points selection	1.	5.	3.	 = 1: Analog fixed = 2: Analog fixed = 3: Panel fixed = 4: Sequence = 5: Pulse train input fixed 	0	0	0		6-137
2	Torque setting input points selection	1.	5.	3.	 = 1: Analog fixed = 2: Serial fixed = 3: Panel fixed = 4: Sequence = 5: Pulse train input fixed 		0	0		6-137
3	Torque ratio 1 setting input points selection	2.	4.	3.	= 2: Serial fixed = 3: Panel fixed = 4: Sequence		0	0		6-137
4	Torque bias 1 setting input points selection	1.	4.	3.	= 1: Analog fixed= 2: Serial fixed= 3: Panel fixed= 4: Sequence		0	0		6-137
5	Torque ratio 2 setting input points selection	2.	4.	3.	= 2: Serial fixed = 3: Panel fixed = 4: Sequence		0	0		6-137
6	Drive/regenerative torque limit input points selection	1.	4.	4.	= 1: Analog fixed = 2: Serial fixed = 3: Sequence = 4: Sequence		0	0		6-137
7	ASR response input points selection	2.	4.	3.	= 2: Serial fixed = 3: Panel fixed = 4: Sequence		0	0		6-137
8	Machine time constant input points selection	2.	4.	3.	= 2: Serial fixed = 3: Panel fixed = 4: Sequence		0	0		6-137

No.	F	Parameter	Min.	Max.	Default	ault Function			tion	Α	pplie	catio	n	Ref.
				-	(Unit)					V/f	VEC	PM	RWE	page
C03 –	Sequen	ce input termina	function	-1	·									0.407
0	F·RUN	Forward run	-11.	16.	1.		r	•	1	0	0	0	0	6-137
$\frac{1}{2}$	EMS	Emergency stop	-11.	16.	3.		Value	Inp	out terminal	0	0	0	0	6-137
2	R·RUN	Reverse run	-11.	16.	4.		-11 -10	PSI11	Relay option	0	0	0	0	6-137
3	F·JOG	Forward jogging	-11.	16.	5.		-10	PSI9	(reversed)	0	0	0	0	6-137
4	R·JOG	Reverse jogging	-11.	16.	6.		-8	PSI8		0	0	0	0	6-137
5	HOLD	Hold signal	-11.	16.	0.		-7	PSI7		0	0	0	0	6-137
0	BRAKE	DC brake	-11.	16.	0.		-0 -5	PSI6 PSI5	Base section	0	0	0	0	6-137
	RESET	Breakdown reset	-11.	16.	Ζ.		-4	PSI4	terminal block	0	0	0	0	6-137
8	COP	serial transmission selection	-11.	16.	0.		-3 -2 -1	PSI3 PSI2 PSI1	(reversed)	0	0	0	0	6-137
9	CSEL	Ramp selection	-11.	16.	0.		0	OFF fixe	ed	0	0	0	0	6-137
А	IPASS	Ratio interlock bypass	-11.	16.	0.		1 2	PSI1 PSI2		0	0	0	0	6-137
В	CPASS	Ramp bypass	-11.	16.	0.		3	PSI3	Base section	0	0	0	0	6-137
С	PIDEN	PID control selection	-11.	16.	0.		4	PSI4 PSI5	terminal block	0	0	0	0	6-137
D	AFS1	Speed setting 1	-11.	16.	16.		6	PSI6 PSI7		0	0	0	0	6-137
E	AFS2	Speed setting 2	-11.	16.	0.		8	PSI8		0	0	0	0	6-137
F	AFS3	Speed setting 3	-11.	16.	0.		9	PSI9	Relay option	0	0	0	0	6-137
C04 –	Sequen	ce input termina	I function	-2		I	10	PSI10	ricial option		1	1		
0	PROG	Program function enable	-11.	16.	0.		12	PLC1	Ruilt in PLC	0	0	0	0	6-137
1	CFS	Serial communication setting select	-11.	16.	0.		13 14 15	PLC3 PLC4	output	0	0	0	0	6-137
2	S0	Program speed selection	-11.	16.	0.		16	ON fixed	t	0	0	0	0	6-137
3	S1	Program speed selection	-11.	16.	0.					0	0	0	0	6-137
4	S2	Program speed selection	-11.	16.	0.					0	0	0	0	6-137
5	S3	Program speed selection	-11.	16.	0.					0	0	0	0	6-137
6	SE	Program speed selection	-11.	16.	0.					0	0	0	0	6-137
7	FUP	Frequency (speed) increase	-11.	16.	0.					0	0	0	0	6-137
8	FDW	Frequency (speed) decrease	-11.	16.	0.					0	0	0	0	6-137
9	BUP	Ratio interlock bias increase	-11.	16.	0.					0	0	0	0	6-137
А	BDW	Ratio interlock bias decrease	-11.	16.	0.					0	0	0	0	6-137
В	IVLM	Ratio interlock bias increase/ decrease selection	-11.	16.	0.					0	0	0	0	6-137
С	AUXDV	Auxiliary drive selection	-11.	16.	0.					0	\bigtriangleup	\bigtriangleup	0	6-137
D	PICK	Pick-up	-11.	16.	0.					0	0	0	0	6-137
E	MBRK_a	ins External brake answer	-11.	16.	0.					0	0	0	0	6-137
F	PRST	STP reset	-11.	16.	0.					0	0	0	0	6-137

No.	Parameter	Min.	Max.	Default		Function	A	pplie	catio	on	Ref.	
				(Unit)				V/f	VEC	РМ	RWE	page
C05 –	Sequence input terminal	function	-3		i					~		0.407
0	S5 Digital torque bias 1	-11.	16.	0.		_		0	0	0	0	6-137
-1	S6 Digital torque blas 2	-11.	10.	0.		Value	Input terminal		0	0	0	6 127
	S7 Digital torque bias 3	-11.	10.	0.		-11	PSI11 PSI10 Polov option	0	0	0	0	0-137
3	selection L	-11.	16.	0.		-10 -9	PSI9 (reversed)	0	\triangle	\triangle	0	6-137
4	AUXSW1 Auxiliary drive No selection H	-11.	16.	0.		-8 -7	PSI8 PSI7	0	\bigtriangleup	\bigtriangleup	0	6-137
5	PLS_IN Pulse train input selection	-11.	16.	0.		-6 -5	PSI6 PSI5 Base section	0	0	0	0	6-137
6	OCLLV1 OCL Level setting 1	-11.	16.	0.		-4 -3	PSI4 terminal block PSI3 (reversed)	0	0	0	0	6-137
7	OCLLV2 OCL Level setting 2	-11.	16.	0.		-2 -1	PSI2 PSI1	0	0	0	0	6-137
8	E.FLT1 External Fault 1	-11.	16.	0.		0	OFF fixed	0	0	0	0	6-229
9	E.FLT2 External Fault 2	-11.	16.	0.		1	PSI1 PSI2	0	0	0	0	6-229
A	E.FLT3 External Fault 3	-11.	16.	0.		3	PSI3 Page continu	0	0	0	0	6-229
В	E.FLT4 External Fault 4	-11.	16.	0.		4	PSI4 terminal block	0	0	0	0	6-229
С	E.FLT5 External Fault 5	-11.	16.	0.		5	PSI5	0	0	0	0	6-229
D	E.FLT6 External Fault 6	-11.	16.	0.		7	PSI7	0	0	0	0	6-229
Е	E.FLT7 External Fault 7	-11.	16.	0.		8	PSI8	0	0	0	0	6-229
F	E.FLT8 External Fault 8	-11.	16.	0.		9	PSI9 Relay option	0	0	0	0	6-229
C06 –	Sequence input terminal	function	- 4		_	10 11	PSI10 PSI11					
0	EXC Pre-excitation	-11.	16.	0.		12	PLC1	-	0		0	6-137
1	ACR ACR	-11.	16.	0.		13	PLC2 Built-in PLC		0	0	0	6-137
2	PCTL P control	-11.	16.	0.		14	13 PLC2 Built-In PLC 14 PLC3 output 15 PLC4		0	0	0	6-137
3	LIM1 Drive torque limiter changeover	-11.	16.	0.		15 16	ON fixed		0	0	0	6-137
4	LIM2 Regenerative torque limiter changeover	-11.	16.	0.					0	0	0	6-137
5	MCH Machine time constant changeover	-11.	16.	0.					0	0	0	6-137
6	RF0 0 setting	-11.	16.	0.					0	0	0	6-137
7	DROOP Drooping changeover	-11.	16.	0.					0	0	0	6-137
8	DEDB Dead band setting	-11.	16.	0.					0	0	0	6-137
9	TRQB1 Torque bias setting 1	-11.	16.	0.					0	0	0	6-137
A	TRQB2 Torque bias setting 2	-11.	16.	0.					0	0	0	6-137
C07 –	Analog input terminal fu	nction		n	1				1	-		
0	Speed setting 1	0.	11.	2.				0	0	0	0	6-137
1	Speed setting 2	0.	11.	3.		Value	Input terminal	0	0	0	0	6-137
2	Speed setting 3	0.	11.	0.		0	0% fixed	0	0	0	0	6-137
3	Ratio interlock bias setting	0.	11.	0.		1	100% fixed Al1	0	0	0	0	6-137
4	Traverse center frequency	0.	11.	0.		3	AI2 AI3	0	0	0	0	6-137
5	PID feedback	0.	11.	0.		5	PAI4 (OP) PAI5 (OP)	0	0	0	0	6-137
6	Torque setting	0.	11.	0.]	7	PAI6 (OP)		0	0	0	6-137
7	Drive torque limiter reduction setting	0.	11.	1.		8 9	8 Built-in PLC output 1 9 Built-in PLC output 2		0	0	0	6-137
8	Regenerative torque limiter reduction setting	0.	11.	1.		10 11	10Built-in PLC output 311Built-in PLC output 4			0	0	6-137
9	Torque bias 1 setting	0.	11.	0.	F	PAI4 to PA	AI6 are for future.		0	0	0	6-137
А	Analog torque bias setting	0.	11.	0.					0	0	0	6-137

No.	Parameter	Min.	Max.	Default	Function	A	oplic	catio	on	Ref.
000	• • • • • •			(Unit)		V/f	VEC	PM	RWE	page
C08 –	Automatic start setting				= 1: off					
0	(To F·RUN/R·RUN)	1.	3.	1.	 2: on with pick-up 3: on with pick-up (re-start after a momentary power loss) 	0	0	0		6-138
C09 –	Parameter protection/op	eration lo	cks	I						
0	Parameter protection	1.	9.	1.	Set to prevent unintentional operation from the operation panel (OPU).Set whether to enable or prohibit data changing for each parameter function unit as shown above.Parameter protection: $\bigcirc: Unprotected (changeable)\times: Protected (unchangeable)Value Block ABlock B, CBlock B, C2XXX$	0	0	0		6-139
1	Operation panel lock	1.	3.	1.	 = 1: Enable control from Operation Panel = 2: Disable control from Operation Panel (except for STOP key, if pressed for 2 seconds, will stop the drive) = 3: Only STOP key is available 	0	0	0	0	6-139
2	LCL switchover protection	1.	2.	1.	 = 1: Disables switchover while the drive is running = 2: Enables switchover while the drive is running 	0	0	0	0	6-139
3	Reveres run sequence (R·RUN) prohibit	1.	2.	1.	Set this to prevent unintentional reverse run operation. When set to "2", the sequence input "R RUN" operation command will be disabled. Note that if the reverse run setting (negative value) is input into the speed setting during "F·RUN" operation, reverse run will start. = 1: Enable = 2: Prohibit	0	0	0	0	6-139
4	Reverse run jogging sequence (R·JOG) prohibit	1.	2.	1.	Set this to prevent unintentional reverse jogging operation. When set to "2", the "R·JOG" operation command will be disabled. Note that if the reverse run setting (negative value) is input into the jogging setting during "F·JOG" operation, reverse run will start. = 1: Enable = 2: Prohibit	0	0	0	0	6-139
5	Reverse run during ACR mode prohibit	1.	2.	1.	Set this to prevent unintentional reverse run operation. When set to "2", reverse run during ACR operation will be prohibited. The reverse run speed will be limited to approx. 1% if reverse run is started. This setting is ignored in the V/f mode. = 1: Enable = 2: Prohibit		0	0		6-140

No	Parameter	Min.	Max.	Default	Function	A	oplie	catio	on	Ref.
				(Unit)		V/f	VEC	РМ	RWE	page
(Fault history buffer clear	0	9999	0.	Set 1 for the setting value to clear the fault history details. The clearing operation will not take place at a setting other than 1. 1: Clear fault history	0	0	0	0	6-140
	7 Default value load	0	9999	0.	 9: All default values load 10: Parameter A 11: Parameters B, C basic functions 12: Parameters B, C extended functions 13: Parameter B software option function Parameter C hardware option function 14: Parameters B basic functions 15: Parameters B extended functions 16: Parameter B software option function 17: Parameters C basic functions 18: Parameters C extended functions 19: Parameter C hardware option function 	0	0	0		6-140
C10	 Custom parameter regis 	ter								
(0 Custom – 0	1.00.0	2.FF.F	1.9F.F	Set for each parameter No. to be displayed	0	0	0	0	6-140
	I Custom – 1	1.00.0	2.FF.F	1.9F.F	parameter.	0	0	0	0	6-140
:	2 Custom – 2	1.00.0	2.FF.F	1.9F.F	Example) To set B13-0 (torque setting), set as 1, 1,3, 0	0	0	0	0	6-140
;	3 Custom – 3	1.00.0	2.FF.F	1.9F.F		0	0	0	0	6-140
4	4 Custom – 4	1.00.0	2.FF.F	1.9F.F		0	0	0	0	6-140
	5 Custom – 5	1.00.0	2.FF.F	1.9F.F	L Sub No.	0	0	0	0	6-140
(6 Custom – 6	1.00.0	2.FF.F	1.9F.F	Main No.	0	0	0	0	6-140
-	7 Custom – 7	1.00.0	2.FF.F	1.9F.F	2: C block	0	0	0	0	6-140
C11	- Operation panel mode s	etting								
() Initial mode	1.	2.	1.	The initial operation mode for when the power is turned ON is set = 1: Local = 2: Remote	0	0	0	0	6-141
	Run command status	1.	3.	1.	The initial operation mode for when the power is turned ON, if using the automatic start function (when C08-0 =2 or 3) during the local operation mode (operation from operation panel) is set. If =2 is set, forward run will start when the run enable state is entered after the power is turned ON. = 1: Stop = 2: Forward run = 3: Reverse run	0	0	0	0	6-141
2	Operation panel frequency change operation	1.	2.	1.	Used to prevent changes to the frequency/rotation speed settings in real time. =1: Change in real time =2: Change using the Set key.	0	0	0	0	6-141
:	Operation panel monitor parameter	0.00.0	1.9F.F	0.00.0	Select the parameters displayed first when the power is turned ON.	0	0	0	0	6-141

No.	No. Parameter	Min.	Max.	Default	Function	A	oplic	atic	on	Ref.
				(Unit)		V/f	VEC	PM	RWE	page
4	LCD panel: Language setting	0.	4.	0.	Select the language displayed on the LCD panel. =0: English =1: French =2: German =3: Spanish =4: Italian (This is displayed only when the LCD panel is connected)	0	0	0	0	6-141
5	LCD panel: Contrast adjustment	-10.	5.	0.	Adjust the contrast of the characters displayed on the LCD panel. (This is displayed only when the LCD panel is connected)	0	0	0	0	6-141
6	LCD panel: Backlight OFF timer setting	0.	255.	0. (s)	Set the time to turn ON the LCD panel's backlight. =0: Always ON =Other than 0: Turns OFF when there is no operation for set time (This is displayed only when the LCD panel is connected)	0	0	0	0	6-142
7	Panel operation method selection	1.	2.	1.	=1: Sub No. selection method =2: Main No. selection method	0	0	0	0	6-142
C12 –	Setting input terminal fu	nction								
0	AI1 Terminal input mode selection	1.	2.	1.	= 1: Voltage input, = 2: Current input	0	0	0		6-142
1	AI1 Voltage input mode selection	1.	3.	1.	= 1: 0 to 10V, = 2: 0 to 5V, = 3: 1 to 5V	0	0	0		6-142
2	AI1 Current input mode selection	1.	2.	1.	= 1: 4 to 20mA, = 2: 0 to 20mA	0	0	0		6-143
3	Filter time constant for Al1 input	2.	250.	8. (ms)	A time constant of setting value/2ms is applied on the input value.	0	0	0		6-144
4	Al2 terminal input mode	1.	2.	1.	= 1: Voltage input, = 2: Current input	0	0	0		6-142
5	Al2 voltage input mode	1.	3.	1.	= 1: 0 to 10V, = 2: 0 to 5V, = 3: 1 to 5V	0	0	0		6-142
6	Al2 current input mode	1.	2.	1.	= 1: 4 to 20mA, = 2: 0 to 20mA	0	0	0		6-143
7	Filter time constant for AI2 input	2.	250.	8. (ms)	A time constant of setting value/2ms is applied on the input value.	0	0	0		6-144
8	AI3 terminal input mode	1.	3.	1.	= 1: 0 to ±10V, = 2: 0 to ±5V, = 3: 1 to 5V	0	0	0		6-144
9	AI3 input gain	0.000	5.000	1.000	A magnification gain is applied on the AI3 input value.	0	0	0	0	6-144
А	Filter time constant for AI3 input	2.	250.	8. (ms)	A time constant of setting value/2ms is applied on the input value.	0	0	0		6-144
В	Program setting filter	0.00	1.00	0.01 (s)	The program setting inputs are filtered with the setting terminal batch. (Prevents incorrect setting caused by chattering.)	0	0	0	0	6-144
С	Pulse train input F1 setting frequency	0.1	1000.0	10.0 (Hz)	There is the following restriction	0	0	0	0	6-145
D	Pulse train input F2 setting frequency	1.	10000.	1000. (Hz)	C12-C x $2 \le$ C12-D	0	0	0	0	6-145
E	Pulse train input frequency LPF time constant	0.	2000.	1. (ms)	Refer to section 5-7-3 for details on the parameters related to the pulse train input	0	0	0	0	6-145
F	Pulse train input judgment time	0.01	20.00	1.00 (s)		0	0	0	0	6-145

No.	Parameter Min. Max. Default (Unit)					Function			A	pplie	catio	on	Ref.		
C12	Outer	t torminal function			(0111)						V/f	VEC	РМ	KWE	Paye
013-			·	01	0	<u>.</u>	-4-12				\sim	\sim	\sim	\sim	6 1 4 5
- 0	AUTT		0.	21.	0.	Sele	ect the s	setting value from t	ine follow	ving		0	0	0	0-145
	AU2 te		0.	21.	3.		, and t			-	0	0	0	0	0-145
	Value	Parameter	101/	Terminal v	oltage	_	Value	Parameter	·	Te	ermi	nal v	olta	ge	_
-	0	Setting frequency	100	at Max. freq	uency	_	11	First First State		5V at	Moto	or rat		urrent	
	1	Setting speed	10V	at Max. spe	ed		12	Actual motor rotatio	n sneed	10V at	t Ma	y sn	eu ci eed	unem	
-	2	Pamp output	10V	at Max. freq	uency		14	Namp output	in speed	10V a	t Ra	ted to	oraue	;	-
-	2		10V	at Max. spe	ed		15	Overload monitor		101/0	+ 100	0/		-	
-	3	Output current (Motor) 5V a	t Motor rate	d current	_	15	(motor protection)		10v a		J%0			_
-	4	Output current (Drive)	5V 8	at Motor rated	current	_	16	Built-in PLC output	1	10V/1	000ł	۱			_
-	5	Output voltage	51/ 2	at MOLOT Tat	eu voltage	-	17	Built-in PLC output	2	10V/1	000	۱			_
	6	Motor output power	×M	otor rated cu	rrent)		18	Built-In PLC output	3	100/1	000	1			_
	7	DC voltage	5V a	t 300V (200	V Series)		19	DM1 for maker	4	100/1	0001	1			_
	•	Overland as a 'to a	5V a	t 600V (400	V Series)	-	20	maintenance		10V/1	000	1			
	8	Overioad monitor	10V	at 100%			21	DM2 for maker		10V/1	000	<u>ו</u>]
	9	Heat sink temperature	e 10V	at 100°C		-		maintenance							
-	10	Motor speed	10V	at Max. spe	ed										
-															
2	RA-R	C output	-55	55	1						0	0	0	0	6-145
	param	neters	-33.		1.						<u> </u>	Ŭ	0	0	0-145
3	PSO1	output	-55	55	4						0	0	0	0	6-145
	param	neters		00.	••	Sele	oct the s	setting value from t	he follow	vina	Ŭ	Ŭ	Ŭ	Ŭ	0 110
4	PSO2	2 output	-55.	55.	8.	table	e, and c	output.			0	0	0	0	6-145
	paran	neters				-1 to	-55 ar	e the reverse outp	ut of 1 to	55.					
5	PSO3	output	-55.	55.	9.						0	0	0	0	6-145
6	FA-Ft		-55.	55.	2.						0	0	0	0	6-145
	paran				l			· · · · · · · · · · · · · · · · · · ·				L			
Valu	e Out	tput Value Outp	ut Va	alue Outpu	It Valu	e Oi	utput	Value Output	Value O	utput si	ignal	Va	alue	Out	put nal
0	Fixed	to OFF 8 IDE	T	16 EC3	. 24	L	LMT	32 PLC1	40	FPOS	S		48	MP	01
1	RI	JN 9 ATI	N .	17 ACC	25	U	LMT	33 PLC2	41 F	or future	e use		49	MP	02
2	FI M	IC 11 SPL)2	18 DCC 19 AUXD	26 V 27	D0 M	RRK	34 PLC3 35 PLC4	42 F 43 F	or future	e use		50 51	MP	03
4	RD	0Y1 12 CO	P	20 ALM	28	D	VER	36 PLC5	44 F	or future	e use		52	MF	05
5	RD	0Y2 13 EC	0	21 FAN	29	E	BPF	37 PLC6	45 F	or future	e use		53	MF	06
6	RI	EV 15 EC	2	22 ASW 23 ZSP	30	Fixed	d to ON	30 PLC7 39 PLC8	40 F 47 F	or future	e use		54 55	MP	07
Valu	e Out	tput Value Outp	out V	alue Signa	lt Valu	e	utput	Value Output	Value C	output s	ignal	V	alue	Out	put
		8 IDE	T ·	16 EC3	-24	L	LMT	-32 PLC1	-40	FPOS	S		48	MF	01
-1	RI	UN -9 AT	N ·	17 ACC	-25	U	LMT	-33 PLC2	-41 F	or future	e use		49	MF	02
-2	FI M	LI -10 SPE)2		-26 V27	Do	IT-End BRK	-34 PLC3 -35 PLC4	-42 F	or future	e use		-50 -51	MF	03
-4	R	DY1 -12 CO	P .	20 ALM	-27	D	VER	-36 PLC5	-44 F	or future	e use		-52	MF	05
-5	R	OY2 -13 EC	0	21 FAN	-29	E	BPF	-37 PLC6	-45 F	or future	e use		-53	MF	06
-6	R	EV -14 EC	2	22 ASW 23 ZSP	-30	Fixe	d to ON	-38 PLC7 -39 PLC8	-46 F	or future	e use		-54 -55	MF	07
			I						<u> </u>						

No.	Parameter	Min.	Max.	Default	Function	Ap	oplic	catio	on	Ref.
C13 -	Output terminal function	<u> </u>		(Unit)		V/f	VEC	PM	RWE	Page
7	Built-in PLC input	0.	19.	0.	Select the details set in address 10h of the built-in PLC memory	0	0	0	0	6-145
8	Built-in PLC input selection 2	0.	19.	0.	Select the details set in address 11h of the built-in PLC memory.	0	0	0	0	6-145
9	Built-in PLC input selection 3	0.	19.	0.	Select the details set in address 12h of the built-in PLC memory.	0	0	0	0	6-145
А	Built-in PLC input selection 4	0.	19.	0.	Select the details set in address 13h of the built-in PLC memory.	0	0	0	0	6-145
В	Pulse train output function	1.	2.	1.	Set "2" when using the pulse train output function. Refer to section 5-8-3 for details.	0	0	0	0	6-146
С	Pulse frequency at 0%	1.	32000.	100. (Hz)	There is the following restriction. C13-C + $1 \le C13$ -D	0	0	0	0	6-146
D	Pulse frequency at maximum frequency/ speed	1.	32000.	1000. (Hz)	Refer to section 5-8-3 for details.	0	0	0	0	6-146
E	Pulse train output parameter selection	0.	4.	0.	Value Output Refer to section 5-8-3 for details. Value Output 0 Output frequency 1 Setting frequency 2 Ramp output 3 Motor speed 4 Actual motor rotation speed	0	0	0	0	6-146
F	Output parameter absolute value calculation selection	1.	2.	1.	Refer to section 5-8-3 for details.	0	0	0	0	6-146
C14 –	Meter output gain								,	
0	Output gain for A01	0.20	2.00	1.00	10V at Max. frequency when this is set to 1.00.	0	0	0	0	6-146
1	Output gain for A02	0.20	2.00	1.00	set to 1.00. (Max. 11V)	0	0	0	0	6-146
2	Random scale (AS) display coefficient	0.01	100.00	30.00	Set the coefficient for the D00-4 and D01-5 random scale display.	0	0	0	0	6-148
3	A01 output offset (Voltage)	-8.00	8.00	0.00 (V)	When C14-7 or 8 is set to 1 or 3, the offset can be fluctuated with this setting value. If the offset is set to a value other than 0V, the output which can be displayed with \pm .	0	0	0	0	6-146
4	A02 output offset (Voltage)	-8.00	8.00	0.00 (V)	such as the output frequency, can be \pm output in the range of 0 to 10V centering on this setting value. The absolute value is output when 0.00 is set.	0	0	0	0	6-146
5	A01 output offset (Current)	-15.0	15.0	0.0 (mA)	When C14-7 or 8 is set to 2, the offset can	0	0	0	0	6-146
6	A02 output offset (Current)	-15.0	15.0	0.0 (mA)	be fluctuated with this setting value.	0	0	0	0	6-146
7	A01 output method selection	1.	3.	1.	=1: Voltage 0V to 10V = 3: Current 4mA to 20mA=2: Voltage 0V to 10V (5V offset)	0	0	0		6-146
8	A02 output method selection	1.	3.	1.	When =2 is set, the gain will be set to a 0.5-fold setting using the 5V point as the reference point.	0	0	0		6-146
9	Al1 random scale coefficient	0.01	100.00	30.00	Analog input: Random scale coefficient dedicated for AI1	0	0	0	0	6-148
А	Al2 random scale coefficient	0.01	100.00	30.00	Analog input: Random scale coefficient dedicated for Al2	0	0	0	0	6-148
В	AI3 random scale coefficient	0.01	100.00	30.00	Analog input: Random scale coefficient dedicated for Al3	0	0	0	0	6-148

No.		Parameter	Min.	Max.	Defa (Uni	ult Function					Aj V/f	oplio VEC	catic PM	on RWE	Ref. page
C15 –	Statu	s output detection	level												
0	Attai deteo	nment (ATN) ction width	0.0	20.0	1 (⁰	1.0 %)	The attained is set.	d outpu	ut (ATN) operatio	on width	0	0	0	0	6-149
1	Curre deteo	ent (IDET) ction level	5.	300.	10 (°)0. %)	The current level is set.	detect	tion (IDET) opera	ation	0	0	0	0	6-149
2	Spee level	ed detection (SPD1) - 1	1.0	105.0	95 (⁰	5.0 %)	The speed of	detecti	on (SPD1, SPD2	2)	0	0	0	0	6-149
3	Spee level	ed detection (SPD2) - 2	1.0	105.0	50 (').0 %)	operation le	vel is s	set.		0	0	0	0	6-149
4	Zero (ZSP	speed detection) level	0.00	50.00	1.	00 (s)	The zero sp level is set.	eed de	etection (ZSP) o	peration	0	0	0	0	6-149
5	RDE	LAY delay time	0.0	1000.0	1	l.0 (s)	Set the dela	ıy time	for RDELAY ou	put.	0	0	0	0	6-150
6	EC0 selec	output fault tion	0.00.0	1.FF.F.	0.00	.0.	When only a this parame fault with the	a spec ter car e set c	ific fault is to be to be set so that o conditions is outp	output, only the ut with	0	0	0	0	6-150
7	EC1 selec	output fault tion	0.00.0	1.FF.F.	0.00	.0.	sequence output:EC0 to EC3. 0. 00. 0				0	0	0	0	6-150
8	EC2 selec	output fault tion	0.00.0	1.FF.F.	0.00	.0.	- Sub No. - Fault No. - 0 : Normal fault				0	0	0	0	6-150
9	EC3 selec	output fault ction	0.00.0	1.FF.F.	0.00	.0.			— :0:Normal 1:Monitor	fault fault	0	0	0	0	6-150
	Normal fault No. table														
Ī		Correspond-	Corre	spond-		Cor	respond-		Correspond-		orre	sno	nd-		
	No.	ing fault	lo. ing	fault	No.	i	ng fault	No.	ing fault	No.	ing	fau	lt		
	00	None ()4 (VC	08		SP	0C	GRD	10	BF	PFLT			
	01	EMS ()5 l	JV	09		CONV	0D	10	11	E.	FLT		_	
	02	PM ()6 P	HL	0A		ATT	0E	CPU	12 F	or fu	ture	use	!	
l	03	OC (07 U	OH	0B		OL	0F	FUSE	13 ⊦	or fu	ture	use		
	Mine	r fault Na tabla													
	Ne		nding for	.14		Na	1 4	C	manding fault		1				
	00	Correspo	one one	lit		05	Pi		sponding fault						
	01	Speed (positio	n) detectio	on error		00	P	ump co	ontrol lower limit						
	02	Carrier f	decelerati	na		07	Al1	curren	t input 3mA or le	SS					
	03	Overload erro	or (50% or	more)		08	Al2	curren	t input 3mA or le	SS					
	04	Speed de	viation err	or		09	Field netw	ork op	tion communicat	ion error					
A	EC0	OFF delay timer	0.0	600.0	C).1 (s)					0	0	0	0	6-150
В	EC1	OFF delay timer	0.0	600.0	C).1 (s)	for the set ti	nor tau me if t	it occurs, delay is he minor fault oc et	s applied currence	0	0	0	0	6-150
С	EC2	OFF delay timer	0.0	600.0	C).1 (s)	Note that if not turn OFI	0.00 is F and i	set, the operation instead will remain	on will in ON.	0	0	0	0	6-150
D	EC3	OFF delay timer	0.0	600.0	C).1 (s)	In either case, this will turn OFF regardles b) of the setting when RST is turned ON.			gardless ON.	0	0	0	0	6-150
E	ALM	OFF delay timer	0.0	600.0	C).1 (s)	of the setting when RST is turned ON.				0	0	0	0	6-150

No.	Parameter	Min.	Max.	Default	Function	A	oplic	catio	on	Ref.
				(Unit)		V/f	VEC	PM	RWE	page
C20 –	Start interlock					-				
0	Start/stop frequency (speed)	0.0	20.0	0.0 (%)	The motor will stop when below this frequency setting.	0	0	0	0	6-151
1	Start/stop frequency (speed) hysteresis	0.0	20.0	1.0 (%)	If the motor stops when the set frequency is set to C20-0 or less, the set frequency must be raised to a level which exceeds C20-0 plus this setting value in order to resume operation.	0	0	0	0	6-151
2	Interlock frequency (speed)	0.0	20.0	0.0 (%)	The motor will not start when the setting is above this frequency. (When using with the setting start, set a value that is larger than the setting start frequency.) When C20-0=0, the setting start/stop will not operate. When C20-2=0, the setting interlock will not operate.	0	0	0	0	6-151
3	RUN delay timer	0.00	10.00	0.00 (s)	Operation is started when the time corresponding to the setting value has elapsed from the run command.	0	0	0	0	6-151
C21 –	Retry/pick-up									
0	Number of retries	0.	10.	0.	Set the number of times to retry. Retry is not executed when set to 0.	0	0	0		6-152
1	Retry wait time	1.	30.	5. (s)	Set the time from fault occurrence to the start of retry.	0	0	0		6-152
2	Pick-up wait time	0.5	10.0	2.0 (s)	Set the time to wait before starting pick-up operation after the output has been cut off.	0	0	0		6-152
3	Pick-up current limit value	50.	300.	100. (%)	Set within the following range only if the output torque is to be limited when restarting. C21-3 setting value ≥ applicable motor exciting current +10%	0	0	0		6-153
4	V/f pick-up function selection	1.	3.	1.	Select the pick-up operation for the reverse run direction. =1: No reverse run pick-up =2: Reverse run pick-up enabled (FMAX) =3: Reverse run pick-up enabled (estimated speed)	0				6-154
5	Sensor-less pick-up function selection	1.	3.	1.	 Select the pick-up function for sensor-less vector control. =1: Reverse run pick-up disabled, start search from NMAX =2: Reverse run pick-up disabled, start search from setting value =3: Reverse run pick-up enabled, start search from NMAX 		0		0	6-154
6	Speed estimation proportional gain for sensor-less pick-up	0.00	100.00	10.00 (%)	Set the speed estimation proportional gain used for pick-up during sensor-less vector control.		0		0	6-154
7	Speed estimation integral gain for sensor-less pick-up	0.00	300.00	1.00 (%)	Set the speed estimation integral gain used for pick-up during sensor-less vector control.		0		0	6-154

No.	Parameter	Min.	Max.	Default	Function	A	oplic	catio	on	Ref.
C22 -	Overload			(Unit)		V/f	VEC	PM	RWE	page
0	Motor overload reference	50.0	105.0	100.0 (%)	Note that when this parameter is changed, Parameters C22-1 and C22-2 will automatically be adjusted to the value of this setting. Take care when decreasing and then increasing this value.	0	0	0		6-155
1	0Hz overload	20.0	105.0	100.0 (%)	The maximum value is as set on C22-2.	0	0	0		6-155
2	0.7Base freq. overload	50.0	105.0	100.0 (%)	The minimum value is as set on C22-1.	0	0	0		6-155
3	Motor overload breakdown reference	110.0	300.0	120.0 (%)	Set the trip overload breakdown reference at 1 minute. A breakdown stoppage (OL-3) will occur after 1 minute with the motor rated reference current value at this value. The default value is 150.0 when heavy-duty is set.	0	0	0		6-155
4	DBR overload	0.0	10.0	1.6 (%)	This parameter is for setting %ED of DBR operation. When DBR transistor or DBR built in the unit is used, set the parameter within the specification. When 0.0 is set, the protection function is disabled. When the external DBR unit is used, set to 0.0.	0	0	0		6-155
5	Motor power loss braking setting	0.	70.	50. (%)	This function is valid when control mode selection is C30-0:f0=1 or auxiliary drive is selected and main circuit option selection is C31-0:f0=2	0	0	0		6-156
6	Carrier frequency automatic reduction function selection	1.	2.	1.	=1: Reduction enabled =2: Reduction disabled	0	0	0	0	6-156
7	Phase failure detection function selection	11.	22.	11.	1 1. f0: Input phase failure detection function selection =1: Function valid =2: Function invalid f1: Output phase failure detection function selection =1: Function valid =2: Function invalid	0	0	0	0	6-156
C24 –	Speed detection error m	onitor		i						
0	Over speed protection level	20.0	200.0	105.0 (%)	The over speed protection operation level is set.		0	0		6-157
1	Control mode changeover during speed detection error	1.	3.	1.	 Select control at speed detection error =1: Speed detection error not monitored =2: Speed detection error monitored (Do not change to sensorless vector control) =3: Speed detection error monitored (Switch to sensorless vector control) Set whether to monitor speed detection errors, such as wire breakage of the speed detector circuit, and to change over from vector control to sensorless vector control. There will be no switch to sensorless control. In this case, select 1 or 2. 	O *1)	0	0		6-157
2	Speed detection error level	1.0	100.0	10.0 (%)	The conditions for judging the speed detection error are set. Set as $C24-2 \ge C24-3$.	0 *1)	0	0	0	6-157
3	Speed detection error recovery level	1.0	100.	5.0 (%)	When the speed detection value deviation is less than this setting value, it is determined that the speed detection has been reset properly.	0 *1)	0		0	6-157

*1) This parameter is used by simple ASR control.

No.	Parameter	Min.	Max.	Default	Function	Applicatio			n	Ref.
004				(Unit)		V/f	VEC	РМ	RWE	page
4	Control mode changeover during speed deviation error	onitor 1.	3.	1.	 Select speed deviation control error. =1: No error monitoring performed, no ALM output, no FLT output =2: Error monitoring performed, no ALM output, FLT output performed =3: Error monitoring performed, ALM output performed, no FLT output 		0	0		6-158
5	Speed deviation error level	1.0	50.0	10.0 (%)	Set the error judgment command and the deviation level for detection.		0	0	0	6-158
6	Speed deviation error judgment time	0.1	20.0	10.0 (s)	Set the time for judging speed deviation.		0	0	0	6-158
7	Reverse error detection level	0.	100.	0. (%)	Set the error detection level for when the motor rotates in the reverse direction of the speed command. Set using the base speed as 100%. The error is not detected when 0 is set.		0	0	0	6-158
C25 –	High-efficiency operation	n		·						
0	Voltage reduction time	0.1	30.0	10.0 (s)	Set the time for the output voltage to drop from the V/f setting value to 0V.	0	0	0		6-158
1	Voltage lower limit setting value	50.	100.	100. (%)	When selecting a high-efficiency operation function, set 50 to 99.	0	0	0		6-158
2	Cooling fan ON/OFF control	1.	2.	2.	 =1: ON / OFF control is enabled. FAN is ON when inverter runs. The fan runs for 10s when starting. =2: ON / OFF control is disabled. FAN is always ON. 	0	0	0		6-159
C26 –	Standard serial transmis	sion sett	ing	-						
0	Function selection	0.	1.	0.	0: Standard serial 1: MODBUS	0	0	0		6-159
1	Parameter change protection	1.	5.	1.	The parameters with a O mark below can be changed. Set-ting value Block A Block B, C Parameter Parameter Basic Extend S/W H/W 1 O O O O O 2 × × × × × × 3 O × × × × × 4 O × O × × × 5 O × O × × × 0: Changeable ×: Unchangeable ×: Unchangeable ×: Unchangeable	0	0	0		6-159
2	Station No.	0.	247.	1.	Set the local station No.	0	0	0		6-159
3	Response timer	0.00	2.00	0.00 (s)	Set the minimum time from receiving command to returning an answer.	0	0	0	0	6-159
4	CN2 standard serial communication baud rate setting	1.	7.	2.	=1: 4800 =2: 9600 =3: 14400 =4: 19200 =5: 38400 =6*: 1200 =7*: 2400 * : =6 & =7 can be used from the version 9457.0+9458.2.	0	0	0	0	6-159
5	CN2 standard serial communication stop bit setting	1.	2.	2.	=1: 1 bit =2: 2 bit	0	0	0	0	6-160
6	CN2 standard serial communication parity setting	1.	3.	3.	=1: None =2: Even =3: Odd	0	0	0	0	6-160
7	Base section serial communication frequency (speed) unit setting	0.	5.	0.	=0: 0.01Hz or 0.1min ⁻¹ unit: signed =1: 0.1Hz or 1min ⁻¹ unit: signed =2: 0.01% unit: signed =3: 0.01Hz or 0.1min ⁻¹ unit: unsigned =4: 0.1Hz or 1min ⁻¹ unit: unsigned =5: 0.01% unit: unsigned	0	0	0	0	6-160
C28 –	Password No.									
0	Password No. function valid	1.	2.	1.	=1: Function invalid =2: Function valid	0	0	0	0	6-160
1	Password No. setting	0.	9999.	0.	Set the password No. Once set the display will return to 0, so make sure not to forget the set number.	0	0	0	0	6-160

Parameter	Min.	Max.	Default	Function						'n	Ref.
Control mode selection	J	L	(Unit)				V/t	VEC	PM	RWE	page
Control mode selection	11.	25.	11.	1 1. 1 0: Th =1: =2: =3: =4: =5: f1: Th =1: =2:	le control mode is V/f control IM speed sensor- control IM speed vector of sensor PM motor control For future additio ne overload mode Normal-duty (120 Heavy-duty (150	set. -less vector control with I with sensor in is set. 1%1min) %1min)	0	0	0		6-161
Main circuit option selec	tion			1			,	,		·	
Main circuit option selection	1111.	1222.	1221.	1 2 2 1. f0: f1: f2: f3:	Motor loss braking 2=ON) DB selection (1=C OVL selection (1= (For future use)	g (1=OFF, DFF, 2=ON) =OFF, 2=ON)	0000	Δ Ο Δ	Δ Ο Δ		6-161
Ground fault detection	1.	2.	1.	=1: Enabled	=2: Disabled		0	0	0	ı	6-161
UVL proportional gain	0.00	1.00	0.00 (%)	Set the gain t the start of U The UVL fun- set. Set a value a rated slip.	for lowering the fr IVL operation. ction will be turne approx. half of the	equency at d OFF if 0 is motor's	0	0	0	0	6-161
UVL integral time constant	2.	200.	10. (ms)	Set the integr operation. Reduce the v	ral time constant i	ior UVL rs.	0	0	0	0	6-161
Output terminal function	(Option)			η			, 	— ,		— ,	
PSO4 output parameters	-55.	55.	10.				0	0	0	0	6-161
PSO5 output parameters	-55.	55.	11.	Select the se table, and ou	atting value from the trop the trop of the strength the s	ne following	0	0	0	0	6-161
PSO6 output parameters	-55.	55.	12.	-1 to -55 are	the reverse output	it of 1 to 55.	0	0	0	0	6-161
PSO7 output parameters	-55.	55.	13.				0	0	0	0	6-161
Output signal Value Output signal Fixed to OFF 8 IDE RUN 9 AT FLT 10 SPI MC 11 SPI RDY1 12 CC LCL 14 EC REV 15 EC ue Output signal RUN -9 AT RUN -9 AT RUN -9 AT RUN -11 SP MC -11 SP AT -11 SP MC -11 SP AT -12 CC B DD -9 C1 SP -12 C0 RDY1 -12 C1 SP -13 E LCL -14 S CL -15	Juit 1al Val 1 1 1 2 1 2 2 2 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Outpusigna 6 EC3 7 ACC 8 DCC 9 AUXD 10 ALM 21 FAN 22 ASW 23 ZSP	It Valu 24 24 25 25 26 27 28 29 7 30 31 -24 25 -26 29 -24 25 -26 20 -27 1 -24 25 -26 20 -26 20 -26 20 -31	e Output signal LLMT ULMT Doff-End MBRK DVER BPF RDELAY Fixed to ON e Output signal LLMT i ULMT i DOff-End 7 MBRK 3 DVER 9 BPF 9 RDELAY Fixed to ON	Value Output signal 32 PLC1 33 PLC2 34 PLC3 35 PLC4 36 PLC5 37 PLC6 38 PLC7 39 PLC8 Value Output signal -32 PLC1 -33 PLC2 -34 PLC3 -35 PLC4 -36 PLC5 -37 PLC6 -38 PLC7 -39 PLC8	Value Output s 40 FPO: 41 For future 43 For future 44 For future 45 For future 46 For future 47 For future 48 For future 49 FO 40 FOO 41 For future 42 For future 43 For future 44 For future 45 For future 46 For future 47 For future 40 FOO 41 For future 42 For future 43 For future 44 For future 45 For future 46 For future 47 For future 48 For future 49 For future	ignal S e use e use e use e use e use e use e use signal S e use e use		alue 48 49 50 51 52 53 54 48 49 -50 -51 -52 -53 -54 -55	Out sig MF MF MF MF MF MF MF MF MF MF MF MF MF	tput nal 201 202 203 204 205 206 207 206 207 208 207 208 209 209 209 209 209 209 209 209
	Parameter Control mode selection Control mode selection Control mode selection Main circuit option selection Main circuit option selection Ground fault detection function UVL proportional gain UVL proportional gain UVL integral time constant Output terminal function PSO4 output parameters PSO5 output parameters PSO6 output parameters PSO7 autput parameters PSO autput parameters PSO autput parameters	ParameterMin.Control mode selectionControl mode selection11.Control mode selection11.Main circuit option selection111.Main circuit option selection11111.Ground fault detection function1.UVL proportional gain0.00UVL proportional gain0.00UVL integral time constant2.Output terminal function0.00PSO4 output parameters-55.PSO5 output parameters-55.PSO6 output parameters-55.PSO7 output paramet	ParameterMin.Max.Control mode selectionII25.Control mode selection11.25.Main circuit option selection111.25.Main circuit option selection1111.1222.Ground fault detection function1.2.UVL proportional gain0.001.00UVL proportional gain0.001.00UVL integral time constant2.200.Output terminal function (Option) parameters-55.55.PSO4 output parameters-55.55.PSO5 output parameters-55.55.PSO6 output parameters-55.55.PSO6 output parameters-55.55.PSO7 output parameters-55.55.PSO7 output parameters-55.55.PSO7 output parameters19ATN 101017ACC REV13ECCWei Signal C13ECCWalue Signal REV13COP CWalue C13COP CWalue C13COP CWalue C13COP CWalue C14EC1 C13COP C1414EC1 C1513COP C14EC1 C1515C2AUX C20AUX C21COP C14EC1 C1415C22AUX C	Parameter Min. Max. Default (Unit) Control mode selection	Parameter Min. Max. Default (Unit) Control mode selection 1 1 6 Control mode selection 11. 25. 11. 1 Control mode selection 11. 25. 11. =3: Main circuit option selection 111. 122.1 122.1. =4: Main circuit option selection 111. 122.2. 122.1. 12.2.1. Main circuit option selection 11. 122.2. 12.1. =1: Failer fill Ground fault detection function 1. 2. 1. =1: Enabled UVL proportional gain 0.00 1.00 0.00 The UVL fun (%) set. Set the gain the start of U UVL integral time constant 2. 200. 10. Set the integ operation. Reduce the V Output terminal function (Option) FSO5 output parameters -55. 55. 10. PSO6 output parameters -55. 55. 11. Select the se atale, and ou faile, and ou failer signal 1 1 Select the se atale, and ou fa	Parameter Min. Max. Default (Unit) Function Control mode selection	Parameter Min. Max. Default (Unit) Function Control mode selection 1	Parameter Min. Max. Default (Unit) Function Ar yr Control mode selection Image: Control mode selection <thimage: control="" mode="" select<="" td=""><td>Parameter Min. Max. Default (Unit) Function Applic (v v cc) Control mode selection 1 1 1 60 1 0 0 0 Control mode selection 11. 25. 11. 1 1 1 1 0</td><td>Parameter Min. Max. Default (Unit) Function Punction Punction Control mode selection Image: Selecti</td><td>Parameter Min. Max. Default (Unit) Function Application (v) tycc/ Park were vere and park were control Control mode selection 11. 25. 11. 12.2 11. 11. 12.2 11. 11. 12.2</td></thimage:>	Parameter Min. Max. Default (Unit) Function Applic (v v cc) Control mode selection 1 1 1 60 1 0 0 0 Control mode selection 11. 25. 11. 1 1 1 1 0	Parameter Min. Max. Default (Unit) Function Punction Punction Control mode selection Image: Selecti	Parameter Min. Max. Default (Unit) Function Application (v) tycc/ Park were vere and park were control Control mode selection 11. 25. 11. 12.2 11. 11. 12.2 11. 11. 12.2

No.	Parameter	Min. Max. Default Function		A	oplic	catio	on	Ref.		
				(Unit)		V/f	VEC	PM	RWE	page
C34 –	Field network interface (PROFIBU	S)	[
0	Station number	0.	126.	1.	Set the station address.	0	0	0		
1	Transmission error detection	1.	2.	1.	Select the transmission error detection =1 : Without detection =2 : Detection (fault output) =3 : Detection (minor fault) When set =1 or COP is Off, no fault is detected and the present operation is kept even if any transmission error is occurred When set = 2 and COP is On, IO-8 or IO-9 is output for any transmission error. When set = 3 and COP is On, minor fault is output for any transmission error and the	0	0	0		
2	HOLD/CLR/Emergency stop	0.	2.	0.	inverter operation follows C34-2 setting. Set HOLD / CLEAR /Emergency stop when C34-1=3 and COP is On. =0 : Hold (hold the set value as it is) =1 : Clear (clear all the set values) =2 : Emergency stop % When emergency stop occurs, the inverter operation should be resumed after the fault reset.	0	0	0		
3	Master timeout time	0.0.	10.0	5.0	Set the master timeout time.	0	0	0		
6	Data range selection	0.	11.	0.	Select the data range for the transmission input/output data. Refer to the "Data Range Selection Table" for details.	0	0	0		6-162
C34 –	Field network interface (CC-Link)								
1	Transmission error detection	1.	2.	1.	Select the transmission error detection =1 : Without detection =2 : Detection (fault output) =3 : Detection (minor fault) When set =1 or COP is Off, no fault is detected and the present operation is kept even if any transmission error is occurred When set = 2 and COP is On, IO-8 or IO-9 is output for any transmission error. When set = 3 and COP is On, minor fault is output for any transmission error and the inverter operation follows C34-2 setting.	0	0	0		
2	HOLD/CLR/Emergency stop	0.	2.	0.	Set HOLD / CLEAR /Emergency stop when C34-1=3 and COP is On. =0 : Hold (hold the set value as it is) =1 : Clear (clear all the set values) =2 : Emergency stop % When emergency stop occurs, the inverter operation should be resumed after the fault reset.	0	0	0		
3	Master timeout time	0.0	10.0	5.0	Set the master timeout time.	0	0	0		
6	Data range selection	0.	11.	0.	Select the data range for the transmission input/output data. Refer to the "Data Range Selection Table" for details.	0	0	0		
7	CC-Link transmission version selection	1.	2.	1.	Set the version of the CC-Link transmission protocol. (For future use) (This parameter setting is invalid when using other communication options.) =1: Ver1 =2: Ver2	0	0	0		

No.	Parameter	Min.	Max.	Default (Unit)	t Function		oplic	atic	on DWC	Ref.
C34 -	Field network interface (IO link II)		(enit)		V/I	VEC	PINI	RWE	page
0	Station number	0.	126.	1.	Set the station address. 02 to 31 (Remote station)	0	0	0		
1	Transmission error detection	1.	2.	1.	Select the transmission error detection =1 : Without detection =2 : Detection (fault output) =3 : Detection (minor fault) When set =1 or COP is Off, no fault is detected and the present operation is kept even if any transmission error is occurred. When set = 2 and COP is On, IO-8 or IO-9 is output for any transmission error. When set = 3 and COP is On, minor fault is output for any transmission error and the inverter operation follows C34-2 setting.	0	0	0		
2	HOLD/CLR/Emergency stop	0.	2.	0.	 Set HOLD / CLEAR /Emergency stop when C34-1=3 and COP is On. =0 : Hold (hold the set value as it is) =1 : Clear (clear all the set values) =2 : Emergency stop ※ When emergency stop occurs, the inverter operation should be resumed after the fault reset. 	0	0	0		
3	Master timeout time	0.0	10.0	5.0	Set the master timeout time. [0.1 s/LSB]	0	0	0		
4	Transmission speed	1.	4.	1.	Set the IO link II metal transmission speed.(This parameter setting is invalid when using other communication options.)=1: 125 kbps=3: 500 kbps=2: 250 kbps=4: 1M bps	0	0	0		
5	Transmission size	1.	2.	1.	Set the IO link II transmission size. (This parameter setting is invalid when using other communication options.) =1: 16W =2: 32W	0	0	0		
6	Data range selection	0.	11.	0.	Select the data range for the transmission input/output data. Refer to the "Data Range Selection Table" for details.	0	0	0		

No.	Para	meter	Min.	Max.	Default (Unit)		Funct	ion		Aj V/f	oplio VEC	catio	on RWE	Ref. page
C50 -	Encoder set	tting	1											
0	Encoder pul output settir	se divided	1.	1023	. 4.	The pulse inp divided in ha source from speed detect Adjust the se pulse is up to	out from th lf, and outp PAOUT an ion PCB. itting value o 70kHz.	e encoder out to an ex d PBOUT so that the	can be kternal on the e output	0 *1)	0	0		6-162
1	Encoder out No. selectio	put pulse n	1.	2	. 1.	= 1 : 2-phase = 2 : 1-phase When using sensor, set w input from the or 1-phase in	e input e input vector con /hether the e encoder iput.	trol with sp number o is a 2-phas	eed f pulses se input	0 *1)	0		0	6-162
2	Encoder AB direction sel	advance ection	1.	2	. 1.	Select the ac signal input f =1: Forward	lvance dire rom the en =2: Reve	ection of the coder. rse	e AB	0 *1)	0	0		6-163
3	Encoder AB selection	Z pulse type	0.	15	. 0.	Set this only be selected v special care	when the s vith C50-2 when settin	signal type , C51-2. Ta ng.	cannot ake	0 *1)	0	0		6-163
	Setting No. 0 1 2 3 4	Setting No. A-IN1 Non invert B-IN1 Non invert Z-IN Non invert AB inter- change 0 - - - - - - - - - - - - - - - - - - - 9 Invert - - - - - - - - - - 9 Invert -									e r- e			
	5 6 7	Invert – Invert	– Invert Invert	Invert Invert Invert		13 14 15	Invert – Invert	– Invert Invert	Invert Invert Invert					
		A-IN B-IN Z-IN			AB interc	changeable → A → B → Z	T T During C	CW rotatic	on t					

*1) This parameter is used by simple ASR control.

No.		Paramete	ər	Min.	Max.	Default	Function	Aŗ	plic	atio	'n	Ref.
054						(Unit)		V/f	VEC	PM F	RWE	page
0	Encod	er setting	(יזא) אר	1.	4.	1.	Select the type of signal input from the encoder. =1: A, B, Z-phase + U, V, W-phase signal =2: A, B, Z-phase + serial absolute signal =3: A, B, Z-phase + U, V, W-phase signal (reduced wiring) =4: SIN, COS signal			0		6-163
1	AB ph select	ase-Z pha ion	se type	0	1.	0.	 =0: Normal =1: When the AB phase and Z phase edge is identical 			0		6-164
2	Encod revers	ler Z signa al	il	1.	2.	1.	Select whether to reverse the Z signal input from the encoder. =1: Do not reverse =2: Reverse			0		6-164
3	Encod directi	ler UVW a on selectio	dvance on	1.	2.	1.	Select the advance direction of the UVW signal input from the encoder. =1: Forward =2: Reverse			0		6-164
4	Z-IN – windin	→ U phase ng phase a	ingle	0.0	359.9	0.0 (°)	Electrical angle from Z-IN to U phase			0	0	6-165
5	Z-IN –	→ U phase	angle	0.0	359.9	0.0 (°)	Electrical angle from Z-IN to u phase			0	0	6-166
6	6 Encoder UVW pulse type selection			0.	7.	0.	Set this only when the signal type cannot be selected with C51-3. Take special care when setting.			0		6-164
Se	etting No.	U-IN Non invert / Invert	V-IN Non invert / Invert	W-IN Non invert / Invert	UV inter change							_ →
	1	Invert			_	V-IIV			1			_ →
	2		Invert		_	W-I						
	3	Invert	Invert		No inter	-	Lipomo Durir	ia C(CW r	otat	ion	t
	4			Invert				5	-	-		-
	5	Invert	– Invert	Invert	-							
	7	Invert	Invert	Invert	-							
7	UVW start w [For re ABZU	measurem vait time educed wir	ient	0.	1000.	2. (ms)	When using the reduced wiring ABZUVW encoder, set the time to wait from the setting of the UVW signal to the measurement of UVW. The timer functions at a 2ms cycle, so set an integer-fold of 2.			0	0	6-167
8	UVW time [For re ABZU	measurem educed wir VW]	ient ing	0.	1000.	2. (ms)	When using the reduced wiring ABZUVW encoder, set the interval to measure the UVW signal. If UVW cannot be measured within this time, a fault will be output. The timer functions at a 2ms cycle, so set an integer-fold of 2.			0	0	6-167
9	ABZ n wait tii [For re ABZU	neasureme me educed wir IVW]	∍nt start ʻing	0.	1000.	2. (ms)	When using the reduced wiring ABZUVW encoder, set the time to wait before starting control with the ABZ signal. The timer functions at a 2ms cycle, so set an integer-fold of 2.			0	0	6-167

6-5 Block-U parameters

The block-U parameters are for the utility mode.

- V/f : Indicates parameters that apply for V/f control (constant torque, variable torque) (C30-0: f0 = 1).
- VEC : Indicates parameters that apply for IM speed sensor-less vector control and IM speed vector control with sensor (C30-0: f0 = 2, 3).
- PM : Indicates parameters that apply for control mode with PM motor sensor (C30-0: f0 = 4).

RWE : Displays the parameters that can be changed during operation.

Reference page: The number of the page providing detailed explanations is indicated.

No.	Parameter	Min.	Max.	Default	Function	A	pplic	catic	n	Ref.
		I	ا 	(Unit)	<u> </u> !	V/f	VEC	PM	RWE	page
U00 –	Parameter Control	 ,	·	, 	T		. 			
0	Parameter copy function	0.	9999.	0.	The parameter copy function is executed while the inverter is stopped. = 1001 : Save The parameter data is saved from the inverter to the operation panel. = 2002 : Load The parameter data is loaded from the operation panel to the inverter. If parameter data outside the setting range, such as for a different inverter capacity, could be loaded, the settings of the parameters not within the setting range may be uncertain. In this case, always turn the power OFF and ON once. If , :: appears when the power is turned ON, enter D20-2 and set the uncertain data. = 3003 : Verify check The operation panel and inverter parameter data contents are verified and checked. If the parameters differ, :: will appear. = 4004 : Clear The parameter data of operation panel is cleared.	0	0	0		6-168
1	Password No. setting	0.	9999.	0.	by inputting the 4-digit parameter set with C28-0 in this parameter.	0	0	0		6-168

Block-U parameters (Utility mode) list

No.	Parameter	Min.	Max.	Default	Function				Ref.	
1110 -	Built-in PLC setting			(onit)		V/f	VEC	PM	RWE	page
0	No. of execution banks	0.	20.	0.	Set the number of banks to be executed at 1 bank/2ms. The built-in PLC is turned OFF when 0 is set. If a fault (CPU.B) occurs in the built-in PLC, 0 is forcibly set. Confirm the built-in PLC command and then set U10-0 again.	0	0	0	0	6-168 6-189 / 6-195
1	Built-in PLC parameter	0.	FFFF.	0. (hex)						
2	Built-in PLC parameter 2	0.	FFFF.	0. (hex)						
3	Built-in PLC parameter 3	0.	FFFF.	0. (hex)						
4	Built-in PLC parameter 4	0.	FFFF.	0. (hex)	Set the user parameters which can be used		0	0	0	6-168 6-189
5	Built-in PLC parameter 5	0.	FFFF.	0. (hex)	by the built-in PLC.	0	0	0	0	/ 6-195
6	Built-in PLC parameter 6	0.	FFFF.	0. (hex)						
7	Built-in PLC parameter 7	0.	FFFF.	0. (hex)						
8	Built-in PLC parameter 8	0.	FFFF.	0. (hex)						
U20 –	Built-in PLC command b	ank 1								
0	Command 1-0	0.	FFFF.	0. (hex)						
1	Command 1-1	0.	FFFF.	0. (hex)						
2	Command 1-2	0.	FFFF.	0. (hex)	Set the built-in PLC command					
3	Command 1-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0	0	6-169 6-189
4	Command 1-4	0.	FFFF.	0. (hex)	This is valid when U10-0 is 1 or more.	Ū	0	•	Ū	/ 6-195
5	Command 1-5	0.	FFFF.	0. (hex)						
6	Command 1-6	0.	FFFF.	0. (hex)						
7	Command 1-7	0.	FFFF.	0. (hex)						
U21 –	Built-in PLC command b	ank 1		i		1				
0	Command 1-8	0.	FFFF.	0. (hex)						
1	Command 1-9	0.	FFFF.	0. (hex)						
2	Command 1-10	0.	FFFF.	0. (hex)	Set the built-in PLC command					0.400
3	Command 1-11	0.	FFFF.	0. (hex)	 Set the built-in PLC command. The commands are executed in order from smallest number. This is valid when U10-0 is 1 or more. 		0	0	0	6-169 6-189
4	Command 1-12	0.	FFFF.	0. (hex)						/ 6-195
5	Command 1-13	0.	FFFF.	0. (hex)						
6	Command 1-14	0.	FFFF.	0. (hex)						
7	Command 1-15	0.	FFFF.	0. (hex)						

No.	Parameter	Min.	Max.	Default	Function			catio	on	Ref.
1122	Duilt in DLC command k	- and 0		(Unit)		V/f	VEC	PM	RWE	page
022 -	- Built-in PLC command r	Jank 2	1	0	1	1	 	1	<u> </u>	1
0	Command 2-0	0.	FFFF.	0. (hex)						ĺ
1	Command 2-1	0.	FFFF.	0. (hex)						
2	Command 2-2	0.	FFFF.	0. (hex)	Set the built in DLC command					
3	Command 2-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.					6-169 6-189
4	Command 2-4	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 2 or more					/ 6-195
5	Command 2-5	0.	FFFF.	0. (hex)	This is valid which o to o is 2 or more.					
6	Command 2-6	0.	FFFF.	0. (hex)						
7	Command 2-7	0.	FFFF.	0. (hex)						
U23 -	- Built-in PLC command k	bank 2								
0	Command 2-8	0.	FFFF.	0. (hex)						
1	Command 2-9	0.	FFFF.	0. (hex)						
2	Command 2-10	0.	FFFF.	0. (hex)						
3	Command 2-11	0.	FFFF.	0. (hex)	Set the built-in PLC command. The commands are executed in order from smallest number					6-169 6-189
4	Command 2-12	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 2 or more					/ 6-195
5	Command 2-13	0.	FFFF.	0. (hex)						
6	Command 2-14	0.	FFFF.	0. (hex)						
7	Command 2-15	0.	FFFF.	0. (hex)						
U24 -	- Built-in PLC command b	bank 3								
0	Command 3-0	0.	FFFF.	0. (hex)						
1	Command 3-1	0.	FFFF.	0. (hex)						
2	Command 3-2	0.	FFFF.	0. (hex)	Set the built-in PLC command					0.400
3	Command 3-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0	0	6-169 6-189
4	Command 3-4	0.	FFFF.	0. (hex)	This is valid when U10-0 is 3 or more.					/ 6-195
5	Command 3-5	0.	FFFF.	0. (hex)						
6	Command 3-6	0.	FFFF.	0. (hex)						
7	Command 3-7	0.	FFFF.	0. (hex)						

No.	Parameter	Min.	Max.	Default	Function	A	ppli	catio	on	Ref.
1105		bank 9	ــــــ ا	(Unit)		V/f	VEC	PM	RWE	page
U25 -	- Built-in PLC command b	bank 3	I		1	1	<u> </u>	 	<u> </u>	rl
0	Command 3-8	0.	FFFF.	(hex)						
1	Command 3-9	0.	FFFF.	0. (hex)						
2	Command 3-10	0.	FFFF.	0. (hex)	Set the built in DLC command					
3	Command 3-11	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.					6-169 6-189
4	Command 3-12	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 3 or more	Ŭ		Ŭ		/ 6-195
5	Command 3-13	0.	FFFF.	0. (hex)	THIS IS VAILU WHEN O TO-0 15 5 OF THORE.					
6	Command 3-14	0.	FFFF.	0. (hex)						
7	Command 3-15	0.	FFFF.	0. (hex)					$\left \right ^{1}$	
U26 -	- Built-in PLC command I	bank 4			•					
0	Command 4-0	0.	FFFF.	0. (hex)					\square	
1	Command 4-1	0.	FFFF.	0. (hex)						
2	Command 4-2	0.	FFFF.	0. (hex)						
3	Command 4-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number					6-169 6-189
4	Command 4-4	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 4 or more	U		U		/ 6-195
5	Command 4-5	0.	FFFF.	0. (hex)						
6	Command 4-6	0.	FFFF.	0. (hex)						
7	Command 4-7	0.	FFFF.	0. (hex)						
U27 -	- Built-in PLC command k	bank 4								
0	Command 4-8	0.	FFFF.	0. (hex)					Ē	
1	Command 4-9	0.	FFFF.	0. (hex)						
2	Command 4-10	0.	FFFF.	0. (hex)	Set the built_in PLC command					
3	Command 4-11	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0		6-169 6-189
4	Command 4-12	0.	FFFF.	0. (hex)	This is valid when U10-0 is 4 or more	Ŭ		Ŭ		/ 6-195
5	Command 4-13	0.	FFFF.	0. (hex)						
6	Command 4-14	0.	FFFF.	0. (hex)						
7	Command 4-15	0.	FFFF.	0. (hex)						

No.	Parameter	Min.	Max.	Default	Function	A	pplic	catio	Ref.	
1120	Duilt in DLC command k			(Unit)		V/f	VEC	PM	RWE	page
U30 -	- Built-in PLC command r	bank 5		0	1	1	 	1	<u> </u>	1
0	Command 5-0	0.	FFFF.	(hex)						ĺ
1	Command 5-1	0.	FFFF.	0. (hex)						
2	Command 5-2	0.	FFFF.	0. (hex)	Set the built in DLC command					
3	Command 5-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.					6-169 6-189
4	Command 5-4	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 5 or more	Ŭ				/ 6-195
5	Command 5-5	0.	FFFF.	0. (hex)	THIS IS Valid when 0 10-0 is 5 or more.					
6	Command 5-6	0.	FFFF.	0. (hex)						
7	Command 5-7	0.	FFFF.	0. (hex)						
U31 -	- Built-in PLC command k	bank 5								
0	Command 5-8	0.	FFFF.	0. (hex)						
1	Command 5-9	0.	FFFF.	0. (hex)						
2	Command 5-10	0.	FFFF.	0. (hex)						
3	Command 5-11	0.	FFFF.	0. (hex)	Set the built-in PLC command. The commands are executed in order from smallest number					6-169 6-189
4	Command 5-12	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 5 or more	0	0	0		/ 6-195
5	Command 5-13	0.	FFFF.	0. (hex)						
6	Command 5-14	0.	FFFF.	0. (hex)						
7	Command 5-15	0.	FFFF.	0. (hex)						
U32 -	- Built-in PLC command b	bank 6								
0	Command 6-0	0.	FFFF.	0. (hex)						
1	Command 6-1	0.	FFFF.	0. (hex)						
2	Command 6-2	0.	FFFF.	0. (hex)	Set the built-in PLC command					0.400
3	Command 6-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0	0	6-169 6-189
4	Command 6-4	0.	FFFF.	0. (hex)	This is valid when U10-0 is 6 or more.					/ 6-195
5	Command 6-5	0.	FFFF.	0. (hex)						
6	Command 6-6	0.	FFFF.	0. (hex)						
7	Command 6-7	0.	FFFF.	0. (hex)						

No.	Parameter	Min.	Max.	Default	Function	Application			Ref.		
1122	Duilt in DLC command b	and C	<u> </u>	(Unit)		V/f	VEC	PM	RWE	page	
033 -	U33 – Built-in PLC command bank 6										
0	Command 6-8	0.	FFFF.	(hex)							
1	Command 6-9	0.	FFFF.	0. (hex)							
2	Command 6-10	0.	FFFF.	0. (hex)	Set the huilt_in PLC command					6-169 6-189	
3	Command 6-11	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0			
4	Command 6-12	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 6 or more					/ 6-195	
5	Command 6-13	0.	FFFF.	0. (hex)							
6	Command 6-14	0.	FFFF.	0. (hex)							
7	Command 6-15	0.	FFFF.	0. (hex)							
U34 -	- Built-in PLC command b	bank 7									
0	Command 7-0	0.	FFFF.	0. (hex)					\square		
1	Command 7-1	0.	FFFF.	0. (hex)				0		6-169 6-189 / 6-195	
2	Command 7-2	0.	FFFF.	0. (hex)	Set the built-in PLC command. The commands are executed in order from smallest number. This is valid when U10-0 is 7 or more.		0				
3	Command 7-3	0.	FFFF.	0. (hex)					0		
4	Command 7-4	0.	FFFF.	0. (hex)							
5	Command 7-5	0.	FFFF.	0. (hex)							
6	Command 7-6	0.	FFFF.	0. (hex)							
7	Command 7-7	0.	FFFF.	0. (hex)							
U35 -	- Built-in PLC command b	bank 7									
0	Command 7-8	0.	FFFF.	0. (hex)	Set the built-in PLC command. The commands are executed in order from smallest number. This is valid when U10-0 is 7 or more.		0	0	0	6-169 6-189 / 6-195	
1	Command 7-9	0.	FFFF.	0. (hex)		0					
2	Command 7-10	0.	FFFF.	0. (hex)							
3	Command 7-11	0.	FFFF.	0. (hex)							
4	Command 7-12	0.	FFFF.	0. (hex)							
5	Command 7-13	0.	FFFF.	0. (hex)							
6	Command 7-14	0.	FFFF.	0. (hex)							
7	Command 7-15	0.	FFFF.	0. (hex)							

No.	Parameter	Min.	Max.	Default (Unit)	Function		pplie	Ref.			
							VEC	PM	RWE	page	
U36 -	U36 – Built-in PLC command bank 8										
0	Command 8-0	0.	FFFF.	0. (hex)	Set the built-in PLC command. The commands are executed in order from smallest number. This is valid when U10-0 is 8 or more.						
1	Command 8-1	0.	FFFF.	0. (hex)							
2	Command 8-2	0.	FFFF.	0. (hex)		0	0	0	0	6-169 6-189 / 6-195	
3	Command 8-3	0.	FFFF.	0. (hex)							
4	Command 8-4	0.	FFFF.	0. (hex)					0		
5	Command 8-5	0.	FFFF.	0. (hex)							
6	Command 8-6	0.	FFFF.	0. (hex)							
7	Command 8-7	0.	FFFF.	0. (hex)							
U37 -	Built-in PLC command b	ank 8		-		_	_				
0	Command 8-8	0.	FFFF.	0. (hex)	Set the built-in PLC command. The commands are executed in order from smallest number. This is valid when U10-0 is 8 or more.						
1	Command 8-9	0.	FFFF.	0. (hex)							
2	Command 8-10	0.	FFFF.	0. (hex)		0	0	0	0	6-169 6-189 / 6-195	
3	Command 8-11	0.	FFFF.	0. (hex)							
4	Command 8-12	0.	FFFF.	0. (hex)							
5	Command 8-13	0.	FFFF.	0. (hex)							
6	Command 8-14	0.	FFFF.	0. (hex)							
7	Command 8-15	0.	FFFF.	0. (hex)							

No.	Parameter	Min.	Max.	Default	Function	Application		Ref.			
				(Unit)		V/f	VEC	PM	RWE	page	
U40 -	- Built-in PLC command r	bank 9	1	1	1	—	 	—	 		
0	Command 9-0	0.	FFFF.	0. (hex)							
1	Command 9-1	0.	FFFF.	0. (hex)							
2	Command 9-2	0.	FFFF.	0. (hex)	Set the built in DLC command					6-169 6-189 / 6-195	
3	Command 9-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.						
4	Command 9-4	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 9 or more				Ŭ		
5	Command 9-5	0.	FFFF.	0. (hex)							
6	Command 9-6	0.	FFFF.	0. (hex)							
7	Command 9-7	0.	FFFF.	0. (hex)							
U41 – Built-in PLC command bank 9											
0	Command 9-8	0.	FFFF.	0. (hex)							
1	Command 9-9	0.	FFFF.	0. (hex)							
2	Command 9-10	0.	FFFF.	0. (hex)	Set the built-in PLC command. The commands are executed in order from smallest number					6-169 6-189 / 6-195	
3	Command 9-11	0.	FFFF.	0. (hex)							
4	Command 9-12	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 9 or more						
5	Command 9-13	0.	FFFF.	0. (hex)							
6	Command 9-14	0.	FFFF.	0. (hex)							
7	Command 9-15	0.	FFFF.	0. (hex)							
U42 -	- Built-in PLC command k	bank 10									
0	Command 10-0	0.	FFFF.	0. (hex)							
1	Command 10-1	0.	FFFF.	0. (hex)						6-169 6-189 / 6-195	
2	Command 10-2	0.	FFFF.	0. (hex)	Set the built-in PLC command. The commands are executed in order from smallest number. This is valid when U10-0 is 10 or more.						
3	Command 10-3	0.	FFFF.	0. (hex)		0	0	0	0		
4	Command 10-4	0.	FFFF.	0. (hex)							
5	Command 10-5	0.	FFFF.	0. (hex)							
6	Command 10-6	0.	FFFF.	0. (hex)							
7	Command 10-7	0.	FFFF.	0. (hex)							
No.	Parameter	Min.	Max.	Default	Function	A	pplic	catio	on	Ref.	
-----	--------------------------	---------	-------	-------------	---	-----	--	-------	-----	----------------	
		ليبيل	-	(Unit)		V/f	VEC	PM	RWE	page	
U43	- Built-in PLC command t	bank 10	r	1	1	1	 	1	1		
0	Command 10-8	0.	FFFF.	0. (hex)							
1	Command 10-9	0.	FFFF.	0. (hex)							
2	Command 10-10	0.	FFFF.	0. (hex)	Sot the built in PLC command						
3	Command 10-11	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0			6-169 6-189	
4	Command 10-12	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 10 or more					/ 6-195	
5	Command 10-13	0.	FFFF.	0. (hex)							
6	Command 10-14	0.	FFFF.	0. (hex)							
7	Command 10-15	0.	FFFF.	0. (hex)							
U44	- Built-in PLC command I	oank 11									
C	Command 11-0	0.	FFFF.	0. (hex)							
1	Command 11-1	0.	FFFF.	0. (hex)							
2	Command 11-2	0.	FFFF.	0. (hex)							
3	Command 11-3	0.	FFFF.	0. (hex)	Set the built-in PLC command. The commands are executed in order from smallest number					6-169 6-189	
4	Command 11-4	0.	FFFF.	0. (hex)	This is valid when 1110.0 is 11 or more					/ 6-195	
5	Command 11-5	0.	FFFF.	0. (hex)							
6	Command 11-6	0.	FFFF.	0. (hex)							
7	Command 11-7	0.	FFFF.	0. (hex)							
U45	- Built-in PLC command k	oank 11									
C	Command 11-8	0.	FFFF.	0. (hex)		Γ					
1	Command 11-9	0.	FFFF.	0. (hex)							
2	Command 11-10	0.	FFFF.	0. (hex)	Set the built in PLC command						
3	Command 11-11	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0	0	6-169 6-189	
4	Command 11-12	0.	FFFF.	0. (hex)	This is valid when U10-0 is 11 or more					/ 6-195	
5	Command 11-13	0.	FFFF.	0. (hex)							
6	Command 11-14	0.	FFFF.	0. (hex)							
7	Command 11-15	0.	FFFF.	0. (hex)							

No.	Parameter	Min.	Max.	Default	Function	Α	pplie	catio	on	Ref.
				(Unit)		V/f	VEC	PM	RWE	page
U46 –	Built-in PLC command b	pank 12		-		i —	i —			
0	Command 12-0	0.	FFFF.	0. (hex)						
1	Command 12-1	0.	FFFF.	0. (hex)						
2	Command 12-2	0.	FFFF.	0. (hex)	Sot the built in PLC command					
3	Command 12-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0	0	6-169 6-189
4	Command 12-4	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 12 or more	Ŭ		Ŭ	Ŭ	/ 6-195
5	Command 12-5	0.	FFFF.	0. (hex)						
6	Command 12-6	0.	FFFF.	0. (hex)						
7	Command 12-7	0.	FFFF.	0. (hex)						
U47 –	Built-in PLC command b	oank 12								
0	Command 12-8	0.	FFFF.	0. (hex)						
1	Command 12-9	0.	FFFF.	0. (hex)						
2	Command 12-10	0.	FFFF.	0. (hex)	Sot the built in PLC command					
3	Command 12-11	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0	0	6-169 6-189
4	Command 12-12	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 12 or more	Ŭ	Ŭ	U	U	/ 6-195
5	Command 12-13	0.	FFFF.	0. (hex)						
6	Command 12-14	0.	FFFF.	0. (hex)						
7	Command 12-15	0.	FFFF.	0. (hex)						

No.	Parameter	Min.	Max.	Default	Function	A	pplic	catio	on	Ref.
				(Unit)		V/f	VEC	РМ	RWE	page
U50 -	- Built-in PLC command b	pank 13	r		t	1	r—	+	 	
0	Command 13-0	0.	FFFF.	0. (hex)						
1	Command 13-1	0.	FFFF.	0. (hex)						
2	Command 13-2	0.	FFFF.	0. (hex)	Set the built in PLC command			ļ		
3	Command 13-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0			6-169 6-189
4	Command 13-4	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 13 or more					/ 6-195
5	Command 13-5	0.	FFFF.	0. (hex)				ļ		
6	Command 13-6	0.	FFFF.	0. (hex)						
7	Command 13-7	0.	FFFF.	0. (hex)						
U51 -	- Built-in PLC command b	ank 13	<u> </u>						<u> </u>	
0	Command 13-8	0.	FFFF.	0. (hex)						
1	Command 13-9	0.	FFFF.	0. (hex)						
2	Command 13-10	0.	FFFF.	0. (hex)						
3	Command 13-11	0.	FFFF.	0. (hex)	Set the built-in PLC command. The commands are executed in order from					6-169 6-189
4	Command 13-12	0.	FFFF.	0. (hex)	This is valid when 1110.0 is 12 or more	0	0	0	0	/ 6-195
5	Command 13-13	0.	FFFF.	0. (hex)	THIS IS VAIID WHEN UTU-UTS TO UT HIDLE.					
6	Command 13-14	0.	FFFF.	0. (hex)						
7	Command 13-15	0.	FFFF.	0. (hex)						
U52 -	- Built-in PLC command b	bank 14								
0	Command 14-0	0.	FFFF.	0. (hex)						
1	Command 14-1	0.	FFFF.	0. (hex)						
2	Command 14-2	0.	FFFF.	0. (hex)	Sat the built in PLC command					
3	Command 14-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0		6-170 6-189
4	Command 14-4	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 14 or more	Ŭ				/ 6-195
5	Command 14-5	0.	FFFF.	0. (hex)						
6	Command 14-6	0.	FFFF.	0. (hex)						
7	Command 14-7	0.	FFFF.	0. (hex)						

No.	Parameter	Min.	Max.	Default	Function	A	pplie	catio	on	Ref.
				(Unit)		V/f	VEC	РМ	RWE	page
U53 -	- Built-in PLC command b	bank 14			t	+	1	+	 	
0	Command 14-0	0.	FFFF.	0. (hex)						
1	Command 14-1	0.	FFFF.	0. (hex)						
2	Command 14-2	0.	FFFF.	0. (hex)	Set the built in DLC command			ļ		
3	Command 14-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.		0			6-170 6-189
4	Command 14-4	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 14 or more					/ 6-195
5	Command 14-5	0.	FFFF.	0. (hex)						
6	Command 14-6	0.	FFFF.	0. (hex)						
7	Command 14-7	0.	FFFF.	0. (hex)						
U54 -	- Built-in PLC command t	bank 15	-						<u> </u>	
0	Command 15-0	0.	FFFF.	0. (hex)				ļ		
1	Command 15-1	0.	FFFF.	0. (hex)						
2	Command 15-2	0.	FFFF.	0. (hex)						
3	Command 15-3	0.	FFFF.	0. (hex)	Set the built-in PLC command. The commands are executed in order from smallest number					6-170 6-189
4	Command 15-4	0.	FFFF.	0. (hex)	This is valid when 1110_0 is 15 or more	U	0			/ 6-195
5	Command 15-5	0.	FFFF.	0. (hex)						
6	Command 15-6	0.	FFFF.	0. (hex)						
7	Command 15-7	0.	FFFF.	0. (hex)						
U55 -	- Built-in PLC command t	bank 15								
0	Command 15-8	0.	FFFF.	0. (hex)						
1	Command 15-9	0.	FFFF.	0. (hex)						
2	Command 15-10	0.	FFFF.	0. (hex)	Set the built in PLC command					
3	Command 15-11	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0		6-170 6-189
4	Command 15-12	0.	FFFF.	0. (hex)	This is valid when U10-0 is 15 or more					/ 6-195
5	Command 15-13	0.	FFFF.	0. (hex)						
6	Command 15-14	0.	FFFF.	0. (hex)						
7	Command 15-15	0.	FFFF.	0. (hex)						

No.	Parameter	Min.	Max.	Default	Function	Α	pplie	catio	on	Ref.
				(Unit)		V/f	VEC	PM	RWE	page
U56 –	Built-in PLC command b	pank 16		-		i —	i —			
0	Command 16-0	0.	FFFF.	0. (hex)						
1	Command 16-1	0.	FFFF.	0. (hex)						
2	Command 16-2	0.	FFFF.	0. (hex)	Set the built in PLC command					
3	Command 16-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0	0	6-170 6-189
4	Command 16-4	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 16 or more	Ŭ	Ŭ	0	0	/ 6-195
5	Command 16-5	0.	FFFF.	0. (hex)						
6	Command 16-6	0.	FFFF.	0. (hex)						
7	Command 16-7	0.	FFFF.	0. (hex)						
U57 –	Built-in PLC command b	oank 16								
0	Command 16-8	0.	FFFF.	0. (hex)						
1	Command 16-9	0.	FFFF.	0. (hex)						
2	Command 16-10	0.	FFFF.	0. (hex)	Sot the built in PLC command					
3	Command 16-11	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0	0	6-170 6-189
4	Command 16-12	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 16 or more	Ŭ	Ŭ	U	0	/ 6-195
5	Command 16-13	0.	FFFF.	0. (hex)						
6	Command 16-14	0.	FFFF.	0. (hex)						
7	Command 16-15	0.	FFFF.	0. (hex)						

No.	Parameter	Min.	Max.	Default	Function	A	ppli	catio	on	Ref.
				(Unit)		V/f	VEC	РМ	RWE	page
U60 -	- Built-in PLC command b	pank 17	ı		t	+		+	 	
0	Command 17-0	0.	FFFF.	0. (hex)						
1	Command 17-1	0.	FFFF.	0. (hex)						
2	Command 17-2	0.	FFFF.	0. (hex)	Set the built in DLC command					
3	Command 17-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.		0			6-170 6-189
4	Command 17-4	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 17 or more					/ 6-195
5	Command 17-5	0.	FFFF.	0. (hex)						
6	Command 17-6	0.	FFFF.	0. (hex)						
7	Command 17-7	0.	FFFF.	0. (hex)						
U61 -	- Built-in PLC command b	ank 17							<u> </u>	
0	Command 17-8	0.	FFFF.	0. (hex)					Γ	
1	Command 17-9	0.	FFFF.	0. (hex)						
2	Command 17-10	0.	FFFF.	0. (hex)						
3	Command 17-11	0.	FFFF.	0. (hex)	Set the built-in PLC command. The commands are executed in order from					6-170 6-189
4	Command 17-12	0.	FFFF.	0. (hex)	This is valid when 110.0 is 17 or more	0	0	0	0	/ 6-195
5	Command 17-13	0.	FFFF.	0. (hex)	THIS IS Valid when 0 to o is in or more.					
6	Command 17-14	0.	FFFF.	0. (hex)						
7	Command 17-15	0.	FFFF.	0. (hex)						
U62 -	- Built-in PLC command b	ank 18				<u> </u>		·	·	
0	Command 18-0	0.	FFFF.	0. (hex)						
1	Command 18-1	0.	FFFF.	0. (hex)						
2	Command 18-2	0.	FFFF.	0. (hex)	Cat the built in DLC command					
3	Command 18-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.		0			6-170 6-189
4	Command 18-4	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 18 or more					/ 6-195
5	Command 18-5	0.	FFFF.	0. (hex)						
6	Command 18-6	0.	FFFF.	0. (hex)						
7	Command 18-7	0.	FFFF.	0. (hex)						

No.	Parameter	Min.	Max.	Default	Function	Α	pplie	catio	on	Ref.
				(Unit)		V/f	VEC	PM	RWE	page
U63 -	Built-in PLC command b	pank 18		i		1	1	1	i	
0	Command 18-8	0.	FFFF.	0. (hex)						
1	Command 18-9	0.	FFFF.	0. (hex)						
2	Command 18-10	0.	FFFF.	0. (hex)	Sat the built in DLC command					
3	Command 18-11	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number		0	0	0	6-170 6-189
4	Command 18-12	0.	FFFF.	0. (hex)	This is valid when 1110.0 is 18 or more		Ŭ	Ŭ	0	/ 6-195
5	Command 18-13	0.	FFFF.	0. (hex)						
6	Command 18-14	0.	FFFF.	0. (hex)						
7	Command 18-15	0.	FFFF.	0. (hex)						
U64 -	Built-in PLC command b	bank 19								
0	Command 19-0	0.	FFFF.	0. (hex)						
1	Command 19-1	0.	FFFF.	0. (hex)						
2	Command 19-2	0.	FFFF.	0. (hex)						
3	Command 19-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number				0	6-170 6-189
4	Command 19-4	0.	FFFF.	0. (hex)	This is valid when 1110.0 is 10 or more		0	0	0	/ 6-195
5	Command 19-5	0.	FFFF.	0. (hex)						
6	Command 19-6	0.	FFFF.	0. (hex)						
7	Command 19-7	0.	FFFF.	0. (hex)						
U65 -	Built-in PLC command b	oank 19								
0	Command 19-8	0.	FFFF.	0. (hex)						
1	Command 19-9	0.	FFFF.	0. (hex)						
2	Command 19-10	0.	FFFF.	0. (hex)	Sot the built in PLC command					
3	Command 19-11	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0	0	6-170 6-189
4	Command 19-12	0.	FFFF.	0. (hex)	This is valid when U10-0 is 19 or more					/ 6-195
5	Command 19-13	0.	FFFF.	0. (hex)						
6	Command 19-14	0.	FFFF.	0. (hex)						
7	Command 19-15	0.	FFFF.	0. (hex)						

No.	Parameter	Min.	Max.	Default	Function	A	pplie	catio	on	Ref.
				(Unit)		V/f	VEC	РМ	RWE	page
U66 –	Built-in PLC command b	pank 20		i			i —			
0	Command 20-0	0.	FFFF.	0. (hex)						
1	Command 20-1	0.	FFFF.	0. (hex)						
2	Command 20-2	0.	FFFF.	0. (hex)	Sat the built in DLC command					
3	Command 20-3	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0	0	6-170 6-189
4	Command 20-4	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 20	U	Ŭ	0	U	/ 6-195
5	Command 20-5	0.	FFFF.	0. (hex)						
6	Command 20-6	0.	FFFF.	0. (hex)						
7	Command 20-7	0.	FFFF.	0. (hex)						
U67 –	Built-in PLC command b	oank 20								
0	Command 20-8	0.	FFFF.	0. (hex)						
1	Command 20-9	0.	FFFF.	0. (hex)						
2	Command 20-10	0.	FFFF.	0. (hex)	Sot the built in PLC command					
3	Command 20-11	0.	FFFF.	0. (hex)	The commands are executed in order from smallest number.	0	0	0	0	6-170 6-189
4	Command 20-12	0.	FFFF.	0. (hex)	This is valid when 1110-0 is 20	U	Ŭ	0	U	/ 6-195
5	Command 20-13	0.	FFFF.	0. (hex)						
6	Command 20-14	0.	FFFF.	0. (hex)						
7	Command 20-15	0.	FFFF.	0. (hex)						

6-6 Function explanation

6-6-1 Explanation of monitor parameters (Block-D parameter) functions

D00-0	
D00-1	

Output frequency in Hz

Output frequency in %

This indicates the frequency currently being output. With D00-1, the maximum frequency is indicated as 100%. $\Box \models \Box$ will display when the gate is closed. $\Box \models$ displays while the DC brake is in action. $\Box \downarrow$ is displayed during pick-up.

D00-2
D00-3

Motor speed in min⁻¹

Motor speed in %

This indicates the current motor speed.

(This is displayed even when operation is stopped.)

With D00-3, the maximum speed is indicated as 100%.

The motor forward run is indicated with a positive polarity, and reverse run is indicated with a negative polarity.

D00-4

Output frequency/motor speed random scale display

The result of the C14-2 random scale display coefficient multiplied by the D00-0: output frequency is displayed for V/f control operation or auxiliary drive operation, and the random scale display coefficient multiplied by the D00-2: motor speed is displayed for IM vector control and PM motor control.

If the value exceeds the range of -99999 to 99999, "OVER." will be displayed.

D00-5

Motor rotation count in %

The motor speed detected with the speed detection option is displayed as a percentage in respect to the maximum speed.

If the speed detection option is provided, the motor speed is displayed even during V/f control or sensor-less vector control.



Set frequency in Hz

Set frequency in %

The currently selected frequency setting value is displayed With D01-1, the maximum frequency is displayed as 100%.

D01-2

Ramp function output speed in min⁻¹

The set speed at ASR input point is displayed. The motor forward run is indicated with a positive polarity, and reverse run is indicated with a negative polarity.

D01-3

Ramp function input speed in min⁻¹

The set speed at the ramp function's input point is displayed. The motor forward run is indicated with a positive polarity, and reverse run is indicated with a negative polarity.

D01-4

Set frequency/input speed Random scale display

The result of the C14-2 random scale display coefficient multiplied by the D01-0: set frequency is displayed for V/f control operation or auxiliary drive operation, and the random scale display coefficient multiplied by the D01-3: ramp function input speed is displayed for IM vector control and PM motor control.

If the value exceeds the range of -99999 to 99999, "OVER." will be displayed.

D02-0
D02-1

Output current in Amps

Output current in %

The output current is displayed. With D02-1, the motor rated current is displayed as 100%. $\Box \subseteq \Box$ will display when the gate is closed.



Overload (OL-1) monitor

If the output current exceeds the unit's rated current, the display value counts up from 0%. In the normal-duty mode (Normal-duty, C30-0 f1 = 1), the display counts up at rate of 120%/minute in respect to the unit's rated current. In the heavy-duty mode (Heavy-duty, C30-0 f1 = 2), the display counts up at a rate of 150%/minute.

When this display value reaches 100%, a fault "OL-1" (unit overload) occurs.

(Note) The unit rated current value differs for the normal-duty mode and heavy-duty mode. Check the levels in Appendix Table 1.

D02-3

Motor overload (OL-3) monitor

If the output current exceeds the motor overload reference set with C22-0 to C22-3, the display counts up from 0%.

When this display value reaches 100%, a fault "OL-3" (motor overload) occurs.

D02-4

Heatsink temperature in °C

The heat sink temperature is displayed.

If this temperature exceeds the fault judgment value, the fault "UOH.1" (overheat) will occur. The fault judgment temperature is either 95°C or 120°C, depending on the capacity.

D02-5

Torque current detection in %

The output current detection value's torque current element is displayed using the motor rated current as 100%.

The polarity is positive during forward run drive, negative during forward run regeneration, negative during reverse run drive, and positive during reverse run regeneration.

D02-6

Excitation current detection in %

During the IM vector control mode, the output current detection value's excitation current element is displayed using the motor rated current as 100%.

During the PM motor control mode, the output current detection value's weak magnetic field current element is displayed using the motor rated current as 100%. This is a negative polarity while the weak magnetic field current is passing.

D02-7	
D02-8	
D02-9	

U phase output current in Amps

V phase output current in Amps

W phase output current in Amps

The output current of each phase is displayed. 금두두 will display when the gate is closed. The correct value is not displayed during pick-up or during automatic tuning.

D03-0 DC voltage in V

The voltage value of the DC middle circuit in the inverter's main circuit is displayed.

D03-1

Output voltage (command) in V

The output current command value is displayed. The display may differ from the actual output voltage. It depends on the power supply voltage. $\Box \in F$ will display when the gate is closed.

D03-2

Output power in kW

The output current command value is displayed. The display may differ from the actual output voltage. It depends on the power supply voltage. EFF will display when the gate is closed.

D03-3

Carrier frequency in kHz

The current carrier frequency is displayed. When the carrier frequency automatic reduction function is activating, the carrier frequency after reduction is displayed.

D04-0~3 Sequence status-Input

The ON/OFF status of the input sequence data is displayed. Each segment of the LED and the signal correspond as shown below.





Sequence input (D04-1)



Sequence input (D04-2)

Sequence input (D04-3)

(Note) The D04-0 to 7 and D05-0, 1 displays are examples of the LED operation panel (U30V240P2).

The following display appears on the LCD operation panel (U30V240P1).





Sequence status-Output

The ON/OFF status of the output sequence data is displayed. Each segment of the LED and the signal correspond as shown below.



Sequence output (D04-4)





Sequence output (D04-5)



Sequence output (D04-6)





Current inverter drive pump No. monitor

This displays the number of the pump currently driven by the inverter.

Next ON pump No. monitor

0 is displayed when all pumps are ON.

Next OFF pump No. monitor

0 is displayed when all pumps are OFF.



Elapsed time in h

The time that the pump currently driven by the inverter has stayed ON continuously is displayed. This is cleared when the pump operation changes over.

D08-0 D08-1 D08-2

Analog input random scale display/Al1 Analog input random scale display/Al2 Analog input random scale display/Al3

The result of the AI1, 2, 3 setting multiplied by the coefficient set in C14-5, 6, 7 is displayed. If the value exceeds the range of -99999 to 99999, "OVER." will be displayed.

D10-0	Built-in PLC display 1
D10-1	Built-in PLC display 2
D10-2	Built-in PLC display 3
D10-3	Built-in PLC display 4

The details of address 36 to 39 of the built-in PLC memory are displayed.



Torque setting input monitor in %

The currently selected torque setting of the current control input points is selected. This is displayed as a percentage in respect to the motor's rated torque.

D11-1

Analog torque setting monitor in %

The setting value input from the analog torque setting is displayed. If the sequence input ACR is ON and the torque setting input point selection C02-2 is set to 1, the torque command value will be displayed here. This is displayed as a percentage in respect to the motor's rated torque.

D11-2

Serial communication torque setting monitor in %

The setting value input from the serial communication torque setting is displayed. If the sequence input ACR is ON and the torque setting input point selection C02-2 is set to 2, the torque command value will be displayed here. This is displayed as a percentage in respect to the motor's rated torque.

D11-3

Operation panel torque setting monitor in %

The torque setting value (B13-0) input from the operation panel is displayed. If the sequence input ACR is ON and the torque setting input point selection C02-2 is set to 3, the torque command value will be displayed here. This is displayed as a percentage in respect to the motor's rated torque.



The Z-phase electric angle is displayed. Use this to adjust the Z-phase when using magnetic pole position estimation.

D16-0	Magnetic pole position estimation: Judgment standard 1 (PM motor drive)
D16-1	Magnetic pole position estimation: Judgment standard 2 (PM motor drive)
D16-2	Magnetic pole position estimation: Judgment standard 3 (PM motor drive)
D16-3	Magnetic pole position estimation: Judgment standard 4 (PM motor drive)

These parameters are used to adjust the magnetic pole position estimation function. Refer to section 3-4-4 for details.

D20-0

Fault history monitor

The fault history reference mode is entered by pressing the $\left(\underbrace{\text{LCL}}_{\text{SET}} \right)$ key. The details are shown below.

Fault history No.	Displayed details	Explanation		
E * 0	Details of primary fault	The error code for the primary fault cause is displayed.		
E * 1	Details of secondary fault	The error code for the fault occurring secondarily is displayed.		
E * 2	Output frequency at fault occurrence	Displayed with 0.01Hz unit.		
E * 3	Output current value at fault occurrence	Displayed with 0.1A unit.		
E * 4	DC voltage value at fault occurrence	Displayed with 1V unit.		
E * 5	Hardware detection fault at fault occurrence	Display item is same as D05-1.		
E * 6	Cumulative power ON time at fault occurrence	Displayed with 1 hour unit.		
E * 7	Cumulative operation time at fault occurrence	Displayed with 1 hour unit.		

(Note) A number between 0 and 3 is substituted for * in the table to indicate faults up to three prior faults. * = 0 indicates the latest fault. Refer to section 4-2-8 LCD Panel and section 4-3-7 LED Panel for details on operations in this mode.

D20-1 Minor failure past record indication

Press the $\begin{pmatrix} LCL \\ SET \end{pmatrix}$ key to enter the minor fault history reference mode. The details are shown below.

Fault history No.	Displayed details	Explanation		
M * 0	Current minor fault	The newly detected minor fault is displayed as shown below.		
M * 1	All minor faults	All minor faults at M*0 occurrence are displayed as shown below.		
M * 2	Output frequency at fault occurrence	Displayed with 0.01Hz unit.		
M * 3	Output current value at fault occurrence	Displayed with 0.1A unit.		
M * 4	DC voltage value at fault occurrence	Displayed with 1V unit.		
M * 5	Hardware detection fault at fault occurrence	Display item is same as D05-0.		
M * 6	Cumulative power ON time at fault occurrence	Displayed with 1 hour unit.		
M * 7	Cumulative operation time at fault occurrence	Displayed with 1 hour unit.		

(Note) A number between 0 and 3 is substituted for * in the table to indicate faults up to three prior faults. * = 0 indicates the latest fault.





D20-2

Parameter A, B and C modification list entry

Press $\begin{pmatrix} ILL \\ SEI \end{pmatrix}$ to enter the mode for referring to and changing parameters which differ from the default values.

D21-0

Cumulative conductivity time

The inverter power ON time after product shipment is counted and shown with a 1-hour unit.

D21-1

Cumulative run time

The inverter operation time after product shipment is counted and shown with a 1-hour unit.



CPU version

ROM version

Display for maker control.

D22-0

Automatic tuning progression display

The progress of automatic tuning is displayed as shown below.



Lower line: Indication of steps required for tuning. (LED light) Lower line: Indication of completed steps. (LED light) The flicker indicates the step currently being executed.

D30-0

Inverter type

The inverter capacity type is displayed.



Option PCB

The mounted optional PCB is displayed. Each segment of the LED corresponds to the optional PCB as shown below.



Option P.C.B. monitor (D30-1)

6-6-2 Explanation of Block-A parameter functions

A00-0	
A00-2	

Local frequency setting

Local speed setting

This is the frequency (V/f control mode) and speed (other control modes) set with the operation panel.

(Note 1) The operation panel speed change operation is set to "change at real time" (C11-2=1) as the factory setting, so the frequency and speed will change in real

time when the () keys (LED panel) are pressed or () knob (LCD panel)

are turned even without pressing the $\binom{\text{LL}}{\text{SET}}$ key. If the $\binom{\text{LL}}{\text{SET}}$ key is pressed, the setting value at that point will be saved.

(Note 2) This frequency and speed setting is validated when the speed setting input point is set in the panel. Refer to section 5-9-1 for details on the speed setting input point.

A00-1	
A00-3	

Jogging frequency

Jogging speed

This is the frequency (V/f control mode) and speed (other control modes) for carrying out jogging with the sequence command F.JOG and R.JOG.

A01-0, 1
A03-0~2
C01-0, 1

Acceleration/deceleration time - 1

DC brake setting

Start/stop frequency

• For V/f control mode (C30-0 f0=1)



A01-1 sets the acceleration time from stop to the maximum frequency, and A01-1 sets the deceleration time from the maximum frequency to stopping. This is the acceleration/deceleration ramp time which is valid when the sequence command CSEL is OFF (factory setting). If the time is too short, the operation could trip with an overcurrent or overvoltage, so set an appropriate value which matches the motor and load inertia.

(Note) The acceleration/deceleration time for jogging (F.JOG, R.JOG) is set with the B10-2, 3 setting value.

For A03-0: DC brake voltage setting, set the output voltage for DC braking at stopping as a percentage in respect to the motor rated voltage.

This parameter is automatically adjusted with automatic tuning (mode 1 and mode 2).

When adjusting this parameter, monitor the output current and adjust in increments of 1% or less. An excessive setting could result in tripping.

* Refer to section 3-4-1 for details on automatic tuning in the V/f control mode.

- For A03-1: DC brake time setting, set the time for carrying out DC braking during operation stop. If this parameter is 0.0, the motor will stop without DC braking.
- C01-0: Start frequency setting is the output frequency setting value for starting operation. The output frequency is increased from this setting value.

When the output frequency reaches the C01-1:

Stop frequency setting when decelerating after the operation stop command (RUN=OFF), DC braking operation will start. When not using DC braking (A03-1 = 0.0), the motor will stop when this setting value is reached.

 For IM sensor-less vector control, IM vector control with sensor, PM motor control mode (C03-0 f0 = 2 to 4)



A01-1 sets the acceleration time from stop to the maximum frequency, and A01-1 sets the deceleration time from the maximum frequency to stopping. This is the acceleration/deceleration ramp time which is valid when the sequence command CSEL is OFF (factory setting). If the time is too short, the operation could trip with an overcurrent or overvoltage, so set an appropriate value which matches the motor and load inertia.

- (Note) The acceleration/deceleration time for jogging (F.JOG, R.JOG) is set with the B10-2, 3 setting value.
- For A03-1: DC brake time setting, set the time for carrying out DC braking during operation stop.

When the speed reaches the zero speed detection level (C15-4) setting value or less while decelerating after the operation stop command (RUN=OFF), DC braking will start. If this parameter is set to 0.0, the motor will stop without DC braking.

For A03-2: DC brake current setting sets the current value output during DC braking.

A02-0

Manual torque boost selection

This parameter selects the manual torque boost function.

This function is valid when A02-0 is set to 2, and is invalid when A02-0 is set to 1. When manual torque boost is selected, the manual torque boost setting will be valid regardless of the automatic torque boost selection state.

A02-1

Automatic torque boost selection

This parameter selects the automatic torque boost function.

This function is valid when A02-1 is set to 2, and is invalid when A02-1 is set to 1.

When automatic torque boost is selected, the R1 drop compensation, slip compensation and maximum torque boost functions will be valid.

- (Note 1) To validate only the slip compensation function when manual torque boost is selected, set all settings other than the slip compensation function (A02-5) to 0 (set A02-3, 4, 6 to 0).
- (Note 2) The square reduction torque setting is always valid regardless of the torque boost selection state.

To invalidate the square reduction torque setting, set (A02-3) to 0.



Torque boost selection block diagram

Automatic torque boost function

The automatic torque boost function carries out voltage boosting and slip compensation using the current detection value. This allows the torque to be improved when starting and at low speed regions. By carrying out automatic turning, the gain, etc., for the automatic torque boost function will be automatically adjusted. Using this function, a 200% starting torque can be output with a standard 3-phase induction motor during a 150% output current. Even with a motor that cannot output a 200% torque due to design, the maximum torque of the motor can be output. The main characteristics with the standard 3-phase induction motor are shown below.







Manual torque boost setting [%]

This parameter is automatically adjusted with automatic tuning (mode 1 and mode 2). When adjusting this parameter, set the boost voltage at 0Hz as a percentage in respect to the rated output voltage (B00-3).

* Refer to section 3-4-1 for details on automatic tuning in the V/f control mode.

A02-3

Square reduction torque setting [%]



When both A02-2 and A02-3 are set, the voltage will be added as shown below.

A02-4

R1 drop compensation gain [%]

Set how much to compensate the voltage drop caused by R1 (B02-0, 1: Motor primary resistance value) measured with automatic tuning. Normally set 100% of the default value.

- (Note 1) If the setting is too high, the rotation may become unstable, and the inverter may trip.
- (Note 2) Sufficient torque might not be attained if the setting is too small.

A02-5

Slip compensation gain [%]

This parameter is automatically adjusted with automatic tuning (mode 2).

When setting manually, set the slip frequency for the motor rated load as a percentage in respect to the base frequency (B00-5). The output frequency changes

according to the motor rated torque as shown below.



- (Note 1) The output frequency will respond with a time constant of approx. 500ms in respect to the changes in the load torque.
- (Note 2) When set too high, the motor rotation could become instable.
- * Refer to section 3-4-1 for details on automatic tuning in the V/f control mode.

A02-6

Maximum torque boost gain [%]

This parameter is automatically adjusted with automatic tuning (mode 2). Set the optimum boost amount for the maximum torque output as a percentage in respect to the rated output voltage (B00-3).

Normally, a value of 10 to 30% is set by automatic tuning.

- (Note 1) When adjusted manually, the sufficient torque may not be attained.
- (Note 2) If set too high, the rotation may become unstable and may trip.

* Refer to section 3-4-1 for details on automatic tuning in the V/f control mode.

A04-0~7

Custom parameters

C10-0~7: The parameters selected with the custom parameter selection can be displayed. This parameter does not appear if this setting is not made. Refer to section 4-4 for details.

A05-0~2

Parameter B and C indicatory skip

The parameter display is skipped for each function in the extended functions, software option functions and hardware option functions.

Unnecessary displays can be reduced with this parameter, allowing operation to be simplified.

All displays are set to skip as the default.

A10-0 ASR response

This is used to calculate the gain of the ASR.

The computing expression for the ASR gain and integral time constant is shown below. ASR gain :

Kp = ASR response (A10-0) [rad/s] × Machine time constant Tm (A10-1 or B15-0) [ms] 1000

ASR integral time constant :

$$Ti = \frac{4}{\text{ASR response (A10-0) [rad/s]}} \times \frac{\text{Compensation coefficient (A10-2)[%]}}{100}$$

A10-1

Machine constant – 1

This is used to calculate the ASR gain. This parameter is valid when the sequence command MCH is OFF. The B15-0 setting value is valid when MCH is ON.

 $Tm [msec] = \frac{10.97 \text{ x } \text{J } [\text{kgm}^2] \text{ x } (\text{Nbase}[\text{min}^{-1}])^2}{Power [W]} \qquad Tm \quad : \text{ Machine time constant} \\ J \quad : \text{ Total inertia } (=1/4 \text{ X } \text{GD}^2[\text{kgfm}^2]) \\ \text{Nbase : Base speed} \end{cases}$

Power : Motor rated output

ASR integral time constant compensation coefficient

Set the compensation coefficient for the ASR integral time constant calculated with ASR response (A10-0). Refer to the computing expression for the ASR integral time constant and set.

ASR drive torque limiter

ASR regenerative torque limiter

ASR emergency stop regenerative torque limiter

ACR drive torque limiter

ACR regenerative torque limiter

Set the limit value for each torque limiter in ASR control.

If the sequence command ACR is OFF, the A10-3 and A10-4 setting values are the torque limit value, and if ACR is ON, the A11-2 and A11-3 setting values are the torque limit value. If the emergency stop method is set to deceleration stop (C00-4=3) and the sequence command EMS turns ON, the A10-5 setting value will be the torque limit value. The acceleration/deceleration time may be longer than the set value depending on these torque limiter values.

(Note) The inverter output current is limited by the overcurrent limit value (B18-0), so the torque may not be generated until the value set in this parameter is reached.

A11-0

ACR response (vector control with IM sensor, sensor-less vector control)

Set the response angle frequency for the current regulator (ACR) with a [rad/s] unit. If this setting value is too high or too low, the current will become unstable, and the overcurrent protection will function.

A11-1

ACR time constant (vector control with IM sensor, sensor-less vector control)

Set the time constant for the current regulator (ACR). If the time constant is too long or too short, the current will become unstable, and the overcurrent protection will function.

A10-3
A10-4
A10-5
A11-2
A11-3

A10-2

A20-0 ACR response (PM motor control)

Set the response angle frequency for the current regulator (ACR). If the ACR response is too high, hunting will occur at a cycle of several ms. If it is too low, the gain for the speed control system cannot be high. Normally, this should be set between 500 and 1500rad/s.

A20-1

ACR time constant (PM motor control)

Set the time constant for the current regulator (ACR). If the time constant is too long or too short, the current will become unstable, and the overcurrent protection will function. Normally, this should be set between 5 and 20ms.



d axis current command cushion time in ms/I1 (PM motor control) q axis current command cushion time in ms/I1 (PM motor control)

This is the cushion setting to prevent instability caused by overshooting, etc., when the current command changes suddenly. Set at how many ms to change the current command value equivalent to the motor rated current. Normally, a value 5ms or more is set.

6-6-3 Explanation of Block-B parameter functions

B00-0	
B01-0	

Rated input voltage setting

B00-0 is used to select the rated input voltage from the following table in the V/f control mode (C30-0 f_0 = 1), and B01-0 is used to select the rated input voltage in all other control modes (C30-0 f_0 = 2 to 4).

B00-0 or B00-1 Setting value	200V system	400V system	B00-0 or B00-1 Setting value	200V system	400V system
1	to 200V	to 380V	1	to 200V	to 380V
2	to 200V	381 to 400V	2	to 200V	381 to 400V
3	201 to 220V	401 to 415V	3	201 to 220V	401 to 415V
4	201 to 220V	416 to 440V	4	201 to 220V	416 to 440V
5	221 to 230V	441 to 460V	5	221 to 230V	441 to 460V
6	231 to 240V	461 to 480V	6	231 to 240V	461 to 480V
7	221 to 230V	381 to 400V	7	221 to 230V	381 to 400V

Small (X000K7 to X055K0, N000K7 to N045K0) Large size (X075K0 or more)

When the B00-0 setting value is changed (when parameter change is entered and $\frac{LL}{SET}$ key is pressed), the B00-3 setting value is changed to the same value. In the same manner, if B01-0 is changed, the B01-3 setting value is changed.

B00-1

Max./base frequency simple setting

The base frequency and maximum frequency combination can be selected as shown below. To set a combination not shown in the table, set B00-1 to 0.

Value	Ftrq [Hz]	Fmax [Hz]		
0	Free setting on B00-4 and B00-5			
1	50	50		
2	60	60		
3	50	60		
4	50	75		

Value	Ftrq [Hz]	Fmax [Hz]
5	50	100
6	60	70
7	60	80
8	60	90
9	60	120

B00-2
B01-1

Motor rated output

Select the motor's rated output at the base frequency and rotation speed.

B01-2

No. of motor poles

Set the number of poles indicated on the motor nameplate.

B00-3	
B01-3	

Motor rated voltage

Set the rated voltage indicated on the motor nameplate.

If B00-3 is set to 39, the output voltage at the base frequency will be the input voltage.

If a value other than 39 is set, the output voltage at the base frequency will be controlled to the value set with this parameter.

If the rated input voltage setting (B00-0, B01-0) is changed, this value is also changed to the rated input voltage value. This cannot be set higher than the rated input voltage.

B00-4
B01-4
B00-5
B01-5

Max. frequency (Fmax)

Max. speed (Nmax)

Motor rated frequency (Fbase)

Base speed (Nbase)

Set the motor's base/maximum frequency and speed.

• V/f control mode (C30-0 f0 = 1)

Set B00-4, B00-5. This parameter setting is valid only when B00-1 is set to 0.

The B00-5 minimum value is B00-4/7 Hz or 1.0 Hz, whichever is larger, and the maximum value is B00-4 Hz or 440.0 Hz, whichever is smaller.

The B00-4 minimum value is B00-5 Hz or 3.0 Hz, whichever is larger, and the maximum value is B00-5x7 Hz or 440.0 Hz, whichever is smaller.

• IM sensor-less vector control mode (C30-0 f0 = 2)

Set B01-4, B01-5. The B01-5 minimum value is B01-4/2 or 150 min⁻¹, whichever is larger, and the maximum value is B01-4 or 9999 min⁻¹, whichever is smaller.

The B01-4 minimum value is B01-5 or 150 min⁻¹, whichever is larger, and the maximum value is B01-5x2 or 9999 min⁻¹, whichever is smaller. And the maximum value is determined by the number of motor poles. The speed is limited where the synchronous frequency is 180Hz.

• IM vector control with sensor mode (C30-0 f0 = 3)

Set B01-4, B01-5. The B01-5 minimum value is B01-4/4 or 150 min⁻¹, whichever is larger, and the maximum value is B01-4 or 9999 min⁻¹, whichever is smaller.

The B01-4 minimum value is B01-5 or 150 min⁻¹, whichever is larger, and the maximum value is B01-5x4 or 9999 min⁻¹, whichever is smaller. And the maximum value is determined by the number of motor poles. The speed is limited where the synchronous frequency is 180Hz.

• PM motor control mode (C30-0 f0 = 4)

Set B01-4, B01-5. The B01-5 minimum value is B01-4/1.5 or 150 min⁻¹, whichever is larger, and the maximum value is B01-4 or 9999 min⁻¹, whichever is smaller.

The B01-4 minimum value is B01-5 or 150 min⁻¹, whichever is larger, and the maximum value is B01-5x1.5 or 9999 min⁻¹, whichever is smaller. And the maximum value is determined by the number of motor poles. The speed is limited where the synchronous frequency is 210Hz.

B00-6 B01-6

Motor rated current

Set the rated current indicated on the motor nameplate.

This is the reference for the overcurrent limit, motor overload standard and analog output, etc.

(Note) The minimum of this parameter is a value of "inverter rating current \times 0.3 in a Heavy-Duty overload setting".

B00-7 B01-7

Carrier frequency

The PWM carrier frequency and control method can be changed to change the tone of the magnetic sound generated from the motor. The relation of the setting range and control method is shown below.

- 1) For X000K7~X055K0, N000K7~N045K0
 - 1.0 to 15.0 : Mono sound method (Actual carrier frequency: 1.0 to 15.0kHz)
 - 15.1 to 18.0 : Soft sound method 1 (Basic carrier frequency: 2.1 to 5.0kHz)
 - 18.1 to 21.0 : Soft sound method 2 (Basic carrier frequency: 2.1 to 5.0kHz)

2) For X075K0 and larger

- 1.0 to 8.0 : Mono sound method (Actual carrier frequency: 1.0 to 8.0kHz)
- 8.1 to 11.0 : Soft sound method 1 (Basic carrier frequency: 2.1 to 5.0kHz)
- 11.1 to 14.0 : Soft sound method 2 (Basic carrier frequency: 2.1 to 5.0kHz)

[Mono sound method]

This control method has a constant PWM carrier frequency. When a low carrier frequency is set, an annoying magnetic sound may be generated.

[Soft sound method]

This control method changes the PWM carrier frequency at a set cycle. As the frequency elements of the magnetic sound is dispersed, the tone is similar to a cicada. If the beat sound that is generated due to the operation frequency is annoying, there may be cases when the beat sound can be suppressed by changing between method 1 and 2.

- (Note 1) When the carrier frequency automatic reduction function is used, the carrier frequency may be reduced automatically by 2.0kHz depending on the output current or inverter temperature. This function is valid only when c22-6 is set to 1. The reduction function is enabled as the factory setting. The setting value and actual carrier frequency may differ, so check the actual carrier frequency with D03-3. The reduction conditions according to each capacity are shown below.
 - X000K7 to X005K5, N000K7 to N005K5 When the power module temperature exceeds 110°C, the carrier frequency is automatically decreased by 2.0kHz.
 - X007K5 to X022K0, N007K5, N011K0 When the power module temperature exceeds 85°C, the carrier frequency is automatically decreased by 2.0kHz.
 - X030K0 or more, N015K0 or more When the heat sink temperature exceeds 75°C and the output current is 110% or more of the inverter rating, or when the heat sink temperature exceeds 95°C, the carrier frequency is automatically decreased by 2.0kHz.
 - * Check the power module and heat sink temperature with D02-4.
- (Note 2) If the output voltage is low (output frequency is low), the actual carrier frequency may be lower than the set carrier frequency. Check the actual carrier frequency with D03-3.
- (Note 3) There are cases when the effect of noise onto the inverter's peripheral devices can be reduced by lowering the carrier frequency.
- (Note 4) If set to higher than the specified carrier frequency, the output current must be deleted. Refer to Fig. 1-2 and Fig. 1-3 in Appendix 1 for details.

B01-8 No. of encoder pulses

The number of pulses per rotation of the encoder in use is set.

B01-9 No-loa

No-load output voltage

The The motor terminal voltage during no-load at the base speed is set.

B02-0~9

Motor circuit constant (IM)

The IM equivalence circuit: T type and T-I type equivalence circuit, and the T type equivalence circuit \rightarrow T-I type equivalence circuit conversion expression is shown below.



$$L\sigma = (\lambda_1 + M) - M^2 / (\lambda_2 + M)$$
$$R_2' = \left(\frac{M}{\lambda_2 + M}\right)^2 \cdot R_2$$

With the VAT300, the circuit constants for the T-I type equivalence circuit are set. The parameters set according to the circuit constants are shown below.

Symbol	Name	Setting parameter
R1	Primary resistance	B02-0, B02-1
R2'	Secondary resistance	B02-2, B02-3
Lσ	Leakage inductance	B02-4, B02-5
M'	Excitation inductance	B02-6, B02-7
Rm	Iron loss resistance	B02-8, B02-9

Note 1) Set the circuit constant as a one-phase value converted into a 3-phase Y connection.

Note 2) If the wiring is long, add the wiring path resistance and inductance elements to the motor constants.

Note 3) Iron loss resistance uses Rm of T type equivalence circuit.

Of these parameters, B02-0 to B02-7 can be automatically adjusted with automatic tuning. Refer to Chapter 3 for details on automatic tuning.

If automatic tuning is not possible, and for the iron loss resistance: B02-8, 9, refer to the above diagram and expression, and the motor design value, and set the appropriate value.

B03-0~5

Motor circuit constant (PM)

Refer to section 6-9-3 for details on setting the PM motor circuit constants.

B05-0~5 Fre

Frequency skip

By setting this parameter, the motor's mechanical resonance point at a specific frequency can be skipped. Valid only during V/f control. Refer to the following diagram, and set each parameter.



(Note) This function controls the frequency setting, so the above skip frequency area will be passed with a ramp function.

B06-0~E

Ratio interlock setting

The ratio interlock operation executes the following expression and corresponds to each speed setting input signal.



(Ratio interlock bias increace/decreace function)

- When IVLM turns ON, the bias value increaced or decreaced by BUP/BDW is added to the ratio interlock bias value (B') as the above (B").
- If BUP turns ON while IVLM is ON, the bias increace/decreace buffer value (B") increaces with the currently valid acceleration ramp rate. When BDW turns ON, the bias increace/decreace buffer value (B") decreaces with the currently valid deceleration ramp rate.
- If both BUP and BDW turn OFF while IVLM is ON, the current bias increace/decreace buffer value (B") is held.
- If IVLM turns OFF, the current bias increace/decreace buffer value (B") is cleared to zero, and the BUP and BDW operations are ignored.
- Even when the operation command (RUN) turns OFF, the current bias increace/decreace buffer value (B") is cleared to zero. The BUP and BDW operations are also ignored in this case.

		Bias (B)		
	Coefficient (A)	During V/f control	During IM vector, PM motor control	
Analog speed setting 1	B06-0	B06-1	B06-2	
Analog speed setting 2	B06-3	B06-4	B06-5	
Analog speed setting 3	B06-6	B06-7	B06-8	
Serial speed setting	B06-9	B06-A	B06-B	
Pulse train input speed setting	B06-C	B06-D	B06-E	

The frequency and speed setting to which the ratio interlock setting is applied, and the set parameters are shown below.

Refer to section 5-9-1 for details on selecting the frequency and speed setting value.

- (Note 1) If the frequency and speed command value is incremented or decremented by this function, the upper limit and lower limit are the maximum frequency and speed.
- (Note 2) When using the auxiliary drive function, this function is automatically passed, and cannot be used.

B07-0~3

Upper/Lower limit setting

Set the upper limit and lower limit for the frequency and speed command value. This setting is valid for all speed command values including analog inputs and serial inputs.

	During V/f control	During IM vector control, PM motor control
Upper limit setting value	B07-0	B07-2
Lower limit setting value	B07-1	B07-3

B10-0	
B10-1	
B10-2	
B10-3	

Acceleration ramp time –2

Deceleration ramp time –2

Acceleration ramp time for jogging

Deceleration ramp time for jogging

The acceleration/deceleration ramp time can be switched by turning the sequence command CSEL ON. Set the CSEL command input terminal with C03-9.

The ramp time for jogging (F•JOG, R•JOG) can be set independently with B10-2 and -3.



(Note) The ramp time is set as the acceleration/deceleration time for 0Hz to maximum frequency (B00-4) and 0 to maximum speed (B01-4) in either case.

B10-4

S-shape characteristics



Acceleration/deceleration with the S-shape pattern is possible by setting this parameter.

This parameter indicates the time of the section shown with ts above. The total acceleration/deceleration times ta and tb will not change. When this parameter is set, all acceleration and deceleration will be as shown above.

(Note 1) Set so that the relation of the B10-4 setting and acceleration/deceleration time is as shown below.

B10-4 Setting value (ts) $\times 2 \le$ acceleration/deceleration time (ta, tb)

(Note 2) When the rotation direction command has been changed, or when the polarity of the frequency or speed command value has ben reversed, the zero frequency and zero speed are passed through. The acceleration/deceleration time will be smaller than the set acceleration/deceleration ramp time (ta, tb).

B10-5

Time unit multiplier

The acceleration/deceleration time setting unit can be changed when an acceleration/ deceleration time in a wider range is to be set.

B10-5 = 1 (standard): × 1 2 : × 0.1 3 : × 10

This parameter will affect all acceleration/deceleration time parameters.

B10-6

S-shape ramp pass function

This function is valid only when the external brake function selection is turned ON with B46-0. If this parameter is validated when using the S-shape ramp function (when B10-4 setting value is not 0), the S-shape will be passed during specific operations, and instead the normal ramp operation will take place.

B10-6 = 1 This function is disabled.

- = 2 The S-shape is passed when the program frequency setting function is used and the sequence command S0 to SE is selecting the B11-0 frequency.
- = 3 S-shape is used only during the acceleration at the start of operation or acceleration/deceleration when the frequency is changed. The S-shape is passed in all other cases.



mode

Program frequency (speed) setting Selection mode setting

This is the frequency • speed setting for when running program run (multi-step frequency • speed setting) by turning the sequence command PROG ON. Set B11-0 to B11-7 using the maximum frequency (B00-4) or maximum speed (B01-4) as 100%. When using the auxiliary drive function, set each maximum frequency setting value as 100%.

The set frequency and speed are selected according to the following table by sequence command S0, S1, S2, S3, SE and B11-8.

(1) For binary mode (B11-8 = 1)

Sequence command					Selected	
SE	S3	S2	S1	S0	frequency	
		OFF	OFF	OFF	B11-0	
		OFF	OFF	ON	B11-1	
* *	OFF	ON	OFF	B11-2		
	OFF	ON	ON	B11-3		
	ON	OFF	OFF	B11-4		
	ON	OFF	ON	B11-5		
		ON	ON	OFF	B11-6	
		ON	ON	ON	B11-7	

* : SE and S3 are not used.

(2) For direct select mode (B11-8 = 2)

Sequence command					Selected	
SE	S3	S2	S1	S0	frequency	
OFF	OFF	OFF	OFF	OFF	Previous values	
OFF	OFF	OFF	OFF	ON	B11-0	
OFF	OFF	OFF	ON	OFF	B11-1	
OFF	OFF	ON	OFF	OFF	B11-2	
OFF	ON	OFF	OFF	OFF	B11-3	
ON	OFF	OFF	OFF	OFF	Previous values	
ON	OFF	OFF	OFF	ON	B11-4	
ON	OFF	OFF	ON	OFF	B11-5	
ON	OFF	ON	OFF	OFF	B11-6	
ON	ON	OFF	OFF	OFF	B11-7	

When S0 to S3 are all OFF, or when two or more are set between S0 and S3, the previous values will be held. If there are no previous values because the power has been turned ON, etc., "0" will be set.



Program run example (When RUN is ON)

Set the sequence command PROG input terminal with C04-0. Set the S0, S1, S2, S3 and SE input terminals with C04-2 to C04-6.

The B11-8 setting is also reflected on the program ramp function (B41-x, B42-x) program mode settings.

B12-0~6

Automatic braking on power failure function

The decelerate at power failure function is valid when B12-0 is set to 2. This setting is also applied when using the auxiliary drive function. This function executes the following operations automatically.

- Operation starts when a power failure occurs, and the DC voltage drops below the value (%) set with B12-1.
- (2) The value set with B12-4 is subtracted from the output voltage when the power failure occurs, and is set as the output frequency.
- (3) Note that if the output frequency at the power failure is less than the value set with B12-5, the value will not be subtracted.
- (4) The motor decelerates to the frequency set with B12-6 at the time set with B12-2.
- (5) The motor decelerates and stops at the time set with B12-3.
- (6) Note that if the frequency set with B12-6 is less than the stop frequency, the motor will decelerate and stop at the time set with B12-2.
- (Note 1) Once this operation is started, the VAT300 will continue this even after the power is restored.
- (Note 2) To restart after stopping, cancel the RUN command once.
- (Note 3) The "FWD", "REV" and "STOP" commands during this operation are invalid from both the operation panel and sequence terminal block. "EMS" is valid.



When using the auxiliary drive function, substitute the parameter No. as shown below, and set according to each auxiliary drive mode.

(Note 4) When using this function and the auxiliary drive function during vector control or PM motor control, set B12-0 and B12-1.

Main drive	Auxiliary drive 0	Auxiliary drive 1	Auxiliary drive 2	Auxiliary drive 3
B12-2	B23-0	B27-0	B2B-0	B2F-0
B12-3	B23-1	B27-1	B2B-1	B2F-1
B12-4	B23-2	B27-2	B2B-2	B2F-2
B12-5	B23-3	B27-3	B2B-3	B2F-3
B12-6	B23-4	B27-4	B2B-4	B2F-4

B13-0 Torque setting

This is the torque set by the operation panel.

This setting value is used as the torque command value when C02-2 is set to 3 (default value).

Refer to section 5-9-2 for details on selecting the torque setting.



Torque ratio 1 setting

Set the torque ratio for the panel parameter (B13-0). Refer to section 5-9-5 for details on selecting the torque ratio 1 setting.

B13-2

Torque bias 1 setting

Set the torque bias for the panel parameter (B13-0). Refer to section 5-9-3 for details on selecting the torque bias 1 setting.



Torque ratio 2 setting

Refer to section 5-9-6 for details on selecting the torque ratio 2 setting.



Double rating speed ratio setting

Refer to section 5-9-4 for details.

-100%

B13-5

Drooping setting

Set the drooping value within the range of the following expression. If it becomes unstable, adjust the drooping setting value or the related parameters.

Torque command

value

Drooping setting value (B13-5) [%] 100 [%] Machine time constant (A10-1 or B15-0) [ms] 1000 Motor speed [min⁻¹] Drooping setting value (B13-5) [%] × Base speed (B01-5) [min⁻¹] Set speed

100%


ASR gain compensation in constant power range

ACR gain compensation in constant power range

This setting compensates the ASR and ACR gain in the constant output range (speed above base speed).

Refer to the following diagram and set the ASR gain compensation with B13-6 and the ACR gain compensation with B13-7.



B13-8, 9 Linear torque limit

Refer to section 6-9-5 for details on these parameters.

B14-0

ASR dead band setting

A dead band zone can be set for the speed control amplifier input with this parameter. Set this dead band zone parameter as a percentage in respect to the base speed. Refer to Fig. 5-3 for details on the speed control.

B15-0

Machine time constant 2

This is used to calculate the ASR amplifier gain. When the relay input machine time constant changeover is ON (MCH is ON), the machine time constant set with this parameter is valid.

 $\label{eq:transform} \mbox{Tm [msec] = 10.97 \times \frac{J \mbox{[kg•m^2] \times (Nbase[min^{-1}])^2}}{Power \mbox{[W]}} \mbox{Tm} : \mbox{Machine time constant} \\ \mbox{J} : \mbox{Total inertia (=1/4 \times GD^2 \mbox{[kgfm^2]})} \\ \mbox{Nbase : Base speed} \\ \mbox{Power : Motor rated output} \end{array}$

When MCH is OFF, the A10-1 (machine time constant -1) setting value is valid.

B16-0~B Automatic torque bias control

This function is used to apply torque bias from the start of operation based on the load feedback prior to operation. This prevents rotation due caused by the load that results when releasing the elevator brake. Either analog or digital load feedback can be selected.

Auto torque bias control calculates the torque bias value from the load feedback (digital/analog). The torque bias is then fixed when performing operation. The torque bias does not vary during operation, and is revised gradually during stoppage.

(1) Setting the automatic torque bias function

When the load feedback is obtained as a digital value using a limit switch, etc., use the digital torque bias.

When the load feedback is obtained as an analog value, use the analog torque bias. Refer to the following diagram and set B16-0.



(2) Selecting the torque bias direction

The torque bias direction can be selected with B16-6. If the motor forward runs when the elevator rises, set B16-6 to 1. If the motor reverse runs, set B16-6 to 2.

(3) Setting the parameters for digital torque bias selection

The torque bias value is set with the digital input using sequence inputs S5 to S7 as shown below.



Set the torque bias value with B16-1 to B16-5.

Set the input terminals for the S5 to S7 signals with C05-0 to 2 as shown below.

Sequence input	Setting parameter
S5	C05-0
S6	C05-1
S7	C05-2

(4) Setting the parameters for analog torque bias selection

When the load feedback is obtained as an analog value, use the analog torque bias. Set the analog torque bias input terminals (AI1, AI2, AI3) with C07-A. Set the voltage and current input, full scale and filter time constants for the input terminals used with C12-0 to C12-A.

Refer to the following diagram and set B16-7 to B. B16-7 to 9 (analog bias voltage) is set as a ratio in respect to the full scale of the input terminal being used.







V/f middle point

When using a motor with special V/f characteristics, the special V/f characteristics can be set as shown below by using this function.



V/f characteristics when using middle V/f function

Normal V/f characteristics

Set B17-B to 2 to use this function.

Refer to the upper left diagram, and set the frequency and voltage in B17-0 to A. Set the voltage as a percentage in respect to the motor rated voltage (B00-3).

If this function is OFF (normal V/f control), the base frequency will be 100% voltage (motor rated voltage), and the maximum frequency will be 100% voltage as shown in the upper right diagram.

When using four or less V/f changeover points, set the setting value to "0.00" in the order of B17-0 \rightarrow B17-2 \rightarrow B17-4 \rightarrow B17-6.

If all of the frequency settings (B17-0, 2, 4, 6, 8) are set to "0.00", the V/f characteristics will be the 100% voltage (motor rated voltage) at the base frequency, and the B17-A setting voltage at the maximum frequency.

A setting example is shown below.



When using 3 V/f changeover points

When not setting a V/f changeover point

The range for each frequency setting value is limited so that the relation B17-0 \leq B17-2 \leq B17-4 \leq B17-6 \leq B17-8 \leq B00-4 is established.

(Note) The V/f middle point function cannot be used with the auxiliary drive function.

B18-0	Over current limit
B18-3	Over current limit function gain
B18-4	Current stabilization gain
B18-5	Over current stall prevention gain
B18-6	Over current stall prevention time constant
B18-7	Drive current limit level 2
B18-8	Drive current limit level 3

The over current limit is a function that lowers the output frequency and suppresses the current so that the motor current does not exceed this parameter setting value during starting or constant running. The setting uses the motor rated current (B00-6) as 100%.

(Note) Set a value larger than the motor no-load current.

The overcurrent limit function is configured of the following three control blocks.



(1) Overcurrent vector limit function

This uses the overcurrent as a vector, and generates a suppressing voltage vector instantly to suppress the current. The response is adjusted with the over current limit gain (B18-3).

Normally, set the default value (0.25).

If the setting value is increased, the response will become faster, but the operation may become unstable.

(2) Current stabilization control

This suppresses the sudden changes in the current phase during overcurrent suppression by controlling the output frequency. The response is adjusted with the over current stabilization gain (B18-4).

Normally, set the default value (0.25).

If the setting value is increased, the torque vibration will be reduced, but the operation may become unstable.

(3) Frequency compensation control

This feeds back the voltage suppressed with the overcurrent vector limit function to the frequency command and prevents stall. The response is adjusted with the over current stall prevention gain (B18-5) and over current stall prevention time constant (B18-6).

Normally, set the default value (B18-5 = 1.00, B18-6 = 100). If the gain setting value (B18-5) is increased or the time constant value (B18-6) is decreased, the response will become faster, but the operation may become unstable.

(Note) The overcurrent limit function is valid at all times regardless of whether automatic tuning has been executed.

B18-1 Re

B18-2

Regenerative current limit

The regenerative torque to deceleration running is limited. Set to 10% when not using the DB option, calculate the value with the following formula and set. V_2

B18-1 setting value = $\left[\left(\frac{VZ}{DBR \text{ resistance value}} \right) / \text{Motor capacity [kW]} \right] \times 100 [\%]$

where V2=148.2 for the 200V system and V2=593 for the 400V system.

Torque stabilization gain

This function suppresses the hunting phenomenon that causes the current to abnormally vibrate during motor operation.

Normally, the default value (1.00) is set, but increase the setting value in increments of approx. 0.05 according to the state of hunting.

Please return to regulated value (1.00) of a set value once, and reduce it by carving about 0.05 when the hunting phenomenon is not controlled even in case of maximum value (4.00). Note that the hunting phenomenon occurs easily in the following cases.

- During a light load or no load
- · When the system inertia is low
- · When the motor's secondary time constant is high (high-efficiency motor)
- When carrier frequency is high

(Note) The hunting phenomenon at a frequency exceeding 66Hz cannot be suppressed.

B19-0 Automatic tuning function

Refer to Chapter 3 for details on automatic tuning

B19-1	
B19-2	

Initial proportion compensation gain (Automatic tuning function) Initial time constant compensation gain (Automatic tuning function)

When the motor with special circuit parameters is applied, the initial condition of automatic tuning is set. Change these value if auto tuning is completed incorrectly and try to auto tuning again. Set these values to increase or decrease with 50% step.

B20-0 -B2F-4

Various settings for auxiliary drive 0 to 3

Refer to section 6-10 for details on the auxiliary drive function.

B30-0
B30-1

Load torque observer gain

Model machine time constant

B30-0 sets the observer gain for the load torque observer.To increase the responsiveness of the external disturbance response characteristics, set a large gain.Note that if the gain is set too high, the output torque could hunt.When set to zero, the load torque observer will not function.Set the model machine time constant used with the B30-1 load torque observer.

Refer to section 6-8-7 for details on the load torque observer function.

B30-2

ASR proportional item change rate limit

If the speed setting value or motor speed change suddenly, this will prevent the ASR's P item from suddenly changing.



This is the integral gain for the adaptive speed estimation mechanism. To increase the speed estimation response, set a large value. Note that if the value is too high, the speed estimation value will hunt.



Regenerative compensation torque limiter 1, 2

Regenerative compensation low-speed area setting 1, 2

The regenerative torque limiter can be changed in the low-speed area. The shaded section shows the operation range. If operation is unstable within the shaded line range, set the parameter so that the unstable point is not within the shaded line area.



B32-0

High-speed flux control gain (IM sensor-less vector control, IM vector control with sensor)

= 1: Disable = 2 to 50: Enable

This is the control gain used for high-speed control of the secondary flux when starting operation.

Use this to control the secondary flux at a high speed at the start of operation or during operation in a constant output range.

High speed control is possible by increasing the gain, but if increased too high, the magnetizing current may hunt.

B32-1

Temperature compensation selection

(IM sensor-less vector control, IM vector control with sensor)

= 1: Disable = 2: Enable

If torque accuracy is required when vector control with sensor is selected (C30-0 [0] = 3, 4), or if speed accuracy is required when sensor-less vector control is selected (C30-0 [0] = 2, 5), the parameter fluctuation of the primary resistance value and secondary resistance value caused by a rise in temperature can be compensated.

B32-2

Voltage saturation compensation selection

(IM sensor-less vector control, IM vector control with sensor)

= 1: Disable = 2: Enable

If the output voltage in control is larger than the voltage that can be output by the inverter, select this control to limit the exciting current to prevent the current or torque from hunting. Select this when raising the output voltage to near the input voltage, or when the input voltage changes.

Note that if voltage saturation occurs, some torque ripple will occur. In this case, lower the B01-9 no-load voltage setting to avoid voltage saturation.

B32-3

Iron loss compensation selection (IM sensor-less vector control, IM vector control with sensor)

= 1: Disable = 2: Enable

This compensates the torque error caused by iron loss. The iron loss resistance value (B02-8, 9) must be set.

B32-4

ACR voltage model FF selection

(IM sensor-less vector control, IM vector control with sensor, PM motor control)

= 1: Disable = 2: Enable

The voltage fluctuation caused by the leakage inductance is feed forward controlled.

The current regulator (ACR) response speed will be increased. Select this if the current hunts in the high-speed operation range during sensor-less control.

Use this function if the current hunts at a high-speed operation range during the IM sensor-less vector control mode.

When using this function with the PM motor control mode, set B32-4 to 2 and B32-5.

B32-5

ACR model voltage FF compensation (PM motor control)

dq axis current non-interference voltage Set this when the ASR proportional gain is high. Set the value between approx. 50.0 and 80.0%. This function is invalid when 0% is set.

B32-6

ACR proportional section dead time compensating factor (PM motor control)

Set a value of approx. 50 to 80% if current vibration at a 3ms cycle occurs at an output frequency of 120Hz or more.

B33-0~7

M fluctuation compensation table reference speed

This is the reference speed for changing the compensation amount according to the operation speed.

If all of B34 is set to the default value (100.0), these will be automatically set when adjusted with automatic tuning mode 4 (B19-0=4).

B34-0~7

M fluctuation compensation

This compensates the exciting inductance fluctuation according to the B33 table reference speed.

Set the compensation table so that the output voltage is constant during no-load operation through the entire operation range.

* This is adjusted with the automatic tuning mode 4 (B19-0 = 4). Refer to Chapter 3 for details on automatic tuning.

B35-0~4
B36-0~6
B38-0~6

Voltage saturation prevention control constant (PM motor control) Field weakening electric current table (PM motor control) Torque to Iq conversion adjustment coefficient table (PM motor control)

Refer to section 6-9 for details on these parameters.

Magnetic pole position estimation (PM motor control)

Refer to section 3-4-4 for details on these parameters.

B40-0

B39-0~3

Software option function

One of the following functions, program ramp, pattern operation, traverse operation, PID or multi-pump can be selected as a software option function. Set the parameters as shown below to use these functions.

Parameter No.	Setting value	Function	Parameter related to function
	1	Function not used	-
	2	Program ramp	B41-0 to B42-7
	3	Pattern run	B50-0 to B59-3
	4	Traverse run	B45-0 to 6
P40.0	5	PID control	B43-0 to A
6	Multi-pump control No main pump rotation		
7		Multi-pump control (1-contact method) No main pump rotation	B43-0 to B44-6
	8	Multi-pump control (2-contact method) No main pump rotation	

B41-0~7 B42-0~7

Program ramp – acceleration

Program ramp – deceleration

The motor can be run with program frequency (speed) setting 0 to 7 using the sequence commands PROG and S0, S1, S2, S3, SE and selection mode setting (B11-8). The program ramp time can also be switched at this time and the motor run.

When the sequence command PROG is OFF, only the RAMP time is changed by S0, S1, S2, S3 and SE. The acceleration/deceleration ramp time selected with S0, S1, S2, S3 or SE is as shown below.

This function operates even when using the auxiliary drive function.

Sequence command					Selected
SE	S3	S2	S1	S0	frequency
		OFF	OFF	OFF	B41-0 B42-0
		OFF	OFF	ON	B41-1 B42-1
	* *	OFF	ON	OFF	B41-2 B42-2
*		OFF	ON	ON	B41-3 B42-3
^		ON	OFF	OFF	B41-4 B42-4
		ON	OFF	ON	B41-5 B42-5
	ON	ON	OFF	B41-6 B42-6	
		ON	ON	ON	B41-7 B42-7

(1) For binary mode (B11-8 = 1)

(2) For direct select mode (B11-8 = 2)

-					
	Sequence command				Selected
SE	S3	S2	S1	S0	frequency
OFF	OFF	OFF	OFF	OFF	Previous values
OFF	OFF	OFF	OFF	ON	B41-0 B42-0
OFF	OFF	OFF	ON	OFF	B41-1 B42-1
OFF	OFF	ON	OFF	OFF	B41-2 B42-2
OFF	ON	OFF	OFF	OFF	B41-3 B42-3
ON	OFF	OFF	OFF	OFF	Previous values
ON	OFF	OFF	OFF	ON	B41-4 B42-4
ON	OFF	OFF	ON	OFF	B41-5 B42-5
ON	OFF	ON	OFF	OFF	B41-6 B42-6
ON	ON	OFF	OFF	OFF	B41-7 B42-7

* : SE and S3 are not used.

When S0 to S3 are all OFF, or when two or more are set between S0 and S3, the previous values will be held. If there are no previous values because the power has been turned ON, etc., "0" will be set.

An example of combination with the program frequency (speed) setting is shown below.



(Note) The acceleration/deceleration ramp time-2 (B10-0, 1) will be selected by turning the sequence command CSEL ON even when using the program ramp (B40-0=2).

B43-0~A PID control

1) Basic PID control operation

The following type of feedback loop can be configured by using the analog input (Al1, Al2, Al3) as a feedback input.



Example of PID control configuration

- (Note 1) PID control functions only in the remote mode (LCL OFF). It does not function during the local mode (LCL ON). In this case, the normal operation mode is entered.
- (Note 2) For PID control, either the mode which operates with the sequence command PIDEN and RUN, or the mode which operates with only PIDEN can be selected with B43-9.
- (Note 3) When using the mode which operates with the sequence command PIDEN and RUN, the PID control will not start even if JOG or BRAKE are turned ON.

The PID operation block is shown below.



- To validate or invalidate PID control during operation, turn the sequence input command PIDEN ON or OFF. The sequence input command PIDEN is assigned to the sequence input terminals with C03-C.
- (2) Refer to Fig. 5-9-1 and select the setting input. The speed setting input can be changed between the parameter setting and sequence input. If the setting value is a Hz unit, the percentage conversion value using the maximum frequency B00-4 as 100% will be input.

- (3) Set the analog input to be used as the feedback input with C07-5. Set the level of the analog input to be used with C12-1, 2 for AI1 and C12-5, 6 for AI2. When inputting AI3 input, set the feedback input between 0 and 10V when C12-8 is 1, and between 0 and 5V when C12-8 is 2.
- (4) The internal signal (lower limit over: LLMT, upper limit over: ULMT), which indicates that the feedback value has exceeded the upper limit (B43-3) and lower limit (B43-4) can be output as a sequence. Set either 24 (LLMT) or 25 (ULMT) for C13-2 to 6.

2) Detected error determination

If PID detection is defective, an error is determined and a breakdown stop (IO-C) occurs.

An error is determined if when the command value is the same or higher than the error determination start level (B43-5), the detected value is the same or lower than the detected error level (B43-6), and the error condition continues for just the detected error determination time (B43-7), and a breakdown stop occurs.

3) Polarity invert flag

The PID input polarity can be inverted using B43-8. The normal PID input is the command value – the detected value, however, this changes to detected value – command value when the polarity is inverted.

4) PID operation selection method

The PID operation conditions can be changed using B43-9 f0.

- f0=1: PID operates when PIDEN=ON and RUN=ON.
- f0=2: PID operates when PIDEN only is ON.
 - (PID operation continues even during stop)

PID output based operation/stop can be performed using B43-9 f1.

- f1=1: Normal operation (Operation stop not performed by PID)
- f1=2: PID output is used to stop operation.

Stop occurs when the PID output reaches the lower limiter.

Stop occurs when the PID output reaches the lower limitter in the case when B43-9 f_1 f0 = 21. Set RUN=OFF and then RUN=ON once again in order to restart operation.

Stop occurs automatically when the PID output reaches the lower limitter in the case when B43-9 f1 f0 =22. Furthermore, operation is restarted when the PID output exceeds the lower limitter + hysteresis (B43-A). Set RUN=OFF to completely stop the motor.

B44-0~6

Multi-pump control

Multi-pump control refers to a function which controls the flow passage pressure at a constant level by running pumps in parallel using one VAT300 and the VAT300' internal relay output (standard 5 points, option 4 points).

The pressure step of the ON/OFF controlled pumps is interpolated by a pump that is variable-speed controlled by the VAT300, which has the PID control function. This maintains the pressure's continuation.

Three types of VAT300 multi-pump control can be selected with the B40-0 setting.

- B40-0=6: Main pump with no rotation function
- B40-0=7: Main pump with rotation function, 1-contact method
- · B40-0=8: Main pump with rotation function, 2-contact method

1) B40-0=6: Main pump with no rotation function

Up to 9 pumps are run in parallel using one VAT300 and the VAT300' internal relay output's 8 points. When main pump with no rotation is selected, the pump controlled with variable speed is fixed.

The system configuration is shown below.



Example of system configuration (When operating nine ON/OFF control pumps)

2) B40-0=7: Main pump with rotation function, 1-contact method

Up to 8 pumps are run in parallel using one VAT300 and the VAT300' internal relay output's 8 points. When main pump with rotation is selected, the pump controlled with variable speed is switched to the least operating pump only when all pumps are stopped.

The system configuration is shown below.



Example of system configuration (When operating eight ON/OFF control pumps)

sequence circuit must be structured. Refer to the following diagram. MPO2 MPO3 MPO1 VAT300 V3 V3 V2 V V2 ν А-F1 V2 A F2 V3 F3 V1 V3 V3 V2 Δ Δ Δ V3 F1 V1 V2 F2 F3 F1 F3 F2 V1 V2 V3

In the above system, if the INV/commercial changeover interlock is required, an external

3) B40-0=8: Main pump with rotation function, 2-contact method

Up to 4 pumps are run in parallel using one VAT300 and the VAT300' internal relay output's 8 points. When main pump with rotation is selected, the pump controlled with variable speed is switched to the least operating pump only when all pumps are stopped.

The system configuration is shown below.



Example of system configuration (When operating four ON/OFF control pumps)

1) Multi-pump control operation

An example of actual operation for the multi-pump control is shown below.



ON/OFF control pump changeover operation (when operating five pumps)

- ULT : PID output upper limit value in VAT300 (B43-3).
- LLT : PID output lower limit value in VAT300 (B43-4).
- T_1 : Pump start holding time (B44-1)
- T₂ : Pump stop holding time (B44-2)
- T_3 : Continuous operation limit time (B44-3)
- T₄ : Changeover time (B44-4)

The ON/OFF control of multiple pumps is carried out so that the operation time of each pump is equal.

- (1) When the PID output reaches ULT and T_1 is passed, the auxiliary pump 2 (MPO2) with the shortest operation time turns ON.
- (2) When the PID output reaches ULT and T₂ is passed, the auxiliary pump 1 (MPO1) with the shortest operation time turns OFF.
- (3) Following (2), when the PID output matches LLT for the time of T₂, the auxiliary pump 3 (MPO3) with the longest operation time turns OFF.
- (4) When the time that the PID output and LLT match does not reach T₂, the pump OFF control will not be carried out.
- Pump changeover function using continuous operation limit (B44-3)
- (5) When the time that the auxiliary pump's ON/OFF control is not carried out reaches T_3 , the pump 4 (MPO4) with the longest operation time within all of the auxiliary pumps turns OFF, and the pump 5 (MPO5) with the shortest operation time will turn ON after T_4 .

If B44-3 is set to 0, changeover following the continuous operation limit is prohibited. The variable speed control pump will not change even if the continuous operation limit time is exceeded.

- Main pump rotation function
- (6) When the main pump rotation function is enabled, the variable speed control pump will change to the pump with the shortest operation time of all pump only when all pumps are stopped. When the power is turned ON, pump 1 is always set as the variable speed control pump.
- (7) Only when B40-0=8 (2-contact method) is selected, and the INV drive pump changes to the commercial power drive or vice versa, a dead time is provided to prevent a current back flow from the motor. Both commercial power relay contacts are OFF during the dead time zone. The dead time zone can be set with B44-5.

Other restrictions related to the pump's ON/OFF control are given below.

- (8) When the PID output reaches ULT, the pumps turn ON in order of the shortest running time upwards based on the regulation in (1). However, when all pumps are ON, and the pump operation run time has been exceeded, a minor fault turns ON as an upper limit alert. The minor fault signal is displayed at D05-0 at this time.
- (9) When the PID output reaches LLT, the pumps will sequentially turn OFF from the pump having the longest operation time following the restriction (2) in the previous page. However, if there are no pumps to turn OFF, the VAT300 will stop. After the pump stop hold time has passed, the minor fault turns ON as a lower limit alert, and is displayed at D05-0 as the monitor. When the PID output rises and leaves LLT, the VAT300 will resume operation.



The FWD and REV LEDs will flicker during the automatic stop operation.

VAT300 automatic operation/stop (when there are three ON/OFF control pumps)

- (10) When B43-9: f0=1 (PID operation method = PIDEN + RUN), all commands to the pump are turned OFF at the same time the operation command (RUN) to the inverter is turned OFF.
- (11) When B43-9: f0=2 (PID operation method = PIDEN only), only the INV drive pump stops, even when the operation command (RUN) to the inverter is turned OFF, and the control pump continues to turn ON and OFF with PID output.

- (12) The following operations are performed when a fault occurs at the inverter. When B43-9: f0=1 (PID operation method = PIDEN + RUN):
 - The pump ON/OFF commands are maintained provided that the operation command (RUN) ON status is maintained.
 - The control pump is not turned ON and OFF, and neither is pump switching performed as time passes.
 - When the operation command (RUN) is turned OFF, all commands to the pump are turned OFF.

When B43-9: f0=2 (PID operation method = PIDEN):

- The pump ON/OFF commands are maintained regardless of whether the operation command (RUN) is turned ON or OFF, and the control pump continues to turn ON and OFF with PID output.
- All commands to the pump are turned OFF when PIDEN is turned OFF.
- (13) When the inverter's power is turned OFF, the operation time history for each pump will be lost.

2) Preparation for operation

- (1) Set the number of pumps to be ON/OFF controlled in parameter B44-0.
 - One to eight units (four units when B40-0 is 8) can be set. The functions of the output signals MP01 to MP08 for multi-pump control are as follows according to the multi-pump control method.

Pump No. (application)		Output signal	
When B40-0 = 6, 7	When B40-0 = 8	output signal	
Pump 1	Pump 1 (INV drive)	MP01	
Pump 2	Pump 1 (Commercial drive)	MP02	
Pump 3	Pump 2 (INV drive)	MP03	
Pump 4	Pump 2 (Commercial drive)	MP04	
Pump 5	Pump 3 (INV drive)	MP05	
Pump 6	Pump 3 (Commercial drive)	MP06	
Pump 7	Pump 4 (INV drive)	MP07	
Pump 8	Pump 4 (Commercial drive)	MP08	

Outputs MP01 to MP08 can be set to a programmable relay output terminal. Using the parameters (from C13-2 to C13-6, and from C33-0 to C33-3), set the VAT300 standard relay outputs PS01 to PS03, RA-RC, FA-FC, and the relay interface option (U30V24RYO) in relay outputs from PS04 to PS07

The pumps are turned on in the order of pump No. 1 to 8.

The option (U30V24RY0) is required to use relay outputs PS04 to 7.

Refer to the Instruction Manual (ST-3477) for details on U30V24RY0.

- (2) The PID control function is used with the multi-pump control.
 - Refer to the explanation on B43-0 to A for details on setting the PID control related parameters (B43-0 to A), selecting the pressure command input, and selecting the feedback input.
 - Multi-pump control is always carried out in the remote mode (LCL = OFF).
 - The operating command is issued from the external sequence input terminal (RUN).
 - Do not perform operation from R.RUN, F.JOG, R.JOG. If these sequence commands are turned ON, operation is possible as PID, however, the relay outputs for each pump all turn OFF.
 - Turn the sequence input command PIDEN ON to validate PID control.
- (3) Refer to the operation explanation drawing in section (1) and set the parameters B44-1 to 5.
- (4) By using the setting interlock function (C20-0 to 3), the VAT300 run/stop can be controlled by the pressure command input (Al1, Al2). In this case, the operation command (RUN) is always ON. Refer to the explanation on C20-0 to 3.

B44-6

Multi-pump control: INV control method at lower limit selection

Select whether to stop the INV or continue operation when the PID output lower limit state continues.

When B44-6=2: Continue is selected, the INV will continue operation without stopping in the "VAT300 automatic operation/STOP" state shown in the previous figure.

B45-0~6 T

Traverse run

Traverse is operation in which the frequency fluctuates with the pattern shown below. This is effective for evenly winding up the thread on a bobbin in a weaving system.



Traverse operation

(1) Traverse run

To carry out traverse run, turn the sequence command PROG ON. (Normal operation will take place if PROG is OFF.)

- 1) If the sequence command RUN or R RUN is turned ON, first, the frequency (speed) will increased as high as the center frequency (speed) in ramp mode (A01-0) at the center frequency (speed), and then traverse run will start.
- When RUN (or R RUN) is turned OFF, the frequency (speed) will decreased to a stop in ramp mode (A01-1).
- During traverse operation, the conventional ramp, S-shape ramp, overcurrent limit (OCL) and overvoltage limit (OVL) will not function. However, these will function while accelerating or decelerating during start or stop.
- 4) The traverse center frequency (rotation speed) input point can be selected with C02-1.
 - C02-1 = 1,2: Analog fixed (C07-4)
 - = 3 : Panel fixed (B45-0)
 - = 4 : Sequence (S0, S1)
 - = 5 : Pulse train input fixed

When using traverse run, set B11-8 to 1 (selection mode setting: binary mode).

If C02-1 is set to 1 or 2, the setting from an external source selected with C07-4 will be the center frequency (speed).

When C02-1 is set to 4, and traverse run is being carried out by turning the PROG command ON, the following operations (2) and (3) will take place when the sequence command S0 and S1 signals are input.

(2) Deviated traverse X, Y operation

The deviated traverse operation shown below takes place with the sequence commands S0 (X) and S1 (Y) when carrying out traverse operation with the PROG command ON.



Deviated traverse (X, Y) operation

The center frequency (speed) rises by X (B45-5) only while S0 (X) is ON. The center frequency (speed) lowers by Y (B45-6) only while S1 (Y) is ON. The rising and lowering timing is the traverse rising and lowering extension operation as shown above.

(3) Changing the center frequency (speed) with settings from an external source

While the PROG command is ON and the traverse operation is taking place, when the sequence commands S0 and S1 both turn ON, the center frequency value (speed) value will be the value set from an external source selected with C07-4.

If only S0 or S1 is ON, the deviated traverse X, Y operation explained in section (2) will take place.

If both S0 and S1 are turned ON, the center frequency (speed) will be the value set from the external terminal. However, the frequency will first return to the center frequency (speed) before rising or lowering to the newly set value. After that, the same operation will take place even when the setting value is changed from an external source.

(4) Precautions for application

- If the parameter No. B45-0 to 6 setting data is changed during traverse operation, the output frequency (speed) will return to the center frequency (speed) once. Then, traverse operation based on the newly set data will take place.
 When returning to the center frequency (speed), the output frequency (speed) will change in ramp mode (A01-0, 1).
- The overcurrent limit (OCL) and overvoltage limit (OVL) functions will not activate during traverse operation, so carefully consider the inverter capacity, motor capacity and traverse related setting values when designing the system.
- 3) The output frequency (speed) is limited between 5.00 and 100.00% during traverse operation.
- When carrying out deviated traverse, take care not to turn the S0 (X) and S1 (Y) commands ON simultaneously.
 If turned ON simultaneously, the (3) center frequency (speed) will change.

B46-0~5

External brake control

The inverter brake can be turned ON and OFF in accordance with the inverter internal sequence. The external brake function contains all types of waiting time settings and an interlock function.



External brake sequence example with program settings used (B46-0 f2=1), and brake answer (B46-5≠0.0)



External brake sequence example with DC brake used (B46-0 f2=2), and no brake answer (B46-5=0.0)

(1) External brake selection

- 1) Select the external brake function using B46-0 f0.
- Select the IDET based interlock function using B46-0 f1. If B46-0 f1 = 2, a breakdown stop occurs at IO-C if IDET is not ON at the point the brake is released (immediately after LB).
- 3) Set the control mode during acceleration waiting time (LB, BL) using B46-0 2.
 The normal operation mode is enabled when B46-0 2 = 1.
 The mode changes to DC brake mode when B46-0 2 = 2.

(2) All types of waiting time

Set the waiting time when using external brake control.

- 1) Use B46-1 to set the waiting time (LB) from RUN until the brake is released.
- 2) Use B46-2 to set the waiting time (BL) from the point the brake is released until acceleration is commenced. When there is a brake answer (B46-5≠0.0sec), set the waiting time from after the brake answer, and if there is no brake answer (B46-5=0), set the waiting time from the point the brake release command is issued. In the case of the normal operation mode setting, changes are not made to the settings during BL, and the settings prior to BL are used.
- Use B46-3 to set the waiting time (DB) from the point ZSP turns ON until the brake is engaged.

(3) Error determination

The following error determination can be made in cases other than IDET based interlock set at B46-0 f1.

- RUN error determination when engaging brake In the case where RUN does not turn OFF in the time set at B46-4 from the time the brake is engaged, a breakdown stop occurs at the end controller due to an external brake RUN error (IO-D). Set to 0.0 sec to turn the RUN error determination OFF.
- 2) Brake answer error determination In the case where (MBRK) brake command and (MBRK_ans) brake answer do not match above the time set at B46-5, an external brake answer error (I0-E) occurs as an external brake breakdown, and a breakdown stop occurs. Set to 0.0 sec to turn the brake answer error determination OFF.

(4) S-shape cushion pass function

If the S-shape characteristics (B10-4) have been set, the S-shape characteristics are applied when engaging the external brake, and therefore there are cases when the frequency does not drop immediately. In order to avoid this, set B10-6=2 or 3 to disable the S-shape characteristics when stopping.

B10-6=2: S-shape passed when program setting is 0.

B10-6=3: S-shape passed when RUN command is OFF.

B47-0~6

Simple ASR control

If the speed detection option preset board (U30V24DN1, DN2, DN3 0r DN5) is installed when V/f control is selected (C30-0=1, 2), simple ASR can be used. Simple ASR involves comparing the frequency command value and motor rotation count (frequency calculation value), and controlling the slippage frequency so that the frequency command matches the motor rotation count.



Simple ASR control block diagram

- (1) Simple ASR control is performed when B47-0 f0 = 2.
- (2) The integral operation is stopped when accelerating if B47-0 f1 = 2. The overshoot when the frequency is attained can be curtailed.
- (3) The proportional gain is set at B47-1. Increase the proportional gain to raise the motor count compliance, however, motor hunting will occur if increased too much.
- (4) Set the integral time constant at B47-2. Shorten the integral time constant to raise the rotation count compliance when the motor has a load, however, the overshoot will increase when the frequency is attained.
- (5) Set the proportional variation rate control at B47-3. Set a small value in order to avoid excess proportional rotational variations.
- (6) Set the compensating torque limitter at B47-4. Simple ASR output is output in a simple torque form. Set a small value for the compensating torque limitter to avoid overcompensating.
- (7) Set the simple ASR pole count at B47-5.
- (8) Set the simple ASR speed detection unit pulse count a B47-6.
- (9) The pick-up operation is required when restarting operation while the motor is rotating. This differs from vector control in that magnetic flux control is not performed. In order to pick up, 500msec finishing time is required in addition to pick-up standby time (C21-2).

(Note 1) Simple ASR differs from vector control in that torque limit control is not possible.

(Note 2) The speed detection value displays at D00-5.



Pattern run function

The frequency (speed), run direction and time can be changed automatically with the pattern run function.



 A max. of ten patterns can be set. Program in the B50-B59 blocks as shown below. The speed setting input point is selected with C02-0 = 4 (sequence). n is the step No. from 0 to 9.

B5n-0: Run mode

- = 0: Stop
- = 1: Forward run
- = 2: Reverse run
- = 3: Final step (set when repeating before B59)
- B5n-1: Run frequency (speed) [%]

B5n-2: Run time [sec.]

B5n-3: Return destination step

= 0 ~ 8

(Set the No. of the step to be executed next when B5n-0 = 3.)

- (2) The sequence command functions will be as shown below during pattern running.
 - RUN: Pattern run starts when this turns ON, and operation starts from the run frequency (speed) and operation time applied when the operation was previously stopped. The inverter will stop when this is turned OFF.
 - (Note 1) The pattern running operates with the remote mode (LCL OFF).
 - (Note 2) The R.RUN, F.JOG, and R.JOG commands are invalid during pattern running.
 - S0: Proceeds to the next step at the edge from OFF to ON. (Skip) By turning this signal ON/OFF with S1 ON (hold), the step can be proceeded in synchronization with the peripheral machine regardless of the internal timer.
 - S1: The internal timer operation will stop when ON. (Hold). Use this to pause the pattern run.
 - S2: When this is turned ON, the operation will be reset to step 0. The S0 and S1 functions are valid only when RUN is ON. The S2 function is not related to the ON/OFF setting of RUN, and is valid at all times.
 When the mode is changed to the local mode (LCL ON), this will be reset to step 0. During pattern run, set B11-8 to 1 (selection mode setting: binary mode).
- (3) When using pattern run, the sequence status output (D04-4) ACC and DCC functions will change as shown below.

ACC: Turns ON when the last step of the pattern run is being executed. (EOS)

DCC: Operates with the reverse logic of the above ACC. (EOS)

B60-0 -B76-6 Spinning frame function

This function is used to perform spinning pattern operation. This differs from the previous pattern operation in that acceleration/deceleration is performed in a straight line cushion (auto setting) until the setting point is reached. Set the parameter selection B60-0 fo to 2 (selection) to enable the spinning frame function.

- (Note 1) The spinning frame function is a V/f control function. Select control mode selection C30-0 f0=1.
- Up to four Speed-Time Patterns (STP) can be set up to a maximum of fifteen steps. Each step is set at the target frequency and time taken to attain that frequency from the previous step. Set each STP end step number at B60-1~4. The time unit can be set at B60-6. This settings is valid for the STP time settings (B63-0~B64-6, B67-0~B68-6, B71-0~B72-6, B75-0~B76-6) and Doff-End alarm time (B60-5).

The frequency and time setting in each step of STP can be changed. Note that changes made to the STP settings during the step will be reflected when the step is updated.



When STP0 is selected, and B60-1=14

(2) STP switching can be performed using the external terminal There are four Speed-Time Patterns (STP), and they are selected at external terminal input (S0, S1, S2, S3). Use parameters B11-8 to select the binary mode and direct input mode.

	,			,
Sequence command				Selection
S3	S2 S1 S0			STP No.
		OFF	OFF	STP0
*	*	OFF	ON	STP1
		ON	OFF	STP2
		ON	ON	STP3

Binary mode (B11-8=*1)

Direct input mode (B11-8=*2)

Se	Selection			
S3	S2 S1 S0			STP No.
OFF	OFF	OFF	OFF	Previous value
OFF	OFF	OFF	ON	STP0
OFF	OFF	ON	OFF	STP1
OFF	ON	OFF	OFF	STP2
ON	OFF	OFF	OFF	STP3

(Note 2) STP switching cannot be performed during operation. If STP switching is performed during operation, the current pattern is maintained, and switching is performed after pattern operation is complete.

(3) Speed-Time Pattern (STP) operation

- STP operation is performed when the sequence command RUN is issued. (F.JOG, R.JOG inching operation cannot be performed.) Operation is commenced from the selected STP Step 0.
- 2) The method of stopping after the pattern ends can be selected with the function selection B60-0 f1.

B60-0: f1 = 1 (automatic stop)

• The inverter automatically stops after the last step is finished. Either normal deceleration ramp or coast to stop can be selected with the operation stop method (C00-1).

B60-0: f1 = 2 (FRQ_SP operation)

- After the last step is finished, the inverter shifts to special frequency (FRQ_SP) at the normal deceleration ramp, and continuous running. Operation at FRQ_SP continuous until the Run command turns OFF.
- When the RUN command turns OFF, the inverter stops with the normal deceleration ramp or coast to stop depending on the operation stop method (C00-1).
- The special frequency (FRQ_SP) can be set with parameter B60-9.



For FRQ_SP operation selection (B60-0=22)

- 3) If the operation command is turned OFF during STP operation, normal deceleration cushion or free-run stop is performed. When restarting operation, after accelerating with the normal acceleration cushion until the previous stop frequency is reached, STP operation is restarted from the previous stop step and operation time.
- 4) When operation is stopped due to a power outage, after resuming the power, pattern operation is restarted from the frequency and time when the stop occurred.

(4) Pattern operation can be reset by the external terminal input (PRST).

Select the input terminal by selecting sequence input (C03-9). A stop occurs when the PRST is turned ON during STP operation. Operation is commenced from STEP0 when restarting operation.

The method for stopping at pattern reset can be selected with function selection B60-0 f1.

B60-0: f1 = 1 (automatic stop)

• The inverter will automatically stop if PRST is turned ON during STP operation. Either normal deceleration ramp or coast to stop can be selected with the operation stop method (C00-1).

B60-0: f1 = 2 (FRQ_SP operation)

- If PRST is turned ON during STP operation, the inverter will shift to special frequency (FRQ_SP) at the normal deceleration ramp, and will continue running. Operation at FRQ_SP continuous until the RUN command turns OFF.
- When the RUN command turns OFF, the inverter stops with the normal deceleration ramp or coast to stop depending on the operation stop method (C00-1).

(5) A Doff-End alarm is output at the final stage of the pattern.

By setting the Doff-End alarm time (B60-5), the Doff-End alarm is output from the point after completion of the final step to the point going back the set time.

The Doff-End alarm remains ON even after the pattern is completed. The Doff-End alarm is cleared by the PRST.

Select the output terminal for the Doff-End alarm with the output selection (C13-2 to 6, C33-0 to 3).

- (Note 3) Even if the Doff-End alarm is ON, when the RUN signal is input, the Doff-End alarm will turn OFF and operation will start from Step 0.
- (Note 4) Normal acceleration/deceleration cushion switching can be performed using CSEL.

The Doff-End alarm time and average frequency calculation is always performed with cushion 1 even if cushion 2 is selected.

(6) Spindle average frequency display (D13-3)

The currently selected STP average frequency is displayed at monitor D13-3. The average frequency is obtained using the following formulae.

$$\begin{split} S_{0} &= \frac{(F_{S}[\%] + F_{0}[\%]) \times T_{0}[sec]}{2} \\ S_{n} &= \frac{(F_{n-1}[\%] + F_{n}[\%]) \times T_{n}[sec]}{2} \quad (n: \ Step \ no.) \\ S_{D} &= \frac{F_{n}[\%] \times T_{D}[sec]}{2} \end{split}$$

1) Operation stop method (C00-1) =1: Free-run stop

Average frequency =
$$\frac{S_0 + S_1 + \dots + S_n}{T_0[sec] + T_1[sec] + \dots + T_n[sec]} \times F_{MAX}[Hz]$$

2) Operation stop method (C00-1) =2: Deceleration stop

Average frequency = $\frac{S_0 + S_1 + \dots + S_n + S_D}{T_0[sec] + T_1[sec] + \dots + T_n[sec] + T_D[sec]} \times F_{MAX}[Hz]$



(7) Hank count display (D13-4)

The current Hank count displays at monitor D13-3. The Hank count is obtained using the following formula.

$$\begin{split} H_{\text{C}} = F_{\text{AVG}} \times T_{\text{RUN}} \times \frac{1}{840} \times \text{Gain} \\ F_{\text{AVG}} \text{ [Hz]: Average frequency} \quad T_{\text{RUN}} \text{ [sec]: Operation time} \\ 840: 1 \text{ Hank} = 840 \text{ yard} \end{split}$$

It is necessary to set the gain (B60-7, B60-8) in order to display the Hank count correctly. The gain is obtained using the following formula.

$$Gain = 2p \times R_s \times \frac{2}{Pole} \times \frac{1}{G_R} \times K_c$$

$$\begin{split} & \mathsf{R}_S: \text{Spindle radius [yard]} \quad \text{Pole: Motor pole count} \\ & \mathsf{G}_R: \text{Gear ratio } = \frac{\mathsf{N}_2}{\mathsf{N}_1} \quad (\mathsf{N}_1: \text{ Motor gear count}, \mathsf{N}_2: \text{Spindle gear count}) \\ & \mathsf{K}_C: \text{ Compensation coefficient (Compensate slippage etc.)} \end{split}$$

(Note 6) The Hank count calculation is continued during operation, however, is reset to zero when the power is turned OFF.

6-6-4 Explanation of Block-C parameter functions

C00-0

Run command method

Set the run command method for the remote operation mode (when "LCL" LED on operation panel is OFF). Set the sequence command, F.RUN, R.RUN and HOLD with C03-0, C03-2 and C03-5.

= 1: F·RUN, R·RUN







= 3: Self hold



(Note) PSI8 to 11 can be used only when the relay interface option is mounted.

C00-1
C00-2

Run/stop methods Jog stop method

- . .
- = 1: Coast to stop
- = 2: Deceleration stop

Coast to stop refers to stopping by turning the output OFF simultaneously with the stop command (F·RUN and R·RUN OFF).

Deceleration stop refers to stopping by decelerating to the stopping frequency with the ramp down after the stop command, and then applying the DC-brake to stop.



(Note) When not using the pick-up function to restart after coast to stop, confirm that the motor is stopped. When not using the pickup function, if the inverter is started while the motor is rotating, the inverter may trip.

Emergency stop (EMS) input logic



C00-4

C00-3

Emergency stop (EMS) mode

Set the method of stopping when the emergency stop sequence input EMS turns ON.

- = 1: Coast to stop, without fault output
- = 2: Coast to stop, with fault output (When the EMS signal turns ON, the output will be shut off, and FLT will be output.)
- = 3: Ramp down to stop (without fault output)

C00-5	Control source switchover method (J1 setting)
	J1 setting =1: OFF =2: ON Select whether to use the sequence input signals from the control PCB terminal block in the local operation mode (when "LCL" LED on operation panel is ON). Refer to section 5-5 for details.
C00-6	Control source switchover method (J2 setting)
	J2 setting =1: OFF =2: ON Select the auxiliary command input when the COP command is ON. Refer to section 5-5 for details.
C00-7	Run contact output condition selection
	The conditions for turning the sequence RUN output ON are set. = 1: ON at pre-excitation (EXC) = 2: OFF at pre-excitation (EXC)
C02-0~8	Various setting input selection
	Refer to section 5-9 for details.
C03-0~F	Sequence input terminal function – 1
C04-0~F	Sequence input terminal function – 2
C05-0~7	Sequence input terminal function – 3
C06-0~A	Sequence input terminal function – 4
	Refer to section 5-3, 5-6 for details. Refer to the explanation for B06-0 to 6 (ratio interlock bias increase/decrease function) for details on C03-A and C04-9 to A.

C07-0~A

Analog input terminal function

Refer to section 5-7 for details.

C08-0

Auto start (To F·RUN/R·RUN)

- = 1: OFF (runs with the run command ON after pre-charging)
- = 2: ON without pick-up
 - If the run command is ON when the power is turned on, run will start after the inverter is charged.
- (Note 1) Pick-up is not executed with this setting, so if the motor is rotating when the power is turned ON, the inverter operation could trip.



= 3: ON with pick-up

If the run command turns ON when the power turns ON, pick-up will start when the inverter charging is completed, and then operation will start. Set this when using momentary restart.

(Note 2) The speed can be detected with the IM vector control with sensor and PM motor control (C30-0 f0 = 3, 4). As pickup operation is not carried out, set C08-0 to 2.





C09-0

Parameter protection

Set this parameter to prevent unintentional operations from operation panel. Changing of the data can be protected per function group with the setting value as shown below.

value	Block	Block B, C				
value	Α	Basic	Extn.	S/W	H/W	
1	0	0	0	0	0	O : Unprotected
2	×	×	×	×	×	(changeable)
3	0	×	×	×	×	× : Protected
4	0	×	0	×	×	(unchangeable)
5	0	×	0	0	×	
6	0	0	0	0	0	
7~8	×	×	×	×	×	
9	0	0	0	0	0	

(Note 1) Set 2 to prohibit all changes.

- (Note 2) Set 1 to allow all changes. The 9 setting is for maker maintenance, so do not set it.
- (Note 3) When using the password number function (when C28-0 is set to 2), this parameter will also be locked. Set U00-1 to the value set with C28-1 to unlock the protection.

C09-1

Operation panel lock

This setting protects the operation panel FWD, REV and STOP key operations.

- = 1: All operation possible
- = 2: All operation prohibited (Note, the motor will stop when the STOP key is pressed for two seconds)
- = 3: Only STOP key can be operated.

C09-2

LCL switchover protection

- = 1: LCL mode switchover $\left(\frac{LL}{SET} \right) + {STOP \choose O}$ keys) during running disabled
- = 2: LCL mode switchover $\left(\underbrace{\left(\underbrace{LCL} \\ \underbrace{SET} \right) + \left(\underbrace{STOP} \\ O \right) \right)$ keys) during running enabled
- (Note) When switching from the local mode to the remote mode, if the terminal block RUN, R.RUN, F.JOG or R.JOG is ON, the mode will not switch even if operation is stopped.

C09-3	
C09-4	

Reveres run sequence (R·RUN) prohibit

Reverse run jogging sequence (R-JOG) prohibit

= 1: Enable = 2: Prohibit

Set this to prevent unintentional reverse run operation.

When set to "2", the sequence input "R RUN(R JOG)" operation command will be disabled. Note that if the reverse run setting (negative value) is input into the speed setting during "F·RUN(F JOG)" operation, reverse run will start.

C09-5 Reverse run during ACR mode prohibit

= 1: Enable = 2: Prohibit

Set this to prevent unintentional reverse run operation. When set to "2", reverse run during ACR operation will be prohibited. The reverse run speed will be limited to approx. 1% if reverse run is started. This setting is ignored in the V/f mode.

C09-6 Fault history buffer clear

The fault history details can be cleared by setting the value to 1 and then pressing $\begin{pmatrix} Idl \\ SET \end{pmatrix}$ key. This setting will not be registered in the internal memory. Thus, this parameter must be set each time.

Nothing will occur if set to a value other than 1.

Use this before handing the unit over to the final user.

(Note) The setting values exceeding 2000 are codes for maker maintenance, so do not set.

C09-7

Default value load

All values per function group are changed to the default values.

- 9: All default values load (Excluding the maker maintenance parameters)
- 10: Parameter A
- 11: Parameters B, C basic functions
- 12: Parameters B, C extended functions
- 13: Parameter B software option function Parameter C hardware option function
- 14: Parameters B basic functions
- 15: Parameters B extended functions
- 16: Parameter B software option function
- 17: Parameters C basic functions
- 18: Parameters C extended functions
- 19: Parameter C hardware option function

Nothing will occur when values other than the above are set. This parameter setting value will not be registered in the internal memory.

(Note) The setting values exceeding 2000 are codes for maker maintenance, so do not set. If set, the following inverter operation may be abnormal.

C10-0~7

Custom parameter register

Refer to section 4-4 for details on operating these parameters.


C11-5

LCD panel: Contrast adjustment

Adjust the contrast of the characters displayed on the LCD panel. The character color will darken as a larger value is set. (Note) This is displayed only when the LCD panel is connected.

C11-6 LCD panel: Backlight OFF timer setting

Set the time that the LCD panel backlight is ON. Set the ON time with a second unit. If the setting value is "0", the backlight will be ON at all times. (Note) This is displayed only when the LCD panel is connected.

```
C11-7
```

Operation panel operation mode selection

The operation panel parameter operation method can be selected from two methods. Refer to section 4-1-3 Selecting the operation method.



All terminal input mode selection Al2 terminal input mode selection

Select the input mode for the Al1 and Al2 terminals.

C12-0, 4 = 1 : Voltage input

= 2 : Current input

Refer to section 5-7 for details on using the analog input terminal.



All voltage input mode selection Al2 voltage input mode selection

When the Al1 and Al2 terminal input mode is set to voltage input (C12-0, 4 = 1), set the full scale of these terminal input signals.

C12-1, 5 = 1 : 0 to 10V = 2 : 0 to 5V = 3 : 1 to 5V

As an example, the relation of the voltage input value and speed setting value when the Al1 and Al2 terminal input function is used for the speed setting is shown below. Refer to Table 5-7-1 for the relation of the analog input value and each setting value when using the input terminal for a function other than speed setting.





Al1 current input mode selection Al2 current input mode selection

When the Al1 and Al2 terminal input mode is set to current input (C12-0, 4 = 2), set the full scale of these terminal input signals.

C12-2, 6 = 1 : 4 to 20mA = 2 : 0 to 20mA

As an example, the relation of the current input value and speed setting value when the Al1 and Al2 terminal input function is used for the speed setting is shown below. Refer to Table 5-7-1 for the relation of the analog input value and each setting value when using the input terminal for a function other than speed setting.





Al3 terminal input mode selection Al3 input gain

Set the full scale of the AI3 terminal analog input signal with C12-8.

C12-8 = 1 : -10V to +10V = 2 : -5V to +5V = 3 : +1V to +5V

A multiplication gain can be applied on the AI3 terminal input value with C12-9.

As an example, the relation of the voltage input value and speed setting value when the Al3 terminal input function is used for the speed setting is shown below. Refer to Table 5-7-1 for the relation of the analog input value and each setting value when using the input terminal for a function other than speed setting.

Refer to section 5-7 for details on using the analog input terminals.



C12-3
C12-7
C12-A

Filter time constant for Al1 input Filter time constant for Al2 input Filter time constant for Al3 input

The filter time constant for the input value of the Al1, Al2 and Al3 terminals can be set. Fluctuation of the setting value caused by input signal noise or chattering, etc., can be suppressed by increasing the time constant.

C12-B

Program setting filter

The program speed and ramp setting are set with the sequence commands S0 to SE, but chattering could occur when these input terminals are changed. In order to avoid this, batch filter processing is performed for S0 to SE.

The input signal is validated when the S0 to SE input terminals obtain the same value for longer than the set time, so the program settings will not change for the time set in C12-B after the input is changed.

Set C12-B to a time longer than that at which chattering could occur, and lower than the setting delay tolerance time.

C12-C
C12-D
С12-Е
C12-F

Pulse train input : 0% setting frequency (F1)

Pulse train input : 100% setting frequency (F2)

Pulse train input frequency LPF time constant

Pulse train input judgment time

Refer to section 5-7-3 for details related to the pulse train input function.

C13-0	A01
C13-1	A02

A01 terminal output

A02 terminal output

The inverter's internal parameters can be output from the control PCB analog output terminals A01 and A02.

C13-7~A

Built-in PLC input selection 1~4

The inverter output analog signals can be input to the built-in PLC. Select the details set in memory numbers 10h to 13h.

The parameters corresponding to the C13-0,1,7 to A setting values and the full scale of those output signals is shown below. The output voltage and current values are output as a percentage of the full scale. Refer to section 5-8 for details on using the analog output terminals. Refer to section 6-11 for details on using Built-in PLC.

The parameters corresponding to the C13-0, 1 setting values and the full scale of those output signals is shown below. The output voltage and current values are output as a percentage of the full scale. Refer to section 5-8 for details on using the analog output terminals.

Value	Parameter	Full scale	Value	Parameter	Full scale
0	Output frequency	Max. frequency	11	Torque current	Motor rated current \times 2
1	Setting frequency	Max. frequency	12	Excitation current	Motor rated current \times 2
1	Setting speed	Max. speed	13	Actual motor rotation speed	Max. speed
2	Ramp output	Max. frequency	14	Namp output	Rated torque × 2
		Max. speed	15	OLT monitor	100%
3	Output current (Motor)	Motor rated current × 2	15	(motor protection)	100 %
4	Output current (Drive)	Drive rated current × 2	16	Built-in PLC output 1	1000h
5	Output voltage	Motor rated voltage	17	Built-in PLC output 2	1000h
6	Motor output power	(Motor rated voltage ×	18	Built-in PLC output 3	1000h
-		Motor rated current) × 2	19	Built-in PLC output 4	1000h
7	DC voltage	200V Series : 300V	20	DM1 for maker maintenance	1000h
		4000 Series . 0000	21	DM2 for maker maintenance	1000h
8	(unit protection)	100%	L		
9	Heat sink temperature	100°C			
10	Motor speed	Max. speed			

(Note 1) DM1 and DM2 for maker maintenance are to be used only by the maker for maintenance. The user must not set C13-0, 1 to 20 or 21.



RA-RC output parameters PSO1, 2, 3 output parameters FA-FC output parameters

Refer to section 5-6-2 for details.

C13-C C13-D C13-E C13-F	С13-В
C13-D C13-E C13-F	C13-C
C13-E C13-F	C13-D
C13-F	С13-Е
	C13-F

Pulse train output function
Pulse frequency at 0%
Pulse frequency at maximum frequency/speed
Pulse train output parameter selection
Output parameter absolute value calculation selection

Refer to section 5-8-3 for details on the pulse train output function.

- C14-7, 8 C14-0, 1 C14-3, 4 C14-5, 6
- A01, A02 output method selection
- A01, A02 output gain
- A01, A02 output offset (Voltage)
- A01, A02 output offset (Current)

The block diagram for the control PCB analog outputs A01 and A02 is shown below.



(Note 1) The maximum output voltage for the A01 and A02 output is approx. 11V. Thus, even if the gain or offset are set to a large value, a voltage higher than this maximum level will not be output.

Set the A01, A02 output method with C14-7, 8.

C14-7, 8 = 1: Voltage output 0V to 10V

- = 2: Voltage output 0V to 10V (with 5V offset)
- = 3: Current output 4mA to 20mA

When using A01, A02 for the voltage output (C14-7, 8 = 1 or 2), connect the control PCB A01/A02 L bit (W3, W4) to the voltage mode side. When using for the current output (C14-7, 8 = 3), set the L bit to the current mode side. Refer to section 5-8 for details on this. When C14-7, 8 is set to 2, the parameter reference point is automatically set to 5V, and the output value gain is set to 0.5-fold.

A gain can be applied on the internal parameter value set with C13-0, 1. Set this gain with C14-0, 1.

When C14-7, 8 is set to 2 and the output gain is set with C14-0, 1, the gain will be (0.5 \times C14-0, 1).

Of the parameters selected with C13-0, 1, those shown below are coded with a plus/minus sign. When these parameters are selected, plus or minus can be added by offsetting the output value.

Setting value	Parameter	Full scale	
0	Output frequency	Max. frequency	
1	Setting frequency Setting speed	Max. frequency Max. speed	
10	Motor speed	Max. speed	
11	Torque current	Motor rated current \times 2	
12	Excitation current	Motor rated current \times 2	
13	Actual motor rotation speed	Max. speed	
14	Namp output	Rated torque × 2	

Set C14-3, 4 for the voltage output, and C14-5, 6 for the current output.

An example of setting a 5V offset for the voltage output is shown below. If C14-7, 8 is set to 2, the offset amount when the offset is set with C14-3, 4 becomes (5V + C14-3, 4 setting value).



(Note 2) If plus or minus is set with offset, the signal is not output from A01, A02 when the power is shut off, so the output will be 0V (-100% in above example).

C14-2

Random scale display coefficient

Set the display value coefficient for the monitor parameter D00-4 (output frequency, speed random scale display) and D01-4 (set frequency, speed, ramp input random scale display. The result of multiplying the output frequency or set frequency, etc., with this setting value is displayed at D00-4, D01-4).

C14-9~B

Al1, Al2, Al3 random scale coefficient

Set the random scale coefficient of the value displayed at monitor parameter D08-0 to 2 (analog input AI1, AI2, AI3 random scale display).

C15-0

Attainment (ATN) detection width

The attained output ATN operation width is set. Set with a percentage to the max. frequency (B00-4) or max. speed (B01-4).



C15-1

Current (IDET) detection level

The current detection (IDET) operation level is set. Set with a percentage of the rated current (B00-6, B01-6).

A 5% hysteresis will occur with the IDET operation.





Speed detection (SPD 1) level - 1 Speed detection (SPD 2) level - 2

The speed detection SPD 1 and 2 operation level is set.

Set with a percentage to the max. frequency (B00-4) or max. speed (B01-4).

The output frequency or the motor speed will be the comparison target.

A 1% hysteresis will occur with SPD1 and 2 operation.

Output frequency



C15-4

Zero speed detection (ZSP) level

The zero speed detection ZSP operation level is set.

Set with a percentage to the max. frequency (B00-4) or max. speed (B01-4).

The output frequency or the motor speed will be the comparison target.

A 1% hysteresis will occur with ZSP operation.



RDELAY output delay time setting

Set the delay time from sequence output RUN OFF to RDELAY OFF in the sequence output RDELAY.

Set the time with a 0.	.1 s unit.	RDI	delay time	
			(C15-5)	
Sequence output				
RDELAY				

If the sequence output RUN turns ON again during the delay time, the ON state will continue. The conditions that cause DELAY to turn OFF at the subsequent RUN OFF will be applied after the delay time elapses again.

(Note) RDELAY is reset if the power is turned OFF.

C15-6~9

C15-5

EC0 to 3 output fault selection

Set the details of the fault assigned to the sequence output EC0 to 3 with the following configuration.

0. 00. 0 Fault sub-code (0x0 to 0xF) Fault main code (0x00 to 0x13) 0: Major fault, 1: Minor fault

C15-A~E

EC0 to 3, ALM OFF delay timer

Set the output hold time for the sequence output assigned to the minor fault output Note that 0.0 is the setting value for holding the sequence output to the input of the fault reset signal (RST).

020-0
C20-1
C20-2
C20-3

Start/stop frequencies (speeds) Start/stop frequency (speed) hysteresis Interlock frequency (speed) Run delay timer

The following types of interlock can be obtained for the run RUN and R·RUN commands.



(1) Setting start/stop function

The motor will run when the frequency (speed) setting is higher than the C20-0 setting value, and will stop when lower.

(2) Start interlock

If the frequency (speed) setting value is larger than C20-2 when the run command (RUN X) is ON, the motor will not start.

Use this function when the frequency setting is to be lowered when starting for safety purposes.

Set C20-2 to 0 when not using this function.

- (Note) When using the set operation start/stop and set interlock function together, set a higher interlock frequency value than that for the set operation start/stop frequency.
- (3) Run delay timer

The motor will be delayed from the run command (RUN X) by the time set in C20-3.



This is used for synchronization with peripheral machines such as mechanical brakes. The run delay timer will not function in the jogging or local modes.

(Note 1) Set the parameter setting values to 0 when not using (1), (2) or (3).

- (Note 2) The (1), (2) and (3) functions will not function during jogging run.
- **(Note 3)** The (3) function will not function during the local mode.
- (Note 4) When interlock is applied on (1), (2) or (3), the FWD and REV LED will flicker.



Number of retries Retry wait time

Retry is a function that performs its own fault reset and restarts with pick-up. Set the number of retries, and the wait time (t_{RW}). If pick-up is not possible within the number of set times, an IO-4 fault will occur.

The errors that are targets of retry are power module $([\neg_1 \neg - n))$, overcurrent $([\neg_1 \neg - n))$, and ground fault $([\neg_1 \neg - n])$.



- (Note 1) If C21-0=0, retry will not function.
- (Note 2) During retry, FLT of the sequence output signals will not function.
- (Note 3) OVT retry may not function correctly if the DC voltage drop is slow.
- (Note 4) If the run command turns Off during retry, the retry will be cancelled and the FLT of the sequence output signals will turn ON.
- (Note 5) The pick-up operation is not carried out during vector control with IM sensor and PM motor control (C30-0 f0 = 3,4).



When a fault occurs on an extremely rare case, this function automatically resets the fault and restarts the operation.

If the fault occurs frequently, the inverter could be damaged, so first remove the cause of the fault.

C21-2

Pick-up wait time

The wait time t_{PW} after the output is cut off to when the pick-up operation is started is set. Set the time to when the motor residual voltage is abated for this parameter. (The residual voltage is a voltage generated by the motor after the inverter output turns OFF, and will be abated in approx. 1 to 5 seconds. This abatement time will take longer if the motor capacity is large.)

Pick-up current limit value

C21-3

The current limit value during pick-up is set. This setting value is applied only during pick-up. Normally, set 100% and use.

Adjust within the following range only when the output torque at restart is to be limited.

C21-3 Setting value \geq Applicable motor excitation current (%) +10% (Normally 30 to 40%)



V/f pick-up function selection

Select the pick-up function for when V/f control is selected (C30-0 f0 =1).

=1: No reverse run pick-up

Select this to restart the motor rotating in the same direction as the command when restarting after an instantaneous power failure. The motor will restart with the overcurrent limit from the maximum frequency in the same direction as the command.

=2: Reverse run pick-up enabled (FMAX)

Select this to restart the motor rotating in the same or reverse direction as the command when restarting after an instantaneous power failure. The motor rotation direction is detected first, and then is restarted with overcurrent limit from the maximum frequency in the detected direction.

=3: Reverse run pick-up enabled (estimated speed)

Select this to restart the motor rotating in the same or reverse direction as the command when restarting after an instantaneous power failure. First the motor rotation direction and frequency are detected, and then the motor restarts with the overcurrent limit from the frequency (detected value +10%) in the detected direction.

C21-5 Sensor-less pick-up function selection

Select the pick-up function for IM speed sensor-less vector control.

- =1: Reverse run pick-up disabled, start search from NMAX
- =2: Reverse run pick-up disabled, start search from setting value
- =3: Reverse run pick-up enabled, start search from NMAX

C21-6

C21-4

Speed estimation proportional gain for sensor-less pick-up

Set the speed estimation proportional gain used for pick-up during IM speed sensor-less vector control.

C21-7

Speed estimation integral gain for sensor-less pick-up

Set the speed estimation integral gain used for pick-up during IM speed sensor-less vector control.

C22-0
C22-1
C22-2
C22-3

Motor overload reference (L0) 0Hz overload (L2) 0.7 Fbase freq. overload (L1) Motor overload breakdown reference

The operation reference for overload (OLT) is set.

(1) Unit overload (OL-1)

Overload protection is performed under the following conditions based on the machine rated current reference. The reference is judged as an overload when the C22-0 setting value is exceeded.

- C30-0 f1 = 2 (Heavy-duty) 150% for one minute, 175% for 2.5
- seconds C30-0 f1 = 1 (Normal-duty) 120% for one minute, 140% for

120% for one minute, 140% for 2.5 seconds

However, the overload reference is reduced by 50% at an output frequency of 1Hz. The machine overload can be monitored at D02-2. Furthermore, analog output is possible if the setting value 8 is selected at C13-0, 1.

(2) Motor overload (OL-3)

Use the C22-3 setting to set the trip breakdown reference current for one minute in the case of a motor rated current (B00-6, B01-6) of 100%. When C22-3 is set to 120% for example, if C22-0 is 100%, and 120% of the motor rated current is output, a breakdown stop will occur due to a motor overload after one minute.

As shown in the diagram on the right, the counterclockwise limit characteristics change by setting C22-0. The diagram on







the right is an example with C22-0 set to 100% and 50% when C22-3=150%.

For the self-cooling motor, when operating at low speed, set C22-1 and C22-2 to meet the motor characteristics. These characteristics are as shown in the diagram on the right.

The motor overload can be monitored at D02-3. Furthermore, select setting value 15 at C13-0, 1 to enable analog output.

C22-4 DBR overload

This parameter is for setting %ED of DB operation. When DB transistor or DBR built in the unit is used, set the parameter within the specification.

When 0.0 is set, the protection function is disabled. When the external DB unit is used, set to 0.0.

C22-5 Motor power loss braking setting

When the motor loss braking function is activated, set the voltage to increase with the base frequency as a percentage in respect to the rated output voltage (B00-3). Normally, 50% of the default value is set.

When the DC voltage attempts to rise due to deceleration operation or a regenerative load, the motor loss braking function raises the inverter output voltage and decreases the motor efficiency to prevent tripping by an overvoltage. This function is valid only when the motor loss braking is selected with the main circuit option selection (C31-0 fO = 2) in the V/f control mode (C30-0 fO = 1).

- (Note 1) Take care to motor heating.
- (Note 2) If the normal V/f setting is inappropriate, the motor efficiency will increase when the voltage is increased and thus tripping by the overvoltage could occur easily.

C22-6

Carrier frequency automatic reduction function selection

Select the validity of the function to automatically reduce the carried frequency to 2kHz when the inverter output current exceeds 110% of the unit's rated current and the cooling fin temperature exceeds the reference value 1, and for when the cooling fin temperature exceeds the reference value 2 regardless of the current.

C22-7

Phase failure detection function selection

Select the validity of the input/output phase failure detection function

- f0: Input phase failure detection function selection1: Function valid 2: Function invalid
- f1: Output phase failure detection function selection 1: Function valid 2: Function invalid

(1) Input phase failure detection

When this function is valid, a fault will be output if the inverter output current exceeds the level 55% or higher than the unit's rating and the DC voltage pulsation width exceeds 15% of the rated voltage (400V series: 600V, 200V series: 300V) for approx. 3 seconds.

(2) Output phase failure detection

When this function is valid, if the output current's 3-phase average value during normal operation exceeds 30% of the motor rated current and one of the phases has not reached 7.5% of the motor rated current, a fault will be output. A judgment time of 0.3 seconds is required when the operation frequency is 40Hz or more, and a time of the output cycle \times 12-fold is required when the frequency is less than 40Hz.

(Example: When the output frequency is 5Hz, the judgment time is 0.2 seconds × 12 fold = 2.4 seconds)

Overspeed protection level

Set the overspeed protection level. Set as a percentage in respect to the maximum frequency (B00-4) or maximum speed (B01-4). The output frequency or motor speed is the target for comparison.



C24-1

C24-0

Control mode changeover during speed detection error

This is valid when vector control with IM sensor (C30-0 f0 = 3) or PM motor control (C30-0 f0 = 4) is selected.

- = 1: The speed detection error is not monitored.
- = 2: The speed detection error is monitored, and if an error occurs, a fault (FLT) is output. The motor then coasts to a stop.
- = 3: The speed detection error is monitored, and if an error occurs, a minor fault (ALM) is output. The control changes from the vector control with IM speed sensor to the IM speed sensor-less vector control, and the operation is continued. When the speed detection returns to the normal state, the control changes again from the sensor-less vector control to the vector control with sensor, and the minor fault output is cleared. The presence of a minor fault due to a speed detection error can be confirmed with the minor fault monitor (D05-0). This is available only during vector control with IM sensor.

C24-2 C24-3

Speed detection error level

Speed detection error recovery level

This is valid when C24-1 = 3.

Set as a percentage in respect to the maximum speed (B01-4).

If the deflection of the speed detection value per 2ms increases above the value set with C24-2, it is judged as a speed detection error, and the control changes from the vector control with sensor to the sensor-less vector control. After changing, when the deflection of the speed estimated value for sensor-less vector control and the speed detection value drops to below the value set with C24-3, it will be judged that the speed detection has returned to the normal state. The control changes again from the sensor-less vector control to the vector control with sensor.

C24-4
C24-5
C24-6

Control mode changeover during speed deviation error Speed deviation error level Speed deviation error judgment time

A speed deviation error occurs when the speed command and speed detection difference is the same or higher than the speed deviation error level (C24-5), and this situation continues for longer than the speed deviation error judgment time (C24-6).

C24-7 Reverse error detection level

Set the error detection level for when the motor rotates in the reverse direction of the speed command.

Set using the base frequency as 100%. The error is not detected when 0 is set.

C25-0

High-efficiency operation Voltage reduction time

This setting value is the time to reduce the output voltage from the V/f setting value to 0V after the output frequency reaches the set frequency.

Normally, the default value (10.0) is set. When using for loads with sudden torque fluctuations, and the output frequency drops remarkably with the overcurrent limit function, set an appropriately low value. If the rotation becomes unstable during the voltage



reduction or recovery operations causing a trip, set an appropriately high value. The high-efficiency operation function is valid when V/f control is selected (C30-0 fo = 1) or auxiliary drive is selected.

C25-1

High-efficiency operation Voltage lower limit setting value

Set a value between 50 and 99 while the inverter is stopped to select the high-efficiency operation function. When not using the high-efficiency

operation function, set 100 while the inverter is stopped.

This setting value is the lower limit of the output voltage reduced when the high-efficiency operation function is selected, and uses the V/f setting voltage (output voltage when not using high-efficiency operation) as the reference.



Normally, the minimum value (50) is set. When using for loads with sudden torque fluctuations, and the output frequency drops remarkably with the overcurrent limit function, set an appropriately high value.

(Note) Slipping will increase during high-efficiency operation, so it is recommended to execute automatic tuning before operation and set the automatic torque boost selection to valid (A02-1 = 2).

<Operation of high-efficiency operation>

Normally for the V/f constant operation, the no-load loss is large with a light load, and the motor efficiency drops remarkably. Thus, according to the load, the output voltage is reduced using the C25-1 setting value as the lower limit in respect to the voltage set with V/f, and the motor efficiency is improved.

C25-2

Cooling fan ON/OFF control

=1: ON/OFF control is enabled

The cooling fan is working during the inerter operation, and it is stopped 5 minutes after the inverter stop. When the inverter is turned On, the cooling fan is working for 10 seconds.

=2: ON/OFF control is disabled

The cooling fan is working while the inverter power is On.

C26-0

Standard serial communication setting Function selection

Select the serial communication method.

- =1: Standard serial .. This is VAT2000 original protocol using ASCII codes.

C26-1

Standard serial communication setting Parameter protection function

The parameters shown with circles in the following table can be changed.

Setting	Parameter A		Parame	ter B, C	
value	i arameter A	Basic	Extend	S/W	H/W
1	0	0	0	0	0
2	×	×	×	×	×
3	0	×	×	×	×
4	0	×	0	×	×
5	0	×	0	0	×

O: Changeable × : Unchangeable

C26-2

Standard serial communication Station No.

Set the local station No. for serial communication with the range from 1 to 247.

C26-3

Standard serial communication Response timer

Set the minimum time for returning an answer after receiving a command during serial communication.

When Modbus communication is selected, the data frame reception complete judgment time (silent time) will be applied.

C26-4

Standard serial communication Baud rate setting

Set the baud rate for serial communication.

=1: 4800bps =2: 9600bps =3: 14400bps =4: 19200bps =5: 38400bps =6: 1200bps =7: 2400bps



Set the password No. used when the password No. function is valid. Once set the display will return to 0, so make sure not to forget the set number. The default password No. is "0000", but once the password has been set, it cannot be reset to the default value even if default value load (C09-7) is executed.

C30-0

Control mode selection

Select the control mode. This parameter is set with the two digits [1] and [0].

- f1: Select the unit overload mode.
 - =1: Normal-duty (120%/1min)
 - =2: Heavy-duty (150%/1min)
- f0: Select the control mode.
 - =1: V/f control
 - =2: IM speed sensor-less vector control
 - =3: Vector control with IM speed sensor
 - =4: PM motor control with sensor
 - =5: Sensor-less PM motor control (for future use)
- (Note) When this parameter is changed, the motor overload breakdown reference (C22-3), overcurrent limit (B18-0), rating related parameter (B00, B01), manual torque boost voltage (A02-2), DC brake voltage (A03-0), as well as these settings in the auxiliary drive (B20 to 2F) will automatically be changed to the specified values when the parameter change is set by pressing the $\left(\frac{CL}{SET}\right)$ key on the operation panel. Always

set this parameter first.

C31-0

Main circuit option selection

Select the usage of the motor loss braking and DB resistor (built-in or external). Refer to the explanation on the motor loss braking setting (C22-5) for details on the motor loss braking function.

The motor loss braking function is valid when V/f control is selected (C30-0 $f_0 = 1$) or auxiliary drive is selected.

C31-1

Ground fault detection function

Set the validity of the ground fault detection function. When this function is valid, the output current's zero phase will be detected. If higher than the judgment value (approx. 50% of the unit rated current), a fault will be detected.

=1: Detection valid =2: Detection invalid

C31-2
C31-3

UVL proportional gain

UVL integral time constant

Set the gain for lowering the frequency at the start of UVL operation. The UVL function will be turned OFF if the UVL proportional gain is set to 0. Normally, a value approx. half of the motor rated slip is set for the UVL proportional gain. If the fault is UVT instead of UVL, reduce the UVL integral time constant.

C33-0
C33-1
C33-2
C33-3

PS04 output parameters

PS05 output parameters

PS06 output parameters

PS07 output parameters

In the same way as C13-2 to 6, select the number of the signal to be output from List of Parameters.

Refer to the Relay Option Manual for details on the output terminals. This parameter does not appear when the relay option PCB is not mounted.

C34-6

Data range selection

Select the data range for the transmission input/output data. Data Range Selection Table.

Setting	Data Sign		Frequency set	ting	Speed settin	g
value size	sıze	5	Data range	Unit	Data range	Unit
0			0d~44000d	0. 01Hz	0d~65535d	0.1min ⁻¹
1	Uns	Unsigned	0d~4400d	0. 1Hz	0d~7200d	1min ⁻¹
2	16bi+		0d~10000d	0.01%	0d~10000d	0. 01%
3	Sigr		-32768d~32767d	0. 01Hz	-32768d~32767d	0.1min ⁻¹
4		Signed	-4400d~4400d	0. 1Hz	-7200d~7200d	1min ⁻¹
5			-10000d~10000d	0.01%	-10000d~10000d	0. 01%
6			0d~44000d	0. 01Hz	0d~72000d	0.1min ⁻¹
7		Unsigned	0d~4400d	0. 1Hz	0d~7200d	1min ⁻¹
8	32bit		0d~10000d	0.01%	0d~10000d	0. 01%
9			-44000d~44000d	0. 01Hz	-72000d~72000d	0.1min ⁻¹
10		Signed	-4400d~4400d	0. 1Hz	-7200d~7200d	1min ⁻¹
11			-10000d~10000d	0.01%	-10000d~10000d	0. 01%

C50-0

C50-1

Encoder pulse divided output setting

When using the speed detection option U30V24DN1, DN2, the signals input from the encoder can be divided by 1/N, and output as 2-phase pulses (A, B phases) with 90° phase difference from the PAOUT and PBOUT terminals.

Set the division ratio N with this parameter.

Adjust the setting value so that the output signal is up to 70kHz.

2-phase, 1-phase encoder selection

Select the number of signals (2-phase, 1-phase) for the encoder being used.

C50-1 = 1: This is set when using an encoder that outputs a 2-phase pulse (A, B-phase) having a 90° phase difference.

The rotation direction can be judged, and the speed can be stably controlled even at low speeds.

Set the No. of pulses for one phase in the No. of encoder pulses (B01-8).

C50-2 = 2: This is set when using an encoder that outputs a 1-phase pulse.

Connect the input signal to the A or B phase input, and always leave one phase unconnected.

The 1-phase pulse signal for a proximity sensor, etc., is converted internally into a 2-phase signal.

With the 1-phase pulse mode, the rotation direction is recognized as the operating command direction. The forward run and reverse run directions are not judged.

A speed detection error could occur due to the effect of chattering in low speed areas, so use a 2-phase encoder when carrying out low-speed run or forward/reverse run.



- (Note 1) The 1-phase pulse mode cannot be used with the PM control mode.
- (Note 2) The speed detection direction (symbol) when 1-phase input is selected is determined based on the movement direction.
- (Note 3) In the case where ACR control is performed using vector control with an IM speed sensor when 1-phase input is selected, this is identified as the rotation direction outlined in Note 2. Exercise due caution with regards to the acceleration direction.

C50-2

Encoder AB advance direction selection

The motor's rotation direction is judged by the advance and delay of the encoder's A and B phase pulse phase.

Refer to the following diagram and set this parameter according to the phase relation of the encoder's AB phase signal during forward run (CCW rotation).

(Note) If C50-2 is set to 2, set C50-3 to 0.







(b) When C50-2 is 2 (CCW rotation)

C50-3

Encoder ABZ pulse type selection

When using an encoder with signal specifications which cannot be handled with the C50-2 and C51-2 settings, set C50-3 and invert or interchange the signals.

(Note) When C50-2 and C51-2 are set, set C50-3 to 0 (signal invert/interchange invalid). The signal conversion circuit will operate with the combinations shown below according to the C50-3 setting No.

C50-3 setting value	A-IN Non invert / Invert	B-IN Non invert / Invert	Z-IN Non invert / Invert	AB inter- change
0	_	_	-	
1	Invert	-	-	
2	-	Invert	-	lates.
3	Invert	Invert	-	Inter-
4	-	I	Invert	invalid
5	Invert	-	Invert	
6	-	Invert	Invert	
7	Invert	Invert	Invert	
8	-	-	-	
9	Invert	-	-	
10	-	Invert	-	4.5
11	Invert	Invert	-	AB inter-
12	-	-	Invert	change
13	Invert	-	Invert	-
14	-	Invert	Invert	
15	Invert	Invert	Invert	



Pulse conversion circuit

C-51-0

Encoder selection

Select the type of encoder signals being used.

- =1 : A, B, Z-phase + U, V, W-phase signal
- =2: A, B, Z-phase + serial absolute signal
- =3: A, B, Z-phase + U, V, W-phase signal (reduced wiring)
- =4: SIN, COS signal



AB phase-Z phase type selection Encoder Z signal reversal

With the VAT300, the A, B and Z phase pulse encoder signals are defined as waveforms which are generated as shown below during forward run (CCW rotation).

C51-1 is set according to the relation of the A phase signal's rising edge and Z phase signal phase. With this setting and at a time of reverse running, the A phase signal's down edge during the Z phase being high is the zero point.

Set C51-1 to 0 when the A phase signal's rising edge is generated while the Z phase signal is High (Fig. (a)). In this case, the A phase signal's rising edge is the zero point (magnetic pole position). In all other cases, set C51-1 to 1. In this case, the Z phase signal rising edge is the zero point. (Fig. (b)) In this case, the Z phase rising edge is the zero point even at a time of the reverse running.

If the Z phase signal needs to be inverted to match the signal definition shown below, set C51-2 to 1.

A phase

B phase

Z phase



(a) When C51-1 is 0 (CCW rotation)

(c) When C51-1 is 0 (during CW rotation)

Zero point

A phase

B phase

Z phase

(Note) When C51-2 is set to 1, set C50-3 to 0.



Zero point



(d) When C51-1 is 1 (during CW rotation)

C-51-3
C-51-6

Encoder UVW advance direction selection Encoder UVW pulse type selection

Time

Set these parameters when using an A, B, Z phase + U, V, W phase signal encoder or reduced wiring type A, B, Z phase + U, V, W phase signal encoder.

When using the reduced wiring A, B, Z phase + U, V, W phase signal encoder, the VAT300 defines the initial signals input to the A, B, Z phases signal cables as the U, V and W phase signals respectively.

Refer to the following diagram and set C51-3 according to the encoder's U, V, W phase signal phase relation during forward run (CCW rotation).



When using an encoder with signal specifications which cannot be handled with the C51-3 setting, refer to the following diagram and table and invert the signals by setting C51-6. When C51-3 is set to 2, set C51-6 to 0 (signal invert invalid).



C51-4

Z-IN \rightarrow U phase winding phase angle

Observe the encoder's Z phase pulse and the inter-linear voltage waveform across the motor terminal UV phases during forward run (CCW rotation), and obtain the phase angle (electric angle) from the relation shown below using the Z phase pulse as a reference. This parameter can be automatically adjusted with the automatic tuning function. Refer to section 3-5-3. Refer to section 3-5-4 for the adjustment method when using the magnetic pole estimation function.



Relation of encoder Z phase pulse and PM motor induced electromotive waveform phase (during CCW rotation)

Z-IN \rightarrow U pulse angle

C51-5

1) When using A, B, Z, phase + U, V, W phase signals or reduced wiring A, B, Z phase + U, V, W phase signals

If there is a phase difference between the Z phase pulse and U phase pulse of the encoder in use, set the phase difference in C51-5.

Set "0°" if there is no phase difference between the Z phase and U phase pulses.

	C51-5		180°	>	ŕ
U-phase					
V-phase		< 60°			
W-phase					

Encoder's Z phase and U, V, W phase signals (during CCW rotation)

2) When using A, B, Z phase + serial absolute signals If there is a phase difference between the Z phase pulse and serial absolute signal zero point, set that phase difference with an angle unit.



Encoder's Z phase and serial absolute signal (during CCW rotation)

3) When using sine wave signals

Set the phase of the sine wave signal when the encoder's Z phase pulse is generated in C51-5.



Encoder's Z phase and sine wave signal (during CCW rotation)

C51-7
C51-8
C51-9

UVW measurement start wait time [For reduced wiring ABZUVW] UVW measurement end time [For reduced wiring ABZUVW] ABZ measurement start wait time [For reduced wiring ABZUVW]

These parameters are set when using the reduced wiring type A, B, Z phase + U, V, W phase signal encoder. Set the parameters according to the specifications of the encoder in use.

When the power is turned ON to the encoder, the A, B and Z phase signal cables are at a high impedance (hereinafter, HI-Z). Set the UVW signal measurement start time in C51-7 using the time that the three signal cables are released from the high impedance state as a reference.

Set the UVW signal measurement end time in C51-8 using the UVW signal measurement start time (C51-7) as a reference.

(If the UVW signal cannot be measured within this time, the fault "SP-6" will be output.) Set the time to start control with the ABZ signal in C51-9 using the UVW signal measurement end time (C51-8) as a reference.

(Note) The timer runs at a 2ms cycle, so all times set here must be as even umber.



6-6-5 Explanation of Block-U parameter functions

U00-0

Parameter copy function

The inverter parameters can be saved in the non-volatile memory in the operation panel. Conversely, the saved parameters can be read to the inverter's non-volatile memory. This function is handy for setting the same parameters in several inverters. Note that all operations in this function, including save, load, verify check and clear, must be executed while the inverter is stopped.

1001: Save

The inverter parameters are saved in the non-volatile memory in the operation panel.

2002: Load

The parameters saved in the operation panel's non-volatile memory are read out to the inverter.

3003: Verify check

The parameter data saved in the operation panel's non-volatile memory is compared against the parameter data saved in the inverter's non-volatile memory. Ξ

4004: Clear

The operation panel's non-volatile memory is cleared.

U00-1

Password No. setting

If the panel data protection function (C09-0) is locked, input the four-digit value set with password No. setting (C28-1) into this parameter and unlock the function. The default password No. is "0000".

U10-0 Built-in PLC No. of execution banks

Set the number of banks executed with the built-in PLC in the range of 0 to 20. If 0 is set, the built-in PLC function will be invalid.

Refer to section 6-11 for details on the built-in PLC function.

* For the ROM version 9457.0+9458.4 and thereafter, the configuration is changed from 64-command * 5-bank to 16-command * 20-bank.

U10-1~8 Built-in PLC parameter

Set the user parameters usable with the built-in PLC. Set with a hex value.

U20-0~7	Built-in PLC command bank 1
U21-0~7	Set the built-in PLC command. The commands are executed in order from the small
	numbers.
	I his is valid when U10-0 is set to 1 or higher. Refer to section 6-11 for details on the built-in PLC function
U22-0~7	Built-in PLC command bank 2
U23-0~7	This is valid when $110-0$ is set to 2 or higher
023-0-1	This is valid which one onsist to 2 of higher.
U24-0~7	Built-in PLC command bank 3
U25-0~7	This is valid when U10-0 is set to 3 or higher.
U26-0~7	Built-in PLC command bank 4
U27-0~7	This is valid when U10-0 is set to 4 or higher.
U30-0~7	Built-in PLC command bank 5
U31-0~7	This is valid when U10-0 is set to 5 or higher.
U32-0~7	Built-in PLC command bank 6
U33-0~7	This is valid when U10-0 is set to 6 or higher.
U34-0~7	Built-in PLC command bank 7
U35-0~7	This is valid when U10-0 is set to 7 or higher.
U36-0~7	Built-in PLC command bank 8
U37-0~7	This is valid when U10-0 is set to 8 or higher.
U40-0~7	Built-in PLC command bank 9
U41-0~7	This is valid when U10-0 is set to 9 or higher.
U42-0~7	Built-in PLC command bank 10
U43-0~7	This is valid when U10-0 is set to 10 or higher.
U44-0~7	Built-in PLC command bank 11
U45-0~7	This is valid when U10-0 is set to 11 or higher.

	_
U46-0~7	Bu
U47-0~7	This

Built-in PLC command bank 12 This is valid when U10-0 is set to 12 or higher.

U50-0~7
U51-0~7

Built-in PLC command bank 13 This is valid when U10-0 is set to 13 or higher.

U52-0~7
U53-0~7

Built-in PLC command bank 14 This is valid when U10-0 is set to 14 or higher.

U54-0~7
U55-0~7

Built-in PLC command bank 15 This is valid when U10-0 is set to 15 or higher.

U56-0~7	
U57-0~7	

Built-in PLC command bank 16 This is valid when U10-0 is set to 16 or higher.

U60-0~7
U61-0~7

Built-in PLC command bank 17 This is valid when U10-0 is set to 17 or higher.

U62-0~7
U63-0~7

Built-in PLC command bank 18 This is valid when U10-0 is set to 18 or higher.

U64-0~7	
U65-0~7	

Built-in PLC command bank 19 This is valid when U10-0 is set to 19 or higher.

U66-0~7	
U67-0~7	

Built-in PLC command bank 20 This is valid when U10-0 is set to 20.

6-7 Setting the overload mode

6-7-1 Selecting the overload mode

Select one of the following modes according to the applicable load. If there is no difference in the load and unit capacity, the unit could be overloaded. Refer to the following table and select the mode which suits the load.

Unit overload mode	Explanation	C30-0 f1
1) Normal-duty setting (Normal-duty)	Select this when the ratio of the maximum load in respect to the rated load is low. The overload reference is 120% of the unit's rated current for one minute.	1
2) Heavy-duty setting (Heavy-duty)	Set this when the ratio of the maximum load in respect to the rated load is high. The overload reference is 150% of the unit's rated current for one minute.	2

- (1) For the default setting, = 1: normal-duty setting (Normal-duty) is selected, so change the setting according to the application. When this parameter is selected, there are parameters with setting values and setting ranges that also fluctuate, so this parameter must be set before the other parameters.
- (2) The parameters with setting values and setting ranges that fluctuate when this parameter is selected are shown below.

No.	Name	•	Min. value	Max. value	Default value	Unit	Function
A02 -	Torque boost						
2	2 Manual torque boost setting		0.00	20.00	(Note 1)	%	Setting of torque boost at 0Hz. This is automatically adjusted by the automatic tuning.
A03 -	DC brake						
0	DC braking voltage		0.01	20.00	(Note 1)	%	This is automatically adjusted by the automatic tuning. When setting manually, monitor the output voltage and change the setting in increments of 1% or less.
B00 -	Output rating						
	Motor rated current	Normal-duty	Heavy- duty rating Current × 0.3	Inverter rating (Note 2)	Inverter rating (Note 2)	A	Reference value for overcurrent limit, OLT, current % display, analog input and output.
6		Heavy-duty					
B18 –	Current limit						
0	Drive current limit	Normal-duty	50.	300.	125. (Note 3)	%	
		Heavy-duty			155.		
C22 –	C22 – Overload						
3	Motor overload breakdown reference	Normal-duty	110.	300.	120.	%	A breakdown stoppage (OL-3) will occur after 1 minute with the motor rated reference
		Heavy-duty			150.		current value at this value.

(Note 1) The default value differs according to the inverter capacity and overload mode selection.

(Note 2) The normal-duty rated current value and heavy-duty rated current value shown in Table 1 are used for the unit's rating values.

(Note 3) When switching the overload mode selection from the heavy-duty setting to the normal-duty setting, 125 is forcibly set.

6-7-2 Overload characteristics

(1) Machine overload (OL-1)

The unit overload detection curve changes in sequence with the overload mode selection. The machine overload characteristics are shown below.

Note that the unit rating current for the normal-duty setting and heavy-duty setting is the reference for the current value (%).



Overload characteristics (machine overload)

(Note 1) When the normal duty operation is selected, an overload inverse time characteristic of 120%, 60s is enabled.

Note that if 122% of the normal-duty rated current is exceeded, a trip will occur at the 140% for 2.5s inverse time characteristics. When the 1.0Hz or less, the trip will occur at inverse time characteristics which drop linearly to 60% for 60s of the normal-duty rated current.

(Note 2) When the heavy duty operation is selected, an overload inverse time characteristic of 150%, 60s is enabled.
 Note that if 155% of the heavy-duty rated current is exceeded, a trip will occur at the 175% for 2.5s inverse time characteristics. When the 1.0Hz or less, the trip will occur at inverse time characteristics which drop linearly to 75% for 60s of the heavy-duty rated current.

(2) Motor overload (OL-3)

This overload protection is a time limit trip based on motor overload reference (C22-0) and motor overload breakdown reference (C22-3).

For example if C22-0=100% and C22-3 = 120%, the protection will trip if the motor reaches a current 120% for 60s.

Refer to C22-0 to 3 in item 6-6 for further details.

6-8 Adjusting the IM vector control speed control related parameters

When running the IM with the VAT300, ASR operation is possible by executing automatic tuning and setting simple speed control parameters. However, when carrying out high-response or high-accuracy control, the parameters must be adjusted in detail. In this section, the configuration of the speed control system is explained, and the adjustment parameters that need to be adjusted are indicated.

6-8-1 Speed control system of IM vector control

The speed control system of IM vector control is configured of blocks as shown below. Automatic tuning is used for adjusting the exciting current control, current regulator, flux observer and speed estimation mechanism, so these parameters often do not need to be adjusted. However, the parameters related to the speed regulator, torque limiter, load torque observer, various low path filters, etc., must be adjusted according to the user's system. Thus, these cannot be simply adjusted with automatic tuning. The final user of the system must adjust these parameters to match the system. Adjustments are carried out while referring to the block diagram below.



(Note) The related parameter Nos. are indicated in the above function blocks.

6-8-2 IM speed regulator

The IM motor speed regulator (ASR) is configured of PI control, and has the following parameters.

Parameter No.	Parameter	Function	
A10-0	ASR response	The required ASR response radian frequency is set.	
A10-1	Machine time constant-1	The time (Tm) to accelerate the motor and load's torque inertia to the base speed at the rated torque is set. (Note)	
A10-2	Integral time constant compensation coefficient	The compensation coefficient applied on the integral time constant of the speed regulator (ASR) is set. Increase the compensation coefficient when the overshooting is large during speed control.	
B13-6	ASR gain compensation in constant power range	This sets the ASR P gain compensation value at the max. speed. By adjusting this parameter, the ASR P can be compensated in the constant power range. If ASR hunting occurs in the sensor-less control's constant output range, set a smaller value.	
B30-2	ASR proportional item change rate limit	If the speed setting value or motor speed change suddenly, this will prevent the ASR's P item from suddenly changing.	

(Note) The machine time constant Tm is expressed with the following expression.

Tm [ms] = $10.97 \times J [kg \cdot m^2] \times (Nbase [min^{-1}]^2 / Power [W])$

J : Total inertia $[kg \cdot m^2]$ (= 1/4 × GD² [kgf · m²]

Nbase : Base speed [min⁻¹]

Power : Motor rated output [W]

6-8-3 Torque limiter for IM speed control

The output torque is limited. Set an appropriate value for protecting the load side.

Drive torque limiter Set this to a large value to increase the torque during driving. Note that output torque control is performed even by the output current limiter (B18-0), so when set excessively, the set torque may not be attained.

Regenerative torque limiter Set this to a large value to increase the torque during regeneration. Note that output torque control is performed even by the output current limiter (B18-0), so when set excessively, the set torque may not be attained. If the DBR or PWM converter, etc., are not provided and an excessively large setting is made, an overvoltage trip could occur during regeneration. In this case, lower the regeneration torque limiter setting.

Parameter No.	Parameter	Function
A10-3	ASR drive torque limiter	The limit value for the ASR drive side is set.
A10-4	ASR regenerative torque limiter	The limit value for the ASR regenerative side is set.
A10-5	Emergency stop regenerative torque limiter	The ASR regenerative side limit value applied during the emergency stop mode is set.
A11-2	ACR drive torque limiter	The ACR drive side limit value is set.
A11-3	ACR regenerative torque limiter	The ACR regenerative side limit value is set.

6-8-4 IM exciting current control

The exciting current is controlled to establish the secondary flux. A current reduction process in the constant output range or during voltage saturation, and high-speed magnetizing control to raise the secondary flux at a high speed are also carried out.

Parameter No.	Parameter	Function
B32-0	Speed flux control gain	This is the control gain used for high-speed control of the secondary flux when starting operation. Use this to control the secondary flux at a high speed at the start of operation or during operation in a constant output range. High speed control is possible by increasing the gain, but if increased too high, the magnetizing current may hunt.
B32-2	Voltage saturation compensation selection	If the output voltage in control is larger than the voltage that can be output by the inverter, select this control to limit the exciting current to prevent the current or torque from hunting. Select this when raising the output voltage to near the input voltage, or when the input voltage changes. Note that if voltage saturation occurs, some torque ripple will occur. In this case, lower the B01-9 no-load output voltage setting to avoid voltage saturation. Note that the output also decreases in proportion to the voltage.
B33-x	Table reference speed	This is the table reference speed used to perform excitation inductance variation compensation.
B34-x	M' fluctuation compensation	This compensates the exciting inductance fluctuation according to the B33 table reference speed. The compensation table is set in order to keep a constant output voltage, when operation is performed without load. * This is adjusted by the automatic tuning mode 4. (B19-0=4)

<Setting the table reference speed>

When all of B34 is set to the default value (=100%), B33 will be automatically set as shown below when adjusted with automatic tuning mode 4 (B19-0=4).

When set manually and the motor largely fluctuates immediately after M' enters the constant output range, the voltage error can be reduced by setting the base speed carefully.



Table reference speed setting method

6-8-5 IM current regulator

The current regulator (ACR) is configured of PI control, and has the following parameters.

Parameter No.	Parameter	Function	
A11-0	ACR response	The ACR response radian frequency is set. If the response is too low or too high, the current will become unstable, and the over current protection will function.	
A11-1	ACR time constant	The ACR time constant is set. If the time constant is too long or too short, the current will become unstable, and the over current protection will function.	
B13-7	ACR gain compensation in constant power range	This sets the ACR P gain compensation value at the max. speed.	
B32-4	ACR voltage model FF selection	The voltage fluctuation caused by the leakage inductance is feed forward controlled.	
		The current regulator (ACR) response speed will be increased. Select this if the current hunts in the high-speed operation range during sensor-less control.	

6-8-6 IM flux observer and speed estimation mechanism

These are parameters used with speed sensor-less vector control.

Parameter No.	Parameter	Function
B31-0	Flux observer gain	This is the feedback gain for the flux observer. If hunting occurs at the estimated speed in the high-speed operation range, adjust within the range of 1.2 to 0.9.
B31-1	Speed estimated proportional gain	This is the proportional gain for the adaptive speed estimation mechanism. To increase the speed estimation response, set a large value. Note that if the value is too high, the speed estimation value will hunt.
B31-2	Speed estimated integral gain	This is the integral gain for the adaptive speed estimation mechanism. To increase the speed estimation response, set a large value. Note that if the value is too high, the speed estimation value will hunt.
6-8-7 IM load torque observer

The disturbance load applied on the motor is calculated and the torque command is compensated. To increase the response toward disturbance, use the load torque observer.

By setting the speed regulator (ASR) to P and using the load torque observer, overshooting can be suppressed.

Parameter No.	Parameter	Function
B30-0	Load torque observer gain	Set the observer gain for the load torque observer. To increase the responsiveness of the external disturbance response characteristics, set a large gain. Note that if the gain is set too high, the output torque could hunt. When set to zero, the load torque observer will not function.
B30-1	Model machine time constant	Set the model machine time constant used by the load torque observer.

6-8-8 Various low path filters of IM vector control

The time constants of the low path filters used for speed detection, speed commands or torque current commands, etc., are set.

By adjusting these time constants, vibration caused by noise and overshooting can be suppressed. Note that if an excessively high value is set, the control performance could drop.

Parameter No.	Parameter	Function
B30-3	Speed setting LPF time constant	Overshooting can be suppressed by setting this to the filter time constant equivalent to the speed response.
B30-4	Speed detection LPF time constant	The speed detection noise is cut.
B30-5	Speed detection LPF time constant for ASR	Set the low path filter time constant used for the speed detection value input into the speed regulator.
B30-6	Speed detection LPF time constant for compensation	Set the low path filter time constant used for the speed detection value for constant output range compensation or iron loss compensation, etc.
B30-7	Torque current command setting LPF time constant	Set the low path filter time constant used for the torque current command.
B30-8	LPF time constant for drooping	Set the low pass filter time constant applied on the dropping value input into the speed regulator.

6-9 Adjusting the PM motor control system parameters

A PM motor with sensor can be controlled with the VAT300. The position detection (speed detection) option dedicated for PM motor operation is required for this. The control of PM motor with sensor has basically the same torque control functions as the IM vector control with sensor, so either ASR operation or ACR operation is possible.

The differences with the IM vector control are listed below.

IM vector control with sensor	PM motor vector control
Only the speed detection is required.	Position detection (rotary encoder) and speed detection option are required.
By controlling the exciting current, the induced electromotive force can be controlled.	The permanent magnet's flux is constant so the terminal voltage is controlled by passing a weak field current. Thus, the constant output range is narrow compared to IM.
DC braking is possible. Even when rotating with the load external force, the machine will stop at the position after movement.	The DC excitation state is established during DC braking. Thus, a torsion angle is generated according to the load torque. The original position is returned to when the load is removed.
The 3-phase inductance is equivalent.	The d axis and q axis inductance differs for the IPM (interior magnet type) motor.
There is a excitation current flow even at no load.	The current is approx. zero during a no-load.
	(When the weak field current control is not functioning.)
There is a time lag between the generation of the exciting current and the generation of the secondary flux, so the torque generation at starting is delayed.	The torque can be output simultaneously with the current generation at starting.
Even during the motor is running, the terminal voltage stays at zero even when the gate is cut off.	While the motor is rotating, an induced electromotive force is generated at the motor terminal even if the gate is cut off. When an overspeed is reached, a regenerative current is generated to the inverter and can cause an overvoltage.

Precautions for using PM motor

- (a) The current is approximately zero during the no-load. It cannot be determined that "the inverter is stopped because the ammeter reading is zero."
- (b) Even if the inverter "CHARGE" LED is not illuminated, motor terminal induced electromotive force occurs while the motor is rotating. There is a possibility of electric shock, and therefore always connect cables after the motor has come to a complete stop. If the speed is significantly higher than the base speed when driving from the load side, the power will be regenerated from the motor, the inverter DC voltage will increase, a voltage overload will occur, and the motor could break down. A mechanical brake or other such protective device is required when external operational torque is applied.

6-9-1 Initializing the parameters

Refer to the PM motor data sheet and set the parameters required for the PM motor control from the panel. All other settings must comply with section 6-8 vector control with sensor. Refer to the test operation section for the encoder settings (C50, C51).

No.	Parameter	Unit	No.
A20 – A	CR control constant (PM)		B35 –
0	ACR response (PM)	rad/s	(
1	ACR time constant (PM)	ms	_
2	d axis current command cushion time (PM)	ms/l1	
3	q axis current command cushion time (PM)	ms/l1	
01 – C	Dutput rating (Vector control)		—
1	Motor rated output (Vector control)	kW	4
2	No. of motor poles (Vector control)	Pole	B36 -
3	Motor rated voltage (Vector control)	V	
4	Max. speed (Vector control)	min ^{−1}	(
5	Motor rated frequency (Vector control)	min ⁻¹	
6	Motor rated current (Vector control)	А	
7	Carrier frequency (Vector control)		
8	No. of encoder pulses (Vector control)	P/R	
9	No-load output voltage (Vector control)	V	
)3 – N	Notor circuit constant (PM)		
0	R1: PM motor primary resistance (Mantissa section)	mΩ	
1	R1: PM motor primary resistance (Exponent section)		
2	Ld: PM motor d axis inductance (Mantissa section)	mH	C38 –
3	Lq: PM motor q axis inductance (Mantissa section)	mH	
4	Ld, Lq: PM motor inductance (Exponent section)		(
5	Rated torque electric current	%/I1	
13 – L	ocal setting		
6	ASR gain compensation in constant power range	%	
7	ACR gain compensation in constant power range	%	
8	Linear torque limit (NTL1) (at 100% torque)	%	
9	Linear torque limit (NTL2) (at 0% torque)	%	

N	No. Parameter		
B35	i – V	oltage control constant (PM)	
_	0	Demagnetizing control operation voltage allowance (PM)	%/V1
-	1	Largest voltage setting (PM)	%/V1
-	2	Field weakening electric current limit value (PM)	%/V1
_	3	Demagnetizing current control proportional gain (PM)	
	4	Demagnetizing current control integral time constant (PM)	ms
B36	i – F (I	ield weakening electric current table PM motor control)	
	0	Field weakening electric current table 0 (PM) (at torque command 0%)	
-	1	Field weakening electric current table 1 (PM) (at torque command 25%)	
-	2	Field weakening electric current table 2 (PM) (at torque command 50%)	
-	3	Field weakening electric current table 3 (PM) (at torque command 75%)	%/I1
_	4	Field weakening electric current table 4 (PM) (at torque command 100%)	
-	5	Field weakening electric current table 5 (PM) (at torque command 125%)	
	6	Field weakening electric current table 6 (PM) (at torque command 150%)	
C38 – Torque to Iq conversion adjustment coefficient table (PM)			
	0	Torque to Iq conversion adjustment coefficient 0 (PM) (at Id command –100%)	
-	1	Torque to Iq conversion adjustment coefficient 1 (PM) (at Id command –75%)	
-	2	Torque to Iq conversion adjustment coefficient 2 (PM) (at Id command –50%)	
-	3	Torque to Iq conversion adjustment coefficient) 3 (PM) (at Id command –25%)	%/l1
-	4	Torque to Iq conversion adjustment coefficient 4 (PM) (at Id command 0%)	
-	5	Torque to Iq conversion adjustment coefficient 5 (PM) (at Id command 25%)	
-	6	Torque to Iq conversion adjustment coefficient 6 (PM) (at Id command 50%)	

(Note) Parameters with a "%I1" unit must be set with a rate that corresponds to the rated current, and the "%/V1" parameters must be set with a ratio corresponding to the rated voltage.

6-9-2 PM motor control speed control system

The PM motor control speed control system is configured of the following types of blocks. Of these blocks, the speed control system and load torque observer section operate as the same functions as the IM vector control. Refer to section 6-8 for details on adjusting these parameters. Refer to section 6-8-8 for details on setting the various low path filters (B30-3 to 8).

The sections unique to the PM motor control are the weak field current control and torque current operation section following the torque command. These are adjusted by setting the parameter sheet data enclosed with the motor from the panel.

Note that as with the IM, the parameters related to the speed regulator, torque limiter, load torque observer and various low path filters differ according to the user's system, and ultimately must be adjusted according to the system in use.



PM speed control system block

(Note) The numbers of the related parameters are indicated in the above function blocks.

6-9-3 Setting the PM motor circuit constants

The resistance and inductance elements are set as the PM motor circuit constants.

- (1) Set the value of one phase converted into a 3-phase & Y connection.
- (2) For the inductance element, set the value including the leakage inductance.
- (3) If the wiring path is long, add the wiring path resistance and inductance elements to the motor constant.

In the following wiring example, the set constants are calculated with the following expressions.



Fig. 6-9-3 PM motor and wiring path circuit constants

6-9-4 PM motor control current regulator

The PM motor control current regulator (ACR) is configured of the PI control, and has the following parameters.

Parameter No.	Parameter	Function
A20-0	ACR response (PM)	The ACR response radian frequency is set. Hunting at a several ms cycle will occur if the ACR response is too high. If the response is too low, the speed control system's gain cannot be set to a high value. Usually this should be set between 500 and 1500rad/s.
A20-1	ACR time constant (PM)	The ACR time constant is set. If the time constant is too long or too short, the current will become unstable, and the over current protection will function. Usually this should be set between 5 and 20ms.
B13-7	ACR gain compensation in constant power range	This sets the ACR P gain compensation value at the max. speed. Usually this should be set to 100% when using PM motor control.
B32-4	ACR voltage model FF selection	When using ACR feed forward compensation, set the setting value to 2, and set B32-5.
B32-5	ACR model voltage FF compensation	This is the compensation gain for the non-interference voltage element added to the ACR output. Use this when the operation frequency is high, or when the current control response is set to a high speed. Set a value of approx. 50 to 80%
B32-6	ACR proportional section dead time compensating factor	If the output frequency is 120Hz or more and an approx. 3ms cycle current vibration occurs, set a value between approx. 50 and 80%.

6-9-5 Torque limiter for PM motor

The output torque is limited. Refer to section 6-8-3 for details on the A10-3 to 5 and A11-2, 3 settings.

Parameter No.	Parameter
B13-8	Linear torque limit
B13-9	

With the PM motor, the weak field voltage range is narrow, and the voltage drop is large because of the armature's reaction. This causes the voltage to easily saturate when the speed increases or when the load is excessive. A linear torque limiter has been added to prevent this voltage saturation. As shown in Fig. 6-9-5-b, this functions simultaneously with the drive/regenerative torque limiter settings and variable torque function. The smaller value is used as the torque limiter value.

This linear torque limiter is set with the speed at 100% torque (B13-8) and speed at 0% torque (B13-9). Do not change the default values (B13-8=400%, B13-9=450%) when not using this linear torque limiter function. This limiter is valid even during IM vector control.





Fig. 6-9-5-a Torque characteristics of IPM motor

Fig. 6-9-5-b Linear torque limiter

6-9-6 Setting the weak field current pattern for the IPM motor

With the IPM (interior magnet type) PM motor with permanent magnet embedded in the iron core, the inductance has reverse salient-pole properties as indicated with $L_d < L_q$. With this type of motor, a large torque is generated with a small current by effectively using the reactance torque by passing a weak field current (negative direction current element for d axis).

The VAT300 has a function to generate a weak field current according to the torque command. These characteristics are set as the table data (B36-0 to 6).

This setting value differs according to the motor design, so set a value which is appropriate for the motor being used. Set zero if the motor or servomotor characteristics are unclear, or when using an SPM (surface permanent magnet) motor.

Set this weak field current table with a panel using positive values. Even if the setting is a positive value, it will be converted into a negative d axis current command internally. Set a negative value to set a current on the magnetizing side. This table setting is valid only when the voltage saturation prevention control is not functioning. When the voltage saturation prevention control explained in the following section is functioning, the weak field current will be automatically increased so a weak field current larger than the characteristics set here will be generated.









6-9-7 Setting the torgue command and Ig current command conversion coefficient for the **IPM** motor

The relational expression of the torque (Trq) and d, q axis current (Id, Iq) which the IPM motor uses to generate the reactance torque from the weak field current is shown below.

$$I_{q} = \frac{\frac{Trq}{(Pole/2)}}{\phi_{m} - (L_{q} - L_{d})I_{d}} = K_{T1} \cdot K_{T2}(I_{d}) \cdot Trq$$

Fig. 6-9-7-a shows these torque characteristics expressed on the Id-Iq axis. Two types of conversion coefficients K_{T1} (B03-5) and K_{T2} (I_d)(B38-0 to 6) can be set with the VAT300 to handle the changes in the torque characteristics caused by this type of weak field current.



IPM motor's Id-Ig axis

 K_{T2} (I_d) is a compensation coefficient which relies on Id. The value is set at the Id's 25% pitch. This compensation coefficient is linearly interpolated as shown in Fig. 6-9-7-b. If Id is outside of this table's range, the table's end setting value (B38-0, 6) is applied.

 K_{T1} (B03-5) is a coefficient used for fine adjustment by increasing and decreasing the entire compensation pattern.

Set these parameters to value appropriate for the motor being used. When driving a motor for which the characteristics are unclear, set all parameters to the default values (B38-0 to 6=100%).

For the IPM motor, set the K_{T_2} (I_d) compensation pattern with B38-0 to 6. Adjust B03-5 to finely adjust and increase or decrease this entire compensation pattern.

The SPM motor does not have a reactance torgue, so set only B03-5. Leave B38-0 to 6 all at the default value (100%).



 \rightarrow Iq conversion coefficient table

 \rightarrow Iq command conversion block diagram

6-9-8 Operation of weak field in IPM motor constant output range

If the PM motor's speed increases, the terminal voltage increases, the inverter's maximum output voltage is reached, and the voltage is saturated. To prevent this voltage saturation, voltage saturation prevention control which automatically passes a weak field current (with reverse polarity of magnet's field flux) to suppress the terminal voltage is applied.

Set the following parameters to validate this function.

- (B35-0) : This setting prevents the voltage saturation which occurs when the power voltage drops. The output voltage is limited to the value obtained by subtracting this setting value from the maximum output voltage corresponding to the power voltage.
- (B35-1) : This setting prevents voltage saturation by suppressing the motor's terminal voltage to a set voltage or less. Normally, the motor's continuous maximum rated voltage (100%: default value) is set.

B35-0 and 1 are set as a ratio of the rated voltage.

The relation of B35-0 and B35-1 is shown below. Normally, the B35-1 setting value is the maximum value of the terminal voltage. However, if the DC voltage drops, the terminal voltage's maximum value is limited to the voltage level attained by subtracting the B35-0 setting value from the output voltage limit value. The weak field current is passed automatically so that the terminal voltage does not exceed that maximum value. Thus, the current control system functions properly even if the motor speed increases or the DC voltage drops.

- (B35-2) : Set the maximum limit value (limit value on Id negative side) for the weak field current generated to prevent voltage saturation as a ratio in respect to the rated current. The magnet could be demagnetized (irreversible demagnetization) if an excessive weak field current is passed. This setting prevents this demagnetization.
- (B35-3, 4): Set the proportional gain and time constant for the voltage saturation prevention control.





6-10 Operating the auxiliary drive motor

With the VAT300, a main drive motor operated with the C30-0:f0 control mode and an auxiliary drive motor operated with V/f control can be run by switching the internal control using the external sequence input AUXDV (auxiliary drive selection) and AUXSW0 and AUXSW1 (auxiliary drive No. selection). The main drive motor and auxiliary drive are switched with the sequence input AUXDV. The auxiliary drive number is switched with AUXSW0 and AUXSW1.

6-10-1 Switching the main and auxiliary drive motor control

The inverter's internal main drive motor control and auxiliary drive motor control is switched with the external sequence input AUXDV. However, the control must be switched while the motor is stopped. If the auxiliary drive selection signal is switched while the inverter is running, the switch will be invalid and instead will switch to the control corresponding to the signal status when the inverter stops. When switching the control, the sequence output RDY1 and RDY2 (READY) turn OFF, and the inverter operation is prohibited. The state of the inverter internal control switching can be confirmed with the sequence output AUXDV (auxiliary drive selection).



(Note) The main and auxiliary drive motor control cannot be switched while the inverter is running. The drive switches to that corresponding to the sequence input AUXDV status when the motor stops.

Switching of main drive motor control and auxiliary drive motor control

6-10-2 Switching control between auxiliary drive motors

The VAT300 has four auxiliary drive operation control parameters No. 0 to 3. No. 0 is valid in the default state. The auxiliary drive number is switched with the external sequence input AUXSW0 and AUXSW1. The inverter must be stopped when switching.

If AUXSW0 or AUXSW1 is changed while the inverter running, the switch will be invalid, and instead will switch to the No. corresponding to the signal status when the inverter stops.

AUX SW1	AUX SW0	Auxiliary drive No.	Corresponding parameters
L	L	0	B20-0 to B23-4
L	Н	1	B24-0 to B27-4
Н	L	2	B28-0 to B2B-4
Н	Н	3	B2C-0 to B2F-4

Relation of sequence input AUXSW0, AUXSW1 and auxiliary drive No., and applicable parameters



- (Note 1) After switching to sequence input AUXSW0 or 1, a delay of 500ms will be applied before the drive No. is switched internally.
- (Note 2) Auxiliary drive No. switching is invalid while the inverter is running.

The auxiliary drive will switch to the number corresponding to the status of AUXSW0 or AUXSW1 when the inverter stops.

Switching control between auxiliary drive motors

6-10-3 Auxiliary drive motor control related parameters

The dedicated parameters for auxiliary drive motor control are shown below.

Dedicated parameters for auxiliary drive motor

(When auxiliary drive No. is set to 0)

No.	Parameter
B20-0 to 5	Output rating (Auxiliary drive 0)
B20-6, 7	Start/Stop frequency (Auxiliary drive 0)
B20-8, 9	Upper/Lower limit (Auxiliary drive 0)
B21-0, 1	Frequency setting (Auxiliary drive 0)
B21-2 to 7	Acceleration/deceleration time (Auxiliary drive 0)
B22-0, 1	Torque boost (Auxiliary drive 0)
B22-2, 3	DC brake (Auxiliary drive 0)
B22-4 to 6	Over current limit (The parameters B18-3~6 are shared with the main drive motor control) (Auxiliary drive 0)
B22-7 to 9	Overload reference (Auxiliary drive 0)
B23-0 to 4	Braking on power deceleration ramp time (Auxiliary drive 0)

6-10-4 Functions and settings that cannot be used during auxiliary drive motor control

As opposed to V/f control (C30-0: f0-1) during main drive motor control, some functions cannot be used with auxiliary drive motor control.

Function and setting that cannot be used	Related parameter and sequence input
Automatic torque boost	A02-4 to 6
Frequency skip	B05-0 to 5
Ratio interlock	B06-0 to 3
V/F middle point	B17-0 to 3
Frequency increment/ decrement	C04-7, 8 (Sequence input FUP/FDW)
Interlock ratio bias increment/decrement	C04-9 to B (Sequence input BUP/BDW/IVLM)
Automatic tuning	B19-0
Primary resistance	B02-0 to 1 (Dedicated for main drive motor)
Control mode selection	C30-0 (Dedicated for main drive motor)

6-11 Built-in PLC Function

The VAT300 has a built-in PLC function. The sequence can be input/output and the analog signals can be input/output with this function. The built-in PLC function has the following features.

- A programmable sequence function is provided in the inverter.
- Commands are input with a command format based on the instruction codes.
- Commands can be input from the operation panel. This allows changes to be made easily at the site.
- Commands can be input with the standard serial. Command generation support software is also available.

6-11-1 Outline explanation of processing system

The built-in PLC function runs with the processing system shown in Fig. 6-11-1.

The interpreter section runs at a 2ms interval, so operations can be carried out at the same sample cycle as the regular inverter process. The commands are separated in units called "banks", and one bank is executed at a 2ms interval. The number of banks to be executed can be set with U10-0 (No. of executed banks), so if the process is heavy, it can be split into twenty banks and executed at a 40ms interval. * For the ROM version 9457.0+9458.4 and thereafter, the configuration is changed from 64-command *



Fig. 6-11-1 Built-in PLC processing system

The built-in PLC reads the commands from the command bank. The command is then interpreted by the interpreter section, and then executed. Each command is operated using a 32-bit general-purpose accumulator and 16t-bit width memory space. Some commands are handled as 16 bits, and some are expanded to 32 bits and handled.

The built-in PLC function carries out the operation in the inverter, so some limits apply to the operation time. Each command is assigned a step count as the execution time. The interpreter increments the step count each time a command is executed. If the incremented step count value exceeds a set value (1280 steps) within a 2ms interval, the CPU-B will stop with a fault. In this case, review the command, and reset the number of steps executed with one bank so that it is smaller than the set value. If the CPU-B fails, the command bank execution number will be forcibly reset to 0. Reset the power to restart the built-in PLC function.

6-11-2 Related parameters

The parameters related to the built-in PLC are listed below. The memory numbers are explained later.

- Panel display (D10-0 to 3): Built-in PLC → Display Four values can be displayed in parameters D10-0 to 3. To display, write the values in memory numbers 32h to 35h.
- (2) Sequence input (C03 to C06): Built-in PLC → Inverter The signals from the built-in PLC can be connected as sequence inputs. The low-order 4 bits of memory No. 28h are PL1 to 4.
- (3) Analog input (C07): Built-in PLC → Inverter The signals from the built-in PLC can be connected as analog inputs. The four words in memory No. 24h to 27h are output as the built-in PLC outputs 1 to 4 (set C07 between 8 and 11).
- (4) Analog output (C13-0, 1): Built-in PLC → Analog output Analog outputs are possible from the built-in PLC. The four words in memory No. 24h to 27h are output as the built-in PLC outputs 1 to 4 (set C13-0,1 between 16 and 19).
- (5) Sequence output (C13-2 to 6): Built-in PLC → Sequence output Sequence output is possible from the built-in PLC. The low-order 8 bits of memory No. 28h are PLC1 to 8.
- (6) Analog input selection (C13-7 to A): Inverter → Built-in PLC The inverter output analog signals can be input to the built-in PLC. Select the details set in memory numbers 10h to 13h.
- (7) No. of Built-in PLC execution banks (U10-0)
 Set the number of banks to be executed with the built-in PLC.
- (8) Built-in PLC parameter (U10-1 to 7): Parameter → Built-in PLC Eight parameters can be input.
 The details set with the parameters are set in memory numbers 2Ah to 31h.
- (9) Built-in PLC command (U20 to U67) Input the commands executed with the built-in PLC.

6-11-3 Memory space

The memory space used with the built-in PLC is shown below. The memory No. is indicated with a hexadecimal.

Memory No.	Name	Details	Unit	Read/ write
0	External analog input 1	Reads input value from Al1	1000h=100%	Read
1	External analog input 2	Reads input value from Al2	1000h=100%	Read
2	External analog input 3	Reads input value from AI3	1000h=100%	Read
5	External serial input 1	Reads serially set speed command	1000h=100%	Read
6	External serial input 2	Reads serially set torque command	1000h=100%	Read
7	External serial input 3	Reads serially set torque ratio 1	1000h=100%	Read
8	External serial input 4	Reads serially set torque bias	1000h=100%	Read
9	External serial input 5	Reads serially set torque ratio 2	1000h=100%	Read
Α	External serial input 6	Reads serially set drive torque limiter	1000h=100%	Read
В	External serial input 7	Reads serially set regenerative torque limiter	1000h=100%	Read
С	External serial input 8	Reds serially set ASR response	0.1r/s/LSB	Read
D	External serial input 9	Reads serially set machine time constant	1ms/LSB	Read
10	Internal analog output 1	Reads output value selected with C13-7	1000h=100%	Read
11	Internal analog output 2	Reads output value selected with C13-8	1000h=100%	Read
12	Internal analog output 3	Reads output value selected with C13-9	1000h=100%	Read
13	Internal analog output 4	Reads output value selected with C13-A	1000h=100%	Read
14	External sequence input 1	Reads state set with terminal block	_	Read
18	External sequence input 5	Reads serially set status	_	Read
19	External sequence input 6	Reads serially set status	_	Read
1A	External sequence input 7	Reads serially set status	—	Read
1B	External sequence input 8	Reads serially set status	-	Read
1C	Internal sequence output 1	Reads inverter sequence output (D04-4)	—	Read
1D	Internal sequence output 2	Reads inverter sequence output (D04-5)	—	Read
1E	Internal sequence output 3	Reads inverter sequence output (D04-6)	-	Read
1F	Internal sequence output 4	Reads inverter sequence output (D04-7)	—	Read
20	Internal sequence output 5	Reads inverter alarm output (D05-0)	-	Read
24	Analog output 1	Writes value output with C13-0/1 = 16	1000h=10V	Write
25	Analog output 2	Writes value output with C13-0/1 = 17	1000h=10V	Write
26	Analog output 3	Writes value output with C13-0/1 = 18	1000h=10V	Write
27	Analog output 4	Writes value output with C13-0/1 = 19	1000h=10V	Write
28	Sequence output	Writes PLC1 to PLC8 output with C13	—	Write
2A	Panel parameter 1	Reads value set with U10-1	-	Read
2B	Panel parameter 2	Reads value set with U10-2	_	Read
2C	Panel parameter 3	Reads value set with U10-3	—	Read
2D	Panel parameter 4	Reads value set with U10-4	_	Read
2E	Panel parameter 5	Reads value set with U10-5	_	Read
2F	Panel parameter 6	Reads value set with U10-6	_	Read
30	Panel parameter 7	Reads value set with U10-7	-	Read
31	Panel parameter 8	Reads value set with U10-8	_	Read
32	Panel display 1	Writes value displayed with D10-0	_	Write
33	Panel display 2	Writes value displayed with D10-1	-	Write
34	Panel display 3	Writes value displayed with D10-2	_	Write
35	Panel display 4	Writes value displayed with D10-3	-	Write
40 to 5F	User memory	Memory which can be read/write freely	_	r/w
60 to 9F	Dedicated memory	Dedicated memory used by commands	_	r/w
A0 to BF	Constant memory	0 to 31d values are loaded at start up		Read

* The memory numbers other than those listed above are for future use.

- * The external analog input is a full scale 100% when the gain is 1.0.
- * The internal analog output unit differs according to the set parameter. However, it is 100% at the maximum or rated display value explained in C13. 10V = 100% conversion applies to the OLT monitor and heat sink temperature.

(The output frequency is 100% at the maximum frequency, and the motor rated current is 100% at the rated current.)

* The following bit assignments apply to the external sequence input 1.

bit0	: Not used	bit4 :PSI4	bit8 : PSI8	bit12: PSI12
bit1	: PSI1	bit5 : PSI5	bit9 : PSI9	bit13: PSI13
bit2	: PSI2	bit6 : PSI6	bit10: PSI10	bit14: PSI14
bit3	: PSI3	bit7 : PSI7	bit11: PSI11	bit15: PSI15

* The following bit assignments apply to the external sequence inputs 5 to 8.

External sequence input 5

bit0	: EMS	bit4	: FJOG	bit8 : HOLD	bit12: IPASS
DITI		DIT5	: KJUG		DITI3: CPASS
bit2	: FRUN	bitb	: EXC	bit10: COP	bit14: AFS1
bit3	: RRUN	bit7	: Not used	bit11: CSEL	bit15: AFS2
Exterr	nal sequence inpu	ıt 6			
bit0	: AFS3	bit4	: S1	bit8 : FUP	bit12: IVLM
bit1	: PROG	bit5	: S2	bit9 : FDW	bit13: AUXDV
bit2	: CFS	bit6	: S3	bit10: BUP	bit14: PICK
bit3	: S0	bit7	: SE	bit11: BDW	bit15: Not used
Exterr	nal sequence inpu	ıt 7			
bit0	: Not used	bit4	: LIM2	bit8 : DEDB	bit12: Not used
bit1	: ACR	bit5	: MCH	bit9 : TRQB1	bit13: Not used
bit2	: PCTL	bit6	: RF0	bit10: TRQB2	bit14: Not used
bit3	: LIM1	bit7	: DROOP	bit11: FPOS	bit15: Not used
Exterr	nal sequence inpu	ıt 8			
hit0	· MBRK-ans	hit4	· S6	hit8 · PLS IN	bit12 · F FI T1
hit1	· PRST	hit5	· S7	hit9 : OCLLV1	bit13: E FLT2
hit2		bit6	· ΔUXSW0	hit10: OCLLV1	$hit14 \cdot F FI T3$
bit2	· 95	bit7	· ALIXON/1	bit11: Not used	
DILO	. 35	ווע	. AUASWI	DILLET NOT USED	DIL15. E.FL14

* For the internal sequence output, the bottom of the display (D04-4 to 7) is the low-order bit, and the top is the high-order bit.

* The following bit assignments apply to the sequence output.

bit0	: PLC1	bit4 : PLC5	bit8 : Not used	bit12: Not used
bit1	: PLC2	bit5 : PLC6	bit9 : Not used	bit13: Not used
bit2	: PLC3	bit6 : PLC7	bit10: Not used	bit14: Not used
bit3	: PLC4	bit7 : PLC8	bit11: Not used	bit15: Not used

6-11-4 Commands

The commands used with the built-in PLC are a 4-digit value.



The commands can be input to the built-in PLC by inputting a

4-digit value in the U20 to U67 parameters.

Command No. Memory No.

The built-in PLC follows the command No. and executes the command using the memory No. X (16-bit) and accumulator A (32-bit). The accumulator is a 32-bit general-purpose register. Most of the commands are passed through the accumulator and operated.

The commands are listed below. Command No. 00 is the bank end command. The built-in PLC executes the commands in order from the head of the command bank. When the command reaches 00, execution of the current command bank is stopped. When the next 2ms interval is reached, the next command bank is executed from the head. If there is no X in the details of each command, the memory No. is random (not used).

No.	Com- mand	Details	Expression indication	No. of steps
00h	NOP	Nothing is executed. End of bank.	None	0
01	LD	X is loaded with sign extended to A.	A=X	85
02	LD_U	X is loaded without encoding A.	A=X	85
03	LD32	X (i) and X (i+1) are loaded as 32 bits.	A=X	100
04	ST_L	Low-order 16 bits of A are stored in X.	X=(short)A	84
05	ST_H	High-order 16 bits of A are stored in X.	X=(short)(A>>16)	85
06	ST32	A is stored in X (i) and X (i+1) as 32 bits.	X=A	101
07	BIT	A's X bit is obtained.	A=(A & bit X)>>X	115
08	SFT_R	A is shifted to the right by X bit. (With sign extension)	A=A>>X	Shift No.* 18+103
09	SFT_L	A is shifted to the left by X bit. (With sign extension)	A=A< <x< td=""><td>Shift No.* 18+103</td></x<>	Shift No.* 18+103
0A		No action takes place. (For future use)		
0B	ADD	X is added to A.	A=A+X	89
0C	ADD32	X (i) and X (i+1) are added to A as 32 bits.	A=A+X	104
0D	SUB	X is subtracted from A.	A=A-X	89
0E	SUB32	X (i) and X (i+1) are subtracted from A as 32 bits.	A=A-X	104
0F	MUL_L	A is multiplied by X. (Low-order 32 bits are obtained)	A=A*X	117
10	MUL_H	A is multiplied by X. (High-order 32 bits are obtained)	A=(A*X)>>16	120
11	DIV	A is divided by X.	A=A/X	183
12 to 14		No action takes place. (For future use)		
15	AND	AND of A and X is obtained and saved in A.	A=A&X	92
16	OR	OR of A and X is obtained and saved in A.	A=A X	92
17	XOR	XOR of A and X is obtained and saved in A.	A=A^X	92
18	NOT	NOT of A is saved in A	A= ⁻ A	77
19 to 1E		No action takes place. (For future use)		
1F	CMP_EQ	If A=X, A=1. In all other cases A=0.	A=(A==X)	97
20	CMP_NE	If A!=X, A=1. In all other cases A=0.	A=(A!=X)	97
21	CMP_GT	If A>X, A=1. In all other cases A=0.	A=(A>X)	97
22	CMP_LT	If A <x, a="0.</td" all="" cases="" in="" other=""><td>A=(A<x)< td=""><td>97</td></x)<></td></x,>	A=(A <x)< td=""><td>97</td></x)<>	97
23	CMP_GE	If A≥X, A=1. In all other cases A=0.	A=(A>=X)	97
24	CMP_LE	If A≤X, A=1. In all other cases A=0.	A=(A<=X)	97
25	JMP	X is added to command pointer unconditionally.	cp+=X	75
26	JMPC	If A!=0, X is added to command pointer.	if(A & bit0) cp+=X	96
27	JMPNC	If A=0, X is added to command pointer.	if(~A &bit0) cp+=X	96
28	NEG	A is inverted to –A.	A=-A	77
29	ABS	Absolute value of A is obtained.	A=ABS(A)	83
2A	LIM_G	If A is signed and A>X, then limit to X	If $(A > X) A=X$	107
2B	LIM_L	If A is signed and A <x, limit="" td="" then="" to="" x<=""><td>If (A < X) A=X</td><td>107</td></x,>	If (A < X) A=X	107
2C to 2D		No action takes place. (For future use)		

List of built-in PLC commands

No.	Com- mand	Details	Expression indication	No. of steps
2E	TIMER1	Count up when input [64] is not 0. If counter [65] is higher than level [66], then output [67]=1 If input [64] is 0, and reset counter [65]	Input : 64 Counter : 65 Level : 66 Output : 67	105
2F	TIMER2	Same as TIMER1	Input : 68 Counter : 69 Level : 6A Output : 6B	105
30	TIMER3	Same as TIMER1	Input : 6C Counter : 6D Level : 6E Output : 6F	105
31	TIMER4	Same as TIMER1	Input : 70 Counter : 71 Level : 72 Output : 73	105
32	LPF1	Use accumulator as input, and execute LPF process with X gain. Output is accumulator.	Input : Acc Gain : X Buffer : [74, 75] Output : Acc	134
33	LPF2	Same as LPF1	Input : Acc Gain : X Buffer : [76, 77] Output : Acc	134
34	LPF3	Same as LPF1	Input : Acc Gain : X Buffer : [78, 79] Output : Acc	134
35	LPF4	Same as LPF1	Input : Acc Gain : X Buffer : [7A, 7B] Output : Acc	134

* A refers to the accumulator (32-bit) and X (16-bit) refers to the general memory or dedicated memory.

* If there is no X in the details of each command, the memory No. is random (not used).

* Unless indicated, the commands are handled as signed extensions.

6-11-5 Usage examples

Examples of using the built-in PLC are shown below.

(1) Operation interlock

Specifications)

The forward run command (F.RUN) is interlocked with the external sequence input (PSI)



Block diagram

Parameters)

- 1) C03-0=12 (Disconnect PSI1 from F.RUN, and connect PLC1 and F.RUN commands.)
- 2) C03-7=0 (PSI2 is used for interlock signal, so disconnect from RESET)

Setting the commands)

(LD	Mem14)	U20-0=0114:	Load external sequence input 1 to accumulator.
(SFT_R	MemA1)	U20-1=08A1	: Shift accumulator one bit to the right. (Use fixed memory A1)
(AND	Mem14)	U20-2=1514:	Obtain AND of accumulator and external sequence input 1
(BIT	MemA1)	U20-3=07A1	: Detect bit 1 of accumulator (Use fixed memory A1)
(ST_L	Mem40)	U20-4=0440:	Retract accumulator value (use user memory 40)
(LD	MemA1)	U20-5=01A1	: Load "1" in accumulator
(NOT)	U20-6=1800:	Reverse accumulator (0×FFFFFFE)
(ST_L	Mem41)	U20-7=0441:	Retract accumulator value (use user memory 41)
(LD	Mem28)	U21-0=0128:	Load sequence output (PLC1 to 8) to accumulator
(AND	Mem41)	U21-1=1541:	Clear PLC1 bit on accumulator
(OR	Mem40)	U21-2=1640:	Update PLC1 bit on accumulator
(ST_L	Mem28)	U21-3=0428:	Write accumulative values to sequence output (PLC1 to 8)
(NOP)	U21-4=0000:	End of bank

Setting the number of execution banks)

1) U10-0=1: Set the number of executed banks to 1 (bank 1 only)

Note) Set the number of execution banks after all settings have been completed. Failure to observe this could result in unexpected operations.

6-12 Explanation of standard serial and Modbus communication

The VAT300 is equipped with a serial transmission function using RS485 as a standard. The inverter can be controlled with a host computer using this function.

Either the Modbus network with Modbus protocol or the VAT300 series original communication protocol standard serial communication can be selected with the parameters.

6-12-1 Connection method

This network is configured of one host computer (master) and 1 to 32 VAT300 units (slaves).

CN2 on the basic section or TB3 is used for the connection.

Refer to section 2-4. Precautions for wiring the control signal for details on CN2 and TB3, and for the wiring methods.

The total length of the connected cable must be within 150 meters.

By using a commercially-available RS485-RS232C converter or USB converter unit as a relay, the inverter can be connected to a host computer equipped with a serial port or USB, such as a commercially-available personal computer.

• Connecting the host computer and VAT300 (1-on-1)



- Do not connect both CN2 and TB3 to the host computer.
- CN2 is a 4-pole 4-core modular connector. Pay attention to the number of poles, and prepare the cable and connector.
- Separates the communication cable from the main circuit cable and other power cables.
- A shielded twisted pair cable should be used for connecting TB3 and the host computer. Connect the shielded twisted pair cable's shield to the TB3 SG.
- When using a 1-on-1 connection, set the inverter's resistance (DS1 No. 1 switch on basic section) to the 120Ω side.
- When connecting the TB3 and shielded twisted pair cable, do not solder the wires which are exposed after the sheath is peeled off.
- If the communication is distorted and not carried out properly because of noise, etc., connect a ferrite core, etc., to the cable, and increase the noise resistance.

When connecting several VAT300 units, connect two wires to each TB3 terminal, and couple the VAT300 units.

An example of the connection is shown below.

• Connecting the host computer and VAT300 (connecting several units)



The details of the TB3 terminal section are shown below.





ltem	Specification
Connection method	RS485, 2-wire type
Transmission distance	Total extension distance: 150m
Baud rate	Select from 1200, 2400, 4800, 9600, 14400, 19200, 38400bps
Transmission method	Start-stop synchronization, half-duplex communication
Frame configuration	Start : 1 bit Data : 8 bits Stop : Select from 1 bit or 2 bits Parity : Select from none, odd or even
Error detection	Sum check, parity, framing
Transmission code	8-bit binary or ASCII
Communication protocol	Select from Modbus-RTU communication or standard serial communication
Number of stations	Set between 1 and 32

6-12-2 Communication specifications

The factory settings are shown below.

Communication protoco	1:	Standard serial communication
Baud rate	:	9600bps
Frame configuration	:	Start: 1bit, Data: 8bit, Stop: 2bit, Parity: odd, Station No.: 01

6-12-3 Procedures for enabling communication with host controller

The communication parameters must be set to enable communication with the host controller. The procedure is given below.

- (1) Select C26-0, and select the communication method. Example: C26-0=0: Select standard serial communication.
- (2) Select the station No. Example: C26-2=18
- (3) Set the baud rate. Example: C26-4=5: 38400bps
- (4) Set the number of stop bits. Example: C26-5=1: Stop bit 1 bit
- (5) Set the parity. Example: C26-6=1: No parity
- (6) After completing the settings, turn the power OFF once. When the control power has turned OFF, turn the power ON again.

No.	Parameter	Unit	Default	Min.	Max.	Function										
C26 –	Standard serial transmis	sion setti	ing													
0	Function selection		0.	0.	1.	0:	Standa	ard serial	1: M	odbus						
						Th ch	ie para anged.	meters w	ith a C	mark	belc	w ca	n be			
						Set- ting Para- value meter Basic Extend S/W H/W										
							ting value	ard serial 1: Modbus meters with a O mark below can be Block A Block B, C Parameter Para- meter Basic Extend S/W H/W O O O O O \times X X X X O X X X X O X X X X O X O X X C X O X X X C X O								
4	Parameter change		4	4	-		1	0	0	0	n Jbus mark below can be , C Parameter xtend S/W H/W O O O × × × O × × O × × O × × O × × Dischangeable n receiving answer. =3: 14400 =6: 1200bps -3=9458.2 and =3: Odd t: signed igned t: unsigned					
1	protection		1.	1.	5.		2	×	×	×	×	×				
							3	0	O O O × × × × × × × × × O × × × O × × × O O × × O O × × O O × v: Unchangeable O No. time from receiving ning an answer. O O							
							4	Block A Para- meter Block B, C Parameter Basic Extend SW H/W O O O O × × × × O × × × O × × × O × × × O × O × O × O × O × O × O × O × O × O × O × O × Inigeable ×: Unchangeable ×: cal station No. inimum time from receiving to returning an answer. =2: 9600 =3: 14400 0 =5: 38400 =6: 1200bps ps be set from D21-3=9458.2 and Additional part of the set from D21-3=9458.2 and Additional part of the set from D21-3								
							5	0	×	0) O ×					
							O: Cha	angeable	×:	Uncha	ange	able				
2	Station No.		1.	0.	247.	Set the local station No.										
3	Response timer	sec.	0.00	0.00	2.00	Set the minimum time from receiving command to returning an answer.										
4	CN2 standard serial communication baud rate setting	bps	2.	1.	7.	=1: 4800 =2: 9600 =3: 14400 =4: 19200 =5: 38400 =6: 1200bps =7: 2400bps =6, 7 can be set from D21-3=9458.2 and above				5						
5	CN2 standard serial communication stop bit setting		2.	1.	2.	=1	: 1 bit	=2:	2 bit							
6	CN2 standard serial communication parity setting		3.	1.	3.	=1	: None	=2:	Even	=3	: Od	d				
7	Base section serial communication frequency (speed) unit setting		0.	0.	5.	=0 =1 =2 =3 =4 =5	: 0.01F : 0.1Hz : 0.01% : 0.01F : 0.1Hz : 0.01%	Iz or 0.1r z or 1min 6 unit: sig Iz or 0.1r z or 1min 6 unit: un	min ⁻¹ unit: gned min ⁻¹ u ⁻¹ unit: signed	nit: sig signec nit: uns unsigr	ned I signe ned	ed				

Communication with the set communication method is now possible. An excerpt of the parameter C26 setting details is given below.

6-12-4 Using the VAT300 Series dedicated communication (standard serial communication)

The following exchanges can be carried out with the host computer by using the VAT300 series dedicated communication protocol (hereinafter, standard serial communication).

- (1) Reading and writing of Block-A, B, C, U parameters
- (2) Reading of Block-D monitor parameters
- (3) Reading and writing of sequence commands
- (4) Reading and writing of frequency commands and speed commands
- (5) Reading and writing of torque commands, torque bias 1 settings, drive torque limiter reduction settings, regenerative torque limiter reduction settings
- (6) Reading of fault history

6-12-4-a. Setting the standard serial transmission function

- (1) When executing setting data write (FW) from the host computer and operating, make sure that the sequence command CFS is ON, and that the various setting input point selection C02 is fixed to serial.
 - Example) 1) Operation mode : Remote (RMT) Speed setting input point selection: C02-0=4 (sequence) CFS command : C04-1=4 (controlled with terminal block input PSI4), or
 - 2) Speed setting input point selection: C02-0=2 (serial fixed) The details of the setting data are determined by the control mode selection (C30-0: f0) and FW command data No. Refer to section 6-12-4-g Setting data write (FW) for details.
- (2) When executing sequence command write (CW) from the host computer and operating, make sure that the sequence command COP is ON.

Example)	Operation mode COP command	:	Remote (RMT) C03-8 = 16 (The inverter is always run with the sequence commands from the bost computer.)
			host computer.)

Refer to section 6-12-4-i Sequence command write (CW) for details on the CW command. Refer to section 5-5 Sequence input logic Fig. 5-5 for details on the sequence input logic.

- **Note)** When sending the auxiliary operation sequence command in Fig. 5-5, make sure that control switchover method (J2 setting) C00-6 is set to serial transmission input. Control switchover method (J2 setting): C00-6 = 2 (serial transmission input)
- (3) Set parameter change protection with C26-1.
- (4) Set the local station number with C26-2.
- (5) Set the response timer value with C26-3. The response timer is the timer which specifies the minimum time for the VAT300 to return the response packet after the host computer sends the command packet.



When setting the frequency/speed and controlling the sequence with serial transmission, the automatic start and restart after power failure functions may not operate correctly. This is caused by a difference in the power voltage operation and time for transmitting the command.

6-12-4-b. Transmission procedure

The VAT300 constantly waits for a command from the host computer. When the VAT300 correctly receives a command from the host computer, it always returns a response as shown in Fig. 4.1.



6-12-4-c. Transmission format

<			1 packet Maximum 128 E	Bytes			>
"("	"G"	STN	TEXT	"&"	SUM	")"	CR

- (1) Data format: 8-bit ASCII
- (2) Packet size: Maximum 128 Bytes
- (3) Packet contents
 - "(" : Head code (1 Byte)
 - "G" : VAT300 designation code (1 Byte)
 - STN : Station No. (2 Bytes) Example) Station $1 \rightarrow$ "01"
 - Input with a hexadecimal.
 - TEXT: Text area
 - "&" : Check sum judgment code (1 Byte)

When not using the check sum, delete the check sum judgment code and check sum.

- SUM : Check sum (2 Bytes)
- ")" : Final code (1 Byte)
- CR : Carriage return (1 Byte)

6-12-4-d. Transmission rules

- (1) When there is a request from the host computer, the VAT300 checks the station No. given in the packet, and processes the request when it matches the local station No. If the station numbers do not match, the packet is ignored.
- (2) Any space codes (20Hex) in the packet sent from the host computer are ignored. Note that the check sum is calculated including the space codes.

(Example)



- (3) The check sum is always added to the response packet. The check sum can be omitted from the packet sent from the host computer, but the check sum is always added to the packet sent from the VAT300.
- (4) All transmission and reception data is 8-bit ASCII data.
- (5) All data input before "(" is input in the reception data is ignored.
- (6) Even if "(" is input while receiving the packet, the data received up to that point will be aborted.(Example)



- (7) The reception is interpreted as done only when ")" CR is received.
- (8) Several commands can be arranged in one packet. (Up to nine commands.) In this case, "," is used as the delimiter between commands.

If there are more than ten commands in one packet, error codes (illegal commands) equivalent to the number of excessive commands will be returned from the VAT300.

Up to nine commands will be executed normally. An example of the command and response is shown below.

(Example) Host computer transmission command packet

(<u>G00FW000000100</u>	00 , <u>FR0000</u> , <u>CW000</u>	<u>0000000040402</u>)CR
(1st command)	↑ (2nd command)	(3rd command)
(de	limiter) (delimiter)	

Response packet

(G00 <u>AK</u> , <u>FR</u>	<u>, 00000001000</u> ,	<u>AK</u> & 0E)
$\mathbf{\Lambda}$	$\mathbf{\Lambda}$	\wedge
(Response to	(Response to	(Response to
1st command)	2nd command)	3rd command)

Make sure that the command packet fits within 128 Bytes. Also make sure that the response packet in respect to the command packet is within 128 Bytes.

(9) A broadcast packet can be sent.

By setting the station No. to "FF", all VAT300 units in the transmission path will process the packet. The VAT300 will not send any response packet in respect to the broadcast packet. Thus, only write request commands are valid in the broadcast packet.

(Example)

(G F F F W 0 0 0 0 0 0 0 4 0 4) CR

(By setting the station No. to "FF", the broadcast packet will be received by all stations.)

6-12-4-e. Creating a check sum



The ASCII codes of the characters between "(" and "&" are added with hexadecimal, and the low-order byte of the obtained value is converted into an ASCII code and used for the check sum.

6-12-4-f. Transmission commands

Basic command format

(2 Byte) (4 Byte) Data No. DATA	CMD (2 Byte)	Data No. (4 Byte)	DATA
---------------------------------	-----------------	----------------------	------

Command list

	Host computer to VAT300											
CMD	Data No.	DATA	Function									
FW	000n	Nnnnnnn (7-digit decimal)	Setting data write									
FR	000n	None	Setting data read									
CW	000n	nn ······ nn (12-digit hexadecimal)	Sequence command write									
CR	000n	None	Only sequence command read									
DW	Annn Bnnn Cnnn Unnn	Nnnnnn (6-digit decimal)	Block-A, B, C, U parameter write									
DR	Dnnn Annn Bnnn Cnnn Unnn	None	Block-D, A, B, C, U parameter read									
ER	000n	None	Fault history read									

	Host computer from VAT300											
CMD	Data No.	DATA	Function									
FR	000n	Nnnnnnn (7-digit decimal)	Setting data read (response)									
CR	000n	nn ······ nn (12-digit hexadecimal)	Sequence command read (response)									
DR	Dnnn Annn Bnnn Cnnn Unnn	Nnnnnn (6-digit decimal)	Block-D, A, B, C, U parameter read (response)									
ER	000n	nn ······ nn (44-digit)	Fault history read (response)									
AK	None	None	Successful completion response in respect to write request command									
NK	Error code nn (2 byte)	None	Error response in respect to command									

6-12-4-g. Setting data write (FW)

Function: The setting data is written to the selected setting register when the sequence command CFS is ON and the various setting input point selection: C02 is set to serial fixed. The contents of the setting data are determined by the control mode selection (C30-0: f0) and data No. Refer to Setting data table for the data No.

Command



Response



(2 Byte)

(Error response: Refer to Section 6. List of transmission error codes for details on the error codes.)

Setting data table

Control mode	ontrol mode DATA No. Name			Unit	Min. value	Max. value		
V/f control C30-0 : f0 = 1	0	0	0	0	Frequency command	Frequency command Following Setting (-)		B00-4:Max. frequency setting
	0	0 0 0 Speed command		Speed command	setting	B01-4:Max. speed setting (-)	B01-4:Max. speed setting	
Vector, PM control	0	0	0 0 0 Torque setting		0.1%	-300.0	300.0	
C30-0 : f0 = 2, 3,	0	0	0	0	Torque bias 1 setting	0.1%	-300.0	300.0
4	0	0	0	0	Drive torque limiter reduction setting	0.1%	0.0	100.0
	0	0	0	0	Regenerative torque limiter reduction setting	0.1%	0.0	100.0

Coded data

(Example)



(The data will be negative data when "-" is added.)

The data can be set as negative data by adding "-" to the highest order digit of the DATA area. In the above example, the data is -123.

Frequency command/speed command unit

The unit for the frequency command/speed command can be changed with the C26-7: frequency (speed) unit setting. Refer to the 6-4: Parameter list or explanations.

The default setting is C26-7=0: 0.01Hz or 0.1min⁻¹ (signed)

6-12-4-h. Setting data read (FR)

Function : The setting value set with the FW command is read and returned.

Command



Refer to section 6-12-5-g. Setting data write (FW) Setting data table for details on DATA No.

Response



When the data to be read is coded

For negative read data, a "-" is added to the highest order digit of the data.

(Example)

			DATA	۱.		
_	0	0	0	1	2	3

(If a "-" is attached to the highest order digit, the data is a negative value.)

In the above example, the data is -123.

6-12-4-i. Sequence command write (CW)

Function : A sequence command is issued to the VAT300. The data sent at this time is held by the internal sequence command register until it is rewritten. To validate this sequence command, the sequence command: COP must be ON.

Refer to section 6-12-5-a Setting the standard serial transmission function for details on setting COP.

Command



6-12-4-j. Sequence command read (CR)

Function : The sequence command set with the CW command is read and returned.



6-12-4-k. Block- A, B, C and U parameter write (DW)

Function : The Block-A, B, C and U parameter data in the VAT300 unit is changed. Note that the parameter change protection may be set with C26-1. Parameters which cannot be changed during operation, cannot be changed during operation. Other parameters which cannot be changed during serial transmission are listed in the cautions.

The data is configured from the list of constants without the decimal point.

Example) A010 (Acceleration ramp time -1) $50.0 \text{ s} \to 000500$

Command

<example: block-a<="" th=""><th>parameter</th><th>setting></th></example:>	parameter	setting>
---	-----------	----------



А Κ (Successful completion) Ν Κ Error code ← (2 Byte)

(Error response Refer to Section 6. List of transmission error codes for details on the error codes.)

Setting data table





The parameters that cannot be changed with the write command are shown below. If the write command is executed for these parameters, an error will be returned (Parameter Read/Write Disable).

- A04-0 to 7 (Custom constants)
- C10-0 to 7 (Custom parameter selection)
- A05-0 to 2 (Block-B, C parameter display skip)
 C26-0 to 7 (Serial transmission setting)
- B19-0 (Automatic tuning function)
- · Parameters not related to control mode selected with C30-0: f0.
 - (Parameters that are not displayed on the operation panel.)

Coded data

The data can be set as negative data by adding "-" to the highest order digit of the DATA area.



6-12-4-I. Block-A, B, C, U and D parameter read (DR)

Function : The values of the block-A, B, C, U and D parameters in the VAT300 are read.

Command



(4-digit decimal data No. Refer to the previous setting data table for details on the

Response



Ν	Κ	Error code	 ←
		(2 Byte)	

(Error response: Refer to Section 6. List of transmission error codes for details on the error codes.)

Setting data table

D	AT	A N	о.	Name					
D	n	n	n	Block-D parameter					
А	n	n	n	Block-A parameter					
в	n	n	n	Block-B parameter					
С	n	n	n	Block-C parameter					
U	n	n	n	Block-U parameter					
Sub No.									
	L			— Main No.					



If the data is coded data targeted for read, "-" will be attached to the highest-order digit of DATA. DATA



6-12-4-m. Fault history read (ER)

Function : The fault history buffer of the VAT300 is read.

Command



(4-digit decimal data No. refer to the table on the right for details on the number.)

I	DAT	A No	-	Explanation
0	0	0	0	Latest fault history
0	0	0	0	Previous fault history
0	0	0	0	2nd to last fault history
0	0	0	0	3rd to last fault history

Response



There are four fault history buffers from the latest to the 3rd to last fault histories. One group of these buffers is stored in the response.

In one buffer, two fault causes, and the output frequency, output current, DC voltage, hardware fault signal, cumulative power ON time, and cumulative run time at the time of fault occurrence are stored. Refer to Appendix Table 4 for the fault cause display and details.

Details of group (DATA)

		-		•																		
;	0	3	0	4	;	0	0	0	0	;	0/—	0	0	0	0	0	;	0	0) ()	0
	Primary fault Secondary fault (4-digit hexadecimal) (4-digit hexadecimal)						Output frequency (5-digit decimal + code)							Output current (4-digit decimal)								
	;	0	3	0	4	;	0	0	0	0	;	0	0	0	0	0	;	0	0	0	0	0
DC voltage Hardware fault signal (4-digit decimal) (4-digit hexadecimal)							Cumu (5-dia	ilativo it deo	e pov cimal	ver C	ON tim	ne	C (!	Cumu 5-dig	ilativ it de	ve ru ecima	n tin al)	ne				

The above information is contained in the response data. A 43-byte data is sent. ";" is used to delimit each item in the group.

Refer to Appendix 3 List of fault codes for details on the primary fault and secondary fault. The hardware fault signal displays the status of the D05-1: Hardware detection fault status bit as a 0 to FF hexadecimal.

6-12-4-n. List of transmission error codes

The error codes added to the NK response in respect to a command from the host computer are shown below.

Error code	Error name	Details
01	Transmission error	A transmission error, such as parity error or overrun error, was detected.
02	Check sum error	The check sum is illegal.
10	Illegal command	The command is not defined.
11	Illegal parameter	 The parameter does not exist, or The transmission format does not match.
12	Illegal data	1) The data limit is exceeded, or 2) The format does not match.
13	Parameter protect	The designated parameter is write-protected. (Write-protected with C26-1.)
14	Changing not possible during operation	The designated parameter cannot be changed during operation.
15	Transmission/reception buffer overflow	The transmission/reception data exceeds 128 Bytes.
16	Parameter read/write disable	A read or write-prohibited parameter was accessed.
20	EEPROM BUSY	The VAT300 is using the non-volatile memory.

6-12-4-o. Serial transmission sequence command Bit assignment table

DATA No : 0 0 0 0

DATA1

	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0	
Always 0		AFS3
PICK		PROG
AUXDV		Always 0
IVLM		S0
IBDW		S1
BUP		S2
Always 0		S3
Always 0		SE

DATA2



DATA No : 0 0 0 1

DATA1

	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0	
Always 0		MBRK_ans
Always 0		- PRST
Always 0		PIDEN
Always 0		S5
Always 0		S6
OCL LV2		S7
OCL LV1		AUXSW0
PLS_IN		AUXSW1

DATA2

	15 14	13 12	11 10	98	7	6 5	4	3 2 1 0	
Always 0									Always 0
Always 0									ACR
Always 0									PCTL
Always 0									LIM1
FPOS							L		LIM2
TRQB2						L			MCH
TRQB1									RF0
DEDB									DROOP
6-12-5 Using Modbus communication

The Modbus communication method is a single master/slave method. Only the master can start communication. The slave detects this communication, executes the designated function, and returns a response message. The master can communicate with the designated slave (station No.) and broadcast to all slaves. When using broadcast transmission, the slave only carries out the designated function and does not return a response message.

The following exchanges can be made with the host computer by using this communication function.

- (1) Reading and writing of Block-A, B, C, U parameters
- (2) Reading of Block-D monitor parameters
- (3) Reading and writing of sequence commands
- (4) Reading and writing of frequency commands and speed commands
- (5) Reading and writing of torque commands, torque bias 1 settings, drive torque limiter reduction settings, regenerative torque limiter reduction settings
- (6) Reading of fault history
- (7) Reading of sequence status

6-12-5-a. Setting the Modbus communication function

- (1) When executing setting data write from the host computer and operating, make sure that the sequence command CFS is ON, and that the various setting input point selection C02 is fixed to serial.
 - Example) 1) Operation mode : Remote (RMT) Speed setting input point selection: C02-0=4 (sequence) CFS command : C04-1=4 (controlled with terminal block input PSI4), or
 - 2) Speed setting input point selection: C02-0=2 (serial fixed)

The details of the setting data are determined by the control mode selection (C30-0: f0). Refer to 6-12-5-f List of Modbus registers and setting examples for details. Refer to Fig. 5-9-1 to Fig. 5-9-8 for the sequence for selecting the determined setting data.

(2) When executing sequence command write from the host computer and operating, make sure that the sequence command COP is ON.

Example)	Operation mode	:	Remote (RMT)
	COP command	:	C03-8 = 16
			(The inverter is always run with the sequence commands from the
			nost computer.)

Refer to section 5-5 Sequence input logic Fig. 5-5 for details on the sequence input logic.

- **Note)** When sending the auxiliary operation sequence command in Fig. 5-5, make sure that control switchover method (J2 setting) C00-6 is set to serial transmission input. Control switchover method (J2 setting): C00-6 = 2 (serial transmission input)
- (3) Set parameter change protection with C26-1.
- (4) Set the local station number with C26-2.



When setting the frequency/speed and controlling the sequence with serial transmission, the automatic start and restart after power failure functions may not operate correctly. This is caused by a difference in the power voltage operation and time for transmitting the command.

6-12-5-b. Modbus protocol

The VAT300 is compatible only with the Modbus compliant RTU mode. The communication protocol for the RTU mode is explained below.

End/start	Address	Function	Data	CRC	End/start
Silent interval of 3.5 characters or more	8bit	8bit	8bit × n	16bit	Silent interval of 3.5 characters or more
Changeable with C26-3	Slave: 1 to 99 Broadcast: 0	Correspondence: 0x01, 0x02, 0x03, 0x08, 0x0F, 0x10, 0x17 Exception response: BIT7: ON		Calculated for each command	Changeable with C26-3

In the RTU mode, a silent interval of 3.5 characters or more (varies according to baud rate) is inserted at the start and end of transmission. The silent interval is a state in which data is not sent. Note that if C26-3 is not equal to 0.00, the setting value will be followed.

The slave side station No. is designated as Address. If a request is made from the slave side, the local station No. is set. The station No. is set with C26-2.

The function executed by the slave is designated in Function and Data. Refer to the following explanations for details on the functions.

CRC is an error check. Each is automatically calculated and set based on the details of Address to Data. The following calculation method is used.

- 1) CRC work = $0 \times FFFF$
- 2) CRC work low-order byte = CRC work low-order byte XOR send data (8-bit)
- 3) The following process is executed according to the state of the CRC work LSB.

CRC work LSB	Process
0	CRC work is shifted one bit to the right. MSB is set to 0 at this time.
1	CRC work is shifted one bit to the right. MSB is set to 0 at this time. The following operation is executed. CRC work = CRC work XOR 0xA001

- 4) The step 3) process is repeated for 8 bits (8 times).
- 5) The steps 2) to 4) are repeated for all send data (data from Address to before CRC).
- 6) The CRC work calculated with steps 1) to 5) is CRC.

Example of command:

<u>01 03 0002 0002 68</u>	(Send command: Read torque setting)
	CRC (Each is automatically calculated and set.)
	DATA2 (number of registers)
	DATA1 (start register)
	Function
	— Address

(designates the station No. of the send destination slave)

\land	CAUTION
---------	---------

In the command example, a space is inserted to delimit each function. Do not insert the spaces when actually inputting the command.

In the above command, input [01030002000265CB], and send.

6-12-5-c. VAT300 Modbus communication time chart

The time chart for communication with the host computer is shown below.



The host computer waits for the silent interval time, and then sends one packet of data.

When sending data continuously, the host computer waits for the silent interval again.

The VAT300 recognizes the data sent after waiting the silent interval as the head of the packet, and starts the reception process. After the data is received, if a state in which no data is received for longer than the silent interval continues, the VAT300 determines that the reception is completed, judges and processes the contents of the command, and creates a request package.

6-12-5-d. Exceptional response code

The VAT300 judges and processes the data based on the packet received from the host computer. If the data is illegal or if data exceeding the range is received, an exception response is returned to indicate that the process cannot be completed.

The exceptional response is sent by setting bit7 of the sent function code to 1.

The exception response code sent after the function code are shown below.

Code	Name	Occurrence conditions
01h	Illegal function	A function code, which is not listed, was set.
02h	Illegal data address	An address which does not exist was set.
03h	Illegal data	An error was found in the data setting.
04h	IO data incorrect setting	In the MUX data instruction, the set and input data exceeds the maximum value or minimum value.
05h	MUX data corresponding No. not found	In the MUX data instruction, the set and input parameter block No. or data No. does not exist.
06h	MUX data incorrect setting	In the MUX data instruction, the write data set with the multiplex data is an illegal data.
07h	MUX data lock	In the MUX data instruction, write or read was not possible. (Refer to CC-Link Function Specifications.)
0Bh	Parameter function code incorrect	A parameter function code which does not exist was set.
0Ch	Outside input data range	The written data exceeds the inverter setting range.
10h	No corresponding parameter	The read/write destination parameter was not found, or is set to "hide".
14h	EEPROM busy	Non-volatile memory is used.

List of exception response codes

An example of the exception response sent from VAT300 is shown below.



CAUTION

In the command example, a space is inserted to delimit each function. Do not insert the spaces when actually inputting the command. In the above example, the response is displayed as [018302C0F1].

6-12-5-e. List of standard serial communication code correspondence

The correspondence of the previous standard serial communication command and the Modbus functions is shown below.

Function	Start register: Function	Standard serial communication command
01h Read Coil Status	0000 : Sequence command (input) 1 read 0020 : Sequence command (input) 2 read	CR
02h Read Input Status	Sequence status (output) read	_
	0000 : V/fFrequency setting read0000 : VEC/PMSpeed setting0002 : VEC/PMTorque setting0004 : VEC/PMTorque bias 1 setting0006 : VEC/PMDrive torque limiter reduction setting0008 : VEC/PMRegenerative torque limiter reduction setting	FR
0.2.6	03E9 : Common Multiplexed data reading value	_
Read Holding Register	Fault information read0063 : Read latest fault information0073 : Read previous fault information0083 : Read 2nd to last fault information0093 : Read 3rd to last fault information00A3 : Read latest minor fault information00B3 : Read previous minor fault information00C3 : Read 2nd to last minor fault information00C3 : Read 3rd to last minor fault information00D3 : Read 3rd to last minor fault information	ER
08h Diagnostic	Self-diagnosis mode	_
0Fh Force Multiple Coils	0000 : Sequence command (input) 1 write 0020 : Sequence command (input) 2 write	CW
10h Preset Multiple Registers	0000 : V/fFrequency setting0000 : VEC/PMSpeed setting0002 : VEC/PMTorque setting0004 : VEC/PMTorque bias 1 setting0006 : VEC/PMDrive torque limiter reduction setting0008 : VEC/PMRegenerative torque limiter reduction setting	FW
	Parameter write	DW
	03E7 : Common MUX command write for the multiplexed data reading value	-
17h Read Multiple Registers	Parameter read	DR

6-12-5-f. List of Modbus registers and setting examples

The details of each function and examples of setting the commands are given in the following section.

Function 01h (Read Coil Status)

Details of function	Start register designation	Number of registers
Sequence command (Input) read	0000h : Sequence command 1 0020h : Sequence command 2	0020h (Sequence data 32 bit)

Function : The sequence command (input) is read.

This function carries out the same process as the CR command in the standard serial transmission function.

Refer to section 6-12-4-o. Serial transmission sequence command bit assignment table for the layout of bits in the read command.

Setting example:

Modbus command setting example					
01 01 0000 0020 3DD2					
	CRC code				
	Number of registers				
	Start register				
	Function				
	Station No.				
Command contents : The co	Command contents : The contents of the sequence command 1 are read.				
Response					
01 01 04 00234167 7BA1 (Si	uccessful example) CRC code Details of data Size (4byte) Function Station No.	01 81 02 C191 (Example of failure) CRC code Exceptional response Function Station No.			

The correspondence of the read data contents and serial transmission sequence command's bit assignment table is shown below.

Standard serial (DATA No.)	MODBUS (Start register)	Details of data	
0000	\rightarrow 0000	<u>1003</u> <u>5007</u>	
0001	\rightarrow 0002	DATA 1	
		DATA 2	

• Function 02h (Read input Status)

Details of function	Start register designation	Number of registers
Sequence status read	000h : Fixed	0040h (Sequence data 64 bit)

Function : The sequence status is read.

Refer to the bit assignment table on the next page for the layout of bits in the read command.

Setting example:

Modbus command setting example				
01 02 0000 0040 79FA	 CRC code Number of registers Start register Function Station No. contents of the sequence status a 	are read.		
Response				
	11F D37D (Successful example) CRC code Status data 2 Status data 1 Size (8 byte) Function Station No.	01 82 03 00A1 (Example of failure) CRC code Exceptional response Function Station No.		

The contents of the read status data are as follow.



Refer to the following table for the bit assignment of each status.

Serial transmission sequence status bit assignment table

Sequence status 0

	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0	
IDET	$\vdash \rightarrow \mid $	ATN
REV		SPD1
LCL		SPD2
RDY2		COP
RDY1		EC0
MC		EC1
FLT		EC2
RUN		EC3

Sequence status 1



Sequence status 2



Sequence status 3

	15 14 13 12 11 10 9	8	76	5 4	3 2 1 0	
MPO8						Always 0
MPO7						Always 0
MPO6						Always 0
MPO5						Always 0
MPO4						Always 0
MPO3						Always 0
MPO2						Always 0
MPO1						Always 0

• Function 03h (Read Holding Register)

Control mode	Details of function	Start register	Number of registers	Unit	Min. value	Max. value
V/f control	Frequency setting	0000h	0002h (32-bit data)	Following	B00-4:Max. frequency setting (-)	B00-4:Max. frequency setting
	Speed setting	0000h	0002h (32-bit data)	C26-7 setting	B01-4:Max. speed setting (-)	B01-4:Max. speed setting
IM vector	Torque setting	0002h	0002h (32-bit data)	0.1%/LSB	-300.0	300.0
PM motor control	Torque bias 1 setting	0004h	0002h (32-bit data)	0.1%/LSB	-300.0	300.0
	Drive torque limiter reduction setting	0006h	0002h (32-bit data)	0.1%/LSB	0.0	100.0
	Regenerative torque limiter reduction setting	0008h	0002h (32-bit data)	0.1%/LSB	0.0	100.0
Common	Multiplexed data reading value	03E9h	0002h (32-bit data)			

Function :

Frequency setting to Regenerative torque limiter reduction setting

These functions carry out the same process as the FR command in the standard serial transmission function.

Multiplexed data reading value

This function reads the multiplexed data and is used when using a PLC without supporting Function17h. Refer to section 6-12-5-g.

Setting example:

Modbus command setting example						
<u>01 03 0002 0002 65CB</u>						
	C code of registers					
Start	t register					
Fund	ction					
Stati	on No.					
Command contents : Torque setting value is read.						
Response						
01 03 04 000003E8 FA8D (Succes	ssful example) <u>0</u>	<u>1 83 02 C0F1</u> (E>	ample of failure)			
	code		CRC code			
Data	1		Exceptional response			
Size	(4 Byte)		Function			
Fund	ction		Station No.			
Stati	on No.					

Frequency command/speed command unit

The unit for the frequency command/speed command can be changed with the C26-7: frequency (speed) unit setting. Refer to the 6-1: Parameter list or explanations.

The default setting is C26-7=0: 0.01Hz or 0.1min⁻¹ (signed)

Deta	ils of function	Start register	Number of registers
	Latest fault history	0063h	0010h
	Previous fault history	0073h	0010h
	2nd to last fault history	0083h	0010h
Fault history buffer	3rd to last fault history	0093h	0010h
	Latest minor fault history	00A3h	0010h
	Previous minor fault history	00B3h	0010h
	2nd to last minor fault history	00C3h	0010h
	3rd to last minor fault history	00D3h	0010h

Function : One block of the fault history is read.

This function carries out the same process as the ER command in the standard serial transmission function. Refer to the following section for the contents read out.

Setting example:

Modbus command setting example					
<u>01 03 0063 0010 B418</u>					
	CRC code				
	Number of registers				
	Start register				
	Function				
	Station No.				
Command contents : Torque setting value is read.					
Response					
	Successful example) CRC code Data Size (32byte)	01 83 02 C0F1 (E	xample of failure) CRC code Exceptional response Function		
	Function		Station No.		
	Station No.				
Refer to the following section	n for the data contents.				

The data is configured of 32 bytes.

Each item is grouped in a 4-byte section. The details of the 4 bytes are shown below. (The values in the following table are a setting example.)

00000203	0000040D	000003E8	0000005F	0000013A	00000001	0000000	0000000
Primary fault details	Secondary fault details	Frequency value at fault	Current value at fault	DC voltage at fault	Hardware fault signal	Cumulative power ON time	Cumulative run time
		0.01Hz/LSB	0.1A/LSB	1V/LSB		1 hour/LSB	1 hour/LSB

Refer to Appendix 3 Fault Codes for details on the primary fault and secondary fault.

The hardware fault signal displays the status of the D05-1: Hardware detection fault status bit as a 0 to FF hexadecimal.

Function 0Fh (Force Multiple Coils)

Details of function	Start register command	Number of registers	No. of bytes
Sequence command	0000h : Sequence command 1	0020h	0004h
(input) write	0020h : Sequence command 2	(Sequence data 32 bit)	

Function : The sequence command is written.

This function carries out the same process as the CW command in the standard serial transmission function.

A 4byte command can be written in one command.

Refer to section 6-12-4-o. Serial transmission sequence command bit assignment table for details on the bit assignment of the sequence command to be written in.

Setting example:



The correspondence of the written sequence command bit assignment is shown below.

Standard serialMODBUS(DATA No.)(Start register)	Details of data
$0 \ 0 \ 0 \ 0 \ 0 \ \rightarrow \ 0 \ 0 \ 0 \ 0 \ $	<u>0123 4567</u>
$0 \ 0 \ 0 \ 1 \rightarrow 0 \ 0 \ 2 \ 0$	DATA 1
	DATA 2

Control mode	Details of function	Start register	Number of registers	Number of bytes	Unit	Max. value	Min. value
V/f control	Frequency setting	0000h	0002h (32-bit data)	04h	Following C26-7	B00-4:Max. frequency setting (-)	B00-4:Max. frequency setting
	Speed setting	0000h	0002h (32-bit data)	04h	setting	B01-4:Max. speed setting (-)	B01-4:Max. speed setting
IM vector	Torque setting	0002h	0002h (32-bit data)	04h	0.1%/LSB	-300.0	300.0
control PM motor	Torque bias 1 setting	0004h	0002h (32-bit data)	04h	0.1%/LSB	-300.0	300.0
control	Drive torque limiter reduction setting	0006h	0002h (32-bit data)	04h	0.1%/LSB	0.0	100.0
	Regenerative torque limiter reduction setting	0008h	0002h (32-bit data)	04h	0.1%/LSB	0.0	100.0

• Function 10h (Preset Multiple Registers)

Function : A value is written into each setting.

This function carries out the same process as the FW command in the standard serial transmission function.

Setting example:

Modbus command	setting example					
01 10 0000 0002 04 00001770 FDBB						
	ode					
Data (4	byte)					
Size						
Numbe	r of registers					
Start register						
Function Station No.						
Command contents : The data value (60.00Hz) is written to the frequency setting.					
Response						
01 10 0000002 41C8 (Successful example) CRC code Response data Function	01 90 02 CDC1 (Example of failure) CRC code Exceptional response Function					
Station No.						

Frequency command/speed command unit

The unit for the frequency command/speed command can be changed with the C26-7: frequency (speed) unit setting. Refer to the 6-1: Parameter list or explanations.

The default setting is C26-7=0: 0.01Hz or 0.1min⁻¹ (signed)

Details of function	Start register designation	Number of registers	Number of bytes	
Parameter write	03EBh	0003h (48 bit-data)	06h	The parameter No. and parameter value are set in the data section.
MUX command write	03E7h	0001h (16 bit-data)	02h	The parameter No. value are set in the data section.

Function :

Parameter write

A value is written to the parameter. This function carries out the same process as the DW command in the standard serial transmission function.

MUX command write

This function is used when using a PLC without supporting Function17h. Refer to section 6-12-5-g..

Setting example:

Modbus command setting example			
01 10 03EB 0003 06 A0000001388 8981			
	CRC code Data (8byte)		
	Size		
	Number of registers		
	Start registers		
	Function		
	Station No.		
Command contents : The data value (50.00Hz) is written to parameter A00-0. Response			
01 10 03EB 0003 F078(Successful example)	01 90 0B 0DC7 (Example of failure)		
CRC code	CRC code		
Response Data	Exceptional response		
Function	Function		
Station No.	Station No.		

Data setting (Byte):

A000	00001388
Parameter designation section	Data designation section

Divide the parameter designation section as shown below and set the parameter No.



Function	Function code
Block-A parameter designation	А
Block-B parameter designation	В
Block-C parameter designation	С
Block-U parameter designation	E

Function 17h (Read Multiple Registers)

Details of function	Start register	Number of registers	No. of bytes
Read parameter value	03E9h	0002h (32-bit data)	-
Read parameter No. setting	03E7h	0001h (16-bit data)	02h

Function : The parameter contents are read.

This process carries out the same process as the DR command in the standard serial transmission function.

Setting example:



Divide the parameter designation section as shown below and set the parameter No.



Function	Function code
Monitor parameter designation	D
Block-A parameter designation	А
Block-B parameter designation	В
Block-C parameter designation	С
Block-U parameter designation	E

CAUTION

The following parameters cannot be changed using Function 10h "setting data write". If the write command is used to the following parameters, the error should be found.

A04-0 to 7 : Custom parameters

A05-0 to 2 : Parameter B and C indicatory skip

B19-0 : Automatic tuning selection

C10-0 to 7 : Custom parameter register

C26-0 to 7 : Standard serial transmission setting

Parameters having no relation to the control mode selected by C30-0:f0

Parameters not displayed on the operation panel by setting A05-0 to 2.

CAUTION

The The following parameters cannot be read using Function 17h and Function 03h + 10h. D04-0 to 7 : Sequence status

D05-0 to 1 : Minor fault monitor

D07-0 : Pump operation status monitor

D08-B : Sequence input terminal status display

D08-C : Speed detection signal input status display

D20-0 : Fault history monitor

D20-1 : Minor failure past record indication

D20-2 : Parameter A, B and C modification list entry

D20-3 : Sequence input display (dedicated for LCD panel)

D20-4 : Sequence output display (dedicated for LCD panel)

D22-0 : Automatic tuning progression display

D30-0 : Inverter type

D30-1 : Option PCB

D30-2 to 5 : Field network option failure monitor

A04-0 to 7 : Custom parameters

C10-0 to 7 : Custom parameter register

However, the following parameters can be read by using other functions

D04-0 to 3 (Sequence status-Input 1 to 4) : can be read by Function 01h

D04-4 to 7 (Sequence status-Output 1 to 4): can be read by Function 02h

D20-0 (Fault history monitor) : can be read by Function 03h

D20-1 (Minor failure past record indication) : can be read by Function 03h

6-12-5-g. Additional function of Modbus

The multiplexed data read through Function 17h can also be read by using Function 10h and 03h at the same time.

Function	Details of function	Start register	Number of registers	No. of bytes
03h	Multiplexed data reading value	03E9h	0002h (32-bit data)	-
10h	MUX command write for the multiplexed data reading value	03E7h	0001h (16-bit data)	02h

In order to read parameters, follow the procedures below.

1) Set the parameter using Function 10h.

2) Set the parameter by using Function 03h, and the parameter setting can be read.

Setting example:

1) Set the parameter using Function 10h.

Modbus command setting example		
<u>01 10 03E7 0001 02 B015 3688</u>		
	— CRC code	
	 Parameter No. 	
	– Size	
	 Number of registers 	
	 Start register 	
	- Function	
	 Station No. 	
Command contents : Set the parameter B01-	5.	
Response		
01 10 03E70001 B1BA (Successful example) CRC code Response data Function Station No.	01 90 03 0C01 (Example of failure) CRC code Exceptional response Function Station No.	

The parameter setting method is the same as that of Function 10h and 17h (refer to the next page).

2) Set the parameter by using Function 03h, and the parameter setting can be read.

Modbus command setting example		
<u>01 03 03E9 0002 15BB</u>		
	CRC code	
	Number of registers	
	Start register	
	Function	
	Station No.	
Command contents : Data read.		
Response		
01 03 04 00000708 F9C5 (Successful example) CRC code Response data Size(4byte) Function Station No.	01 83 10 40FC (Example of failure) CRC code Exceptional response Function Station No.	

When the above procedure of 1) and 2) are correctly transferred, B01-5 will be shown in the response data column.

This time the response data should be 00000708h=1800d (default of B01-5)

Divide the parameter designation section as shown below and set the parameter No.



Function	Function code
Monitor parameter designation	D
Block-A parameter designation	А
Block-B parameter designation	В
Block-C parameter designation	С
Block-U parameter designation	E

6-13 ROM revisions

Functions changed / added by the revised ROMs

6-13-1 External failure function (available from the version 9457.0+9458.1)

- (1) This function enables to cause a failure intentionally by a signal through the programmable sequence input terminal and to stop the inverter.
- (2) The inverter will stop with free-running.
- (3) The sequence inputs for the external failure function (C05-8~F) should be allocated to the input terminals.
- (4) The sequence inputs and failure codes are as listed below.

Sequence inputs	Failure codes
C05-8	E.FLT1
C05-9	E.FLT2
C05-A	E.FLT3
C05-B	E.FLT4
C05-C	E.FLT5
C05-D	E.FLT6
C05-E	E.FLT7
C05-F	E.FLT8

(5) Return from the failure status after checking all the allocated input terminals are OFF (without failure) and also there is any other failure caused.

Notes for External failure function

• If a failure has already existed, the panel display will not be renewed even if the input terminals are turned ON.

• When plural input terminals are allocated for this function and are turned ON at the same time, the panel will display the failure code of the first terminal turned ON.

• This function is only available by the input through the terminal board. This function will not work by the signals input thorough Modbus, the standard serial interface, etc..

6-13-2 Field network option failure monitor (available from the version 9457.0+9458.3)

D30-2	
D30-3	

Field network option failure monitor 1 (status)

Field network option failure monitor 2 (status)

These parameters will be displayed when the field network optional PCB is installed. The segment corresponding to the error on the PCB will be turned on, and will be turned off when the error is eliminated.

D30-4	
D30-5	

Field network option failure monitor 1 (latch)

Filed network option failure monitor 2 (latch)

These parameters will be displayed when the field network optional PCB is installed. If transmission error is detected as failure (C34-1=2), the segment corresponding to the error on the PCB will be turned on, and will not be turned off even when the error is eliminated. The segment will be turned off by the failure reset. If transmission error is not detected as failure or is detected as minor failure, each segment will not be turned on.



6-13-3 Analogue input display (available from the version 9457.0+9458.4)

D08-3	Al1 Input voltage display
D08-4	Al2 Input voltage display
D08-5	AI3 Input voltage display

The voltage on Al1, 2 and 3 terminals will be displayed in a unit of 0.01V. When the Al terminals are for current setting, "0" will be displayed.

D08-6	Al1 Input current display
D08-7	Al2 Input current display
	The summer the Ald and AQ terminals will be displayed in a write for Adam A

The current on the Al1 and A2 terminals will be displayed in a unit of 0.01mA. When the AI terminals are for voltage setting, "0" will be displayed.

D08-8	Al1 Input display (in %)
D08-9	Al2 Input display (in %)
D08-A	Al3 Input display (in %)
	The current or voltage on the Al1, 2 and 3 terminals will be displayed in % against 10V and

20mA as 100%.

D08-B

Sequence input terminal status display

The input status of the sequence input terminals (PSI1~7) and the sequence input terminals on the relay PCB (PSI8~11) will be displayed.

D08-C

Speed detection signal input status display

Encoder signal input status will be displayed.



Sequence input terminal status(D08-B)



Speed detection signal input status(D08-C)

Chapter 7 Options

7-1 Outline of options

The VAT300 Series options include those shown below. This chapter will focus on the stand-alone options and main circuit wiring devices.





Table	7-1-a
-------	-------

Item Type		Function
Main circuit	wiring devices	
Circuit Breaker (MCCB) or fuse	(Refer to Table 7-1-b.) Refer to Chapter 9 when using a UL/cUL compliant product.	Always install this device to protect the wiring of the inverter and peripheral devices.
Magnetic contactor (MC)	Select a device for the inverter rating. (Refer to Table 7-1-b.)	Install this device to provide an operation interlock. When using the DB unit, always install this device to protect the DBR. (Refer to Fig. 2-3-a.)
Stand-alone	options	
ACL	ACR-DDD (Refer to Table 7-1-b.)	Always install the AC reactor (ACL) in the following cases. - For N045K0/X055K0 or lower capacities (heavy duty) When the capacity of the power supply transformer exceeds 500kVA - For X075K0 or higher capacities (heavy duty) When the capacity of the power supply transformer exceeds 10 times the inverter capacity. This is also effective in improving the power factor of the inverter input, in suppressing the current high harmonics and extending the life of the main circuit's electrolytic capacitor. The power factor will be approx. 0.9.
DCL	DCR-DDD (Refer to Table 7-1-b.)	Same as ACL, DC reactor (DCL) is effective in improving the power factor of the inverter input, in suppressing the current high harmonics and extending the life of the main circuit's electrolytic capacitor. The power factor will be approx. 0.9.
EMI filter	3SUPD-DDD (Refer to Table 7-1-b.)	This device suppresses the electromagnetic noise generated by the inverter. Mounting of this device is recommended for creating a balance with the peripheral devices of the inverter.
DB unit	U2KV23DBU-□□ (Refer to Table 7-1-b.)	This is used when the motor is to be stopped with dynamic braking.
Surge Absorber	ACFRxxx + RC filter	This suppress surge voltage at motor side, which may be generated, if length of output motor cable exceeds of 50mts

7. Options

Built-in PCB options (These are built-in type options mounted on the basic PCB of the inverter.)					
ltem	Type (Instruction manual)	Function		Indication of rating nameplate (Note 1)	
Speed detection 1 (complimentary type compatible)	U30V24DN1 N62P30609=1-01 (PCST-3480)	This is a speed detection PCB for the complimentary output type encoder. Response frequency: Change between 60±10kHz and 20kHz.	Ι	1	
Speed detection 2 (line driver compatible)	U30V24DN2 N62P30610=1-01 (PCST-3481)	This is a speed detection PCB for the line driver output type encoder. Response frequency: 250kHz (signal: A, B, Z, S phase)	Ι	2	
Speed detection 3 (PM compatible)	U30V24DN3 N62P30611=1-01 (PCST-3482)	This is a speed (pole position) detection PCB for the PM drive control, and is compatible with the line driver output type encoder. Response frequency: 250kHz (signal: A, B, Z, U, V, W phase)	Ι	3	
Speed detection 4 (Note 2)	U30V24DN4 N62P30642=1-01 (PCST-3483)	Speed detection PCB compatible with Heidenhain ERN1387. 1Vp-p 2-phase, 2-set sine wave + Z-phase pulse	Ι	4	
Speed detection 6	U30V24DN6 N62P30609=2-01 (PCST-3480)	This is a speed detection PCB for the single-phase complementary output type encoder circuit. The signal high level is set to 4V or more, and the low level is set to 1.0V or less.	Ι	6	
Relay interface	U30V24RY0 N62P30612=1-01 (PCST-3477)	This is used to expand the contact input/output points. Relay input : 4 points (PSI8 to 11) 1c contact output : 4 points (PSO4 to 7)	III	Ν	
Parallel interface	U30V24PI0 N62P30614=1-01 (PCST-3475)	This is used to receive parallel settings from the PLC. Parallel data input : 16 bits Data length : 16, 12, 8 bits selective Format : Binary or BCD selective Open collector output : 2 points (PSO4, 5)	Ш	М	
Insulated Al/AO (Note 2)	U30V24AI0 N62P30622=1-01 (PCST-3479)	An insulated 4ch analog input, analog output is possible. Analog input : 16 bits (input range ±10V) Analog output : 12 bits (output range 10V)	Π	S	
Profibus-DP interface	U30V24SL0 N62P30616=1-01 (PCST-3466)	This is used to make a connection with the network on the Profibus-DP communication protocol. Transmission speed : 12Mbps No. of stations : 126 stations in one network	III	Н	
CC-Link interface	U30V24SL3 N62P30619=1-01 (PCST-3472)	This is used to make a connection with the CC-Link network. Transmission speed : 156kbps, 625kbps, 2.5Mbps, 5Mbps, 10Mbps (DIP switch settings can be made.) No. of stations : 64 stations in one network	III	к	
DeviceNet interface	U30V24SL2 N62P30618=1-01 (PCST-3470)	This is used to make a connection with the DeviceNet network. Transmission speed : 125kbps, 250kbps, 500kbps (DIP switch settings can be made.) No. of stations : 64 stations in one network	III	J	
CANopen interface	U30V24SL1 N62P30617=1-01 (PCST-3468)	This is used to make a connection with the CANopen network. Transmission speed : 125kbps, 250kbps, 500kbps, 1Mbps (DIP switch settings can be made.) No. of stations : 128 stations in one network	Ш	I	

(Note 1) "0" indicates that the optional PCB is not installed. (Note 2) The speed detection 4 (U30V24DN4) and insulated AI/AO (U30V24AIO) cannot be used simultaneously.

VAT300	Motor	MCCB	Line	EMC	Dynamic Braking	DBR	INPUT	DC	Surge Absorber (5)
Туре	KW(1)	(2) (A)	MC	Filter (3)	Module	(Note 4)	AC Reactor	Reactor	Reactor + RC
N000K7	0.75	15	CL00	Built in	Built in DB	TLR216P200	ACRP6A2H5	-	-
N001K5	1.5	15	CL00	Built in	Built in DB	TLR108P200	ACRP9A1H3	-	-
N002K2	2.2	15	CL00	Built in	Built in DB	TLR74P200	ACRP12A0H84	-	-
N004K0	4	20	CL01	Built in	Built in DB	TLR44P600	ACRP18A0H56	-	-
N005K5	5.5	30	CL02	Built in	Built in DB	TLR29P600	ACRP27A0H37	-	-
N007K5	7.5	40	CL04	U30F3075EB	Built in DB	TLR22P600	ACRP35A0H27	DCRP45A0H55	-
N011K0	11	60	CL04	U30F3075EB	Built in DB	TLR15P1000	ACRP55A0H18	DCRP60A0H4	-
N015K0	15	80	CL06	U30F3100EB	Built in DB	TLR11P1200	ACRP70A0H14	DCRP80A0H3	-
N018K5	18.5	100	CL07	U30F3100EB	Built in DB	TLR8,8P1500	ACRP80A0H14	DCRP100A0H24	-
N022K0	22	125	CL09	U30F3130EB	U2KV23DBUL2	TLR7,4P1800	ACRP97A0H11	DCRP120A0H2	-
N030K0	30	150	CL10	U30F3180EB	U2KV23DBUL3	TLR5P2500	ACRP140A0H072	DCRP150A0H17	-
N037K0	37	200	CK75	U30F3250ES	U2KV23DBUL3	TLR4P3000	ACRP180A0H056	DCRP180A0H14	-
N045K0	45	225	CK75	U30F3250ES	U2KV23DBUL4	-	ACRP200A0H051	DCRP220A0H11	-
X000K7	0.75	15	CL00	Built in	Built in DB	TLR864P200	ACRP3A8H1	-	ACFRP10A + RC
X001K5	1.5	15	CL00	Built in	Built in DB	TLR432P200	ACRP4A5H1	-	ACFRP10A + RC
X002K2	2.2	15	CL00	Built in	Built in DB	TLR295P200	ACRP6A3H4	-	ACFRP10A + RC
X004K0	4	15	CL00	Built in	Built in DB	TLR175P600	ACRP10A2H	-	ACFRP10A + RC
X005K5	5.5	20	CL00	Built in	Built in DB	TLR118P600	ACRP14A1H4	-	ACFRP14A + RC
X007K5	7.5	25	CL02	Built in	Built in DB	TLR86P600	ACRP18A1H1	DCRP25A2H1	ACFRP18A + RC
X011K0	11	30	CL04	Built in	Built in DB	TLR59P1000	ACRP27A0H75	DCRP32A1H6	ACFRP27A + RC
X015K0	15	40	CL04	Built in	Built in DB	TLR43P1000	ACRP35A0H58	DCRP40A1H2	ACFRP35A + RC
X018K5	18.5	50	CL04	Built in	Built in DB	TLR35P1500	ACRP38A0H58	DCRP50A0H96	ACFRP38A + RC
X022K0	22	60	CL06	Built in	Built in DB	TLR29P1800	ACRP45A0H45	DCRP60A0H82	ACFRP45A + RC
X030K0	30	80	CL06	Built in	U2KV23DBUH3	TLR22P2500	ACRP70A0H29	DCRP80A0H58	ACFRP62A + RC
X037K0	37	100	CL07	U30F3100EB	U2KV23DBUH3	TLR18P3000	ACRP90A0H22	DCRP100A0H49	ACFRP90A + RC
X045K0	45	125	CL09	U30F3130EB	U2KV23DBUH4	TLR15P3700	ACRP90A0H22	DCRP125A0H40	ACFRP90A + RC
X055K0	55	150	CL09	U30F3180EB	U2KV23DBUH4	-	ACRP115A0H18	DCRP140A0H32	ACFRP115A + RC
X075K0	75	200	CK75	U30F3250ES	U2KV23DBUH4	-	ACRP160A0H14	DCRP180A0H25	ACFRP160A + RC
X090K0	90	225	CK08	U30F3250ES	U2KV23DBUH4	-	ACRP185A0H11	DCRP210A0H25	ACFRP185A + RC
X110K0	110	300	CK85	U30F3320ES	U2KV23DBUH4	-	ACRP225A0H096	DCRP270A0H18	ACFRP300A + RC
X132K0	132	350	CK09	U30F3400ES	U2KV23DBUH4	-	ACRP300A0H067	DCRP310A0H14	ACFRP300A + RC
X160K0	160	400	CK09	U30F3600ES	U2KV23DBUH4	-	ACRP360A0H056	DCRP400A0H13	ACFRP360A + RC
X200K0	200	500	CK95	U30F3600ES	U2KV23DBUH4	-	ACRP460A0H056	DCRP540A0H08	ACFRP460A + RC
X250K0	250	600	CK10	U30F31000ES	2xU2KV23DBUH4	-	ACRP550A0H039	DCRP650A0H07	ACFRP550A + RC
X315K0	315	800	CK11	U30F31000ES	2xU2KV23DBUH4	-	ACRP700A0H035	DCRP740A0H06	ACFRP700A + RC
X400K0	400	1000	CK12	U30F31000ES	2xU2KV23DBUH4	-	ACRP850A0H023	DCRP950A0H05	ACFRP850A + RC
X475K0	475	1200		U30F31600ES	3xU2KV23DBUH4	-	ACRP950A0H016	DCRP1000A0H04	ACFRP950A + RC

Table 7-1-bMain circuit wiring device ratings, and stand-alone option preparation
drawing numbers and types (Normal-duty)

(Note 1) Device selection conditions, for Normal Duty (Overload capacity 120%, 60s)

- The input current is calculated as follows: $I = (IMkW)/\eta IM/\eta INV/COS ø/voltage/\sqrt{3}$
- The η_{IM} (motor efficiency) is 0.85 for 11kW or less, 0.9 for 15kW or more.
- The η_{INV} (inverter efficiency) is 0.95.
- · COSø is 0.5 to 0.6 at the input power factor. When using ACL or DCL, recalculate as 0.9.
- The power supply voltage is 200V/380V. (If the power supply voltage differs, recalculate and select.) **(Note 2)** Fuses or MCCB given are for IEC Ratings
 - When complying with UL/cUL, use a UL certified fuse as indicated in section 9-1.
- (Note 3) Built-in EMC filters only in specified ratings and for drives U3SN____F_ or U3SX____F_
- (Note 4) External Dynamic Braking Resistors for optimal performance. Note drives up to U3SN011K0 and U3SX11K0 include a built in DBR, which should be disconnected when using the external DBR Check 7-3-1 section.
- (Note 5) The Surge absorber -useful when length of motor cable is more than 50mts- is configured using the output reactor shown in above table plus RC filter, N11P34018=7 (use up to 1kHz carrier frequency)

VAT300	Motor	MCCB	Line	EMC	Dynamic Braking	DBR	INPUT	DC	Surge Absorber (5)
Туре	KW (1)	(2) (A)	MC	Filter (3)	Module	(Note 4)	AC Reactor	Reactor	Reactor + RC
N000K7	0.4	15	CL00	Built in	Built in	TLR405P200	ACRP4A2H5	-	-
N001K5	0.75	15	CL00	Built in	Built in	TLR216P200	ACRP6A2H5	-	-
N002K2	1.5	15	CL00	Built in	Built in	TLR108P200	ACRP9A1H3	-	-
N004K0	2.2	20	CL00	Built in	Built in	TLR74P200	ACRP12A0H84	-	-
N005K5	4	30	CL01	Built in	Built in	TLR44P600	ACRP18A0H56	-	-
N007K5	5.5	35	CL02	U30F3075EB	Built in	TLR29P600	ACRP27A0H37	DCRP32A0H78	-
N011K0	7.5	50	CL04	U30F3075EB	Built in	TLR22P600	ACRP35A0H27	DCRP45A0H55	-
N015K0	11	70	CL04	U30F3100EB	Built in	TLR15P1000	ACRP55A0H18	DCRP60A0H4	-
N018K5	15	90	CL06	U30F3100EB	Built in	TLR11P1200	ACRP70A0H14	DCRP80A0H3	-
N022K0	18.5	125	CL07	U30F3130EB	U2KV23DBUL2	TLR8,8P1500	ACRP80A0H14	DCRP100A0H24	-
N030K0	22	125	CL09	U30F3180EB	U2KV23DBUL2	TLR7,4P1800	ACRP97A0H11	DCRP120A0H2	-
N037K0	30	150	CL10	U30F3250ES	U2KV23DBUL3	TLR5P2500	ACRP140A0H072	DCRP150A0H17	-
N045K0	37	200	CK75	U30F3250ES	U2KV23DBUL3	TLR4P3000	ACRP180A0H056	DCRP180A0H14	-
X000K7	0.4	15	CL00	Built in	Built in	TLR864P200	ACRP3A8H1	-	ACFRP10A + RC
X001K5	0.75	15	CL00	Built in	Built in	TLR864P200	ACRP3A8H1	-	ACFRP10A + RC
X002K2	1.5	15	CL00	Built in	Built in	TLR432P200	ACRP4A5H1	-	ACFRP10A + RC
X004K0	2.2	15	CL00	Built in	Built in	TLR295P200	ACRP6A3H4	-	ACFRP10A + RC
X005K5	4	15	CL00	Built in	Built in	TLR175P600	ACRP10A2H	-	ACFRP10A + RC
X007K5	5.5	20	CL00	Built in	Built in	TLR118P600	ACRP14A1H4	DCRP18A2H9	ACFRP14A + RC
X011K0	7.5	25	CL02	Built in	Built in	TLR86P600	ACRP18A1H1	DCRP25A2H1	ACFRP18A + RC
X015K0	11	35	CL04	Built in	Built in	TLR59P1000	ACRP27A0H75	DCRP32A1H6	ACFRP27A + RC
X018K5	15	50	CL04	Built in	Built in	TLR43P1000	ACRP35A0H58	DCRP40A1H2	ACFRP35A + RC
X022K0	18.5	60	CL04	Built in	Built in	TLR35P1500	ACRP38A0H58	DCRP50A0H96	ACFRP38A + RC
X030K0	22	70	CL06	Built in	U2KV23DBUH2	TLR29P1800	ACRP45A0H45	DCRP60A0H82	ACFRP45A + RC
X037K0	30	80	CL06	U30F3100EB	U2KV23DBUH3	TLR22P2500	ACRP70A0H29	DCRP80A0H58	ACFRP62A + RC
X045K0	37	100	CL07	U30F3130EB	U2KV23DBUH3	TLR18P3000	ACRP90A0H22	DCRP100A0H49	ACFRP90A + RC
X055K0	45	125	CL09	U30F3180EB	U2KV23DBUH4	TLR15P3700	ACRP115A0H18	DCRP125A0H40	ACFRP115A + RC
X075K0	55	150	CK75	U30F3180EB	U2KV23DBUH4	-	ACRP115A0H18	DCRP140A0H32	ACFRP115A + RC
X090K0	75	200	CK08	U30F3250ES	U2KV23DBUH4	-	ACRP160A0H14	DCRP180A0H25	ACFRP160A + RC
X110K0	90	225	CK85	U30F3250ES	U2KV23DBUH4	-	ACRP185A0H11	DCRP210A0H25	ACFRP185A + RC
X132K0	110	300	CK09	U30F3320ES	U2KV23DBUH4	-	ACRP225A0H096	DCRP270A0H18	ACFRP225A + RC
X160K0	132	350	CK09	U30F3400ES	U2KV23DBUH4	-	ACRP300A0H067	DCRP310A0H14	ACFRP300A + RC
X200K0	160	400	CK95	U30F3600ES	U2KV23DBUH4	-	ACRP360A0H056	DCRP400A0H13	ACFRP360A + RC
X250K0	200	500	CK10	U30F3600ES	U2KV23DBUH4	-	ACRP460A0H056	DCRP540A0H08	ACFRP460A + RC
X315K0	250	700	CK11	U30F31000ES	2xU2KV23DBUH4	-	ACRP550A0H039	DCRP650A0H07	ACFRP550A + RC
X400K0	315	800	CK12	U30F31000ES	2xU2KV23DBUH4	-	ACRP700A0H035	DCRP740A0H06	ACFRP700A + RC
X475K0	400	1000		U30F31000ES	2xU2KV23DBUH4		ACRP850A0H023	DCRP950A0H05	ACFRP850A + RC

Table 7-1-bMain circuit wiring device ratings, and stand-alone option preparation
drawing numbers and types (Heavy-duty)

(Note 1) Device selection conditions for Heavy Duty (Overload capacity 150%, 60s)

- The input current is calculated as follows: $I = (IMkW)/\eta IM/\eta INV/COS$ /voltage/ $\sqrt{3}$
- The η_{IM} (motor efficiency) is 0.85 for 11kW or less, 0.9 for 15kW or more.
- The η_{INV} (inverter efficiency) is 0.95.
- · COSø is 0.5 to 0.6 at the input power factor. When using ACL or DCL, recalculate as 0.9.
- The power supply voltage is 200V/380V. (If the power supply voltage differs, recalculate and select.)
- (Note 2) Fuses or MCCB given are for IEC Ratings
 - When complying with UL/cUL, use a UL certified fuse as indicated in section 9-1.
- (Note 3) Built-in EMC filters only in specified ratings and for drives U3SN____F_ or U3SX____F_
- (Note 4) External Dynamic Braking Resistors for optimal performance. Note drives up to U3SN011K0 and U3SX015K0 include a built in DBR, which should be disconnected when using the external DBR Check 7-3-1 section.
- (Note 5) The Surge absorber -useful when length of motor cable is more than 50mts- is configured using the output reactor shown in above table plus RC filter, N11P34018=7 (use up to 1kHz carrier frequency)

7-2 Built-in PCB option

This is a built-in type option mounted on the VAT300 control PCB.

One type can be selected from option I, option II and option III. Up to three types of PCB options can be mounted at once.

These PCB options are connected to the connector on the VAT300 control PCB, and can be easily mounted even after purchasing the VAT300.

Refer to each instruction manual for details on the PCB options.

* A dedicated PCB mounting jig is required when mounting the PCB option II and III at the same time.

7-2-1 Option classes

(1) Option I

This is the PCB option for speed detection 1 to 4. The mounting position I is fixed.

(2) Option II

This is the PCB option for the Insulated AI/AO interface, etc. The mounting position is position II.

(3) Option III

This is the PCB option for the relay interface, serial communication etc. The mounting position is position III.

(Position III is PCB mounted on the PCB option at position II.) Refer to Table 7-1-a for the detailed option classes.



Built-in PCB option mounting drawing

Notes for moving Operation panel folder

Do not raise the operation panel folder with an angle of larger than 90°, so that the folder should not be fallen off.

If the operation panel folder should be taken off, push the hinges of the folder lightly and insert them into the original positions.



Fig. 7-2-1-b



Fig. 7-2-1-c

7-3 Dynamic braking (DB) option

The VAT300 has a dynamic braking option.

Note) When Unit built-in DBR is used, set the DBR overload protection parameter (C22-4) to less than the actual used %ED (Max. 10.0). When the external DB unit is used, set C22-4 to 0.0.

7-3-1 Built-in DB circuit N018K0 / X022K0 and smaller

The DB transistor is built in as a standard for the N018K0 / X022K0 and smaller capacities.

For the N011K0/X015K0 and smaller capacities, the DB resistor (DBR) can be built in as an option. When using the DB, use at 10%ED or less as shown in Fig. 7-3-1-a.

When using the dynamic braking option, set the Regenerative current limit (B18-1) and the DB option selection (C31-0 f_0).



Fig. 7-3-1-a

(1) Unit built-in DBR

The specification of DBR built into the unit is shown in Table 7-3-1-a. If these resistors are applied, use within t(sec) shown in Table 7-3-1-a.

Inverter	Resistance	Built-in	Heavy-duty		Norma	al-duty	t
type VAT300 U3S_	capacity (W)	DBR (Ω)	Motor capacity (kW)	Braking torque (%)	Motor capacity (kW)	Braking torque (%)	(sec) (Note 1)
N000K7	120	220	0.4	200	0.75	110	30
N001K5	120	220	0.75	110	1.5	55	30
N002K2	120	220	1.5	55	2.2	35	30
N004K0	120	180	2.2	45	4.0	25	20
N005K5	120	110	4.0	40	5.5	30	10
N007K5	120	91	5.5	35	7.5	25	10
N011K0	120	91	7.5	25	11	15	10
X000K7	120	430	0.4	340	0.75	220	10
X001K5	120	430	0.75	220	1.5	130	10
X002K2	120	430	1.5	130	2.2	75	10
X004K0	120	430	2.2	75	4.0	40	10
X005K5	120	430	4.0	40	5.5	30	10
X007K5	120	430	5.5	30	7.5	20	10
X011K0	120	430	7.5	20	11	15	10
X015K0	120	430	11	15	15	10	10

Table 7-3-1-a Unit built-in DBR

(Note 1) Set C22-4 to [t / 600sec] × 100%.

(2) External DB resistor

If the braking torque is insufficient with the above built-in resistor, provide an external DB resistor with a circuit as shown in Fig. 7-3-1-b. When using an external DB resistor, remove the built-in DB resistor. The resistance value and usable minimum resistance value to obtain a 100% braking torque is shown in Table 7-3-1-b.

When using the external DB resistor, use of a burning prevention circuit, including the thermal relay (76D) shown in Fig. 7-3-1-b. is recommended.



Fig. 7-3-1-b DBR circuit

	Неа	avy-duty	Nor	mal-duty
Inverter type VAT300 U3S_	Motor capacity (kW)	100% braking resistance type	Motor capacity (kW)	100% braking resistance type
N000K7	0.4	TLR405P200	0.75	TLR216P200
N001K5	0.75	TLR216P200	1.5	TLR108P200
N002K2	1.5	TLR108P200	2.2	TLR74P200
N004K0	2.2	TLR74P200	3.7	TLR44P600
N005K5	4.0	TLR44P600	5.5	TLR29P600
N007K5	5.5	TLR29P600	7.5	TLR22P600
N011K0	7.5	TLR22P600	11	TLR15P1000
N015K0	11	TLR15P1000	15	TLR11P1200
N018K5	15	TLR11P1200	18	TLR8,8P1500
X000K7	0.4	TLR864P200	0.75	TLR864P200
X001K5	0.75	TLR864P200	1.5	TLR432P200
X002K2	1.5	TLR432P200	2.2	TLR295P200
X004K0	2.2	TLR295P200	3.7	TLR175P600
X005K5	4.0	TLR175P600	5.5	TLR118P600
X007K5	5.5	TLR118P600	7.5	TLR86P600
X011K0	7.5	TLR86P600	11	TLR59P1000
X015K0	11	TLR59P1000	15	TLR43P1000
X018K5	15	TLR43P1000	18	TLR35P1500
X022K0	18	TLR35P1500	22	TLR29P1800

	Table	7-3-1-b	External DBR
--	-------	---------	--------------

Resistance	Wire	Dimensions						
(Note1)	(mm²)	Α	В	С	D	Е	G	Туре
TLR405P200	2.5	215	80	235	40 Ø	-	-	1(*)
TLR216P200	2.5	215	80	235	40 Ø	-	-	1(*)
TLR108P200	2.5	215	80	235	40 Ø	-	-	1(*)
TLR74P200	2.5	215	80	235	40 Ø	-	-	1(*)
TLR44P600	2.5	430	95	460	57	-	-	1
TLR29P600	2.5	430	95	460	57	-	1	1
TLR22P600	2.5	430	95	460	57	-	1	1
TLR15P1000	2.5	430	105	460	66	-	-	1
TLR11P1200	4	430	125	460	80	-	-	1
TLR864P200	2.5	215	80	235	40 Ø	-	-	1(*)
TLR432P200	2.5	215	80	235	40 Ø	-	-	1(*)
TLR295P200	2.5	215	80	235	40 Ø	-	-	1(*)
TLR175P600	2.5	430	95	460	57	-	-	1
TLR118P600	2.5	430	95	460	57	-	-	1
TLR86P600	2.5	430	95	460	57	-	1	1
TLR59P1000	2.5	430	105	460	66	-	-	1
TLR43P1000	2.5	430	105	460	66	-	-	1
TLR35P1500	2.5	430	105	460	139	105	65	2

Table 7-3-1-c Exte	nal DBR Dimensions
--------------------	--------------------

- Note 1 Recommended resistor is rated for a ED of 10%, with maximum braking time of 20 sec. For braking large inertia loads, ask your supplier for an appropriate resistor. Note that VAT300 up to N011K5 and up to X015K5, include DB resistor as shown in table 7-3-1a. This should be disconnected when using external resistors
- Type 1(*) As type 1, but provided with 210mm output cable (No terminals)



7-3-2 External DB unit N022K0 / X030K0 and higher

Use an external DB unit when carrying out dynamic braking with the N022K0/X030K0 and larger unit. Applicable DB unit, the resistance value and usable minimum resistance value to obtain a 100% braking torque, is shown in Table 7-3-2.

Connect the DB unit as shown in Fig. 7-3-2. When carrying out dynamic braking with one DB unit, use at 10%ED or less as shown in Fig. 7-3-1-a. If the braking torque is insufficient with one unit, connect a DB unit in parallel.

Set in module U2KV23DBU the parameters A0.x and A1.x at least. Check manual of U2KV23DBU.



Fig. 7-3-2 DB unit connection

Table 7-3-2	External	DB unit
-------------	----------	----------------

Inverter	Heavy-duty			Normal-duty			
type VAT300 U3S_	Motor (kW)	DB unit type U2KV23_	100% braking resistance (3)	Motor (kW)	DB unit type U2KV23_	100% braking resistance (3)	
N022K0	18		TLR8,8P1500	22	DBUL2	TLR7,4P1800	
N030K0	22	DDOLL	TLR7,4P1800	30		TLR5P2500	
N037K0	30		TLR5P2500	37	DBOES	TLR4P3000	
N045K0	37	DBOES	TLR4P3000	45	DBUL4	(4) 3.8Ω	
X030K0	22	DBUH2	TLR29P1800	30		TLR22P2500	
X037K0	30		TLR22P2500	37	08013	TLR18P3000	
X045K0	37	DB0115	TLR18P3000	45		TLR15P3700	
X055K0	45		TLR15P3700	55		(4) 12.5Ω	
X075K0	55		(4) 12.5Ω	75		(4) 9.2Ω	
X090K0	75		(4) 9.2Ω	90		(4) 7.7Ω	
X110K0	90		(4) 7.7Ω	110	DBOIN	(4) 6.3Ω	
X132K0	110	DBOIN	(4) 6.3Ω	132		(4) 5.2Ω	
X160K0	132		(4) 5.2Ω	160		(4) 4.3Ω	
X200K0	160		(4) 4.3Ω	200		(4) 3.4Ω	
X250K0	200		(4) 3.4Ω	250		(4) 5.6 $\Omega \times 2$ sets	
X315K0	250		(4) $5.6\Omega \times 2$ sets	315	DBUH4 \times 2 units	(4) $4.4\Omega \times 2$ sets	
X400K0	315	DBUH4 \times 2 units	(4) $\overline{4.4\Omega \times 2 \text{ sets}}$	400		(4) $\overline{3.4\Omega \times 2 \text{ sets}}$	
X475K0	400		(4) $\overline{3.4\Omega \times 2}$ sets	475	DBUH4 × 3 units	(4) $4.5\Omega \times 3$ sets	

(1) Set the following parameters when using external DB unit.

C31-0 f1 = 2 : With DB B18-1 = 100% : Regenerative current limit B22-5 = 100% : Regenerative current limit (Auxiliary drive0) B26-5 = 100% : Regenerative current limit (Auxiliary drive1) B2A-5 = 100% : Regenerative current limit (Auxiliary drive2) B2E-5 = 100% : Regenerative current limit (Auxiliary drive3)

(2) Obtain the power generation capacity and DBR resistance value with the following expressions.

Power generation capacity (kW) = $\frac{\text{Regenerative torque}}{\text{Motor rated torque}} \times 0.85 \times \text{Motor capacity (kW)}$

DBR resistance value = K Power generation capacity

Note that for the 200V Series, K = 148.2For the 400V Series, K = 593

- (3) GE standard resistors TLRxxx are given for drives up to X055K0, and 5%ED. Ask your dealer for bigger ratings or heavier duty usage
- (4) Braking resistors for ratings above X055K0 are are only available by special request to GE. Resistance value is shown in ohms. Ask your dealer for details

7-3-3 Dimensions of external Dynamic Braking Resistors and Braking Units

(1) External Resistors



Resistance	Wire	Dimensions						
(Note1)	(mm²)	Α	в	С	D	ш	G	Туре
TLR8,8P1500	4	430	105	460	139	105	65	2
TLR7,4P1800	6	430	105	460	139	105	65	2
TLR5P2500	16	430	105	460	207	185	136	2
TLR4P3000	16	410	180	430	139	119	68	2
TLR29P1800	4	430	105	460	139	105	65	2
TLR22P2500	6	430	105	460	207	185	136	2
TLR18P3000	16	410	180	430	139	119	68	2
TLR15P3700	16	410	180	430	139	119	68	2

(2) External Braking Units



U2KV23DBUL1, L2, L3 U2KV23DBUH1, H2, H3





U2KV23DBUH4

7-4 AC Reactors, DC Reactors and Surge absorbers

Select the ACL and DCL according to the Table 7-1-b inverter type. Refer to Table 7-4-a, Table 7-4-b and Table 7-4-c for the outline dimension. The ACL is equivalent to a 3% impedance of the inverter capacity.

		DIMENSIONS (mm)					Weight	Losses	
Catalolg #	Drawing	Α	В	С	D	Е	Ø	(kg)	w
ACRP4A2H5	1	120	80	152	41	100	6	1,3	16
ACRP6A2H5	1	120	80	152	41	100	6	1,5	18
ACRP9A1H3	1	120	80	152	41	100	6	1,6	17
ACRP12A0H84	1	120	80	152	41	100	6	1,7	18
ACRP18A0H56	1	120	90	152	51	100	6	2,4	21
ACRP27A0H37	1	150	95	183	46	125	6	3,3	32
ACRP35A0H27	1	150	95	183	46	125	6	3,7	35
ACRP55A0H18	1	150	110	183	61	125	6	5,5	42
ACRP70A0H14	1	150	111	250	77	100	9	5,6	100
ACRP80A0H14	1	150	121	250	87	100	9	7,1	108
ACRP97A0H11	1	150	126	250	92	100	9	7,8	124
ACRP140A0H072	3	180	166	216	92	120	9	11,9	155
ACRP180A0H056	3	180	176	216	102	120	9	14,2	175
ACRP200A0H051	3	180	186	216	112	120	9	15,9	210
ACRP3A8H1	1	120	80	152	41	100	6	1,4	17
ACRP4A5H1	1	120	80	152	41	100	6	1,5	16
ACRP6A3H4	1	120	80	152	41	100	6	1,7	19
ACRP10A2H	1	120	90	152	51	100	6	2,5	23
ACRP14A1H4	1	150	95	178	46	125	6	3,2	29
ACRP18A1H1	1	150	95	178	46	125	6	4	35
ACRP27A0H75	1	150	106	233	72	100	9	4,8	77
ACRP35A0H58	1	150	111	233	77	100	9	5,5	98
ACRP38A0H58	1	150	116	233	82	100	9	6,4	96
ACRP45A0H45	1	150	121	233	87	100	9	7,1	102
ACRP70A0H29	1	150	151	250	117	100	9	11	147
ACRP90A0H22	1	180	136	286	102	120	9	13,1	158
ACRP115A0H18	1	180	156	301	122	120	9	16,9	186
ACRP160A0H14	3	240	181	288	107	160	9	25,7	268
ACRP185A0H11	3	240	181	288	107	160	9	26,3	255
ACRP225A0H096	3	240	191	288	117	160	9	30,7	305
ACRP300A0H067	3	240	226	288	142	160	9	40,4	356
ACRP360A0H056	3	240	226	288	142	160	9	42,2	425
ACRP460A0H056	3	300	258	400	142	200	9	64,1	595
ACRP550A0H039	3	300	258	400	142	200	9	64,9	636
ACRP700A0H035	3	360	316	472	202	300	11	116,2	991
ACRP850A0H023	3	420	296	544	178	350	11	115	856
ACRP950A0H016	3	420	306	544	188	350	11	123,6	934

Table 7-4-a Outline dimensions of ACL







7. Options

		DIME	NSIONS	(mm)				Weight	Losses
Catalolg #	Drawing	Α	В	С	D	E	Ø	(kg)	W
DCRP32A0H78	5	100	110	173	91	75	6	3,9	37
DCRP45A0H55	5	120	110	203	86	90	6	6,1	33
DCRP60A0H4	5	120	120	220	96	90	6	6,4	41
DCRP80A0H3	5	120	135	220	111	90	6	7,1	45
DCRP100A0H24	5	120	135	235	111	90	6	7,1	51
DCRP120A0H2	5	160	150	285	130	120	9	13,4	43
DCRP150A0H17	5	160	160	285	140	120	9	15	50
DCRP180A0H14	6	160	156	288	82	120	9	11,6	71
DCRP220A0H11	6	160	161	288	87	120	9	12,9	77
DCRP18A2H9	5	100	95	178	76	75	6	3,5	42
DCRP25A2H1	5	100	95	183	76	75	6	3,5	54
DCRP32A1H6	5	100	110	183	91	75	6	3,9	59
DCRP40A1H2	5	100	110	183	91	75	6	3,9	56
DCRP50A0H96	5	120	110	209	86	90	6	6,1	60
DCRP60A0H82	5	120	120	226	96	90	6	6,4	65
DCRP80A0H58	5	120	135	226	111	90	6	7,1	58
DCRP100A0H49	5	120	135	241	111	90	6	7,1	91
DCRP125A0H40	5	160	150	293	130	120	9	13,4	79
DCRP140A0H32	5	160	150	293	130	120	9	3,9	74
DCRP180A0H25	6	160	186	288	112	120	9	18,3	92
DCRP210A0H25	6	160	216	288	142	120	9	24,2	132
DCRP270A0H18	6	160	226	288	152	120	9	27,7	127
DCRP310A0H14	6	160	246	288	162	120	9	29,8	151
DCRP400A0H13	6	200	231	400	147	150	9	40,9	190
DCRP540A0H08	6	200	251	400	157	150	9	45,7	212
DCRP650A0H07	6	200	281	400	177	150	9	56,2	237
DCRP740A0H06	6	200	296	400	192	150	9	61,6	265
DCRP950A0H05	6	240	356	472	252	180	11	99,3	256
DCRP1000A0H04	6	240	366	472	262	180	11	103,1	257

Table 7-4-b Outline dimensions of DCL







7-4-1 Surge Absorbers Surge absorber usage is shown on Table 7-1b, for both Normal Duty and Heavy duty ratings. Other details are given below. Surge absorber is composed by two items, ACFR reactor and RC filters

		DIMENSIONS (mm)						Weight	Losses
Catalolg #	Drawing	Α	В	С	D	E	Ø	(kg)	W
ACFRP10A	1	120	80	152	41	100	6	1,2	16
ACFRP14A	1	120	80	152	41	100	6	1,2	15
ACFRP18A	1	120	80	152	41	100	6	1,2	17
ACFRP27A	1	120	80	157	41	100	6	1,4	18
ACFRP35A	1	120	90	157	51	100	6	2,2	21
ACFRP38A	1	120	90	157	51	100	6	2,2	21
ACFRP45A	1	150	110	183	67	125	6	4,1	33
ACFRP62A	1	150	101	250	67	100	9	4,2	66
ACFRP90A	1	150	121	250	87	100	9	7,5	84
ACFRP115A	1	180	131	299	97	120	9	12,1	112
ACFRP160A	3	180	211	216	137	120	9	21,1	183
ACFRP185A	3	240	181	288	107	160	9	25,5	218
ACFRP225A	3	240	216	288	142	160	9	36,6	304
ACFRP300A	3	300	231	400	147	200	9	59,3	477
ACFRP360A	3	300	266	400	182	200	9	78,3	593
ACFRP460A	3	360	308	472	212	300	11	122,4	728
ACFRP550A	3	360	338	472	242	300	11	145,8	863
ACFRP700A	3	420	371	544	273	350	11	209,7	1486
ACFRP850A	3	480	446	616	328	400	11	336,3	1104
ACFRP950A	3	480	476	616	358	400	11	377	1267

Catalolg # RC	Drawing	VAT300 setting for CF	Weight (kg)	Losses W
N11P34018=7	Fig. 06	Maximum Carrier frequency 1kHz		297







D= 135mm for N11P34018=7

7-5 EMI filter

EMC compliance for VAT300 is achieved either by either built-in filters in the drive or by external filters. Built in filters are available for drives up to 30KW/400V (U30SX030K0_) only. For larger drives, an external EMI filter should be used when complience with EMC is required. Check table 7-1-b or the tables below to select the filter according to inverter type

VAT300	VAT300	Second Environment EN61800-3 Category C3	First Environment EN61800-3 Category C2	
Series	Model	Filter type	Add ferrite cores	
2001/	U30N000K7F		P : ZCAT3035-1330 × 3	
Series	U30N001K5F		C : ZCAT3035-1330×1	
with built in filter	U30N002K2F	Built-in the drive	M : ZCAT3035-1330 × 1	
	U30N004K0F		NA	
	U30N005K5F		NA	
	U30X000K7F			
400\/	U30X001K5F		P : ZCAT3035-1330×3	
Series	U30X002K2F	Built-in the drive	C : ZCAT3035-1330 × 1	
with built in filter	U30X004K0F		M : ZCAT3035-1330 × 1	
	U30X005K5F			
	U30X007K5F			
	U30X011K0F			
	U30X015K0F	Built in the drive	NA	
	U30X018K5F		NA	
	U30X022K0F			
	U30X030K0F			

Table 7.5.1 VAT300 Drives with Built-in Filter

*2) P: Ferrite cores for power cable; C: Ferrite cores for control cable; M: Ferrite cores for motor cable

Table 7.5.2 External filters	for VAT300 drives w	vithout Built-in Filter ((200V series)
------------------------------	---------------------	---------------------------	---------------

VAT300	VAT300	Second Environment	(EN61800-3 Category C3)			
Series	Model	Model External filter selection				
Oches	Model	Use with VAT300 in ND	Use with VAT300 in HD			
	U30N000K7S	U30F3016EB	U30F3016EB			
200V	U30N001K5S	U30F3016EB	U30F3016EB			
Series	U30N002K2S	U30F3016EB	U30F3016EB			
	U30N004K0S	U30F3030EB	U30F3030EB			
	U30N005K5S	U30F3030EB	U30F3030EB			
	U30N007K5S	U30F3075EB	U30F3075EB			
	U30N011K0S	U30F3075EB	U30F3075EB			
	U30N015K0S	U30F3100EB	U30F3100EB			
	U30N018K5S	U30F3100EB	U30F3100EB			
	U30N022K0S	U30F3130EB	U30F3130EB			
	U30N030K0S	U30F3180EB	U30F3180EB			
	U30N037K0S	U30F3250ES	U30F3250ES			
	U30N045K0S	U30F3250ES	U30F3250ES			

VAT300 Series	VAT300	Second Environment (EN61800-3 Category C3)									
	Model										
(00) (11001/0001/70	Use with VAI300 (ND)	USE WITH VAI 300 (HD)								
400V	030X000K7S	U30F3016EB	U30F3016EB								
Series	U30X001K5S	U30F3016EB	U30F3016EB								
	U30X002K2S	U30F3016EB	U30F3016EB								
	U30X004K0S	U30F3016EB	U30F3016EB								
	U30X005K5S	U30F3030EB	U30F3030EB								
	U30X007K5S	U30F3030EB	U30F3030EB								
	U30X011K0S	U30F3030EB	U30F3030EB								
	U30X015K0S	U30F3055EB	U30F3055EB								
	U30X018K5S	U30F3055EB	U30F3055EB								
	U30X022K0S	U30F3075EB	U30F3075EB								
	U30X030K0S	U30F3100EB	U30F3100EB								
	U30X037K0S	U30F3100EB	U30F3100EB								
	U30X045K0S	U30F3130EB	U30F3130EB								
	U30X055K0S	U30F3180EB	U30F3180EB								
	U30X075K0S	U30F3250ES	U30F3180EB								
	U30X090K0S	U30F3250ES	U30F3250ES								
	U30X110K0S	U30F3320ES	U30F3320ES								
	U30X132K0S	U30F3400ES	U30F3320ES								
	U30X160K0S	U30F3600ES	U30F3400ES								
	U30X200K0S	U30F3600ES	U30F3600ES								
	U30X250K0S	U30F31000ES	U30F3600ES								
	U30X315K0S	U30F31000ES	U30F31000ES								
	U30X400K0S	U30F31000ES	U30F31000ES								
	U30X475K0S	U30F31600ES	U30F31000ES								

Table 7.5.3 External filters for VAT300 drives without Built-in Filter (400V series)

	Dimensions										
EMI Filter	L	L-1	н	W	Х	Y	М	D	Kg		
U30F3016EB	250	220	70	45	235	25	M5	M5	1.7		
U30F3030EB	270	240	85	50	255	30	M5	M5	1.8		
U30F3055EB	250	220	90	85	235	60	M6	M5	3.1		
U30F3075EB	270	240	135	80	255	60	M6	M6	4		
U30F3100EB	270	240	150	90	255	65	M10	M6	5.5		
U30F3130EB	270	240	150	90	255	65	M10	M6	7.5		
U30F3180EB	380	350	170	120	365	102	M10	M6	11		

7.5.1 External filter dimensions, Book case type



7.5.1 External filter dimensions, Standard brick case type

	Dimensions											Weight				
EMI Filter	w	W1	Х	L	L1	Y	н	H1	κ	М	D	D1	F	Ι	PE	Kg
U30F3250ES	190	140	165	300	392	240	116	41	20	Ø12	15	42	Ø11	40	M10	7
U30F3320ES	260	210	235	300	392	240	116	41	20	Ø12	15	42	Ø11	60	M10	10.3
U30F3400ES	260	210	235	300	392	240	116	41	20	Ø12	15	42	Ø11	60	M10	10.3
U30F3600ES	260	210	235	300	392	240	116	48,5	20	Ø12	15	42	Ø11	60	M10	11
U30F31000ES	280	230	255	350	460	290	166	64	25	Ø12	25	50	Ø17	65	M12	18
U30F31600ES	300	250	275	400	592	340	166	61	25	Ø12	25	52	Ø17	80	M12	27



PE
Chapter 8 Maintenance and Inspection

- Always wait at least 10 minutes after turning the input power OFF before starting inspections. Wait at least 10 minutes after turning the input power OFF before starting work. Make sure that the displays on the operation panel have gone out before removing the front cover. Remove the front cover, and confirm that the "CHARGE" LED in the unit has gone out. Also check that the voltage between L+1 or L+2 and L- is 15V or less before starting the inspections. Failure to observe this could lead to electric shocks.
- Maintenance, inspections and part replacement must be done by a designated person. (Remove all metal accessories such as watches, bracelets, etc., before starting the work.) (Always use an insulation measure tool.)
 Failure to observe this could lead to electric shocks and injuries.
- Always turn the power OFF before inspecting the motor or machine. A potential is applied on the motor terminal even when the motor is stopped.
 Failure to do so could lead to electric shocks and injuries.
- Do not use parts other than those designated for the replacement parts. Contact your inverter dealer for replacement parts. Failure to observe this could lead to fires.



• Vacuum the inverter with a vacuum cleaner to clean it. Do not use water or organic solvents. Failure to observe this could lead to fires or damage.

8-1 Inspection items

The inspection must be carried out periodically. Determine the cycle according to the installation environment and working frequency of the VAT300. If there are any abnormalities, the cause must be inspected immediately and countermeasures taken.

(1) Daily inspections

Inspection item	Inspection details and work		
Temperature/humidity	Confirm that the ambient temperature is -10 to 50° C, and that the humidity is 95% or less with no dew condensation.		
Oil mist, dust and corrosive gas	Confirm that there is no oil mist, dust or corrosive gas, etc., in the VAT300.		
Abnormal noise and vibration	Confirm that there is no abnormal noise or vibration from the installation site or VAT300.		
Input power source	Confirm that the input voltage and frequency are within the specifications range.		
Cooling fan	Confirm that the cooling fan rotates normally and that no lint, etc. is stuck on it.		
Indicator	Confirm that all lamps on the operation panel light properly.		

Table 8-1-a

Table 8-1-b

(2) Periodic inspections

Inspection item	Inspection details and work		
VAT300 appearance	Check the state of dirt and dust on the vent or heatsink, and clean if necessary.		
VAT300 interior	Check the state of dirt and dust on the PCB and inside the equipment, and clean if necessary.		
Terminal block	Tighten the terminal block screws if loose.		
Cooling fan	Replace the fan every three years.		
Electrolytic capacitor	Confirm that there is no liquid leaking or sheath discoloration. Please exchange electrolytic capacitors of a main circuit for about five years. (When the average annual temperature of the panel in which the VAT300 is stored is 25°C or less. Please consult our company when it is used in the environment for the average temperature to exceed 25°C during year.)		
Insulation test	An insulation test has been completed at the factory, so avoid performing a megger test on the VAT300 when possible. If unavoidable, follow (Note 1).		
Encoder	Confirm that there is no looseness or play in the bearings or couplings. The bearings are durable parts. This is approx. 10,000 hours at 6000rpm, and approx. 30,000 hours at 3000rpm.They must be replaced periodically.		

(Note 1) Use the following procedures when an insulation test must be carried out. Pay special care as an incorrect test could damage the product.

Megger test of main circuit

- Turn OFF the power to all circuits connected to the VAT300, and confirm that the operation panel display has turned OFF. Then, remove the front cover.
 Confirm that the "CHARGE" LED on the PCB has gone out, and that the voltage between L+1, L+2 and L- (if unit capacity does not have L-, negative pole of main circuit electrolytic capacitor) is completely discharged.
- Short-circuit the main circuit terminals in a batch as shown in Fig. 8-1. If the unit capacity does not have an L- terminal, add the main circuit electrolytic capacitor negative pole to the batch short-circuit.

If the test voltage could be applied on the control circuit, disconnect the control terminal block wiring.

- 3) Carry out the megger test at 500VDC. Connect the + pole of the megger tester to where the main circuit is short-circuited in a batch, and connect the pole to the ground (grounding terminal), so that the test voltage is not applied on the other circuits.
- 4) When the VAT300 isolated, the state is normally if the megger measurement results are $1M\Omega$ or more.



Fig. 8-1 Main circuit megger test

• Testing the control circuit's insulation

Test the control circuit's insulation with the tester's high-resistance range. Never perform a megger test or pressure test.

- 1) Turn OFF the power to all circuits connected to the VAT300, and confirm that the operation panel display has turned OFF. Then, remove the front cover. Confirm that the "CHARGE" LED on the PCB has gone out, and that the voltage between L+1, L+2 and L- is completely discharged.
- 2) Disconnect all wires connected to the control circuit terminal.
- 3) Measure the resistance between the control circuit terminal and ground. The insulation is normal if the resistance is $1M\Omega$ or more.

(3) Inspection of spare parts, etc.

The inspections shown in Table 8-1-b must be performed even for parts which are not powered for a long time, such as spare parts. The characteristics of the large capacity electrolytic capacitor, used in the main circuit, will drop if the capacitor is not energized for a long time. Turn the power ON for approx. five hours once every six months. Also check the operation of the VAT300 at this time. If the inverter has not been energized for a long time, do not connect it directly to a commercial power supply. Instead, energize it by using a Slidac, etc., to gradually increase the input voltage and confirm that there is no abnormality.

Temperature	+5°C(winter) ~ +35°C(summer)
Change in temperature	±10°C/day
Humidity	Below 75% RH(without condensation)
Atmosphere	Without oil mist, dust, corrosive gas
Vibration	Not allowed
Altitude	1000 m or below
Condition	Without direct light / ultraviolet rays

(4) Storage conditions

8-2 Measuring devices

As the voltage and current on the input and output sides include high harmonics, the measured value will differ according to the measuring device. When measuring with a device for commercial frequencies, measure with the following circuits and noted measuring devices.

Use of a digital power meter is recommended for performing a highly accurate measurement.



Fig. 8-2 Measurement circuit example

8-3 Protective functions

The VAT300 has the protective functions shown in Table 8-3.

Table 8-3	Protective	function

Name	Function		
Overcurrent trip (OC)	The output is cut off and the inverter stops if the instantaneous value of the output current exceeds the preset value.		
Overvoltage trip (OV)	The output is cut off and the inverter stops if the instantaneous value of the DC voltage in the main circuit exceeds the preset value.		
Undervoltage trip (UV)	The output is cut off and the inverter stops if the DC voltage drops to approx. 65% or less due to a power failure or voltage drop during operation.		
Overcurrent limit	If an overload occurs, the output frequency is automatically adjusted so that the output current is less than the overcurrent limit (125% as a standard) set with B18-0.		
Overvoltage limit	If the output frequency is reduced suddenly, the DC voltage will rise in the main circuit due to the regenerative power. The output frequency will be automatically adjusted to prevent the DC voltage in the main circuit from exceeding the preset value.		
Overload trip (OL)	The output will be cut off and the inverter will stop if the overload characteristics set with C22-0, 1, 2 and 3 are exceeded. The setting (120% for 1 min. as a standard) can be changed according to the characteristics of the motor. In addition to the above setting, 120% for one minute (standard) or 150% for one minute can be selected with the unit overload mode selection (C30-0).		
Overheat (UOH)	An increase in the heat sink temperature is detected with the thermistor and thermostat. When the temperature exceeds the preset value, the output is cut off and the inverter is stopped.		
Self-diagnosis (IO, dER, CPU)	The built-in CPU, peripheral circuits and data are tested and monitored for abnormalities.		
Grounding trip (GRD)	The output will be cut off and the inverter will stop if a ground fault is detected.		
Power module fault (PM)	The operation of the main circuit power module protection function is detected, and the inverter will stop if a fault is detected.		
Phase failure (PHL)	A phase failure in the main circuit input/output is detected, the output is shut off, and the operation is stopped.		

8-4 Troubleshooting with fault display

The countermeasures for when the inverter stops with a fault displayed are shown in Table 8-4.

Display symbol	Name Causes and countermeasures	
8.8.8.8.8.8. EMS	Emergency stop	 The sequence input EMS has been activated. Check the signal wiring. This fault occurs when C00-4 is set to 2.
В. 8. 8. 8. 8. РМ-п	Power module	 Indicates that the short circuit protection circuit activated. The power module in the main circuit may be broken. Replace if there is any abnormality. A short circuit in the load may have occurred. A ground fault may have occurred in the power cable or motor. Restore the grounded point. The power module may have malfunctioned due to noise. Improve the installation environment in respect to noise, such as the grounding method or wiring distance. Refer to the following for sub-code n. Sub-code: n Stopped In constant speed operation Accelerating Decelerating Braking In ACR In excitation
8.88888 OC-1	Overcurrent during stop	 The power module in the main circuit may be broken. Replace if there is any abnormality. A ground fault may have occurred in the power cable or motor. Restore the grounded point. The power module may have malfunctioned due to noise. Improve the installation environment in respect to noise, such as the grounding method or wiring distance.
8 8 8 8 8 oc-2	Overcurrent during constant speed operation	 A sudden change in the load or short circuit may have occurred. Reduce the load fluctuation. The power voltage may have dropped. The inverter may be running in an unstable range. Set the frequency jump (B05-0 to 5), or adjust the torque stabilizing gain (B18-2). The state may also be improved by changing the carrier frequency (B01-7). (Note 1) The speed loss prevention control may not match the load. Halve the speed loss prevention gain B18-5, and double the time constant B18-6. If the state is improved, finely adjust. A ground fault may have occurred in the power cable or motor. Restore the grounded point. The power module may have malfunctioned due to noise. Improve the installation environment in respect to noise, such as the grounding method or wiring distance.

Table 8-4 Troubleshooting

(Note 1) Refer to the Appendix Table output Current Derating when changing the carrier frequency. Pay special attention to the state such as motor heating.

Display symbol	Name	Causes and countermeasures
		 Increase the acceleration time setting (A01-0). The speed or frequency setting may have increased suddenly before the flux was established. Adjust (A01-0). When using V/F control, this state may be avoided by using the external brake control (B46). When using vector control, executing pre-excitation may be effective. However, sufficient timing with the mechanical brakes must be provided if the load could drop, etc. Reduce the torque boost voltage (A02-2).
8.8.8.8 oc-3	Overcurrent during acceleration	 An excess GD², short circuit or rapid fluctuation of the load may have occurred. An overcurrent may have been detected when passing through an unstable area. Set the frequency jump (B05-0 to 5), or adjust the torque stabilizing gain (B18-2). The state may also be improved by changing the carrier frequency (B01-7). (Note 1) The speed loss prevention control may not match the load. Halve the speed loss prevention gain B18-5, and double the time constant B18-6. If the state is improved, finely adjust. A ground fault may have occurred in the power cable or motor. Restore the grounded point.
88888 oc-4	Overcurrent during deceleration	 Increase the deceleration time setting (A01-1). A short circuit or rapid fluctuation of the load may have occurred. An overcurrent may have been detected when passing through an unstable area. Set the frequency jump (B05-0 to 5), or adjust the torque stabilizing gain (B18-2). The state may also be improved by changing the carrier frequency (B01-7). (Note 1) The speed loss prevention control may not match the load. Halve the speed loss prevention gain B18-5, and double the time constant B18-6. If the state is improved, finely adjust. A ground fault may have occurred in the power cable or motor. Restore the grounded point
8.8.8.8.8. oc-5	Overcurrent during braking	 Reduce the brake voltage setting (A03-0). A short circuit or rapid fluctuation of the load may have occurred. A ground fault may have occurred in the power cable or motor. Restore the grounded point.
8.8.8.8.8 oc-6	Overcurrent during ACR	 A short circuit or rapid fluctuation of the load may have occurred.
88888 0C-7	Overcurrent during pre-excitation	 A ground fault may have occurred in the power cable or motor. Restore the grounded point.

Display symbol	Name	Causes and countermeasures
8.8.8.8.8 oc-9	Overcurrent during automatic tuning	 Increase the acceleration time setting (A01-0). Increase the deceleration time setting (A01-1). A short circuit or rapid fluctuation of the load may have occurred. Adjust the torque stabilizing gain (B18-2). A ground fault may have occurred in the power cable or motor. Restore the grounded point.
8 8 8 8 8 ov-1	Overvoltage during stop	 The power supply voltage may have risen. Reduce the voltage to within the specified range. A surge voltage may be superimposed on the power supply. Check the power system.
8 8 8 8 8 8 ov-2	Overvoltage during constant speed operation	 The power supply voltage may have risen. Reduce the voltage to within the specified range. The rotation speed or load may have fluctuated. The overcurrent limit may have functioned because of a sudden change in the load, etc. Refer to OC-2 and 3 above.
8 8 8 8 8 ov-3	Overvoltage during acceleration	
8 8 8 8 8 ov-4	Overvoltage during deceleration	 The load GD² may be too large. Set the deceleration time (A01-1) according to the load GD². The power supply voltage may have risen. Reduce the voltage to within the specified range. The overcurrent limit may have functioned because of a sudden change in the load, etc. Refer to OC-4.
8 8 8 8 8 ov-5	Overvoltage during braking	
8 8 8 8 8 ov-6	Overvoltage during ACR	1. The power supply voltage may have risen.
88888 ov-7	Overvoltage during pre-excitation	Reduce the voltage to within the specified range.
8 8 8 8 8 ov-9	Overvoltage during automatic tuning	

Display symbol	Name	Causes and countermeasures
8.8.8.8.8 UV-n	Undervoltage	 The power voltage may have dropped, and input phase failure may have occurred, or an instantaneous power failure may have occurred. Check the power supply system and correct if necessary. Refer to the following for sub-code n. Sub-code: n Stopped In constant speed operation Accelerating Decelerating Braking In ACR In excitation In automatic tuning.
8 8 8 8 8 UOH.n	Overheat	 A trouble may have occurred in the cooling fan. Replace if necessary. The ambient temperature may have risen. Lower the ambient temperature. (50°C or less) The vent or heatsink may be clogged. Clean the dirt and dust accumulated in the vent, etc. The carrier frequency may be set too high. Confirm that the setting is within the range given in Appendix Table 1 (Note 5). Refer to the following for sub-code n. Sub-code: n Detect with thermistor Detect with thermostat
8.8.8.8.8 SP-1	Overspeed	 Displays indicating that the motor rotation count exceeded the overspeed setting value (C24-0). Adjust the ASR response (A10-0, 1), and suppress the overshooting. Increase the acceleration time setting (A01-0), or change the speed setting so that it is gradual.
88888 SP-2	Speed detection error	 Indicates that the motor rotation speed fluctuation ratio exceeded the error level setting value (C24-2). Check the encoder wiring.
88888	Speed deviation error	 Indicates that the difference between the motor rotation speed command value and detected value exceeds the error detection setting value (C24-5, 6). Check the encoder wiring. The speed command may be set incorrectly, or the S-pattern characteristics setting may be too high. Set the speed command and B10-4 properly.
8.8.8.8.8 SP-4	Reverse run detection error	 The motor rotated in the reverse direction of the speed command and exceeded the error detection setting value (C24-7). Check whether the motor ran in reverse because of the load, and check the ASR torque limiter (A10-3, 4) setting values.

Display symbol	Name	Causes and countermeasures
88888 SP-5	Encoder initialization error 1	 Indicates that an encoder initialization error occurred during PM motor control. A, B, Z phase + U, V, W phase signals Indicates that the UVW signal is abnormal. Check the encoder selection (C51-0) and encoder wiring. A, B, Z phase + serial absolute signals Indicates that the serial signal is not being received correctly. Check the encoder selection (C51-0) and encoder wiring. A, B, Z phase + U, V, W phase signals (Reduced wiring) Indicates that the signal is abnormal. Check the encoder selection (C51-0) and encoder wiring. SIN, COS signal Indicates that the signal is abnormal. Check the encoder selection (C51-0) and encoder wiring.
88888 SP-6	Encoder initialization error 2	 Indicates that an encoder initialization error occurred during PM motor control. A, B, Z phase + serial absolute signals Indicates that the received serial signal is abnormal. Check the encoder wiring. Improve the installation environment in respect to noise. A, B, Z phase + U, V, W phase signals (Reduced wiring) Indicates that the UVW signal is abnormal. Check the encoder selection (C51-0), time setting (C51-7 to 9) and encoder wiring. SIN, COS signal Indicates that the SIN or COS signal is disconnected. Check the encoder wiring.
88888	Fuse blown	 Indicates that the main circuit fuse in the use is disconnected. (Limited to capacities having a fuse warning contact.) Check that the main circuit input/output wiring is correct. Check whether any foreign debris has entered the unit, or whether there is any short-circuit or ground fault. If the fuse is blown, it must be replaced.
88888	Parallel unit signal cutoff	 Indicates that the connection signal was disconnected when using a parallel machine. Check the wiring and connector.

Display symbol	Name	Causes and countermeasures
88888 ATT-n	Automatic tuning abnormal completion n: Step No.	 n = 1 The motor may not be connected correctly. Check the connection. The B00 and B01 parameters may not be set correctly. Check the parameter settings. n = 2 The B00 and B01 parameters may not be set correctly. Check the parameter settings. n = 3 The load and machine may not be separated. Separate the load and machine. Increase the acceleration time (A01-0). Increase the deceleration time (A01-1). If the motor vibrates, increase the torque stabilizing gain (B18-2). n = 4 The load and machine may not be separated. Separate the load and machine. If the motor vibrates, increase the torque stabilizing gain (B18-2). n = 5 If the motor does not stop. Increase the acceleration/deceleration time (A01-0, A01-1). If the motor is stopped. The B00 and B01 parameters may not be set correctly. Check the parameter settings. n = 6 The B00 and B01 parameters may not be set correctly. Check the parameter settings. n = 8 The voltage did not stabilize for one second or longer during pulse measurement. Adjust the pulse voltage for magnetic pole estimation (B39-1) and pulse width for magnetic pole estimation (B39-2). n = 9 Automatic tuning did not end correctly even after retrying three times. Adjust the pulse voltage for magnetic pole estimation (B39-1) and pulse width for magnetic pole estimation (B39-2).
8.8.8.8.8 OL-1	Equipment load	 VAT300 may have overloaded. Reduce the load or increase the inverter capacity. If this occurs at a low speed, avoid continuous operation at a low speed, or decrease boost (A02-2) and brake voltage (A03-0).
8.8.8.8.8. OL-2	DBR overload	 The regenerative power may be excessive. Increase the deceleration time, and reduce the regenerative power. C22-4: DBR overload may not be set correctly. Set a value appropriate for DBR and the unit.

Display symbol	Name	Causes and countermeasures
8.8.8.8 OL-3	Motor overload	 The motor may have overloaded. Reduce the load or increase the motor and inverter capacity. If this occurs at a low speed, avoid continuous operation at a low speed, or decrease boost (A02-2) and brake voltage (A03-0). When using vector control, the problem may be improved by lowering the no-load voltage (B01-9).
8 8 8 8 8 GRD.n	Grounding	 A ground fault may have occurred in the power cable or motor. Restore the grounded point. The power module may have malfunctioned due to noise. Improve the installation environment in respect to noise, such as the grounding method or wiring distance. Refer to the following for sub-code n. Sub-code: n Stopped In constant speed operation Accelerating Decelerating Braking In ACR In excitation In automatic tuning.
8.8.8.8.8 10-1	I/O error (gate turn-off circuit error)	 The VAT300 may be malfunctioning due to external noise, etc. Look for the noise source and remove the cause. The control circuit may be faulty. The OC, OV, GRD or PM fault may have occurred immediately after the run command was input (within 6ms). Check the faulty history, and investigate the cause.
8.8.8.8.8. 10-2	I/O error (A/D converter error)	 The VAT300 may be malfunctioning due to external noise, etc. Look for the noise source and remove the cause. The control circuit may be faulty.
8.8.8.8.8. 10-3	I/O error (current detection error)	 The current detector connectors may be connected improperly. Properly connect these. The current detection may be faulty.
8.8.8.8.8 10-4	I/O error (retry time-out)	 Retry has failed. There are no countermeasures for this code, so reset the VAT300.
8.8.8.8.8 ю-в	PID error	 The PID settings or detected input may be incorrect. Check the settings or detection value.

Display symbol	Name	Causes and countermeasures
8.8.8.8.8. 10-c	External brake IDET error	 The output current did not reached the current detection value (C15-1) when releasing the external brake. Check that the settings are correct, or that the motor wiring connections are correct.
8.8.8.8.8. 10-d	External brake RUN error	 RUN did not turn OFF after engaging the external brake. Check that the settings are correct, or that the RUN command is OFF within B46-4.
<u>8.8.8.8.8</u> ю-е	External brake answer error	 The brake command and answer signal from the brake do not match. Check the answer signal from the brake.
8.8.8.8.8. CPU-n	CPU error	 The unit may be malfunctioning due to external noise, etc. Look for the noise source and remove the cause. The control circuit may be faulty. For all sub-codes other than 8, turn the power off and on once. Refer to the following for sub-code n. Sub-code: n Watch dog error (CPU operation is delayed. This is detected during normal operation. CPU operation error CPU internal RAM error EEPROM check sum error EEPROM read error EEPROM write error (This is only displayed. The gate is not cut off, and FLT is not output.) Stack overflow B: Built-in PLC overload
8.8.8.8.8. Der	E ² PROM data error	 The parameter setting value is incorrect. Correct the parameter setting value with the following procedure. Select D20-2 with the monitor mode, and press the set key. The parameter for which an error occurred will display. Set the correct parameter in this state. Press the ▲ and ▼ keys to sequentially display the erroneous parameters.
88888 EP.ERR.	Verify check data error	 An error may have occurred when using verify check in the parameter copy function using the operation panel. Execute the parameter copy function again.

Display symbol	Name	Causes and countermeasures			
		 There may be a phase failure in the AC input power supply. Investigate the AC input power supply, and eliminate the phase failure. 			
88888 PHL1	Input phase failure	 The AC input wiring may be disconnected. Check the tightening, etc., of the AC input wire. The load pulsation may be too high, or the motor control may be hunting. Suppress the load pulsation, or lower the ASR response. 			
		 When using an electrical circuit configuration which includes the external circuit, it may be resonating. Contact GE. 			
		1. The motor's primary coil may not be correct.			
88888	Output phase	 The motor wiring may be disconnected. 			
PHL2	landre	Check the wire tightening state, etc.			
8.8.8.8.8 E.FLT1 to 8	External fault	 The programmable sequence input terminal set for the external fault has turned ON. Turn the input OFF. Check the terminal block wiring. 			
(Symbol example shows E.FLT8)					
00000		 At least one of the pre-charge magnetic contactors installed in 200H or larger units may not be working properly. Turn the power off and check the magnetic 			
MC-1	MC error	 contactors. 2. There may be a failure in the auxiliary contacts of the pre-charge magnetic contactors installed in 200H or larger units. Check the auxiliary contacts. 			

8-5 Troubleshooting with no fault display

The causes and countermeasures for errors with no fault display are shown in Table 8-5.

Table 8-5 Troubleshooti

Phenomenon	Causes and countermeasures
Motor does not run	1. The input/output cable may be incorrectly wired, the motor may be incorrectly connected, a phase failure may have occurred or the power voltage may have dropped. Check and correct the wiring. Confirm that READY is completed with D04-4, that the run command related bits (RDY1, RDY2, MC, RUN) are lit, and that the fault bit (FLT) is not lit.
	 The motor may be locked or the load excessively heavy. Reduce the load. If the starting torque is insufficient during V/f control, adjust the torque boost (A02). A large starting torque can be attained by selecting automatic torque boost (A02-1;2), and finely adjusting the slip compensation gain (A002-5) and maximum torque boost gain (A02-6) attained with automatic tuning.
	 The reverse run interlock function (C09-3) may be set or the other parameters may be incorrect. Check the RUN, REV and EMS signals with D04-0. If the signal is input, cancel it once before starting. The veltage may not be output to the VAT200 output terminal. Measure
	the output voltage, and confirm that the three phases are balanced.
	The local/remote setting may be incorrect. Set according to the required mode.
	 The frequency (speed) command may not be input. When using V/F control, refer to D01-0 (D01-4 for vector control), and check the currently set value. Refer to section 5-9 for details.
	7. When using vector control, the encoder signal may not be input correctly. Check the encoder signal. Check that the D00-2 rotation detection is correct when the motor is manually turned forward and reverse. If abnormal, check the wiring, etc. Change the encoder phase order (C50-2, C51-3).
Motor runs in opposite direction	 The output terminals U, V, and W sequence may be incorrect. Interchange the phase sequence. When using vector control, also change the encoder phase order (C50-2, C51-3) according to the changes in the main circuit phase order.
	 2. The sequence input wires for forward/reverse run may not be connected to the specified terminals. Connect the wires as follows: Forward run: Short-circuit terminals PSI1 - RY0 (When input terminal function setting is C03-0=1 (default value)) Reverse run: Short-circuit terminals PSI4 - RY0 (When input terminal function setting is C03-2=4 (default value))
Motor runs but the speed does not vary	 The load may be too heavy. Reduce the load.
	 The frequency setting signal level may be too low. Check the signal level and circuit. When using V/F control, refer to D01-0 (D01-4 for vector control), and check the currently set value. Refer to section 5-9 for details.

Phenomenon	Causes and countermeasures
Motor acceleration/	1. The motor acceleration/deceleration time setting (A01-0, 1) may be too
deceleration is not smooth	 low. Increase the acceleration/deceleration time. Reduce the manual torque boost voltage (A02-2). If automatic torque boost (A02-1) is selected, adjust A02-5 and A02-6. The speed or frequency setting may have increased suddenly before the flux was established. Adjust (A01-0). When using V/F control, this state may be avoided by using the external brake control (B46). When using vector control, executing pre-excitation may be effective. However, sufficient timing with the mechanical brakes must be provided if the load could drop, etc. An unstable area may have been passed through. Set the frequency jump (B05-0 to 5), or adjust the torque stabilizing gain (B18-2). When using IM speed sensor-less vector control, carry out the adjustment
Motor speed varies during constant speed operation	 in item 3-5-2. The load may be fluctuating excessively or the load is too heavy. Reduce the load or fluctuation. When using vector control, adjust ASR response (A10-0, 1). To increase the speed control response in respect to sudden load fluctuations (impact drop load, etc.), adjust B30-0, 1. Hunting could occur if this is set too high. The speed detection may be affected by noise. Improve the installation environment in respect to noise, such as the grounding method or wiring distance. If the speed fluctuates during IM speed sensor-less vector control, adjust the speed estimation related parameters (B31-0, 1, 2). The inverter-motor ratings may not match the load. Select an inverter-motor set that matches the load.
Motor speed is too high or low	 The number of poles or voltage may be incorrect. Check the motor specifications. The maximum frequency (speed) or base frequency [B00-4, 5 (B01-4, 5)] may be incorrect. The motor terminal voltage may be low.
Operation panel display cannot be changed, or the display is frozen. Cannot display target operation mode.	 The operation panel connector may be disconnected, or the cable may be broken. Check the connector and wiring. Communication with the operation panel may be disconnected because of noise. Turn the VAT300 power OFF once, wait for the operation panel display to go out, and then turn the power ON again.
Cannot pick up	 The parameter settings or external setting may be incorrect. PICK (C04-D), automatic start (C08-0) and the control signals from the external source (run command, pick-up command, emergency stop input, etc.) may not be input correctly. Correctly set the related parameters. The pick-up related parameters may not be adjusted properly. Adjust the pick-up related parameters (C21). The overcurrent limit related parameters may not be adjusted properly. If an overcurrent fault (OC) or overvoltage fault (OV) occurs, adjust the overcurrent speed loss prevention gain and time constant (B18-5, 6). Try setting B18-5 to half of the preset value (0.50) and B18-6 to double the value (200). If an effect is observed, finely adjust the settings. Note that the effect may differ according to the motor and load.

Chapter 9 Compatible Standards

9-1 UL/cUL Standards

The VAT300 complies with UL508C and CSA C22.2 No.14. Observe the following matters when using the inverter as a UL/cUL Standard compatible product.

- 1) Use the inverter in an installation environment which does not exceed the set maximum ambient temperature.
- For the main circuit connected to the inverter, use a "75°C CU" "voltage rating 600V or higher" copper wire.
- 3) Use the wire sizes given in Table 9-1-a and Table 9-1-b for the main circuit wiring. Use a UL/CSA Certified round crimp terminal which matches the wire diameter for the terminal connection. Crimp the crimp terminal with a crimping tool recommended by the maker.
- 4) When wiring the circuit, tighten with the torque given in Table 9-1-a and Table 9-1-b.
- 5) Integral solid state short circuit protection does not provide branch circuit protection, Branch circuit protection must be provided in accordance with the National Electric Code and any additional local codes.
- 6) Always provide a UL Certified fuse or UL Certified Molded Case Circuit Breaker (MCCB) protection circuit shown in Table 9-1-c on the input side of the inverter. Use a fuse for the 011L/015H and smaller capacities.
- 7) Use a power that complies with the following conditions for the inverter's input power.

N000K7 to N045K0, 240VAC or less, Short-circuit current 10,000A or less X000K7 to X055K0, 480VAC or less, Short-circuit current 10,000A or less X075K0 to X475K0, 480VAC or less, Short-circuit current 42,000A or less

- 8) Install the inverter as "open type equipment".
- 9) The installation environment must satisfy "pollution degree 2".
- 10) The inverter has a motor overload protection function. Refer to Chapter 6, and set parameters C22-0 to 3 correctly.

Motor overload (OL-3)

Use the C22-3 setting to set the trip breakdown reference current for one minute in the case of a motor rated current (B00-6, B01-6) of 100%. When C22-3 is set to 120% for example, if C22-0 is 100%, and 120% of the motor rated current is output, a breakdown stop will occur due to a motor overload after one minute.

As shown in Fig.9-1-a, the counterclockwise limit characteristics change by setting C22-0. The diagram on the right is an example with C22-0 set to 100% and 50% when C22-3=150%.

For the self-cooling motor, when operating at low speed, set C22-1 and C22-2 to meet the motor characteristics. These characteristics are as shown in Fig.9-1-b.

The motor overload can be monitored at D02-6. Furthermore, select setting value 15 at C13-0, 1 to enable analog output.

11) Use the control terminals RA/RC, FA/FB/FC at 30VAC/DC or less.



Fig.9-1-a Overload characterristics Overload reference



Fig.9-1-b Reduction of the Overload reference by frequency.

	Terminal	Terminal		L1, L2	, L3, U, V,	w	Ð	Grou	ind
Inverter type VAT300 U3S_	screw size	tore N∙m	que Ib-in	Terminal connector Part No.	AWG	mm²	Terminal connector Part No.	AWG	mm²
N000K7	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1
N001K5	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1
N002K2	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1
N004K0	M4	1.8	15.9	R5.5-4	10	5.3	R5.5-4	12	3.3
N005K5	M4	1.8	15.9	8-4	8	8.4	R5.5-4	10	5.3
N007K5	M5	3.0	26.5	R8-5	8	8.4	R5.5-5	10	5.3
N011K0	M5	3.0	26.5	R14-5	6	13.3	R5.5-5	10	5.3
N015K0	M6	4.5	39.8	38-6	3	26.7	R8-6	8	8.4
N018K5	M8	9.0	79.7	R38-8	2	33.6	R8-8	8	8.4
N022K0	M8	9.0	79.7	R60-8	1	42.4	R14-8	6	13.3
N030K0	M8	9.0	79.7	R60-8×2P	1/0×2P	53.5×2P	R14-8	6	13.3
N037K0	M10	10.0	88.5	R60-10×2P	1/0×2P	53.5×2P	R14-10	6	13.3
N045K0	M10	10.0	88.5	R60-10×2P	1/0×2P	53.5×2P	R22-10	4	21.2
X000K7	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1
X001K5	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1
X002K2	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1
X004K0	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1
X005K5	M4	1.8	15.9	R5.5-4	12	3.3	R5.5-4	12	3.3
X007K5	M4	1.8	15.9	R5.5-4	10	5.3	R5.5-4	10	5.3
X011K0	M4	1.8	15.9	8-4	8	8.4	R5.5-4	10	5.3
X015K0	M5	3.0	26.5	R8-5	8	8.4	R5.5-5	10	5.3
X018K5	M5	2.0	17.4	R14-5	6	13.3	R5.5-5	10	5.3
X022K0	M5	2.0	17.4	R14-5	6	13.3	R5.5-5	10	5.3
X030K0	M6	4.5	39.8	R22-6	4	21.2	R8-6	8	8.4
X037K0	M8	9.0	79.7	R38-8	2	33.6	R8-8	8	8.4
X045K0	M8	9.0	79.7	R60-8	1	42.4	R14-8	6	13.3
X055K0	M8	9.0	79.7	R60-8	1/0	53.5	R14-8	6	13.3
X075K0	M10	28.9	255.7	R60-10×2P	1/0×2P	53.5×2P	R14-10	6	13.3
X090K0	M10	28.9	255.7	R60-10×2P	1/0×2P	53.5×2P	R14-10	6	13.3
X110K0	M10	28.9	255.7	R60-10×2P	1/0×2P	53.5×2P	R22-10	4	21.2
X132 L1,L2,L3	M10	28.0	255.7	R80-10×2P	3/0×2P	85.0×2P	P22 10	1	21.2
K0 U, V, W	NI TO	20.9	200.7	R80-10×2P	2/0×2P	67.4×2P	NZZ-10	Ŧ	21.2
X160K0	M10	28.9	255.7	R100-10×2P	4/0×2P	107.2×2P	R38-10	3	26.7
X200K0	M10	28.9	255.7	R150-10×2P	300×2P	152×2P	R38-10	2	33.6
X250K0	M16	125	1106	R200-16×2P	400×2P	203×2P	R60-16	1	42.4
X315 L1,L2,L3	M16	105 14	1106	R150-16×4P	300×4P	152×4P	D60 16	1/0	53 5
K0 U, V, W		120	1100	R100-16×4P	4/0×4P	107.2×4P	100-10	1/0	53.5
X400 L1,L2,L3	00 L1,L2,L3	125	1106	R200-16×4P	400×4P	203×4P	D80 16	2/0	67.4
K0 U, V, W		120	1100	R200-16×4P	350×4P	177×4P	100-10	2/0	07.4
X475K0	M16	125	1106	R200-16×4P	400×4P	203×4P	R80-16	3/0	85.0

Table 9-1-a Terminals, Applicable Wire Sizes and Tightening Torque (For Normal-duty)

	Terminal Tightening L1, L2, L3, U		L3, U, V, W		e	Ground				
Inverter type VAT300 U3S_	screw size	toro N∙m	que Ib-in	Terminal connector Patt No.	AWG	mm²	Terminal connector Part No.	AWG	mm²	
N000K7	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1	
N001K5	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1	
N002K2	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1	
N004K0	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1	
N005K5	M4	1.8	15.9	R5.5-4	10	5.3	R2-4	14	2.1	
N007K5	M5	3.0	26.5	R8-5	8	8.4	R2-5	14	2.1	
N011K0	M5	3.0	26.5	R14-5	8	8.4	R2-5	14	2.1	
N015K0	M6	4.5	39.8	R22-6	6	13.3	R2-6	14	2.1	
N018K5	M8	9.0	79.7	R38-8	3	26.7	R2-8	14	2.1	
N022K0	M8	9.0	79.7	R60-8	2	33.6	R5.5-8	12	3.3	
N030K0	M8	9.0	79.7	R60-8	1	42.4	R5.5-8	10	5.3	
N037K0	M10	10.0	88.5	R60-10×2P	1/0×2P	53.5×2P	R5.5-10	10	5.3	
N045K0	M10	10.0	88.5	R60-10×2P	1/0×2P	53.5×2P	R14-10	6	13.3	
X000K7	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1	
X001K5	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1	
X002K2	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1	
X004K0	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1	
X005K5	M4	1.8	15.9	R2-4	14	2.1	R2-4	14	2.1	
X007K5	M4	1.8	15.9	R5.5-4	12	3.3	R2-4	14	2.1	
X011K0	M4	1.8	15.9	R5.5-4	10	5.3	R2-4	14	2.1	
X015K0	M5	3.0	26.5	R5.5-5	8	8.4	R2-5	14	2.1	
X018K5	M5	2.0	17.4	R8-5	8	8.4	R2-5	14	2.1	
X022K0	M5	2.0	17.4	R14-5	6	13.3	R2-5	14	2.1	
X030K0	M6	4.5	39.8	R22-6	6	13.3	R2-6	14	2.1	
X037K0	M8	9.0	79.7	R38-8	4	21.2	R5.5-8	12	3.3	
X045K0	M8	9.0	79.7	R38-8	2	33.6	R5.5-8	10	5.3	
X055K0	M8	9.0	79.7	R60-8	1	42.4	R14-8	6	13.3	
X075K0	M10	28.9	255.7	R60-10	1/0	53.5	R14-10	6	13.3	
X090K0	M10	28.9	255.7	R60-10×2P	1/0×2P	53.5×2P	R14-10	6	13.3	
X110K0	M10	28.9	255.7	R60-10×2P	1/0×2P	53.5×2P	R14-10	6	13.3	
X132K0	M10	28.9	255.7	R60-10×2P	1/0×2P	53.5×2P	R14-10	6	13.3	
X160 L1,L2,L3	M10	28.0	255.7	R80-10×2P	3/0×2P	85.0×2P	D14 10	6	13.3	
K0 U, V, W	MITO	28.9 255.	20.9 200.7	R80-10×2P	2/0×2P	67.4×2P	1(14-10	0	10.0	
X200K0	M10	28.9	255.7	R100-10×2P	4/0×2P	107.2×2P	R14-10	6	13.3	
X250K0	M16	125	1106	R150-16×2P	300×2P	152×2P	14-16	6	13.3	
X315K0	M16	125	1106	R200-16×2P	400×2P	203×2P	22-16	4	21.2	
X400 L1,L2,L3	_1,L2,L3 U, V, W M16 125	M16 125 1106	1106	R150-16×4P	300×4P	152×4P	22-16	4	21.2	
K0 U, V, W			R100-16×4P	4/0×4P	107.2×4P					
X475 L1,L2,L3	M16	125	1106	R200-16×4P	400×4P	203×4P	22-16	4	21.2	
K0 U, V, W	123	J, V, W	120		R200-16×4P	350×4P	177×4P	22 10	r	21.2

Table 9-1-b Terminals, Applicable Wire Sizes and Tightening Torque (For Heavy-duty)

(Note1) "x2p" refers to two parallel connections. (Note2) Terminal and crimping tools maker : JST Mfg. Co., Ltd.

Crimping tools :

Ratchet Hand Tool, Model No. YHT-2210 (up to 10AWG) Pneumatic Hand Tool, Model No. YA-5 (from 8AWG up to 1/0AWG)

Inverter type	Applicable protection circuit	Fuse/MCCB rated current (A)			
VAT300-U3S_		Normal-duty	Heavy-duty		
N000K7		15	15		
N001K5		15	15		
N002K2	LU Cartified from	15	15		
N004K0	(Voltage rating 300V Class T Fast Acting)	20	15		
N005K5		30	20		
N007K5		40	30		
N011K0		60	40		
N015K0		80	60		
N018K5	UL Certified fuse	100	80		
N022K0	(Voltage failing 500V Class T Fast Acting)	125	100		
N030K0	UI Certified Molded Case Circuit Breaker	150	125		
N037K0	(MCCB)	200	150		
N045K0		225	200		
X000K7		15	15		
X001K5		15	15		
X002K2		15	15		
X004K0	UL Certified fuse	15	15		
X005K5	(Voltage rating 600V Class J Fast Acting)	20	15		
X007K5		25	20		
X011K0		30	25		
X015K0		40	30		
X018K5		50	40		
X022K0	UL Certified fuse	60	50		
X030K0	(voltage rating ooov class 5 rast Acting)	80	60		
X037K0	UL Certified Molded Case Circuit Breaker	100	80		
X045K0	(MCCB)	125	100		
X055K0		150	125		
X075K0		200	150		
X090K0		225	200		
X110K0		300	225		
X132K0		350	300		
X160K0	UL Certified fuse	400	350		
X200K0	(Voltage rating 600V Class J Fast Acting)	500	400		
X250K0		600	500		
X315K0		800	600		
X400K0		1000	800		
X475K0		1200	1000		

Table 9-1-c Input protection fuse, MCCB rated current

9-2 CE Marking

The VAT300 from N000K7 to N045K0 and X000K7 to X475K0 ratings, comply with the EMC Directives and Low Voltage Directives. Observe the following matters when using the inverter as an EMC Directive compliant product.

9-2-1 EMC Instruction of preface

This Instruction details how to meet the EMC directives (89/336/EEC) with VAT300. It is important to understand and before installation and operation of drive. The VAT300 designed to meet the EMC directives and are suitable for use in the Industrial, Residential, Commercial and Light Industrial Environments. These drives have been tested with the power cables and control leads connected as shown in Fig. 9-2-a. If these drives are connected with fewer control leads than these examples, it may be possible to reduce installation costs by using ordinary cables rather than screened cables which are recommend in this manual. It is strongly advised however that a compliance test should be performed under the actual operating conditions to certify that the system complies with the relevant EMC requirements.

This instruction also details how to use filters for installation: the installation where the drives are installed as stand-alone equipment without being fitted into any enclosure, and the installation where the drives are installed inside a metal enclosure.



9-2-2 Installation environment

Table 9-2-a shows the EMC standard conformity table of VAT300. Basically, the VAT300 conforms with the EN61800-3 Category C3. First environment Category C2 however, is achieved for drives up to to N002K2 and up to X005K5, by installing ferrite cores in I/O power cables. (Details in Table 9-2-c.).

In Residential, Commercial, or Light Industrial Environment, install VAT300 drives up to 55KW inside a metal structure cabinet, and and ensure that the drive is not installed adjacent to devices or equipment, like measuring devices, that are not CE marked.

For VAT300 in size X075K0 and larger that are not designed for use in the Residential, Commercial and Light Industrial Environments, ensure that no device or equipment is installed adjacent to the drive that is intended for the Residential, Commercial and Light Industrial Environments only, as interference with such equipment may occur.

Conformity standard	First environment (EN61800-3:Category C2)	Second environment (EN61800-3:Category C3)
The view of VAT300	from N000K7 to N002K2 from X000K7 to X005K5	from N004K0 to N045K0 from X007K5 to X475K0

Table 9-2-a EMC standard conformity table of VAT300

9-2-3 Input filters and their connections



2. Electrical shock hazards. The input filters must be fully earthed. Otherwise, there may be a risk of electrical shocks and the effectiveness of filters will be impaired.

In most cases, the input filter should be installed as closely to the drive as possible to ensure its effectiveness. The following table shows the maximum distance between the filter and the drive. This may be changed, if, for instance, a complete system is filtered in its entirety. In this case, the whole system would require testing to ensure EMC compliance.

Sizes	Max. distance
N000K7~N005K5, X000K7~X030K0	0.3 meter
N007K5 ~N045K0 . X037K0~X475K0	0.5 meter

Table 9-2-b Max. distance between drive and filter

Ensure that the input filter is securely and effectively earthed. If the drive is installed on a metal plate, install the filter on the same plate and then earth the plate. This is effective to reduce EMI.

9-2-4 Choosing and installing power cables

9-2-4-a Choosing power cables

The input cables to the drive via the filter must be selected from those specified in the drive's manual. The output cables from the drive must be screened or armoured cables (see Fig. 9-2-a) and should be selected from Table 9-1-a or Table 9-1-b.

9-2-4-b Installing power cables

The power cables comprises three sections: one on the primary side of the filter, one between the filter and the drive and one on the output of the drive. Ensure that these are not installed in parallel to each other and that these are laid down apart from each other by at least 0.5m. Please also ensure that the screen of the output cable is earthed at both ends with one end connected to the drive's earth terminal and the other end to that of the motor. Please arrange the termination at the drive's end inside the drive enclosure, and if this is not possible and the cable is terminated outside the drive enclosure, terminate the cables as closely to the drive's conduit hole as possible, i.e., within 0.1 m from it.

AC Supply



Fig.9-2-a Installation (Stand-alone)

9-2-5 Choosing and connecting control leads

Control leads should be selected in accordance with the instructions in the drive's manual and should be screened if they are used for a speed setting circuitry, analogue signal circuitry for metering, or relay signal circuitry. The screen should be connected to the drive's earth or COM terminal only (refer to Fig.9-2-a) The control leads should be wired away from the power cables. If the control leads must run across the power cables, cross them at the right angle, and if they are laid down alongside each other, ensure to separate them by at least 0.5 m. When the section which runs along the power cables exceeds 10 m, separate them further more. The control leads should not share the same conduit hole of the drive with the power cables. Separate analogue control leads from relay control leads.

To reduce emission and to increase immunity, ensure that no control leads are connected that are not used. Also, ensure that control leads are wired in such manner that they are as short as possible.

The relay signal controller and analogue speed setting controller, analog signal meters should be put in a metal box together.

9-2-6 Earthing method

Earth the drive, motor and filter in such manner that the earthing cables are as short as possible. Select and install earthing cables in accordance with local requirements. It is recommendable to use low impedance earthing cables, i.e. those that can carry as much current as possible. If the motor does not share the same earth post with the drive and filter, do not connect the screen and earth lead of the drive's output cable to the motor.

9-2-7 EMI and EMC

The EMC directives set out immunity requirements for the electrical drive (ability to work properly without being affected by external electromagnetic disturbance), in addition to the previously enforced emission requirements (electromagnetic disturbance generated by the electrical drive).

In addition to the radiated noise directly generated from the drive and its connected cables, the emission requirement includes the conducted noise which is conducted outside the drive through the input cables.

Immunity is the ability of a drive to operate properly without being affected by an external disturbance.

The EMC compliance is only achieved when the drive's immunity level exceeds its emission level under its operating environment.

In addition to the immunity against a radiated and conducted disturbance, the EMC directives also requires of the drive the immunity against static electricity discharges and fast transients.

A human body can easily be charged with static electricity by merely walking on carpet and with a mere touch on the drive, this static electricity will be discharged through it. A discharging spark can be at such a magnitude that it can damage the drive.

A drive which is installed near cables connected to a switchable inductive load can often operate incorrectly due to a fast transient induced on its control leads at a switching of the inductive load.

These are just a few examples of disturbance to which the drive is exposed, and the drive is now required to operate correctly without being affected by such disturbance.

9-2-8 Considerations to measuring devices

All the cables and leads connected to the drive or filter should be regarded as active sources of electrical noise. For inspection or service, use measuring devices or equipment that are CE marked. If they require an external power supply, use one which is separate or well insulated from that of the drive system.

Even for a system that comprises CE marked equipment and devices only, an EMC compliance test may be required if the whole system is exported from one country to another. Ask the local government for details.

9-2-9 Installation into a metal cabinet

To clear the levels of the Residential, Commercial, Light Industrial Environments and the Industrial Environment for the drives up to 475kW, the following method of installation is required.

9-2-9-a When using drives with built-in EMI filters (N000K7 to N005K5, X000K7 to X030K0))

(1) Install the drive with built-in filters in a metal cabinet. This ensure to meet Second Environment Category C3.

Note that drives from N000K7 to N002K2 and from X000K7 to X005K5, can meet First environment Category C2, by installing 3 pieces of the ferrite cores on the power source cable, one on the motor cable and other on the control cable as shown in Fig. 9-2-b.

All these 5 ferrites are delivered into the drive package, when order VAT300 with built-in filter.

- (2) The power source cable and motor cable outside the metal cabinet should be shielded and made to be as short as possible. Electrically connect the shield to the earth terminal of the motor.
- (3) In order to suppress the noise emission from the cables, earth the shield of the power source cable and motor cable to the metal cabinet with metal clamps.
- (4) Use the shielded cables for the drive control wiring and earth the shield to the metal cabinet with a metal clamp.

9-2-9-b When using the external EMI filters (VAT300- up N045K0 and up to X475K0)

- (1) Install the drive unit in a metal cabinet and put the EMI filter on the power source cable as shown in Fig. 9-2-c.
- (2) The power source cable and motor cable outside the metal cabinet should be shielded and as shortest as possible. Electrically connect the shield to the earth terminal of the motor.
- (3) It is not necessary to use shielded cables for the control circuit wiring inside the metal cabinet. However, make the EMI filter power source cable and the motor cable as short as possible, and separate them as far from each other as possible.
- (4) In order to suppress the noise emission from the cables, earth the shield of the power source cable and motor cable to the metal cabinet with metal clamps.
- (5) Use the shielded cables for the drive control wiring and earth the shield to the metal cabinet with a metal clamp.



Fig.9-2-c



Fig. 9-2-d

Example to meet EN61800-3, Category C2 for built-in filter drives, up to N002K2 or up to X005K5

Ferrite Core	Туре	Manufacturer
FC	ZCAT3035-1330	TDK





Example to meet EN61800-3, Category C3 for built-in filter drives, up to N005K5 or up to X030K0

9-2-10 Selecting and fitting of filters

VAT300	VAT300	Second Environment EN61800-3 Category C3	First Environment EN61800-3 Category C2	
Series	Model	Filter type	Add ferrite cores	
000)/	U30N000K7F		P : ZCAT3035-1330 × 3	
Series	U30N001K5F		C : ZCAT3035-1330 × 1	
with built in filter	U30N002K2F	Built-in the drive	M : ZCAT3035-1330 × 1	
	U30N004K0F		NA	
	U30N005K5F		NA	
	U30X000K7F	Built-in the drive		
400\/	U30X001K5F		P : ZCAT3035-1330×3	
Series with built in filter	U30X002K2F		C : ZCAT3035-1330×1	
	U30X004K0F		M : ZCAT3035-1330 × 1	
	U30X005K5F			
	U30X007K5F			
	U30X011K0F			
	U30X015K0F	Built in the drive	ΝΔ	
	U30X018K5F			
	U30X022K0F			
	U30X030K0F			

 Table 9-2-c
 VAT300 Drives with Built-in Filter

*2) P: Ferrite cores for power cable; C: Ferrite cores for control cable; M: Ferrite cores for motor cable

Table 9-2-d	External filters for Drives without Built-in Filter ((200V series)	
	External more set brittee mineral bank in this		

VAT300 Sorios	VAT300 Model	Second Environment External fi	Second Environment (EN61800-3 Category C3) External filter selection						
Series	Model	Use with VAT300 in ND	Use with VAT300 in HD						
	U30N000K7S	U30F3016EB	U30F3016EB						
200V	U30N001K5S	U30F3016EB	U30F3016EB						
Series	U30N002K2S	U30F3016EB	U30F3016EB						
	U30N004K0S	U30F3030EB	U30F3030EB						
	U30N005K5S	U30F3030EB	U30F3030EB						
	U30N007K5S	U30F3075EB	U30F3075EB						
	U30N011K0S	U30F3075EB	U30F3075EB						
	U30N015K0S	U30F3100EB	U30F3100EB						
	U30N018K5S	U30F3100EB	U30F3100EB						
	U30N022K0S	U30F3130EB	U30F3130EB						
	U30N030K0S	U30F3180EB	U30F3180EB						
	U30N037K0S	U30F3250ES	U30F3250ES						
	U30N045K0S	U30F3250ES	U30F3250ES						

VAT200	VAT200	Second Environment	Second Environment (EN61800-3 Category C3)						
Series	Model	External fi	Iter selection						
Oches	Model	Use with VAT300 (ND)	Use with VAT300 (HD)						
	U30X000K7S	U30F3016EB	U30F3016EB						
4001/	U30X001K5S	U30F3016EB	U30F3016EB						
400V Series	U30X002K2S	U30F3016EB	U30F3016EB						
Oches	U30X004K0S	U30F3016EB	U30F3016EB						
	U30X005K5S	U30F3030EB	U30F3030EB						
	U30X007K5S	U30F3030EB	U30F3030EB						
	U30X011K0S	U30F3030EB	U30F3030EB						
	U30X015K0S	U30F3055EB	U30F3055EB						
	U30X018K5S	U30F3055EB	U30F3055EB						
	U30X022K0S	U30F3075EB	U30F3075EB						
	U30X030K0S	U30F3100EB	U30F3100EB						
	U30X037K0S	U30F3100EB	U30F3100EB						
	U30X045K0S	U30F3130EB	U30F3130EB						
	U30X055K0S	U30F3180EB	U30F3180EB						
	U30X075K0S	U30F3250ES	U30F3180EB						
	U30X090K0S	U30F3250ES	U30F3250ES						
	U30X110K0S	U30F3320ES	U30F3320ES						
	U30X132K0S	U30F3400ES	U30F3320ES						
	U30X160K0S	U30F3600ES	U30F3400ES						
	U30X200K0S	U30F3600ES	U30F3600ES						
	U30X250K0S	U30F31000ES	U30F3600ES						
	U30X315K0S	U30F31000ES	U30F31000ES						
	U30X400K0S	U30F31000ES	U30F31000ES						
	U30X475K0S	U30F31600ES	U30F31000ES						

 Table 9-2-e
 External filters for Drives without Built-in Filter (400V series)

9-2-10-c Insulation test

If an insulation test is performed on a system incorporating VAT300 and filters, do one of the following.
• Remove the input filters from the system during the test. (For precautions for the drive, see Chapter 2.)

Perform the test at the maximum voltage of 1500VAC.

Appendix 1 Type Description System

Standard specifications

■ 200V Series VAT300- U3SN000K7 to U3SN045K0

		ltem	Specifications												
		System	200V Series												
Т	ype	(VAT300-U3SN0_)	00K7	01K5	02K2	04K0	05K5	07K5	11K0	15K0	18K0	22K0	30K0	37K0	45K0
		Rated capacity [kVA] (Note 1)	1.7	2.8	3.8	5.5	8.3	11	16	21	26	30	41	51	60
	uty	Max. continuous rated current [A] (Note 2)	5.0	8.0	11	16	24	33	46	61	76	88	118	146	174
	Normal-d	Max. applicable motor [kW] (Note 3)	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45
bu		Carrier frequency (Note 4)		1 to 15kHz (Default : Soft sound 4kHz)											
er ratii		Overload current rating		120% for 1 min., 140% for 2.5 seconds											
Invert		Rated capacity [kVA] (Note 1)	1.0	1.7	2.8	3.8	5.5	8.3	11	16	21	26	30	41	51
	duty	Max. continuous rated current [A] (Note 2)	3.0	5.0	8.0	11	16	24	33	46	61	76	88	118	146
	leavy-(Max. applicable motor [kW] (Note 3)	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37
	Т	Carrier frequency (Note 4)		1 to 15kHz (Default : Soft sound 4kHz)											
		Overload current rating		150% for 1 min., 175% for 2.5 seconds											
Po sup	wer oply	Rated input voltage: rated input frequency			200 te 50 c	o 240V or 60Hz	±10% ±5%				2	00 to 23 50 or 60	0V ±10 Hz ±5%	%	
Ou	tput	Rated output voltage (Note 5) (Note 6)	200 to 240V (Max.)												
		Output frequency						0.1	1 to 440	Hz					
		EMI filter		Buil	t-in (opt	tion)				St	andalor	ne (optic	on)		
cuit .	s	DC reactor						Stand	alone (d	option)					
ain cir	device	Dynamic braking circuit				Built-	in (stan	dard)				St	andalor	ie (optic	on)
Σ		Dynamic braking resistor			Buil	t-in (opf	tion)				St	andalor	ne (optic	on)	
	uo	Structure				Wa	ill-moun	ted				Wall- Free-s	-mounte standing	ed (stano type (c	dard) option)
-	ncti	Enclosure					IP20						IP	00	
	nstr	Cooling method	Self-c	ooling					Force	ed air co	oling				
Ċ	3	Approx. weight (kg)			3			Ę	5	1	2	2	3	3	0
		Paint color						Mu	insell N	4.0					
Working environment				Indoor Relativ Altitud Freed	rs, Work ve humi le: 1000 om from	king am dity: 95 Im or les n corros	bient ter %RH or ss, Vibra ive or e	mperatu below ation: 4. xplosive	ire: -10 (no dew 9m/s ² o gases,	to 50°C / conder r less , steam,	(Note 7 nsation) dust, o	7) , il mist o	r cotton	lint.	

		ltem						Ş	Specifi	cations	6					
		System	400V Series													
-	Туре	e (VT300 U3SX0_)	00K7	01K5	02K2	04K0	05K5	07K5	11K0	15K0	18K0	22K0	3K0	37K0	45K0	55K0
		Rated capacity [kVA] (Note 1)	1.7	2.5	3.8	6.0	9.0	12	16	21	26	30	42	51	60	75
	uty	Max. continuous rated current [A] (Note 2)	2.5	3.6	5.5	8.6	13	17	23	31	37	44	60	73	87	108
	Normal-d	Max. applicable motor [kW] (Note 3)	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55
bu		Carrier frequency (Note 4)	1 to 15kHz (Default : Soft sound 4kHz)													
er rati		Overload current rating		120% for 1 min., 140% for 2.5 seconds												
Invert		Rated capacity [kVA] (Note 1)	1.0	1.7	2.5	3.8	6.0	9.0	12	16	21	26	30	42	51	60
	duty	Max. continuous rated current [A] (Note 2)	1.5	2.5	3.6	5.5	8.6	13	17	23	31	37	44	60	73	87
	leavy-	Max. applicable motor [kW] (Note 3)	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45
	-	Carrier frequency (Note 4)		1 to 15kHz (Default : Soft sound 4kHz)												
	Overload current rating			150% for 1 min., 175% for 2.5 seconds												
Pov sup	wer oply	Rated input voltage: rated input frequency						38 5	80 to 48 50 or 60	80V ±10)Hz ±5%)% %					
Out	tput	Rated output voltage (Note 5) (Note 6)	380 to 480V (Max.)													
		Output frequency	0.1 to 440Hz													
	vices	EMI filter		Built-in (option) Standalone (option)									ne)			
-	an	DC reactor						Sta	andalor	ne (opti	on)					
		Dynamic braking circuit				В	uilt-in (s	standar	d)				Sta	andalor	ie (optio	on)
.: (M	Mair	Dynamic braking resistor			E	Built-in	(option)				Sta	andalor	ne (opti	on)	
	ICHOL	Structure					Wa	ll-mour	ited					Wa (s Free-s	ll-mour standare standine (option)	ited d) g type)
-	ISIL	Enclosure						IP20							IP00	
	3	Cooling method	Self-c	ooling					Fo	orced a	ir cooli	ng		1		
		Approx. weight (kg)			3				5			12		2	3	27
		Paint color							Munse	ell N4.0						
Working environment				Indoo Relat Altitu Freed	ors, Wo tive hur de: 100 dom fro	rking a nidity: § 00m or om corre	mbient 95%RH less, Vi osive o	temper or belo bration r explos	rature : ow (no : 4.9m/ sive ga	-10 to s dew co s² or le ses, ste	50°C (I ndensa ss eam, du	lote 7) ition), ist, oil r	nist or	cotton I	int.	

■ 400V Series VAT300- U3SX000K7 to U3SX055K0

		ltem	Specifications											
		System	400V Series											
•	Гуре	e (VAT300-U3SX_)			075K	090K	110K	132K	160K	200K	250K	315K	400K	475K
		Rated capacity [kVA] (Note 1)			102	124	148	173	222	297	360	409	513	603
	luty	Max. continuous rated current [A] (Note 2)			147	179	214	249	321	428	519	590	740	870
	Normal-d	Max. applicable motor [kW] (Note 3)			75	90	110	132	160	200	250	315	400	475
bu		Carrier frequency (Note 4)		1 to 8kHz (Default : Soft sound 4kHz)										
ter rati		Overload current rating				120% fo	r 1 min.	, 140%	for 2.5	second	s			
Inver		Rated capacity [kVA] (Note 1)			75	102	124	148	173	222	297	360	409	513
	duty	Max. continuous rated current [A] (Note 2)			108	147	179	214	249	321	428	519	590	740
	eavy-	Max. applicable motor [kW] (Note 3)			55	75	90	110	132	160	200	250	315	400
	I	Carrier frequency (Note 4)		1 to 8kHz (Default : Soft sound 4kHz)										
		Overload current rating	150% for 1 min., 175% for 2.5 seconds											
Power	supply	Rated input voltage: rated input frequency						3	380 to 4 50 or 60	80V ±59)Hz ±5%	%			
Ou	tput	Rated output voltage (Note 5) (Note 6)						38	30 to 48	0V (Ma	x.)			
		Output frequency					0.1	1 to 440	Hz					
		EMI filter			-		Stand	alone (o	option)					
cuit	ŝ	DC reactor						Sta	and-Alo	ne (opti	on)			
ain cir	device	Dynamic braking circuit					Stand	alone (d	option)					
Σ		Dynamic braking resistor					Stand	alone (d	option)					
Structure Wall-mounted (standard), Free-standing type (option))						
Enclosure IP00 (standard), IP20 (option)								ion)						
-	stru	Cooling method					Force	ed air co	ooling					
6		Approx. weight (kg)			42	45	60	65	90	100	200	285	290	295
Ľ	-	Paint color					Μι	insell N	4.0					
Working environment Indoors, Working ambient temperature : -10 to 50°C (Note 7) Relative humidity: 95%RH or below (no dew condensation), Altitude: 1000m or less, Vibration: 4.9m/s ² or less Freedom from corrosive or explosive gases, steam, dust, oil mist or cottor							r cotton	lint.						

■ 400V Series VAT300, U3SX075K0 to U3SX475K0

- (Note 1) The output voltage indicates the output capacity [kVA] at 200V for the 200V series, and 400V for the 400V series.
- (Note 2) Indicates the total effective value including the higher harmonics.
- (Note 3) Indicates the case for the standard 4-pole squirrel cage motor.
- (Note 4) If 4kHz is exceeded when using the normal-duty setting, and if 4, 6, 8 or 10kHz is exceeded when using the heavy-duty setting, the maximum continuous rated current must be lowered.

• For 200V series, normal-duty setting

Capacity	4kH	6kHz	8kHz	10kHz	12kHz	15kHz	Derating
N000K7	5.0	4.7	4.4	4.1	3.9	3.6	
N001K5	8.0	7.5	7.0	6.6	6.2	5.8	
N002K2	11.0	10.3	9.7	9.0	8.6	7.9	
N004K0	16.0	15.0	14.1	13.1	12.5	11.5	4k to 10kHz; 20/ /1kHz
N005K5	24.0	22.6	21.1	19.7	18.7	17.3	10k to 15kHz: 2%/1kHz
N007K5	33.0	31.0	29.0	27.1	25.7	23.8	
N011K0	46.0	43.2	40.5	37.7	35.9	33.1	
N015K0	61.0	57.3	53.7	50.0	47.6	43.9	
N018K5	76.0	71.4	66.9	62.3	59.3	54.7	
N022K0	88.0	82.7	77.4	72.2	66.9	59.0	
N030K0	118.0	110.9	103.8	96.8	89.7	79.1	3%/1kHz
N037K0	146.0	137.2	128.5	119.7	111.0	97.8	5 /0/ TKHZ
N045K0	174.0	163.6	153.1	142.7	132.2	116.6	

• For 400V series, normal-duty setting

Capacity	4kH	6kHz	8kHz	10kHz	12kHz	15kHz	Derating
X000K7	2.5	2.3	2.0	1.8	1.6	1.4	
X001K5	3.6	3.2	2.9	2.5	2.3	2.0	
X002K2	5.5	5.0	4.4	3.9	3.5	3.0	
X004K0	8.6	7.7	6.9	6.0	5.5	4.7	
X005K5	13.0	11.7	10.4	9.1	8.3	7.2	4k to 10kHz: 5%/1kHz
X007K5	17.0	15.3	13.6	11.9	10.9	9.4	10k to 15kHz: 3%/1kHz
X011K0	23.0	20.7	18.4	16.1	14.7	12.7	
X015K0	31.0	27.9	24.8	21.7	19.8	17.1	
X018K5	37.0	33.3	29.6	25.9	23.7	20.4	
X022K0	44.0	39.6	35.2	30.8	28.2	24.2	
X030K0	60.0	54.0	48.0	42.0	36.0	27.0	
X037K0	73.0	65.7	58.4	51.1	43.8	32.9	5%/1kHz
X045K0	87.0	78.3	69.6	60.9	52.2	39.2	570/TKTZ
X055K0	108.0	97.2	86.4	75.6	64.8	48.6	
X075K0	147.0	132.3	117.6	\square			
X090K0	179.0	161.1	143.2				
X110K0	214.0	192.6	171.2				
X132K0	249.0	224.1	199.2		\backslash		
X160K0	321.0	288.9	256.8				5%/1kHz
X200K0	428.0	385.2	342.4				570/TKTZ
X250K0	519.0	467.1	415.2				
X315K0	590.0	531.0	472.0			\mathbf{i}	
X400K0	740.0	666.0	592.0				
X475K0	870.0	783.0	696.0				

Capacity	4kH	6kHz	8kHz	10kHz	12kHz	15kHz	Derating
N000K7	\rightarrow	\rightarrow	\rightarrow	3.0	2.8	2.6	
N001K5	\rightarrow	\rightarrow	\rightarrow	5.0	4.7	4.3	
N002K2	\rightarrow	\rightarrow	\rightarrow	8.0	7.5	6.8	
N004K0	\rightarrow	\rightarrow	\rightarrow	11.0	10.3	9.4	10k to 15kHz: 2%/1kHz
N005K5	\rightarrow	\rightarrow	\rightarrow	16.0	15.0	13.6	
N007K5	\rightarrow	\rightarrow	\rightarrow	24.0	22.6	20.4	
N011K0	\rightarrow	\rightarrow	\rightarrow	33.0	31.0	28.1	
N015K0	\rightarrow	\rightarrow	46.0	43.2	41.4	38.6	8k to 10kHz: 3%/1kHz
N018K5	\rightarrow	\rightarrow	61.0	57.3	54.9	51.2	10k to 15kHz: 2%/1kHz
N022K0	\rightarrow	76.0	71.4	66.9	62.3	55.5	6k to 15kHz: 3%/1kHz
N030K0	\rightarrow	88.0	82.7	77.4	72.2	64.2	
N037K0	118.0	110.9	103.8	96.8	89.7	79.1	3%/1kHz
N045K0	146.0	137.2	128.5	119.7	111.0	97.8	

• For 200V series, heavy-duty setting

• For 400V series, heavy-duty setting

Capacity	4kH	6kHz	8kHz	10kHz	12kHz	15kHz	Derating
X000K7	\rightarrow	\rightarrow	\rightarrow	1.5	1.4	1.3	
X001K5	\rightarrow	\rightarrow	\rightarrow	2.5	2.4	2.1	
X002K2	\rightarrow	\rightarrow	\rightarrow	3.6	3.4	3.1	
X004K0	\rightarrow	\rightarrow	\rightarrow	5.5	5.2	4.7	10k to 15kHz: 3%/1kHz
X005K5	\rightarrow	\rightarrow	\rightarrow	8.6	8.1	7.3	
X007K5	\rightarrow	\rightarrow	\rightarrow	13.0	12.2	11.1	
X011K0	\rightarrow	\rightarrow	\rightarrow	17.0	16.0	14.5	
X015K0	\rightarrow	\rightarrow	23.0	20.7	19.3	17.3	
X018K5	\rightarrow	\rightarrow	31.0	27.9	26.0	23.3	8k to 10kHz: 5%/1kHz 10k to 15kHz: 3%/1kHz
X022K0	\rightarrow	\rightarrow	37.0	33.3	31.1	27.8	
X030K0	\rightarrow	\rightarrow	44.0	39.6	35.2	28.6	8k to 15kHz: 3%/1kHz
X037K0	\rightarrow	60.0	54.0	48.0	42.0	33.0	
X045K0	\rightarrow	73.0	65.7	58.4	51.1	40.2	
X055K0	87.0	78.3	69.6	60.9	52.2	39.2	5%/1kHz
X075K0	108.0	97.2	86.4			•	
X090K0	147.0	132.3	117.6				
X110K0	179.0	161.1	143.2				
X132K0	214.0	192.6	171.2				
X160K0	249.0	224.1	199.2				
X200K0	321.0	288.9	256.8	-			5%/TKHZ
X250K0	428.0	385.2	342.4	-		<	
X315K0	519.0	467.1	415.2	1		\mathbf{i}	
X400K0	590.0	531.0	472.0	1			
X475K0	740.0	666.0	592.0	1			1

The carrier frequency automatic reduction function may automatically reduce the carrier frequency to 2.0kHz depending on the output current or inverter temperature. This function is valid only when C22-6 is set to 1. The reduction function is enabled as the factory setting. The setting value and actual carrier frequency may differ, so check the actual carrier frequency with D03-3. The reduction conditions for each capacity are shown below.

• For For X000K7 to X005K5, N000K7 to N005K5 If the power module temperature exceeds 110°C, the carrier frequency is automatically reduced to 2.0kHz.

- For X007K5 to X022K0, N007K5, N011K0 If the power module temperature exceeds 85°C, the carrier frequency is automatically reduced to 2.0kHz.
- For 030H or more, 015L or more
 If the heat sink temperature 75°C is exceeded and the output current exceeds 110% or if the
 heat sink temperature 95°C is exceeded, the carrier frequency will automatically change to
 2.0kHz.
- * Check the power module and heat sink temperature with D02-4.
- (Note 5) An output voltage exceeding the input voltage cannot be attained. (The upper limit of the output voltage effective value is the DC voltage/1.37.)
- (Note 6) The rated output voltage for the sensor-less vector control mode, vector control with sensor mode, PM control with sensor mode and the sensor-less PM control mode is as follows. 200V series : 160V/180V/190V respectively in respect to input voltage 200V/220V/240V 400V series : 300V/320V/360V/380V respectively in respect to input voltage 380V/400V/440V/480V
- (Note 7) The following conditions apply to the upper limit of the working ambient temperature when using the normal-duty setting.



(1) N005K5

If the ambient temperature exceeds 40°C, reduce the output current by 2% per 1°C. (2) N011K0 / X005K50 (NF)/ X015K0

If the ambient temperature exceeds 40°C, reduce the output current by 0.5% per 1°C.
■ Control specifications table

/		V/f control	Speed sensor-less vector control	Vector control with speed sensor (Note 1)	PM motor control with sensor (Note 2)	Sensor-less PM motor control (Note 4)
	Control method		All Sine wave	digital control approximation PW	M	
control	Transfer frequency	Mono-soun Soft sound	nd mode : 1 to 15kl mode : Average Frequen (3 tone n	Hz (0.1kHz increme frequency 2.1 to 5k cy modulation meth nodulation, 4 tone n	nts) :Hz od nodulation)	Mono-sound mode: 4kHz or 6kHz
uency	Output frequency resolution			0.01Hz		
Freq	Frequency setting resolution		0. 0. In respect t	01Hz (digital) 03% (analog) o maximum frequer	псу	
	Frequency accuracy		±0.01% ±0.0% (a	(digital) at 25±10°C analog) at 25±10°C		
	Voltage/frequency characteristics	Middle V/f point of five points randomly set between 3 and 440Hz can be set	Randomly set betw 9999min ¹ (max. 1	veen 150 and 80Hz)	Randomly set between 150 and 9999min ⁻¹ (max. 210Hz)	Randomly set between 150 and 9999min ⁻¹ (max. 240Hz)
	Torque boost	Manual/automatic selective		-	_	
	Max. torque boost	Max. torque for applicable motor is output when used with automatic tuning.		-	-	
ifications	Automatic tuning	Automatic measurement of Automatic measurement of Basic method which does r method which rotates moto	motor constants various parameters not rotate motor, and extended r are available motor constants bit rotate motor, and extended r are available motor constants bit rotate motor, and extended position estimation			Automatic measurement of motor constants (Rotates motor)
l spec	Starting frequency	Set between 0.1 and 60.0Hz		-	_	
Contro	Starting torque	 200% or more (Note 3) Using motor At 150% of rated current Attainment time approx. 3 sec. 	_			 Approx. 50% Using standard sensor-less control motor At 150% of rated current
	Acceleration/ deceleration time	Acceleration/de	on × 8			
	Acceleration/ deceleration mode		Linear/S	-character selective		
	Operation method		3 modes selectiv • Forward run/re • Run stop/forw • Forward run p	ve everse run ard run reverse run ulse/reverse run pu	lse/stop	

(Note 1) The IM speed detection option PCB is required.

⁽Note 2) This is for the PM motor (may differ depending the manufacturer). The PM speed detection option PCB is required.

⁽Note 3) Differs according to the motor capacity, rated voltage and rated frequency. If 45kW is exceeded, starting torque is approx. 150%.

⁽Note 4) Sensor-less PM motor control is under development for energy-saving operation of fan/pump

■ Control specifications table (continued)

/			V/f control	Speed sensor-less vector control	Vector control with speed sensor (Note 1)	PM motor control with sensor (Note 2)	Sensor-less PM motor control (Note 4)		
	Stop	method	Deceleration stop in respec	t to run, emergency	y stop and inching,	coast to stop select	tive		
SL	DC t	praking	Braking start frequency, randomly set between 0.1 and 60.0Hz Braking voltage, randomly set between 0.1 and 20.0%	Braking sta Braking	irt speed, randomly current ,randomly	set between 0.00 a set between 50 and	and 50.00% d 150%.		
atio		Braking time		Randomly set bet	tween 0.0 and 20.0	seconds			
lifice	Outp	out frequency	0 to 440Hz	0 to 1	80Hz	0 to 210Hz	0 to 240Hz		
ol spec		Control range	Simple ASR function is not specified	1 : 100	1 : 1000	1 : 100	1 : 5		
Contre	ntrol	Constant output range	Up to 1 : 7	Up to 1 : 2	Up to 1 : 4	Up to	1 : 1.5		
	Speed co	Control accuracy (At Fmax ≥ 50Hz)	±0.01%	±0.5%	±0.01%	±0.1	01%		
		Control response	Simple ASR function is not specified	5Hz	30Hz		_		
	Multi frequ	i-step Jency setting		Acceleration/dece 5-bit n	8 steps eleration time as ch on-encode mode	angeable			
Ratio interlock setting Ratio interlock Ratio interlock setting Ratio interlock setting Ratio interlock setting Ratio interlock Ratio interlo			During remote setting mode y = Ax + B + C y: Operation results x: Operation input A: 0.000 to ±10.000 B: 0.00 to ±440.00Hz C: Auxiliary input With output upper/lower limit	During remote setting mode y = Ax + B + C y: Operation results x: Operation input A: 0.000 to ±10.000 B: 0 to ±9999min ⁻¹ C: Auxiliary input With output upper/lower limit					
etting	Freq	uency jump	Three places can be set Width can be varied between 0.0 and 10Hz			-			
S	Slip	compensation	Operation/non selective Slip compensation gain: 0.0 to 20.0		-	_			
	Auto funct	matic run tion		on ective					
	Built funct	-in PLC tion	Arithmetic operations, logic sequence input/output and Program capacity: max. 16	cal operations, size comparison and LPF operations, etc., in respect to the I analog input/output are possible. S commands * 20 banks, operation cycle: 1 bank in 2ms					
	Othe	ers	PID control Pick-up Automatic start Restart after instantaneous power failure Reverse run prevention Traverse pattern				Pick-up (auto-start, re-start after momentary stop) : impossible		
output	Ope	ration panel	Local/remote changeover of copy of all parameters Mountable outside unit (ext	peration, forward ru	un/reverse run diree 3m)	ct operation, referer	nce, change and		
input/c	L	CD type	Display : 16 ch Operation : Operation	aracters * 2 lines ate with knob and s	Status display LED et key	: 4 points			
Control	L	ED type	Display : 7-seg Operation : Operation	ment LED × 5 digits ate with ▲▼ keys	s + sign Status/ur + set key	hit display LED: 7 po	pints		
	Sequ	uence input	Programmable : 7 poir	nts sink/source cha	ngeable, PSI7 is us	ed as pulse train in	put		

■ Control specifications table (continued)

Sequence output	Relay 1c contact: 1 point (p open collector: 3 points (pro The programmable details o run, direction operation, cur Voltage input (0 to 10V, 0 to Voltage input (0 to ±10V, 0 to feedback, etc.)	rogrammable), rela ogrammable), PS03 can be changed be rent reached, spee	y 1a contact: 1 poin is used as pulse traven speed detect d reached, accelera	t (programmable), ain output ion, pre-charging co ation, deceleration a	omplete, reverse
Frequency setting	Voltage input (0 to 10V, 0 to Voltage input (0 to ±10V, 0 t feedback. etc.)	9 5V, 1 to 5V) or cur			and fault code
	Pulse train input (max. 10kl	to ±5C, 1 to 5V): 1 Hz): 1 point	rent input (4 to 20m point (used with seq	A, 0 to 20mA): 2 po uential ratio operat	bints ion or PID
Meter output	Voltage output (0 to 10V) or Change between output fre	- current output (4 t quency, output volt	o 20mA): 2 points (p age, output current,	programmable) DC voltage, etc.	
Serial interface	Communication protocol: M Connection method: RS485 Transmission method: Start 1200/2400/4800/9600/1440 check, parity, framing	odbus-RTU or VAT 5, 2-wire type, Trans -stop synchronizati 00/19200/38400bps	300 series dedicate mission distance: tr on, half-duplex com , No. of stations: ma	d communication (solal extension dista munication, Baud r ax. 32 units, Error d	standard serial) nce 150m or less, ate: select from etection: Sum
Preventive	Overcurrent limit (primary c limit, overload warning, carr (selective)	urrent limit level char ier frequency autor	angeable in three st natic reduction at ov	ages), overcurrent verload (cooling fin	limit, undervoltage overheat)
Shut-off	Overcurrent, overvoltage, u temperature rise, ground fa	ndervoltage, IGBT ult, other self-diagn	fault, phase failure (osis	(input/output), overl	oad, cooling fin
ault history	Past four faults recorded. R frequency/current/DC voltag time	ecorded details: pri ge before shutoff, h	mary cause, secon ardware latch, cum	dary cause, output ulative ON time, cui	nulative operation
Overload withstand level	Normal-duty setting 120% for 1 minute, 140% inverse time characteristi Heavy-duty setting 150% for 1 minute, 175% inverse time characteristi	o for 2.5 seconds (rec cs o for 2.5 seconds (rec cs	educed to 60% for 1	minute from 1Hz to	o 0.1Hz), o 0.1Hz),
	leter output erial interface reventive hut-off ault history everload ithstand level	leter output Voltage output (0 to 10V) or Change between output fre erial interface Communication protocol: M Connection method: RS485 Transmission method: Start 1200/2400/4800/9600/1440 check, parity, framing reventive Overcurrent limit (primary c limit, overload warning, carr (selective) hut-off Overcurrent, overvoltage, u temperature rise, ground fa ault history Past four faults recorded. R frequency/current/DC voltage time verload Normal-duty setting 120% for 1 minute, 140% inverse time characteristit Heavy-duty setting 150% for 1 minute, 175% inverse time characteristit	Intervention Voltage output (0 to 10V) or current output (4 to Change between output frequency, output volta erial interface Communication protocol: Modbus-RTU or VAT: Connection method: RS485, 2-wire type, Trans erial interface Transmission method: Start-stop synchronization 1200/2400/4800/9600/14400/19200/38400bps; check, parity, framing reventive Overcurrent limit (primary current limit level chalimit, overload warning, carrier frequency autor (selective) hut-off Overcurrent, overvoltage, undervoltage, IGBT frequency/current/DC voltage before shutoff, hat time ault history Past four faults recorded. Recorded details: prifrequency/current/DC voltage before shutoff, hat time Normal-duty setting 120% for 1 minute, 140% for 2.5 seconds (reinverse time characteristics Heavy-duty setting 150% for 1 minute, 175% for 2.5 seconds (reinverse time characteristics	Intervention Voltage output (0 to 10V) or current output (4 to 20mA): 2 points (p Intervention Communication protocol: Modbus-RTU or VAT300 series dedicate Connection method: RS485, 2-wire type, Transmission distance: t Transmission method: Start-stop synchronization, half-duplex com 1200/2400/4800/9600/14400/19200/38400bps, No. of stations: ma check, parity, framing Overcurrent limit (primary current limit level changeable in three st limit, overload warning, carrier frequency automatic reduction at or (selective) hut-off Overcurrent, overvoltage, undervoltage, IGBT fault, phase failure (temperature rise, ground fault, other self-diagnosis Past four faults recorded. Recorded details: primary cause, second frequency/current/DC voltage before shutoff, hardware latch, current werload 120% for 1 minute, 140% for 2.5 seconds (reduced to 60% for 1 inverse time characteristics Heavy-duty setting 120% for 1 minute, 175% for 2.5 seconds (reduced to 75% for 1 inverse time characteristics	Notes and mpd (max row 2), r point Notes and mpd (max row 2), r point Notes and mpd (max row 2), r point Voltage output (0 to 10V) or current output (4 to 20mA): 2 points (programmable) Change between output frequency, output voltage, output current, DC voltage, etc. erial interface Communication protocol: Modbus-RTU or VAT300 series dedicated communication (s Connection method: RS485, 2-wire type, Transmission distance: total extension dista Transmission method: Start-stop synchronization, half-duplex communication, Baud r 1200/2400/4800/9600/14400/19200/38400bps, No. of stations: max. 32 units, Error d check, parity, framing Overcurrent limit (primary current limit level changeable in three stages), overcurrent limit, overload warning, carrier frequency automatic reduction at overload (cooling fin (selective) hut-off Overcurrent, overvoltage, undervoltage, IGBT fault, phase failure (input/output), overl temperature rise, ground fault, other self-diagnosis ault history Past four faults recorded. Recorded details: primary cause, secondary cause, output frequency/current/DC voltage before shutoff, hardware latch, cumulative ON time, cur time Normal-duty setting 120% for 1 minute, 140% for 2.5 seconds (reduced to 60% for 1 minute from 1Hz to inverse time characteristics Heavy-duty setting 150% for 1 minute, 175% for 2.5 seconds (reduced to 75% for 1minute from 1Hz to inverse time characteristics







Fig. 1

Fig. 2

	200V Series	VAT300 N000K7 to N045K0. 400V Series	VAT300 X000K7 to X055K0
--	-------------	--------------------------------------	-------------------------

Ту	ре			Dimensio	ons (mm)			Main	Weight	Fig
200V Series	400V Series	WO	W1	H0	H1	D	ød	terminal	(kg)	Fig.
N000K7 N001K5 N002K2 N004K0 N005K5	X000K7 X001K5 X002K2 X004K0 X005K5	155	140	250	235	180	6	M4	3	
	X007K5 X011k0									
N007K5 N011k0	X015k0	205	190	275	260	196	7	M5	5	1
	X018k0 X022k0	000	0.40	250	220	000			12	
N015K0	X030k0	260	240	350	330	298		M6		
N018K5	X037k0									
N030K0	X045k0	300	200	470	450			M8	23	
	X055k0					317	10		27	2
N037K0 N045K0		340	240	520	500			M10	30	



Fig. 3

■ 400V Series	VAT300- X075K0 to X475K0
---------------	--------------------------

Туре				Dime	ensions	(mm)			Main	Weight	F !				
	400V Series	W0	W1	H0	H1	D	ød	øE	terminal	(kg)	Fig.				
	X075K0	435	300	615	595					42					
	X090K0		500	010	595	350	10	20	M10	45					
	X110K0	500	400	710	684	550	10	20		60					
	X132K0	500	000	400	110	004				IVITO	65				
	X160K0	580	580	580	580	580	400	1020	000		12	23		90	з
	X200K0	560	400	1020	330		15	25		100					
	X250K0	580	400	1260	1230	470		22	M16	200					
	X315K0					470	15			285					
	X400K0	870	600	1260	1230		15	25	IVITO	290					
	X475K0									295					

Code	Displa	ау	Fault	Description	Retry
00	8,8,8,8,		No fault	No fault recorded.	×
01	8888	(EMS)	Emergency stop	Indicates that sequence signal EMS has been input in C00-4 = 2 (fault output at emergency stop) mode.	×
02	8888	(PM-n)	Power module error	Power module fault 2: during operation at the set speed n: sub-code 1: during stop 2: during operation at the set speed 3: during acceleration 4: during deceleration 5: during braking 6: during ACR 7: during excitation 9: during automatic tuning	0
03	8888	(OC-n)	Over current	The output has risen to or beyond 300%. n: sub-code 1: during stop 2: during operation at the set speed 3: during acceleration 4: during deceleration 5: during braking 6: during ACR 7: during excitation 9: during automatic tuning	0
04	8888	(OV-n)	Over voltage	The DC voltage has risen to or beyond the preset level. (Vdc ≥ 800 or 400V) n: sub-code 1: during stop 2: during operation at the set speed 3: during acceleration 4: during deceleration 5: during braking 6: during ACR 7: during excitation 9: during automatic tuning	0
05	8888	(UV-n)	Under voltage	While the drive is running, the DC voltage has lowered to or beyond the preset level (65% of the rating). n: sub-code 1: during stop 2: during operation at the set speed 3: during acceleration 5: during braking 6: during ACR 7: during excitation 9: during automatic tuning When C08-0=2, 3 (automatic start), only the symbol is displayed, and the FLT LED does not operate.	×
06	8,8,8,8	(PHL.n)	Phase failure	This indicates that there is a phase failure in the AC input power supply.n: sub-code1: Input phase failure2: Output phase failure	×
07	8888	(UOHn.)	Overheat	The heatsink temperature has risen. n: sub-code 1: Detected with thermistor 2: Detected with thermostat	0
08	8888	(SP-n)	Speed error	This indicates that the motor rotation speed is abnormal. n: sub-code 1: Overspeed (C24-0 over) 2: Speed (magnetic pole position) detection error (C24-2) 3: Speed deviation error (C24-5) 4: Reverse run detection error 5: Encoder initialization error 1 6: Encoder initialization error 2	×
09	8888	(CONV.)	Converter fan fault	This indicates that trouble has occurred in the converter cooling fan. (Only on parallel machines mounted with a converter fan.)	0
0A	88888	(ATT-n.)	Automatic tuning abnormal completion	This indicates that the automatic tuning did not complete normally. n: sub-code (Automatic tuning step) 1: Setting error 2: Calculation operation error 3: Operation error 4: Load error 5: End process error 6: Convergence operation error 7: Magnetic pole position estimation motor rotation error 8: Magnetic pole position estimation voltage stability error 9: Magnetic pole position estimation retry error	×
0В	8888	(OL-n.)	Overload	Indicate that the output current exceeded the thermal operation time having inverse time characteristics. When Normal-duty is set, the standard characteristics are 120% for one minute in respect to the motor rated current value. At 122% or more in respect to the inverter rated current, this will be 140% for 2.5 seconds. When Heavy-duty is set, the standard is 150% for one minute in respect to the motor rated current value. At 155% or more in respect to the inverter rated current, this will be 175% for 2.5 seconds. n: sub-code 1: Equipment overload 2: DBR overload 3: Motor overload	0

Appendix 3. Fault Codes

Code	Displa	ay	Fault	Description	Retry
0C	8888	(GRD. n)	Ground	The Drive has sensed grounded conditions on the output. n: sub-code 1: during stop 2: during operation at the set speed 3: during acceleration 4: during deceleration 5: during braking 6: during ACR 7: during excitation 9: during automatic tuning	0
0D	8888	(IO-n.)	I/O error	 There has been an error in communications through the I/O port. n: sub-code 1: Gate shutdown circuit error. A feedback signal has disagreed to a gate shutdown command. 2: A/D convertor error. The A/D convertor has been jammed. 3: Current detector offset. The offset of the current detector has increased to or beyond 0.5V. 4: Retry time out. Indicates that the operation was not successful within the No. of retries set in C21-0. 7: This indicates that the field network interface option cannot be started up. 8: Watch-dog error in the transmission between the field network interface and the basic PCB. (transmission jam / stop) 9: Field network interface error. The details can be shown in D30-2~5. B: PID error C: External brake IDET error D: External brake RUN error E: External brake answer error F: Thermistor fault 	×
0E	8888	(CPU. n)	CPU error	 There has been an error while the CPU, RAM or ROM is in the self-diagnosis mode at power-up. n: sub-code 1: Watch-dog error, indicating that the CPU has been jammed. This fault may appear during at-speed operation. 2: CPU calculation error. 3: CPU RAM error. 4: External RAM error. 6: E²PROM check-sum error. 7: E²PROM read error. 8: E²PROM write error. This error is only displayed, and the gate will not shut down and FLT will not be output. A: Stack overflow B: Built-in PLC overload * CPU1 to 6, 7 and 8 are specific fault output functions and cannot be output. 	×
0F	8888	(FUSE)	Fuse blown	Indicate that the main circuit's fuse has blown.	0
10	88888	(BPFLT)	Parallel unit signal cutoff	Indicates that the connection signal with the parallel unit has been cut off.	0
11	88888	(E.FLTn)	External fault	Indicates that an external fault was input from the programmable sequence input terminal. n: sub-code 1: Terminal set with C05-8 turned ON 2: Terminal set with C05-9 turned ON 3: Terminal set with C05-A turned ON 4: Terminal set with C05-B turned ON 5: Terminal set with C05-C turned ON 6: Terminal set with C05-D turned ON 7: Terminal set with C05-E turned ON 8: Terminal set with C05-F turned ON	×
13	88888	(MC-n.)	MC error	At least one of the pre-charge magnetic contactors in 200H or larger units may not be working properly. n : sub-code 1 : Magnetic contactor nor working well when the power on.	×
-	8888	(dEr)	E ² PROM data error	 Indicates that there is an error in the various data stored in the E²PROM. For details, enter the monitor mode: D20-2, and correct the data. Caution) If this appears when starting up, the details will not be stored internally. Thus, after starting up normally, these details cannot be read with the fault history (D20-0). 	×

Display	Name	Explanation
8888	OFF	 Indicates that the motor is stopped.
8888	RUN	 Indicates that the motor is running. Occurs when a parameter, which cannot be changed during operation, was changed during operation.
8888	LOCK	 Indicates that the parameters are locked. Occurs when a parameter locked with C09-0 was operated. Also occurs when a key other than the STOP key was pressed while key operations were prohibited with C09-1.
8888	RETRY	 Indicates that the operation is being retried. The value displayed at the same time is the number of retries.
8.8.8.8	BRAKE	 Indicates that the brakes are being applied.
8.8.8.8	Pick Up	 Indicates that pick-up is being applied.
8888	Over	 Indicates that the scale display has exceeded the upper limit 99999.
88888	EEPROM Error	 Indicates that an error occurred during the parameter copy function's verify check using the operation panel.
8888	ERROR	 Indicates that the fault display mode is active.
8888	Minor Error	 Indicates that the minor fault display mode is active.
8888	LIST	 Indicates that the list display mode is active.
88,888	Auto Tuning Start	 Indicates that automatic tuning will be started.
88.88	Auto Tuning End	Indicates that automatic tuning has ended.
8888	Data CHANGE	Indicates the head of the list display.
8888	Data END	Indicates the end of the list display.

Appendix 4. Display Messages

Appendix 5. Segment LED Display

(1) Numeric

Display	8	В	8	B	8	ß	8	8	8	8
Numerics	0	1	2	3	4	5	6	7	8	9

(2) Alphabet

Display	8	8	8	8	8	8	8	8	-8,	8
Alphabet	А	B (b)	С	D (d)	Е	F	G	Н	I	J

Display	8	ā	a.	8	8	8	8	- 8	Я	8
Alphabet	L	M (m)	N (n)	0	Р	Q (q)	R (r)	S	T (t)	U

Display	B,	8	8	8	8
Alphabet	V (v)	Y	_	ा (Brac	⊥ kets)

		Revision history							
Revision	Issued on	Revision details	CPU version	ROM version					
A	July 2007		9457.0	9458.4					
В	Aug. 2007		9457.0	9458.4					

GE Consumer & Industrial C/o GE Inspection Technologies 129-135 Camp Road St Albans Hertfordshire AL1 5HL, (UK)

GE POWER CONTROLS IBERICA Marqués de Comillas 1 E-08225 Terrassa

GE CONSUMER & INDUSTRIAL GmbH Sachsenring 83 D-50677 Köln

GE POWER CONTROLS FRANCE 7, Rue Nicolas Robert BP32 ZI La Garenne F-93601 Aulnay sous Bois Cédex

GE POWER CONTROLS ITALIA Viale Brianza 181 Cisinello Balsamo I-20092 Milano

GE POWER CONTROLS BELGIUM Nieuwevaart 51 B-9000 Gent



GE imagination at work