



**Customer Electricity Supply**

230VAC Single Phase  
230VAC Three Phase  
400VAC Three Phase



**Local Isolator.**



**Power Drive Services  
EMERGENCY BRAKE  
(INJ-?-?-EMR)**  
Provides Dynamic  
Braking Of Motor In  
Emergency Situation.



**Conventional  
Motor  
Starter**  
STAR DELTA, INVERTER,  
SOFT STARTER  
DOL ETC.



**Emergency Trip Switches  
Safety Switches**  
Dynamic Braking  
Required For Emergency  
Purposes. **Note**  
emergency circuit at  
main voltage. Low  
voltage option available  
on request



**AC  
Motor**